

How to Get Free and Largest Block of Contiguous Memory Using SNMP

Document ID: 15216

Introduction

Prerequisites

- Requirements

- Components Used

- Conventions

Background Information

Procedure

- Example

Related Information

Introduction

This document describes how to get free and the largest block of contiguous memory using Simple Network Management Protocol (SNMP).

Prerequisites

Requirements

There are no specific requirements for this document.

Components Used

The information in this document is valid only for Cisco IOS® devices.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Conventions

Refer to Cisco Technical Tips Conventions for more information on document conventions.

Background Information

Memory leaks and abnormal network events are the main reasons for monitoring memory consumption and fragmentation. A memory leak occurs when a process requests memory blocks and does not release the block when it is finished with it. Eventually, the process uses up all of the available memory. This is considered a bug, and it eventually causes a router to crash. Not enough memory prohibits the router, among other things, from creating more buffers. The lack of memory can also affect the capability of the router to grow data structures such as a routing table.

Procedure

Monitoring free memory and the largest free block of memory on Cisco IOS software devices can be good indicators of router health. The variables to look for are **ciscoMemoryPoolFree** (.1.3.6.1.4.1.9.9.48.1.1.1.6) and **ciscoMemoryPoolLargestFree** (.1.3.6.1.4.1.9.9.48.1.1.1.7) from CISCO-MEMORY-POOL-MIB.

```
.1.3.6.1.4.1.9.9.48.1.1.1.6
ciscoMemoryPoolFree OBJECT-TYPE
    -- FROM CISCO-MEMORY-POOL-MIB
    SYNTAX          Gauge
    MAX-ACCESS      read-only
    STATUS          Current
    DESCRIPTION     "Indicates the number of bytes from the memory pool
that are currently unused on the managed device.
 ::= { iso(1) org(3) dod(6) internet(1) private(4) enterprises(1) cisco(9)
ciscoMgmt(9) ciscoMemoryPoolMIB(48) ciscoMemoryPoolObjects(1) ciscoMemoryPoolTable(1)
ciscoMemoryPoolEntry(1) 6 }
```

Note: The sum of **ciscoMemoryPoolUsed** and **ciscoMemoryPoolFree** is the total amount of memory in the pool.

```
.1.3.6.1.4.1.9.9.48.1.1.1.7
ciscoMemoryPoolLargestFree OBJECT-TYPE
    -- FROM CISCO-MEMORY-POOL-MIB
    SYNTAX          Gauge
    MAX-ACCESS      read-only
    STATUS          Current
    DESCRIPTION     "Indicates the largest number of contiguous bytes from
the memory pool that are currently unused on
the managed device."
 ::= { iso(1) org(3) dod(6) internet(1) private(4) enterprises(1) cisco(9)
ciscoMgmt(9) ciscoMemoryPoolMIB(48) ciscoMemoryPoolObjects(1) ciscoMemoryPoolTable(1)
ciscoMemoryPoolEntry(1) 7 }
```

Example

These tables show sample output from the **show memory** command for both high-end and low-end routers:

High-end routers (7xxx series):

Router>**show memory**

	Head	Total(b)	Used(b)	Free(b)	Lowest(b)	Largest(b)
Processor	614708E0	112785184 A	11720752 B	101064432 C	100574424 D	100599288 E
Fast	614508E0	131072 A	72664 B	58408 C	58408 D	58364 E

--More--

Low-end routers (4xxx, 2500, 3600, and so forth series):

Router>**show memory**

	Head	Total(b)	Used(b)	Free(b)	Lowest(b)	Largest(b)
Processor	6291DE80					

		16654720 A	11768556 B	4886164 C	4538264 D	4772980 E
I/O	3900000	7340032 A	4898680 B	2441352 C	2290528 D	2441116 E

--More--

This information is highlighted in the show memory tables:

- **A** "Total(b)" is the total amount of memory, in bytes, available for the processor after the Cisco IOS software is loaded. If you want to know how much memory the Cisco IOS software takes on the router, subtract the Total bytes shown here from the total amount of dynamic RAM (DRAM) or system memory (processorRam) installed on the router. The total input/output (I/O) memory or Fast memory is based on the physical I/O memory installed on the low-end routers or based on the amount of packet memory allocated on high-end routers from system memory (typically, 2 MB on Route/Switch Processor (RSP) platforms).

```
.1.3.6.1.4.1.9.3.6.6
processorRam OBJECT-TYPE
    -- FROM OLD-CISCO-CHASSIS-MIB
    SYNTAX          Integer
    MAX-ACCESS      read-only
    STATUS          Deprecated
    DESCRIPTION     "Bytes of RAM available to CPU."
 ::= { iso(1) org(3) dod(6) internet(1) private(4) enterprises(1)
       cisco(9) temporary(3) chassis(6) 6 }
```

- **B** "Used(b)" is the total amount of memory, in bytes, currently used (**ciscoMemoryPoolUsed**) by the router.

```
.1.3.6.1.4.1.9.9.48.1.1.1.5
ciscoMemoryPoolUsed OBJECT-TYPE
    -- FROM CISCO-MEMORY-POOL-MIB
    SYNTAX          Gauge
    MAX-ACCESS      read-only
    STATUS          Current
    DESCRIPTION     "Indicates the number of bytes from the memory
pool that are currently in use by applications on the managed device."
 ::= { iso(1) org(3) dod(6) internet(1) private(4) enterprises(1) cisco(9)
       ciscoMgmt(9) ciscoMemoryPoolMIB(48) ciscoMemoryPoolObjects(1)
       ciscoMemoryPoolTable(1) ciscoMemoryPoolEntry(1) 5 }
```

- **C** "Free(b)" is the total amount of memory, in bytes, currently free [**ciscoMemoryPoolFree** (**.1.3.6.1.4.1.9.9.48.1.1.1.6**) or **freeMem** (**.1.3.6.1.4.1.9.2.1.8**)] in the router.

```
1.3.6.1.4.1.9.2.1.8
freeMem OBJECT-TYPE
    -- FROM OLD-CISCO-SYS-MIB
    SYNTAX          Integer
    MAX-ACCESS      read-only
    STATUS          Obsolete
    DESCRIPTION     "The freeMem mib object is obsolete as of IOS 11.1
                    It has been replaced with the cisco memory pool mib"
 ::= { iso(1) org(3) dod(6) internet(1) private(4) enterprises(1) cisco(9)
       local(2) lsystem(1) 8 }
```

- **D** "Lowest(b)" is the lowest amount of memory that was free at some point in time since the last reload of the router. There is no equivalent MIB for this value.
- **E** "Largest(b)" is the largest contiguous block of memory free in the router [**ciscoMemoryPoolLargestFree** **.1.3.6.1.4.1.9.9.48.1.1.1.7**]. This is the most important field to look at in this output.

Related Information

- **SNMP Technology Support**
 - **IP Application Services Design Tech Notes**
 - **Technical Support & Documentation – Cisco Systems**
-

[Contacts & Feedback](#) | [Help](#) | [Site Map](#)

© 2008 – 2009 Cisco Systems, Inc. All rights reserved. [Terms & Conditions](#) | [Privacy Statement](#) | [Cookie Policy](#) | [Trademarks of Cisco Systems, Inc.](#)

Updated: Mar 28, 2006

Document ID: 15216
