

Troubleshoot and Configure Initial Wireless Services Module (WiSM) Setup

Document ID: 91473

Introduction

Prerequisites

- Requirements

- Components Used

- Conventions

Background Information

Configure Communication Between the Supervisor 720 and Cisco WiSM

Verification Steps

NetPro Discussion Forums – Featured Conversations

Related Information

Introduction

This document discusses the commands used to verify and troubleshoot the initial WiSM setup. This document also covers the basic steps necessary to configure the Catalyst 6500 Supervisor Engine 720 (Sup720) to communicate with the WiSM module that is installed in it.

Prerequisites

Requirements

Ensure that you have some basic knowledge about the Wireless LAN Controller and its configuration, as well as some basic knowledge of the Cisco Catalyst 6500 Switches that run Supervisor 720 and features such as the EtherChannel Link Aggregation (LAG). Apart from these, there are no specific requirements for this document.

Components Used

The information in this document is based on the Cisco WiSM module installed in a Catalyst 6500 Supervisor Engine 720 that runs Native Cisco IOS® Software Release 12.2(18)SXF2, but the commands apply to all the IOS versions that support the Supervisor 720 and the WiSM card.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Conventions

Refer to Cisco Technical Tips Conventions for more information on document conventions.

Background Information

The Cisco WiSM is a member of the Cisco Wireless LAN Controller family. It works in conjunction with the Cisco Aironet Lightweight Access Points, Cisco WCS, and Cisco Wireless Location Appliance to deliver a

secure and unified wireless solution that supports wireless data, voice, and video applications.

The Cisco WiSM smoothly integrates into the Cisco Catalyst 6500 Series Switch and a Cisco Catalyst 6500 Supervisor Engine 720. All Supervisor Engine 720 versions are supported. The WiSM is also supported on Cisco 7600 Routers that run only Cisco IOS® Software Release 12.2(18)SXF5.

This table lists the supported slots on the Cisco Catalyst 6500 for the Cisco WiSM:

Slot	6503-E	6504-E	6506	6509	6513
1-3	X	X	X	X	
4		X	X	X	
5-6			X	X	
7-8				X	
9				X	X
10-13					X

Note: The Catalyst 6500 Series Switch chassis can support up to five Cisco WiSMs without any other service module installed. If one or more service modules are installed, the chassis can support up to a maximum of four service modules, WiSMs included.

The Cisco WiSM consists of two Cisco 4404 Controllers, so the IT staff must be aware that two separate controllers exist on a single module. The first controller is considered the WiSM-A card, while the second controller is considered the WiSM-B card. Interfaces and IP addressing have to be considered on both cards independently. WiSM-A manages 150 access points, while WiSM-B manages a separate lot of 150 access points. These controllers can be grouped together in a mobility group that form a cluster.

There are multiple types of interfaces on each controller of the Cisco WiSM; three of them are pre-defined types that must be present and configured at setup time:

- Management interface (pre-defined and mandatory)
- AP-manager interface (pre-defined and mandatory)
- Virtual interface (pre-defined and mandatory)
- Operator-defined interface (user-defined)
- Service-port interface (pre-defined and mandatory)

Read Configuring a Cisco Wireless Services Module and Wireless Control System for details of each of the type of interfaces.

On the WiSM, the service port is used to synchronize the Supervisor Engine and the WiSM.

Configure Communication Between the Supervisor 720 and Cisco WiSM

After the Cisco WiSM controller is installed in a slot and detected by the Supervisor, these configurations are made on the Supervisor Engine to communicate with WiSM.

1. Create a DHCP scope for the Service-Port of the Catalyst WiSM.

```
ip dhcp excluded-address 192.168.10.1 192.168.10.2
```

```

!
ip dhcp pool wism-service-port

network 192.168.10.0 255.255.255.0

default-router 192.168.10.1

```

Alternatively, you can also session (**session slot X proc 1 or 2**) or console directly into WiSM and set static IP addresses (**config Interface Address Service-Port**).

Make sure that the service port IP address is not a routable IP address in your network because it is only used for communication between the Sup 720 and the WiSM.

Note: VLSM is supported on all ports, which includes the Service port.

2. Create the WiSM Service Port Gateway and assign the IP address.

Create a VLAN in the Supervisor 720. This VLAN is local to the chassis and is used for communication between Cisco WiSM and Catalyst Supervisor 720 over a Gigabit Interface on the Supervisor and a service port in the Cisco WiSM.

```

interface Vlan192

Description WiSM Service Port Gateway or Management Interface on CAT6K
ip address 192.168.10.1 255.255.255.0

```

Note: There should already be a network management VLAN interface to reach the Cat6k.

3. Assign the WiSM Service Ports to a VLAN.

Configure this command to use VLAN 192 to communicate with the service-port.

```

wism service-vlan 192

```

4. Create the WiSM Management/AP-Manager Gateway Interface on Cat6k.

This is an example configuration:

```

interface vlan40

Description WiSM Management/AP-Manager Interface Gateway
ip address 40.1.1.1

```

Note: Software Release 12.2(18)SXF5 introduced new WiSM commands to use with auto-LAG ports (in the high 200 range). These commands can be used instead of steps 5 and 6. Repeat the two commands for controller 1 and controller 2 in the WiSM module.

```

wism module <module/slot no> controller 1 native-vlan 40

```

```

wism module <module/slot no> controller 1 allowed-vlan native vlan id(40), vlan id1, vlan2, etc...

```

5. Create two port-channel interfaces on Cat6k with dot1q trunking, trust dscp, and native VLAN, which allows untagged packets from the management port.

Create two port-channel interfaces for the two independent controllers in the Cisco WiSM and assign VLAN 40 as the native interface.

```

interface Port-channel X

```

```

switchport trunk encapsulation dot1q
switchport trunk native vlan 40

switchport mode trunk
mls qos trust dscp
spanning-tree portfast trunk

```

Similarly, create another port channel interface for the other controller on the WiSM.

6. Configure the WiSM controller 1 and 2 interfaces.

As soon as the Cisco WiSM controller is detected by the Supervisor at the beginning, eight Gigabit Interfaces are created, which range from *Gig<slot number on which the module is installed>/1* to *Gig<slot number>/8*.

Configure these Gigabit Interfaces as trunk ports with VLAN 40 as the native VLAN. Make sure that the native VLAN is not tagged while you do the Cisco WiSM configuration. This is a configuration example:

```

router(config)# interface range gigabitEthernet
<slot>/1 4
or
router(config)# interface range gigabitEthernet
<slot>/5 8

switchport trunk encapsulation dot1q
switchport trunk native vlan 40

switchport mode trunk
mls qos trust dscp
spanning-tree portfast trunk
channel-group <port-channel no> mode on

```

Verification Steps

This section describes the commands used to verify the WiSM setup.

1. In order to verify which version of CAT IOS is running, issue the command

show version.

```

Router#show version
Cisco Internetwork Operating System Software
IOS (tm) s72033_rp Software (s72033_rp-ADVENTERPRISEK9_WAN-M), Version 12.2(18)SXF5,
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2006 by cisco Systems, Inc.
Compiled Sat 08-Jul-06 02:54 by kellythw
Image text-base: 0x40101040, data-base: 0x42D88000

ROM: System Bootstrap, Version 12.2(14r)S1, RELEASE SOFTWARE (fc1)
BOOTLDR: s72033_rp Software (s72033_rp-ADVENTERPRISEK9_WAN-M), Version 12.2(18)SXF5,

... skip ...

cisco WS-C6503-E (R7000) processor (revision 1.1) with 458720K/65536K bytes of memor
Processor board ID FOX0920047A
SR71000 CPU at 600Mhz, Implementation 0x504, Rev 1.2, 512KB L2 Cache
Last reset from power-on
SuperLAT software (copyright 1990 by Meridian Technology Corp).
X.25 software, Version 3.0.0.
Bridging software.

```

```

TN3270 Emulation software.
3 Virtual Ethernet/IEEE 802.3 interfaces
20 Gigabit Ethernet/IEEE 802.3 interfaces
1917K bytes of non-volatile configuration memory.
8192K bytes of packet buffer memory.

65536K bytes of Flash internal SIMM (Sector size 512K).
Configuration register is 0x2102

```

- Note:** The WiSM requires a Supervisor 720 that runs Native IOS Version 12.2(18)SXF2 or later.
- In order to verify that the Cat6k has a Supervisor 720 and a WiSM card, use the command `show module`

```

Router#show module
Mod Ports Card Type Model Serial No.
-----
 1     2 Supervisor Engine 720 (Active) WS-SUP720-BASE SAD0717003H
 3    10 WiSM WLAN Service Module WS-SVC-WISM-1-K9 SAD09280AZU

Mod MAC addresses Hw Fw Sw Status
-----
 1 000c.ce63.eb0c to 000c.ce63.eb0f 2.1 7.7(1) 12.2(18)SXF5 Ok
 3 0030.f274.ae36 to 0030.f274.ae45 0.3 12.2(14r)S5 12.2(18)SXF5 Ok

Mod Sub-Module Model Serial Hw Status
-----
 1 Policy Feature Card 3 WS-F6K-PFC3A SAD071902DP 1.1 Ok
 1 MSFC3 Daughterboard WS-SUP720 SAD071700L3 1.2 Ok
 3 Centralized Forwarding Card FARFEL SAD0929038U 0.3 Ok

Mod Online Diag Status
-----
 1 Pass
 3 Pass

```

Note: The output of the `show module` command from the switch shows WiSM with 10 ports. But only 8 ports are used for port-channel configuration, port-channel1 and port-channel2. The other 2 ports are used as service ports.

- In order to verify the slot in which the WiSM is installed, issue the command

show wism status.

This is an example output of this command:

```

Router#sh wism status
Service Vlan : 158, Service IP Subnet : 172.16.158.131/255.255.255.128
WLAN
Slot Controller Service IP Management IP SW Version Status
-----+-----+-----+-----+-----+-----+-----
 3 1 172.16.158.142 140.1.3.10 3.2.116.21 Oper-Up
 3 2 172.16.158.143 140.1.3.11 3.2.116.21 Oper-Up

```

For 6503-E, only slots 1 through 3 work. For 6504 through 6506, only slots 1 through 4 work. For 6509, only slots 1 through 9 work. For 6913, it is completely opposite; only slots 9 through 13 work. For more detailed information refer to WiSM Troubleshooting FAQ

- In order to verify the WiSM status from the Cat6k side, issue the command

show wism module X controller Y status


```
(WiSM-slot3-1) >show interface
summary
```

Interface Name	Port	Vlan Id	IP Address	Type	Ap Mgr	
ap-manager		LAG	untagged	192.168.3.9	Static	Yes
management		LAG	untagged	192.168.3.10	Static	No

NetPro Discussion Forums – Featured Conversations

Related Information

- [Configuring a Cisco Wireless Services Module and Wireless Control System](#)
- [WiSM Troubleshooting FAQ](#)
- [Catalyst 6500 Series WLSM to Catalyst 6500 Series WiSM Migration Guide](#)
- [Catalyst 6500 Series Switch and Cisco 7600 Series Router Wireless Services Module Installation and Verification Note](#)
- [Password Recovery Procedure for the Wireless LAN Controller Module \(WLCM\) and Wireless Services Module \(WiSM\)](#)
- [Cisco Catalyst 6500 Series Wireless Services Module](#)
- [Cisco Wireless LAN Controller Configuration Guide, Release 4.0](#)
- [WLC FAQ](#)
- [Wireless LAN Controller and Lightweight Access Point Basic Configuration Example](#)
- [Technical Support & Documentation – Cisco Systems](#)

[Contacts & Feedback](#) | [Help](#) | [Site Map](#)

© 2007 – 2008 Cisco Systems, Inc. All rights reserved. [Terms & Conditions](#) | [Privacy Statement](#) | [Cookie Policy](#) | [Trademarks of Cisco Systems, Inc.](#)

Updated: Aug 04, 2008

Document ID: 91473
