



INDEX

A

- AC power
 - specifications [A-1](#)
- altitude
 - guidelines [B-2](#)

C

- cabling requirements
 - inline network adapter [5-7](#)
 - inline network adapter (examples) [5-9](#)
- connections
 - power [3-7](#)
 - troubleshooting [6-2](#)
- connectors and ports
 - Interface Module [5-4](#)
 - Interface Module module [5-6](#)
 - locations [1-4](#)
- console port [1-4](#)
- corrosion
 - preventing damage [B-3](#)
- cover
 - removing [4-2](#)

D

- DC power
 - installation precautions [2-5](#)
- dust
 - preventing damage [B-3](#)

E

- electromagnetic interference
 - See EMI
- electrostatic discharge
 - See ESD
- EMI
 - preventing effects of [B-3](#)
- environment
 - maintaining [B-1](#)
- ESD
 - preventing damage [2-5, B-3](#)
- Ethernet controller
 - troubleshooting [6-3](#)
 - troubleshooting (chart) [6-3](#)
- Ethernet port
 - connector pinouts [1-4](#)

F

- front panel
 - figure [1-2](#)
 - LEDs [1-3](#)

H

- hardware
 - troubleshooting [6-1](#)
- hardware option
 - problems [6-7](#)
- humidity
 - maintenance guidelines [B-2](#)

I

- I/O connectors [1-3](#)
- inline network adapter
 - cabling examples [5-9](#)
 - cabling requirements [5-7](#)
- installation
 - warnings [2-1](#)
- Interface Module
 - description [5-1](#)
 - specifications [A-2](#)
- intermittent problems
 - troubleshooting [6-6](#)

L

- LEDs
 - checking [3-8](#)
 - description [1-3](#)
 - front panel (table) [1-3](#)
 - Interface Module [5-5, 5-6](#)
- line conditioners
 - using [B-5](#)

M

- magnetism
 - preventing effects of [B-4](#)
- maintenance [B-1 to B-5](#)
- memory
 - problems [6-7](#)

N

- network
 - connection problems [6-3](#)
 - removing WAVE from [3-8](#)

P

- ports
 - Interface Module [5-4, 5-6](#)
 - serial [1-4](#)
- power
 - connecting to system [3-7](#)
 - problems [6-7](#)
- power source interruptions
 - preventing damage from [B-4](#)
- power supplies
 - using uninterruptible [B-6](#)
- problem solving
 - overview [6-1](#)
 - tips [6-5](#)

R

- radio frequency interference
 - See RFI
- removing or replacing WAVE [3-8](#)
- RFI
 - preventing effects of [B-3](#)

S

- safety
 - general precautions [2-4](#)
 - warnings [2-1](#)
- serial port
 - description [1-4](#)
 - problems [6-8](#)
- shock
 - preventing damage [B-4](#)
- site environment
 - maintenance factors [B-1](#)
- surge protectors
 - using [B-5](#)
- switches

- troubleshooting [6-2](#)
- system problems
 - identifying [6-1](#)
- system reliability [2-5](#)

T

- temperature
 - maintenance guidelines [B-2](#)
- troubleshooting
 - connections [6-2](#)
 - Ethernet controller [6-3](#)
 - network connections [6-3](#)
 - switches [6-2](#)
 - system hardware [6-1](#)
 - undetermined problems [6-4](#)

U

- undetermined problems
 - troubleshooting [6-4](#)
- uninterruptible power supplies
 - using [B-6](#)

V

- vibration
 - preventing damage [B-4](#)

W

- warnings
 - installation [2-1](#)
- WAVE
 - installing [3-2](#)
 - maintaining [B-1](#)
 - removing or replacing [3-8](#)

