



## Managing Users

---

This chapter contains the following sections:

- [Adding a User, on page 1](#)
- [Adding a Role, on page 2](#)
- [Adding a Group, on page 3](#)

## Adding a User

After creating a user, you can change the password, but you cannot change the roles assigned to the user.

### Procedure

---

**Step 1** Navigate to the **User Management** tab under **Administration** and click + **User** to add a user.

**Step 2** In the **Add User** window, complete the following fields:

Name	Description
<b>Username</b> field	The name that you want to assign to the user.
<b>Password</b> field	The password for the user. Passwords must be between 8 and 256 characters long, contain uppercase and lowercase characters, have at least one numeric character, and have at least one nonalphanumeric character.
<b>Verify Password</b> field	Verify the password by re-entering it.

Name	Description
Choose <b>Role(s)</b> drop-down list	Choose the role that you want to assign to the user. You can assign more than one role. It can be one of the following: <ul style="list-style-type: none"> <li>• <b>Application User</b>—Provides privileges that are defined in the specified application.</li> <li>• <b>Security</b>—Provides privileges that are defined in the security application.</li> <li>• <b>Network Administrator</b>—Provides full administrative privileges to all applications.</li> <li>• <b>Network Operator</b>—Provides read-only privileges to all applications.</li> <li>• <b>Slice User</b>—Provides access to a specified slice.</li> </ul>
Enter a <b>Role Name</b> field	If you choose <b>Application User</b> , enter the name that you want to assign to the role.

**Step 3** Click **Save** in the **User Management** window or click **Cancel** to cancel the action.

## Adding a Role

### Procedure

**Step 1** Navigate to the **User Management** tab under **Administration** and click + **Role**.

**Step 2** In the **Add Role** window, complete the following fields:

Field	Description
Name field	The name of the role.
Level drop-down list	Choose the level that you want to assign to the role. This can be one of the following: <ul style="list-style-type: none"> <li>• App-Administrator—Has full access to all Cisco Nexus Data Broker resources.</li> <li>• App-User—Has full access to resources that are assigned to his resource group and resources that are created by another user who has similar permissions.</li> </ul>
Assign <b>Group(s)</b>	Assign groups to the selected role.

**Step 3** Click **save**.

---

## Adding a Group

### Procedure

---

**Step 1** Navigate to the **User Management** tab under **Administration** and click **+ Groups**.

**Step 2** In the **Add Group** window, complete the following field:

Field	Description
<b>Resource Group Name</b>	The name of the resource group.
<b>Select Switch Node</b>	Select a switch node from the drop-down list.
<b>+ Assign Switch and Ports</b>	Click <b>+</b> to add a new switch to the group.
<b>Select Ports</b>	Select the ports associated with the switch.
<b>Assign Group to Roles</b>	Assign a role to the group.

**Step 3** Click **Save**.

---

