

INDEX

Numerics

- 12-port 4-Gbps switching modules
 - BB_credit buffers [6-12](#)
 - configuration guidelines [5-17](#)
 - default settings [5-30](#)
 - See also switching modules
- 16-port switching modules
 - configuring BB_credits [6-1](#)
 - LEDs [2-16](#)
 - See also switching modules
- 24-port 4-Gbps switching modules
 - bandwidth fairness [5-24](#)
 - configuration guidelines [5-16](#)
 - default settings [5-30](#)
 - example configurations [6-11](#)
 - oversubscription [5-20](#)
 - shared resources [5-10](#)
 - See also switching modules
- 24-port 8-Gbps switching modules
 - default settings [5-30](#)
 - example configurations [6-7](#)
- 32-port switching modules
 - configuring BB_credits [6-1](#)
 - See also switching modules
- 4/44-port 8-Gbps switching modules
 - default settings [5-30](#)
 - example configurations [6-8](#)
- 48-port 4-Gbps switching modules
 - bandwidth fairness [5-24](#)
 - configuration guidelines [5-16](#)
 - default settings [5-30](#)
 - example configurations [6-9](#)

- oversubscription [5-20](#)
- shared resources [5-10](#)
- See also switching modules
- 48-port 8-Gbps switching modules
 - default settings [5-30](#)
 - example configurations [6-6](#)
 - See also switching modules
- 4-port 10-Gbps switching modules
 - BB_credit buffers [6-13](#)
 - configuration guidelines [5-18](#)
 - default settings [5-30](#)
 - See also switching modules

A

- administrative speeds
 - configuring [2-12](#)
- administrative states
 - description [2-8](#)
 - setting [2-11](#)
- ALPA caches
 - description [2-22](#)
- auto port mode
 - description [2-7](#)
 - interface configuration [2-3](#)
- autosensing speed
 - Generation 2 switching modules [2-13](#)

B

- bandwidth fairness
 - disabling [5-26](#)
 - enabling [5-24](#)

Send documentation comments to fm-docfeedback@cisco.com

Generation 2 switching modules [5-24](#)

BB_credit buffers

12-port 4-Gbps switching module allocations [6-12](#)

12-port 4-Gbps switching module considerations [6-12](#)

24-port 4-Gbps switching module allocations [6-10](#)

24-port 4-Gbps switching module considerations [6-11, 6-12](#)

24-port 8-Gbps switching module considerations [6-7](#)

4/44-port 8-Gbps switching module considerations [6-8](#)

48-port 4-Gbps switching module considerations [6-9](#)

48-port 8-Gbps switching module considerations [6-6](#)

4-port 10-Gbps switching module allocations [6-13](#)

4-port 10-Gbps switching module considerations [6-13, 6-14, 6-15](#)

allocation defaults (table) [6-6, 6-7, 6-8, 6-9](#)

BB_credits

configuring [6-2](#)

description [6-1](#)

reason codes [2-9](#)

BB_SC

enabling [6-19](#)

beacon modes

configuring [2-17](#)

identifying LEDs [2-16](#)

bit errors

reasons [2-17](#)

bit error thresholds

configuring [2-17](#)

description [2-17](#)

B port mode

description [2-7](#)

interface modes [2-7](#)

bridge port mode. See B port mode

buffer pools

Generation 2 switching modules [6-3](#)

buffer-to-buffer credits. See BB_credits

buffer-to-buffer start change. See BB_SC

C

Cisco MDS 9216i switches

configuring extended BB_credits [6-17](#)

configuring NPV [9-8](#)

D

dedicated rate mode

description [5-6](#)

migrating from shared rate mode [5-15, 5-16](#)

migrating to shared rate mode [5-16, 5-17](#)

destination IDs

exchange based [8-5](#)

flow based [8-4](#)

domain IDs

assignment failures [2-10](#)

domain manager

isolation [2-10](#)

dynamic bandwidth management

description [5-9](#)

E

EISLs

PortChannel links [8-2](#)

enhanced ISLs. See EISLs

E port mode

classes of service [2-4](#)

description [2-4](#)

E ports

32-port guidelines [2-3](#)

32-port switching module configuration guidelines [8-8](#)

configuring [2-12](#)

isolation [2-10](#)

Ethernet interface

configuring [3-1](#)

default settings [3-3](#)

Send documentation comments to fm-docfeedback@cisco.com

interface information [3-1](#)
 Device Manager [3-2](#)
 Fabric Manager [3-1](#)
 overview [3-1](#)
 exchange link parameter. See ELP
 expansion port mode. See E port mode
 extended BB_credits
 configuring [6-18](#)
 Generation 2 switching modules [6-16](#)
 licensing [6-16](#)

F

fabric loop port mode. See FL port mode
 fabric port mode. See F port mode
 fcdomains
 overlap isolation [2-10](#)
 FCoE Configuration Wizard [4-8](#)
 Fibre Channel interface
 default settings [2-29](#)
 Fibre Channel interfaces
 administrative states [2-8](#)
 BB_credits [6-1](#)
 characteristics [2-2 to 2-11](#)
 configuring [2-10](#)
 configuring beacon modes [2-17](#)
 configuring bit error thresholds [2-17](#)
 configuring descriptions [2-13](#)
 configuring frame encapsulation [2-16](#)
 configuring port modes [2-12](#)
 configuring receive data field sizes [6-19](#)
 configuring speeds [2-12](#)
 deleting from PortChannels [8-20](#)
 disabling [2-11](#)
 enabling [2-11](#)
 graceful shutdown [2-11](#)
 modes [2-3 to 2-7](#)
 operational states [2-8](#)
 performance buffers [6-2](#)

 reason codes [2-8](#)
 states [2-8](#)
 taking out of service on Generation 2 switching modules [5-26](#)
 troubleshooting operational states [2-9](#)
 See also interfaces [2-8](#)
 FL port mode
 classes of service [2-5](#)
 description [2-5](#)
 FL ports
 configuring [2-12](#)
 description [2-5](#)
 nonparticipating code [2-10](#)
 See also Fx ports
 F port mode
 classes of service [2-5](#)
 description [2-5](#)
 F ports
 configuring [2-12](#)
 description [2-5](#)
 See also Fx ports
 frame encapsulation
 configuring [2-16](#)
 Fx ports
 32-port default [2-3](#)
 configuring [2-12](#)
 description [2-7](#)
 interface modes [2-7](#)
 See also F ports; FL ports [2-7](#)

G

Generation 1 switching modules
 extended BB_credits [6-16](#)
 port index allocations [5-11](#)
 Generation 2 switching modules
 buffer groups [6-3 to 6-14](#)
 configuring [5-14 to 6-19](#)
 configuring port speeds [5-18](#)

Send documentation comments to fm-docfeedback@cisco.com

- configuring rate modes [5-19](#)
- default settings [5-30](#)
- description [5-1 to 5-3](#)
- dynamic bandwidth management [5-9](#)
- extended BB_credits [6-16, 6-17](#)
- out-of-service interfaces [5-10](#)
- port groups [5-3](#)
- port index allocations [5-11](#)
- port rate modes [5-4](#)
- recovering from powered-down state [5-12](#)
- releasing shared resources [5-27](#)
- taking interfaces out of service [5-26](#)

Generation 3 switching modules

- default settings [5-30](#)

I

interfaces

- adding to PortChannels [8-17, 8-18](#)
- configuring data field size [6-19](#)
- configuring descriptions [2-13](#)
- default settings [2-29](#)
- deleting from PortChannels [8-20](#)
- forced addition to PortChannels [8-19](#)
- isolated states [8-18](#)
- SFP types [2-19](#)
- suspended states [8-18](#)

interface statistics

- gathering [2-19](#)

IPv4 default gateways

- configuring mgmt0 interfaces [2-27](#)

ISLs

- PortChannel links [8-2](#)

L

LEDs

- beacon mode states [2-16](#)

- speed [2-17](#)
- licenses
 - extended BB_credits [6-16](#)
- load balancing
 - description [8-4](#)
 - PortChannels [8-2](#)

M

management interfaces

- configuring [2-27](#)
- default settings [2-29](#)
- features [2-27](#)

mgmt0 interfaces

- configuring [2-27](#)
- default settings [2-29](#)
- features [2-27](#)

MPS-14/2 modules

- configuring extended BB_credits [6-17](#)

N

NL ports

- interface modes [2-7](#)

nonparticipating codes

- description [2-10](#)

NPIV

- description [9-1](#)
- enabling [9-2](#)

NP links [9-4](#)

N port identifier virtualization. See NPIV

NL ports

- See also Nx ports

NP-ports [9-4](#)

NPV, configuring [9-8](#)

NPV mode [9-4](#)

Send documentation comments to fm-docfeedback@cisco.com

O

operational states

- configuring on Fibre Channel interfaces [2-12](#)
- description [2-8](#)

out-of-service interfaces

- description [5-10](#)

oversubscription

- disabling restrictions [5-22](#)
- enabling restrictions [5-23](#)
- Generation 2 switching modules [5-20](#)
- ratios [5-20](#)

P

performance buffers

- configuring [6-2](#)
- description [6-2](#)

PortChannel modes

- description [8-6](#)

PortChannel Protocol

- autocreation [8-22](#)
- configuring autocreation [8-23](#)
- converting autocreated groups to manually configured [8-23](#)
- creating channel group [8-21](#)
- description [8-20](#)
- enabling autocreation [8-23](#)

PortChannels

- adding interfaces [8-17, 8-18](#)
- administratively down [2-10](#)
- comparison with trunking [8-3](#)
- compatibility checks [8-18](#)
- configuration guidelines [8-10](#)
- creating [8-16](#)
- default settings [8-25](#)
- deleting [8-16](#)
- deleting interfaces [8-20](#)
- description [8-1](#)

examples [8-2](#)

forcing interface additions [8-19](#)

Generation 2 switching module interfaces [5-12](#)

interface states [8-18](#)

load balancing [8-4](#)

misconfiguration error detection [8-11](#)

verifying configurations [8-24](#)

port groups

- assigning extended BB_credits [6-17](#)
- description [5-3](#)

Generation 2 Fibre Channel switching modules [5-3](#)

Generation 3 Fibre Channel switching modules [5-7](#)

port indexes

- description [5-11](#)

port modes

- auto [2-7](#)
- description [2-3 to 2-7](#)

port rate modes

- configuring [5-19](#)
- dedicated [5-6](#)
- description [5-4](#)
- oversubscribed [5-7](#)
- shared [5-7](#)

See also rate modes

port speeds

- configuring [2-12](#)
- configuring on Generation 2 switching module interfaces [5-18](#)

R

rate modes

- configuring on Generation 2 switching module interfaces [5-19](#)
- See also port rate modes

reason codes

- description [2-8](#)

receive buffer groups. See buffer groups

receive data field sizes

Send documentation comments to fm-docfeedback@cisco.com

configuring [6-19](#)

recovery

- from powered-down state [5-12](#)

S

SD port mode

- description [2-6](#)
- interface modes [2-6](#)

SD ports

- configuring [2-12](#)

SFPs

- displaying transmitter types [2-19](#)
- transmitter types [2-18](#)

shared rate mode

- description [5-7](#)
- migrating from dedicated rate mode [5-16, 5-17](#)
- migrating to dedicated rate mode [5-15, 5-16](#)
- oversubscription [5-20](#)

source IDs

- exchange based [8-5](#)
- flow based [8-4](#)

SPAN destination port mode. See SD port mode

SPAN tunnel port mode. See ST port mode

ST port mode

- description [2-7](#)
- interface modes [2-7](#)
- limitations [2-7](#)

ST ports

- interface modes [2-7](#)

subnet masks

- configuring mgmt0 interfaces [2-27](#)

switch ports

- configuring attribute default values [2-18](#)

T

TE port mode

- classes of service [2-6](#)
- description [2-6](#)

TE ports

- trunking restrictions [7-3](#)

TF port mode

- classes of service [2-6](#)
- description [2-6](#)

TL port mode

- classes of service [2-5](#)
- description [2-5](#)

TL ports

- ALPA caches [2-22](#)
- configuring [2-12, 2-22](#)
- description [2-20](#)

translative loop port mode. See TL port mode

trunk-allowed VSAN lists

- description [7-9 to 7-11](#)

trunking

- comparison with PortChannels [8-3](#)
- configuration guidelines [7-4](#)
- configuring modes [7-7](#)
- default settings [7-11](#)
- description [7-1](#)
- link state [7-7](#)
- merging traffic [7-4](#)
- restrictions [7-3](#)

trunking E port mode. See TE port mode

trunking F port mode. See TF port mode

trunking protocol

- default settings [7-11, 7-12](#)
- default state [7-6](#)
- description [7-6](#)
- detecting port isolation [7-4](#)
- disabling [7-7](#)
- enabling [7-7](#)

trunk mode

- configuring [7-7, 7-8](#)
- default settings [7-11](#)
- status [7-7](#)

Send documentation comments to fm-docfeedback@cisco.com

V

virtual FC interface

- assigning to VSANs [4-7](#)

- configuring [4-2](#)

- Device Manager [4-4](#)

- Fabric Manager [4-2](#)

- creating

- Device Manager [4-12](#)

- Fabric Manager [4-10](#)

- default settings [4-13](#)

- deleting [4-13](#)

- limitations [4-1](#)

- overview [4-1](#)

virtual interface

- configuring

- FCoE Configuration Wizard [4-8](#)

VLANs

- mapping to VSANs [4-4](#)

- using Device Manager [4-6](#)

- using Fabric Manager [4-5](#)

VSAN IDs

- allowed list [7-11](#)

- multiplexing traffic [2-6](#)

VSAN interfaces

- configuring [2-28](#)

- creating [2-28](#)

- description [2-28](#)

VSANs

- allowed-active [7-4](#)

- configuring allowed-active lists [7-11](#)

- configuring trunk-allowed lists [7-9 to 7-11](#)

- mismatches [2-10](#)

- TE port mode [2-6](#)

- TF port mode [2-6](#)

- trunk-allowed [7-4](#)

VSAN trunking. See trunking

W

WWNs

- suspended connections [2-10](#)

Z

zones

- merge failures [2-10](#)

Send documentation comments to fm-docfeedback@cisco.com