



INDEX

F

- Fibre Channel write acceleration
 - default settings [3-3](#)
 - enabling [3-2](#)
 - estimating number of write buffers [3-1](#)
 - licensing [3-1](#)
 - modifying number of write buffers [3-2](#)

I

- Intelligent Storage Services
 - disabling (procedure) [2-6](#)
 - disabling with force option [2-6](#)
 - enabling (procedure) [2-3](#)
 - Fibre Channel write acceleration [3-3](#)
 - SCSI flow services [2-1 to 2-8](#)
 - SCSI flow statistics [2-1 to 2-8](#)

S

- SCSI flow configuration clients
 - description [2-3](#)
- SCSI flow data path support
 - description [2-3](#)
- SCSI flow managers
 - description [2-2](#)
- SCSI flow services
 - configuring [2-3 to, 2-3 to 2-6](#)
 - configuring (procedure) [2-4](#)
 - default settings [2-8](#)
 - description [2-1](#)
 - functional architecture (figure) [2-2](#)

SCSI flow configuration clients [2-3](#)

SCSI flow data path support [2-3](#)

SCSI flow managers [2-2](#)

SCSI flow statistics

clearing (procedure) [2-8](#)

default settings [2-8](#)

description [2-6](#)

enabling [2-7](#)

SSMs

disabling Intelligent Storage Services (procedure) [2-6](#)

enabling Intelligent Storage Services (procedure) [2-3](#)

Fibre Channel write acceleration [3-3](#)

provisioning Intelligent Storage Services (procedure) [2-3](#)

SCSI flow services [2-1 to 2-8](#)

SCSI flow statistics [2-1 to 2-8](#)

Send documentation comments to fm-docfeedback@cisco.com