



Preface

This preface describes the audience, organization, conventions, and documentation for the *Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.0(4)SV1(3)*.

This preface includes the following sections:

- [Audience, page ix](#)
- [Document Organization, page ix](#)
- [Document Conventions, page x](#)
- [Recommended Reading, page xi](#)
- [Available Documents, page xi](#)
- [Obtaining Documentation and Submitting a Service Request, page xii](#)

Audience

This guide is for network administrators with the following experience and knowledge:

- An understanding of virtualization
- Using VMware tools to configure a vswitch



Note

Knowledge of VMware vNetwork Distributed Switch is not a prerequisite.

Document Organization

This publication is organized as follows:

Chapter and Title	Description
Chapter 1, “Overview”	Describes port profiles and their use.
Chapter 2, “Creating Port Profiles”	Describes how to create, enable, and configure port profiles.
Chapter 3, “Configuring Port Profile Inheritance”	Describes port profile inheritance, how to configure it, and how to remove inheritance from a port profile.

Send document comments to nexus1k-docfeedback@cisco.com.

Chapter and Title	Description
Chapter 4, “Configuring System Port Profiles”	Describes system port profiles and how to configure them.
Chapter 5, “Configuring Port Channels in Port Profiles”	Describes port channels in port profiles and how to configure them.
Chapter 6, “Configuring a Private VLAN in a Port Profile”	Describes how to configure a port profile to be used as a private VLAN (PVLAN).
Chapter 7, “Verifying the Port Profile Configuration”	Lists and describes the commands used to verify port profile configurations
Appendix A, “Port Profile Configuration Limits”	Lists the maximum configuration limits for port profile features.

Document Conventions

Command descriptions use these conventions:

boldface font	Commands and keywords are in boldface.
<i>italic font</i>	Arguments for which you supply values are in italics.
{ }	Elements in braces are required choices.
[]	Elements in square brackets are optional.
x y z	Alternative, mutually exclusive elements are separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use these conventions:

<code>screen font</code>	Terminal sessions and information the device displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

This document uses the following conventions for notes and cautions:



Note

Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Send document comments to nexus1k-docfeedback@cisco.com.

Recommended Reading

Before configuring the Cisco Nexus 1000V, we recommend that you read and become familiar with the following documentation:

- *Cisco Nexus 1000V Getting Started Guide, Release 4.2(1)SV1(4)*
- *Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.2(1)SV1(4)*
- *Cisco VN-Link: Virtualization-Aware Networking white paper*

Available Documents

This section lists the documents used with the Cisco Nexus 1000 and available on [Cisco.com](http://www.cisco.com) at the following url:

http://www.cisco.com/en/US/products/ps9902/tsd_products_support_series_home.html

General Information

Cisco Nexus 1000V Documentation Roadmap, Release 4.0(4)SV1(3)

Cisco Nexus 1000V Release Notes, Release 4.0(4)SV1(3)

Cisco Nexus 1000V Compatibility Information, Release 4.0(4)SV1(3)

Cisco Nexus 1010 Management Software Release Notes, Release 4.0(4)SP1(1)

Install and Upgrade

Cisco Nexus 1000V Software Installation Guide, Release 4.0(4)SV1(3)

Cisco Nexus 1000V Software Upgrade Guide, Release 4.0(4)SV1(3)

Cisco Nexus 1000V VEM Software Installation and Upgrade Guide, Release 4.0(4)SV1(3)

Cisco Nexus 1010 Virtual Services Appliance Hardware Installation Guide

Configuration Guides

Cisco Nexus 1000V License Configuration Guide, Release 4.0(4)SV1(3)

Cisco Nexus 1000V Getting Started Guide, Release 4.0(4)SV1(3)

Cisco Nexus 1000V High Availability and Redundancy Configuration Guide, Release 4.0(4)SV1(3)

Cisco Nexus 1000V Interface Configuration Guide, Release 4.0(4)SV1(3)

Cisco Nexus 1000V Layer 2 Switching Configuration Guide, Release 4.0(4)SV1(3)

Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.0(4)SV1(3)

Cisco Nexus 1000V Quality of Service Configuration Guide, Release 4.0(4)SV1(3)

Cisco Nexus 1000V Security Configuration Guide, Release 4.0(4)SV1(3)

Cisco Nexus 1000V System Management Configuration Guide, Release 4.0(4)SV1(3)

Cisco Nexus 1010 Software Configuration Guide, Release 4.0(4)SP1(1)

Send document comments to nexus1k-docfeedback@cisco.com.

Programming Guide

Cisco Nexus 1000V XML API User Guide, Release 4.0(4)SV1(3)

Reference Guides

Cisco Nexus 1000V Command Reference, Release 4.0(4)SV1(3)

Cisco Nexus 1000V MIB Quick Reference

Cisco Nexus 1010 Command Reference, Release 4.0(4)SP1(1)

Troubleshooting and Alerts

Cisco Nexus 1000V Troubleshooting Guide, Release 4.0(4)SV1(3)

Cisco Nexus 1000V Password Recovery Guide

Cisco NX-OS System Messages Reference

Network Analysis Module Documentation

Cisco Network Analysis Module Software Documentation Guide, 4.2

Cisco Nexus 1000V NAM Virtual Service Blade Installation and Configuration Guide

Network Analysis Module Command Reference Guide, 4.2

User Guide for the Cisco Network Analysis Module Virtual Service Blades, 4.2

Cisco Network Analysis Module Software Release Notes, 4.2

Obtaining Documentation and Submitting a Service Request

For information about obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.