



# Preface

---

**Revised: October 30, 2012, OL-25004-02**

This document describes the Cisco BTS 10200 Softswitch features applicable to Session Initiation Protocol (SIP) subscribers and trunks. It also provides the procedures necessary to provision these features.

## Organization

This SIP Guide contains the following chapters:

- [Chapter 1, “SIP Network Overview”](#)—Provides an overview of the BTS 10200 functions in the SIP network.
- [Chapter 2, “SIP Subscribers”](#)—Explains how to provision and use the features applicable to SIP subscribers.
- [Chapter 3, “SIP Trunks”](#)—Explains how to provision and use the features applicable to SIP trunks.
- [Chapter 4, “SIP System Features”](#)—Explains how to provision and use features applicable to all SIP system operations.

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.

## Document Change History

The following table lists the revision history for the *Cisco BTS 10200 Softswitch SIP Guide, Release 6.0.3*.

Version Number	Issue Date	Status	Reason for Change
OL-25004-02	October 30, 2012	Revised	Updated the <a href="#">“Provisioning Session Timers for SIP Subscribers”</a> section on page 11.
OL-25004-01	August 10, 2011	Initial	Initial document for Release 6.0.3.