



# ACS Service Scheme Trigger Configuration Mode Commands

The ACS Service Scheme Trigger Configuration Mode is used to configure the set of triggers to be handled under the associated service-scheme.

## Command Modes

Exec > ACS Configuration > ACS Service Scheme Configuration > ACS Service Scheme Trigger Configuration  
**active-charging service** *service\_name* > **service-scheme** *service\_scheme\_name* > **trigger** { **flow-create** | **loc-update** | **sess-setup** }

Entering the above command sequence results in the following prompt:

```
[local] host_name(config-servscheme-trigger) #
```



## Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [end, on page 1](#)
- [exit, on page 2](#)
- [priority, on page 2](#)

## end

Exits the current configuration mode and returns to the Exec mode.

## Product

All

## Privilege

Security Administrator, Administrator

## Syntax Description

**end**

## Usage Guidelines

Use this command to return to the Exec mode.

## exit

Exits the current mode and returns to the parent configuration mode.

<b>Product</b>	All
<b>Privilege</b>	Security Administrator, Administrator
<b>Syntax Description</b>	<b>exit</b>
<b>Usage Guidelines</b>	Use this command to return to the parent configuration mode.

## priority

This command allows you to assign priority to the trigger events in service-scheme.

<b>Product</b>	ACS
<b>Privilege</b>	Security Administrator, Administrator
<b>Command Modes</b>	Exec> ACS Configuration> ACS Service Scheme Configuration> ACS Service Scheme Trigger Configuration <b>active-charging service</b> <i>service_name</i> > <b>service-scheme</b> <i>service_scheme_name</i> > <b>trigger</b> { <b>flow-create</b>   <b>loc-update</b>   <b>sess-setup</b> } Entering the above command sequence results in the following prompt: <pre>[local]host_name(config-servscheme-trigger)#</pre>
<b>Syntax Description</b>	<b>priority</b> <i>priority</i> <b>trigger-condition</b> <i>trigger_condn_name</i> <b>trigger-action</b> <i>trigger_action_name</i> <b>no priority</b> <i>priority</i>

**no**  
If previously configured, deletes the specified configuration.

**priority**  
Specifies the priority to be assigned to the trigger events.  
*priority* must be an integer from 1 through 127.

**trigger-condition** *trigger\_condn\_name*  
Specifies the trigger condition definition.  
*trigger\_condn\_name* must be an alphanumeric string of 1 through 63 characters.

**trigger-action** *trigger\_action\_name*  
Specifies the trigger action definition.

*trigger\_action\_name* must be an alphanumeric string of 1 through 63 characters.

---

**Usage Guidelines**

Use this command to assign priority to the trigger events configured in service-scheme. The priority must be unique within a trigger.

**Example**

The following command is configured to set priority as *10* with respective trigger condition *tc1* and trigger action *tal*:

```
priority 10 trigger-condition tc1 trigger-action tal
```

■ priority