

Configuration de la fonction de rappel MS entre un routeur et un PC Windows

Contenu

[Introduction](#)

[Conditions préalables](#)

[Conditions requises](#)

[Composants utilisés](#)

[Conventions](#)

[Théorie générale](#)

[Configurez](#)

[Résumé de configuration](#)

[Diagramme du réseau](#)

[Configurations](#)

[Configuration de client Windows](#)

[Windows 95 et configuration de client 98](#)

[Windows NT et configuration 2000 de client](#)

[Vérifiez](#)

[Dépannez](#)

[Dépannage des commandes](#)

[Informations connexes](#)

Introduction

L'implémentation de Microsoft du rappel n'est pas conforme avec [RFC 1570](#) . [Cependant, en raison de la grande part de marché du client réseau commuté de Microsoft, Cisco a mis en application le Control Protocol du rappel de service Microsoft \(MSCB\) dans la version de logiciel 11.3\(2\)T et ultérieures de Cisco IOS®.](#)

Conditions préalables

Conditions requises

Assurez-vous de répondre à ces exigences avant d'essayer cette configuration :

- Configurez le serveur d'accès à distance (NAS) pour recevoir des appels analogiques du client. Le rappel est une fonctionnalité supplémentaire d'accès distant de modem. , Vérifiez par conséquent si cet aspect fonctionne correctement. Ceci peut vous aider à dépanner.
- Le circuit T1/E1 doit être capable du dialout. Contactez votre opérateur téléphonique (compagnie de téléphone) pour vérifier ceci.

Composants utilisés

Les informations dans ce document sont basées sur le Logiciel Cisco IOS version 11.3(2)T et les versions ultérieures.

Ce scénario a été testé sur un PC avec le réseau de connexion à distance de Windows.

Les informations présentées dans ce document ont été créées à partir de périphériques dans un environnement de laboratoire spécifique. Tous les périphériques utilisés dans ce document ont démarré avec une configuration effacée (par défaut). Si vous travaillez dans un réseau opérationnel, assurez-vous de bien comprendre l'impact potentiel de toute commande avant de l'utiliser.

Conventions

Pour plus d'informations sur les conventions des documents, référez-vous aux [Conventions utilisées pour les conseils techniques de Cisco](#).

Théorie générale

Le rappel exécute dans cette commande :

1. Un utilisateur sur PC (client) se connecte au serveur d'accès Cisco.
2. Le processus de rappel est négocié pendant la phase du Link Control Protocol de Protocole point à point (PPP) (LCP).
3. L'authentification de PPP est exécutée.
4. Le logiciel de Cisco IOS valide des règles de rappel pour ce utilisateur ou ligne et déconnecte l'appelant pour le rappel.
5. Le serveur d'accès Cisco compose le client.

Il y a quatre types de MSCB :

1. Aucun rappel.
2. Numéro de rappel personnalisé par l'utilisateur.
3. numéro de rappel (préconfiguré) Serveur-spécifié.
4. Liste de numéro de rappel préconfiguré.

La configuration par défaut n'est aucun rappel (option 1). Des Option 2 ou 3 peuvent être configurés :

- Localement (si aucun serveur d'AAA n'est utilisé).
- Dans le profil TACACS+ ou d'utilisateur RADIUS (si l'AAA est utilisé).

Si l'option 2 est configurée, l'utilisateur est incité à introduire son numéro de rappel. Si l'option 3 est configurée, la demande offre seulement un choix, qui est le nombre administrateur-défini.

Cisco implémente seulement la fonctionnalité de serveur de rappel de MSCB et pas de la fonctionnalité de client de rappel. Ceci signifie qu'un routeur de Cisco peut être utilisé seulement en tant que serveur MSCB et pas en tant que client MSCB. En outre, l'implémentation de Cisco de MSCB exige de l'authentification d'être exécutée sur le client.

Configurez

Cette section vous fournit des informations pour configurer les fonctionnalités décrites dans ce document.

[Résumé de configuration](#)

Pour activer MSCB, vous devez activer le **rappel de ppp** recevez la commande sous l'interface de réception (par exemple, group-async). En outre, parce que l'authentification est exigée, vous devez activer l'authentification de Password Authentication Protocol (PAP) ou de protocole d'authentification CHAP (Challenge Handshake Authentication Protocol) :

```
ppp authentication chap pap
```

Deux chats-script sont créés automatiquement. Ce sont les chats-script d'**offhook** et de **rappel** :

```
chat-script offhook "" "ATH1" OK
chat-script callback ABORT ERROR ABORT BUSY ""
"ATZ" OK "ATDT \T" TIMEOUT60 CONNECT \c
```

Les chats-script sont également automatiquement appliqués aux lignes en service :

```
line 1 24
  script modem-off-hook offhook
  script callback callback
```

Un utilisateur doit **être autorisé** à s'appeler de retour. Vous pouvez configurer ceci localement sur le NAS ou sur le serveur externe d'AAA (RAYON ou TACACS+), basé sur où les informations de nom d'utilisateur et mot de passe sont stockées.

C'est une configuration locale pour un utilisateur qui s'appelle de retour à 5551212 :

```
username callmeback callback-dialstring 5551212 password cisco
```

Cette configuration locale s'applique aux utilisateurs qui sont permis pour spécifier leur propre numéro de rappel :

```
username callmeback callback-dialstring "" password cisco
```

[Diagramme du réseau](#)

Ce document utilise la configuration réseau suivante :

[Configurations](#)

Ce document utilise la configuration suivante :

- isdn2-2 (routeur AS5200)

isdn2-2 (routeur AS5200)
Current configuration: ! version 11.3 service timestamps debug datetime msec service password-encryption no service udp-small-servers no service tcp-small-servers ! hostname isdn2-2 !

```

aaa new-model
aaa authentication login default none
aaa authentication login use-local local
aaa authentication ppp default local
aaa authorization network local
!--- Runs authorization for network-related service
requests (Example: PPP). !--- For an AAA server
implementation, replace "local" with TACACS+ or RADIUS
in !--- these statements. enable secret 5 <deleted> !
username callmeback callback-dialstring "" password 7
<deleted> !--- This is for mobile users. The client
specifies the callback number. !--- If a RADIUS server
is used, this information can be offloaded to the
server. ip domain-name cisco.com isdn switch-type
primary-5ess chat-script offhook "" "ATH1" OK chat-
script callback ABORT ERROR ABORT BUSY "" "ATZ" OK "ATDT
\T" TIMEOUT 60 CONNECT \c !--- The chat script
"callback" is used for the callback connection. clock
timezone PST -8 clock summer-time PDT recurring ! !
controller T1 0 !--- Active T1 Primary Rate Interface
(PRI). framing esf clock source line secondary linecode
b8zs pri-group timeslots 1-24 ! controller T1 1 shutdown
! interface Ethernet0 ip address 172.16.25.52
255.255.255.240 ! interface Serial0 no ip address
shutdown ! interface Serial1 no ip address shutdown !
interface Serial0:23 !--- D-channel for T1 0. ip
unnumbered Ethernet0 encapsulation ppp dialer-group 1
isdn incoming-voice modem !--- Allows incoming ISDN
voice calls to be switched to the onboard modems. peer
default ip address pool default ! interface Group-Async1
ip unnumbered Ethernet0 ip tcp header-compression
passive encapsulation ppp async mode interactive peer
default ip address pool default no cdp enable ppp max-
bad-auth 3 ppp callback accept !--- Allows the group-
async to accept a callback request to a remote host. ppp
authentication chap !--- CHAP, PAP, or both must be
enabled for callback. group-range 1 12 ! router eigrp
202 network 172.16.0.0 distance 90 172.16.25.49 0.0.0.0
no auto-summary ! ip local pool default 172.16.25.59
172.16.25.62 !--- Default IP address pool for dial-in
clients. ip default-gateway 172.16.25.49 ip classless
dialer-list 1 protocol ip permit ! line con 0 line 1 6
autoselect during-login autoselect ppp script modem-off-
hook offhook script callback callback !--- Specifies a
chat script to issue AT commands to the modem during a
callback attempt. !--- The chat-scripts "offhook" and
"callback" were configured earlier. login authentication
use-local modem InOut transport input all line 7 12 !---
These modems are busied out and not used. autoselect
during-login autoselect ppp login authentication use-
local modem InOut modem busyout transport input all line
aux 0 exec-timeout 0 0 line vty 0 4 password 7 <deleted>
! end

```

[Configuration de client Windows](#)

[Windows 95 et configuration de client 98](#)

Pour le Windows 95 et 98 PC, il n'y a aucune configuration spéciale de côté client pour le rappel. Le serveur d'accès manipule les caractéristiques de rappel de la connexion. Le Windows 95 ou le

PC 98 affiche un message « attendant rappel » pour indiquer qu'un rappel est en cours.

Windows NT et configuration 2000 de client

Configurez ces Plateformes pour demander le rappel. Terminez-vous ces étapes pour les configurer :

1. Choisissez le **début > les programmes > les accessoires > les transmissions > les connexions de réseau et de connexion à distance**.
2. Choisissez les **préférences avancées > commutées** du menu.
3. Cliquez sur l'onglet de **rappel** pour accéder au menu de caractéristiques de rappel suivant les indications de la [figure 1](#).
4. Configurez vos options de rappel comme nécessaires : Pour ne pas utiliser la fonction de rappel, ne cliquez sur l'**aucun** bouton de **rappel**. Pour être incité ce qui à faire quand un serveur offre le rappel, cliquez sur le **demande pendant la composition quand le serveur offre le** bouton. Pour recevoir automatiquement des offres de rappel, cliquez sur **toujours l'appeler je de retour au bouton ci-dessous de nombres**, et sélectionnez le périphérique pour l'utiliser de la liste. Pour changer le numéro de téléphone de rappel, sélectionner le périphérique et cliquer sur le bouton d'**éditer**. Introduisez le nombre dans le **champ Numéro de téléphone** suivant les indications de la figure 1, et puis cliquez sur OK-dans l'appel moi de retour à la zone de dialogue.
5. Cliquez sur le **champ Numéro de téléphone**, et introduisez le nombre dans l'appel je de retour à la boîte de dialogue (représentée sur le [schéma 1](#)). Cliquez sur **OK** quand vous avez terminé.
6. Quand vous êtes de finition, cliquez sur OK dans la boîte de dialogue Préférences commutée. **Figure 1 – Accédez aux caractéristiques de rappel**

Vérifiez

Cette section présente des informations que vous pouvez utiliser pour vous assurer que votre configuration fonctionne correctement.

Certaines commandes **show** sont prises en charge par l'[Output Interpreter Tool \(clients enregistrés\)](#) uniquement), qui vous permet de voir une analyse de la sortie de la commande show.

- **active de show isdn** — affiche des informations au sujet des appels entrants et sortants en cours RNIS. Utilisez cette commande de vérifier si le rappel a été avec succès terminé. Si le rappel est réussi, l'**active de show isdn** affiche l'appel comme sortant sur le serveur de rappel.
- **utilisateurs d'exposition** — affiche des informations au sujet des lignes actives sur le routeur. Vous pouvez également utiliser l'ordre de **show caller** si votre version des supports logiciels de Cisco IOS il.
- **show dialer** — les informations générales de diagnostic d'expositions pour des interfaces configurées pour le Routage à établissement de connexion à la demande (DDR).

Dépannez

Cette section fournit des informations que vous pouvez utiliser pour dépanner votre configuration.

Dépannage des commandes

Remarque: Avant d'exécuter les commandes **debug**, référez-vous à la section **Informations importantes sur les commandes Debug**.

Pour plus d'informations sur des commandes de **débogage**, voyez la [référence de débogage des commandes de Cisco IOS version 12.0](#).

- **debug aaa authentication** — affiche des informations sur l'authentification d'AAA.
- **autorisation de debug aaa** — affiche des informations sur l'autorisation d'AAA.
- **debug callback** — événements de rappel d'affichages quand le routeur emploie un modem et un script de conversation pour faire appel de retour à une ligne de terminal.
- **debug modem** — te permet d'observer l'activité de ligne du modem sur un serveur d'accès.
- **debug ppp [paquet | négociation | erreur | authentification]** — affiche des informations sur le trafic et échanges d'un interrèseau qui implémente le PPP. *paquet* — paquets PPP d'affichages étant envoyés et reçus. (Cette commande affiche des vidages mémoire de paquet à bas niveau.) *négociation* — paquets PPP d'affichages transmis pendant le startup de PPP, quand des options PPP sont négociées. *erreur* — erreurs de protocole et statistiques sur les erreurs d'affichages associées avec la négociation et l'exécution de connexion PPP. *authentification* — messages du protocole d'authentification d'affichages, qui incluent des échanges de CHAP et PAP.
- **mettez au point les talks-show** la prise de contact qui se produit entre le serveur d'accès et son modem interne tandis que le modem est chargé pour composer pour sortir. Un chat-script est un ensemble de paires de chaîne expect-send qui définissent la prise de contact entre l'équipement pour terminal de données (DTE) et les périphériques du Data Communications Equipment (DCI).
- **debug isdn q931** — affiche les messages d'établissement d'appel et de désinstallation RNIS Q.931 (canal D) et les met au point. Dans ce scénario, l'appel par modem est porté en tant que service de support vocal au-dessus du réseau téléphonique public commuté (PSTN).
- **debug modem csm** — te permet de dépanner des problèmes du module de commutation d'appel (CSM) sur des Routeurs avec des modems numériques internes. Avec cette commande, vous pouvez tracer la séquence complète d'appels entrant et sortants de commutation.

```
isdn2-2#show debug General OS: Modem control/process activation debugging is on AAA
Authentication debugging is on AAA Authorization debugging is on PPP: PPP protocol negotiation
debugging is on ISDN: ISDN Q931 packets debugging is on Chat Scripts: Chat scripts activity
debugging is on Modem Management: Modem Management Call Switching Module debugging is on isdn2-
2# !--- This is the initial call from the client. *Mar 1 01:24:48.643: ISDN Se0:23: RX <- SETUP
pd = 8 callref = 0x36 *Mar 1 01:24:48.647: Bearer Capability i = 0x9090A2 *Mar 1 01:24:48.651:
Channel ID i = 0xA98393 *Mar 1 01:24:48.651: Called Party Number i = 0xC1, '4084327528' *Mar 1
01:24:48.663: ISDN Se0:23: Incoming call id = 0xA *Mar 1 01:24:48.671:
EVENT_FROM_ISDN::dchan_idb=0x7F8EE0, call_id=0xA, ces=0x1 bchan=0x12, event=0x1, cause=0x0 *Mar
1 01:24:48.671: VDEV_ALLOCATE: slot 0 and port 3 is allocated. *Mar 1 01:24:48.675:
EVENT_FROM_ISDN:(000A): DEV_INCALL at slot 0 and port 3 *Mar 1 01:24:48.675: CSM_PROC_IDLE:
CSM_EVENT_ISDN_CALL at slot 0, port 3 *Mar 1 01:24:48.679: Fast Ringing On at modem slot 0, port
3 *Mar 1 01:24:48.699: ISDN Se0:23: TX -> CALL_PROC pd = 8 callref = 0x8036 *Mar 1 01:24:48.703:
Channel ID i = 0xA98393 *Mar 1 01:24:48.735: ISDN Se0:23: TX -> ALERTING pd = 8 callref = 0x8036
*Mar 1 01:24:49.699: Fast Ringing Off at modem slot 0, port 3 *Mar 1 01:24:49.699:
CSM_PROC_IC1_RING: CSM_EVENT_MODEM_OFFHOOK at slot 0, port 3 *Mar 1 01:24:49.711: ISDN Se0:23:
TX -> CONNECT pd = 8 callref = 0x8036 *Mar 1 01:24:49.783: ISDN Se0:23: RX <- CONNECT_ACK pd = 8
callref = 0x36 *Mar 1 01:24:49.799: EVENT_FROM_ISDN::dchan_idb=0x7F8EE0, call_id=0xA, ces=0x1
bchan=0x12, event=0x4, cause=0x0 *Mar 1 01:24:49.799: EVENT_FROM_ISDN:(000A): DEV_CONNECTED at
```

slot 0 and port 3 *Mar 1 01:24:49.803: CSM_PROC_IC4_WAIT_FOR_CARRIER:CSM_EVENT_ISDN_CONNECTED at slot 0, port 3 *!--- Modem has established carrier.* *Mar 1 01:25:11.123: **TTY4: DSR came up** *Mar 1 01:25:11.127: tty4: Modem: IDLE->READY *Mar 1 01:25:11.131: TTY4: EXEC creation *Mar 1 01:25:11.135: AAA/AUTHEN: create_user (0x7B009C) user='' ruser='' port='tty4' rem_addr='async/4084327528' authen_type=ASCII service=LOGIN priv=1 *Mar 1 01:25:11.139: AAA/AUTHEN/START (3134998138): port='tty4' list='use-local' action=LOGIN service=LOGIN *Mar 1 01:25:11.143: AAA/AUTHEN/START (3134998138): found list use-local *Mar 1 01:25:11.143: AAA/AUTHEN/START (3134998138): Method=LOCAL *!--- Local AAA.* *Mar 1 01:25:11.147: AAA/AUTHEN (3134998138): status = GETUSER *Mar 1 01:25:13.951: TTY4: Autoselect(2) sample 7E *Mar 1 01:25:13.955: TTY4: Autoselect(2) sample 7EFF *Mar 1 01:25:13.959: TTY4: Autoselect(2) sample 7EFF7D *Mar 1 01:25:13.959: TTY4: Autoselect(2) sample 7EFF7D23 *Mar 1 01:25:13.963: TTY4 **Autoselect cmd: ppp negotiate** *Mar 1 01:25:13.967: AAA/AUTHEN/ABORT: (3134998138) because Autoselected. *Mar 1 01:25:13.967: AAA/AUTHEN: free_user (0x7B009C) user='' ruser='' port='tty4' rem_addr='async/4084327528' authen_type=ASCII service=LOGIN priv=1 *Mar 1 01:25:13.975: TTY4: EXEC creation *!--- PPP has been autoselected and begins negotiation.* %LINK-3-UPDOWN: Interface Async4, changed state to up *Mar 1 01:25:16.611: As4 PPP: Treating connection as a dedicated line *Mar 1 01:25:16.611: As4 **PPP: Phase is ESTABLISHING**, Active Open *!--- LCP negotiation begins.* *Mar 1 01:25:16.615: As4 LCP: O CONFREQ [Closed] id 3 len 25 *Mar 1 01:25:16.619: As4 LCP: ACCM 0x000A0000 (0x0206000A0000) *Mar 1 01:25:16.623: As4 LCP: AuthProto CHAP (0x0305C22305) *Mar 1 01:25:16.623: As4 LCP: MagicNumber 0x608D04A3 (0x0506608D04A3) *Mar 1 01:25:16.627: As4 LCP: PFC (0x0702) *Mar 1 01:25:16.627: As4 LCP: ACFC (0x0802) *Mar 1 01:25:16.751: As4 LCP: I CONFACK [REQsent] id 3 len 25 *Mar 1 01:25:16.755: As4 LCP: ACCM 0x000A0000 (0x0206000A0000) *Mar 1 01:25:16.755: As4 LCP: AuthProto CHAP (0x0305C22305) *Mar 1 01:25:16.759: As4 LCP: MagicNumber 0x608D04A3 (0x0506608D04A3) *Mar 1 01:25:16.763: As4 LCP: PFC (0x0702) *Mar 1 01:25:16.763: As4 LCP: ACFC (0x0802) *Mar 1 01:25:17.003: As4 **LCP: I CONFREQ** [ACKrcvd] id 3 len 23 *!--- Incoming CONFREQ.* *Mar 1 01:25:17.003: As4 LCP: ACCM 0x000A0000 (0x0206000A0000) *Mar 1 01:25:17.007: As4 LCP: MagicNumber 0x004A4A09 (0x0506004A4A09) *Mar 1 01:25:17.007: As4 LCP: PFC (0x0702) *Mar 1 01:25:17.011: As4 LCP: ACFC (0x0802) *Mar 1 01:25:17.011: As4 **LCP: Callback 6** (0x0D0306) *!--- Peer requests MS Callback (Option 6). !--- A PPP callback request uses Option 0.* *Mar 1 01:25:17.015: As4 **LCP: O CONFACK** [ACKrcvd] id 3 len 23 *Mar 1 01:25:17.015: As4 LCP: ACCM 0x000A0000 (0x0206000A0000) *Mar 1 01:25:17.019: As4 LCP: MagicNumber 0x004A4A09 (0x0506004A4A09) *Mar 1 01:25:17.023: As4 LCP: PFC (0x0702) *Mar 1 01:25:17.023: As4 LCP: ACFC (0x0802) *Mar 1 01:25:17.023: As4 LCP: **Callback 6** (0x0D0306) *!--- NAS CONFACKS all LCP parameters. !--- If the NAS refuses Callback (completely or just MS Callback), LCP may fail.* *Mar 1 01:25:17.027: As4 LCP: State is Open *!--- Authentication begins.* *Mar 1 01:25:20.095: As4 PPP: Phase is AUTHENTICATING, by this end *Mar 1 01:25:20.099: As4 CHAP: O CHALLENGE id 4 len 28 from "isdn2-2" *Mar 1 01:25:20.187: As4 CHAP: I RESPONSE id 4 len 26 from "callmeback" *Mar 1 01:25:20.191: AAA/AUTHEN: create_user (0x7ADEAC) user='callmeback' ruser='' port='Async4' rem_addr='async/4084327528' authen_type=CHAP service=PPP priv=1 *Mar 1 01:25:20.195: AAA/AUTHEN/START (44582883): port='Async4' list='' action=LOGIN service=PPP *Mar 1 01:25:20.199: AAA/AUTHEN/START (44582883): using "default" list *Mar 1 01:25:20.199: AAA/AUTHEN/START (44582883): Method=LOCAL *!--- Authentication passes.* *Mar 1 01:25:20.203: AAA/AUTHEN (44582883): **status = PASS** *!--- Check authorization for LCP. !--- With local AAA, this should pass. !--- For server-based AAA, this must be explicitly configured on the server.* *Mar 1 01:25:20.207: AAA/AUTHOR/LCP As4: Authorize LCP *Mar 1 01:25:20.207: AAA/AUTHOR/LCP: Async4: (3405067782): user='callmeback' *Mar 1 01:25:20.211: AAA/AUTHOR/LCP: Async4: (3405067782): send AV service=ppp *Mar 1 01:25:20.211: AAA/AUTHOR/LCP: Async4: (3405067782): send AV protocol=lcp *Mar 1 01:25:20.215: AAA/AUTHOR/LCP: Async4 (3405067782): Method=LOCAL *Mar 1 01:25:20.219: AAA/AUTHOR (3405067782): Post authorization status = PASS_ADD *Mar 1 01:25:20.223: AAA/AUTHOR/LCP As4: Processing AV service=ppp *Mar 1 01:25:20.223: AAA/AUTHOR/LCP As4: Processing AV protocol=lcp *Mar 1 01:25:20.227: AAA/AUTHOR/LCP As4: Processing AV service=ppp *Mar 1 01:25:20.227: AAA/AUTHOR/LCP As4: Processing AV protocol=lcp *!--- Callback-dialstring is null, so user is allowed to specify !--- their own callback number.* *Mar 1 01:25:20.227: AAA/AUTHOR/LCP As4: **Processing AV callback-dialstring=** *!--- Authentication ACK is returned to client.* *Mar 1 01:25:20.235: As4 **CHAP: O SUCCESS** id 4 len 4 *!--- Callback negotiation proceeds. Because callback-dialstring !--- is null, MCB debug says "Callback Number - Client ANY".* *Mar 1 01:25:20.239: As4 **MCB: User callmeback Callback Number - Client ANY** *!--- The callback number of the client is requested. Client receives a dialog !--- box that prompts the user to type in the callback number. !--- Request is sent every two seconds. If the user is slow to type a response, !--- the call remains in this phase for a long time.* *Mar 1 01:25:20.243: Async4 PPP: O MCB Request(1) id 20 len 9 *Mar 1 01:25:20.243: Async4 MCB: O 1 14 0 9 2 5 0 1 0 *Mar 1 01:25:20.247: As4 MCB: **O Request Id 20 Callback Type Client-Num delay 0** %LINEPROTO-5-UPDOWN: Line protocol on Interface Async4, changed state to up *Mar 1 01:25:22.459: As4 MCB: **Timeout in state WAIT_RESPONSE** *Mar 1 01:25:22.463: Async4 PPP: O MCB Request(1) id 21 len 9 *Mar 1

01:25:22.463: Async4 MCB: O 1 15 0 9 2 5 0 1 0 *Mar 1 01:25:22.467: As4 MCB: **O Request Id 21
Callback Type Client-Num delay 0** *Mar 1 01:25:24.499: As4 MCB: Timeout in state WAIT_RESPONSE
*Mar 1 01:25:24.503: Async4 PPP: O MCB Request(1) id 22 len 9 *Mar 1 01:25:24.503: Async4 MCB: O
1 16 0 9 2 5 0 1 0 *Mar 1 01:25:24.507: As4 MCB: O Request Id 22 Callback Type Client-Num delay
0 *Mar 1 01:25:26.543: As4 MCB: Timeout in state WAIT_RESPONSE *Mar 1 01:25:26.547: Async4 PPP:
O MCB Request(1) id 23 len 9 *Mar 1 01:25:26.547: Async4 MCB: O 1 17 0 9 2 5 0 1 0 *Mar 1
01:25:26.551: As4 MCB: O Request Id 23 Callback Type Client-Num delay 0 *Mar 1 01:25:28.583: As4
MCB: Timeout in state WAIT_RESPONSE *Mar 1 01:25:28.587: Async4 PPP: O MCB Request(1) id 24 len
9 *Mar 1 01:25:28.587: Async4 MCB: O 1 18 0 9 2 5 0 1 0 *Mar 1 01:25:28.591: As4 MCB: O Request
Id 24 Callback Type Client-Num delay 0 *!--- Client returned the callback number. Notice that the
response !--- is for the initial request id 20.* *Mar 1 01:25:29.763: Async4 PPP: **I MCB
Response(2) id 20** len 17 *Mar 1 01:25:29.767: Async4 MCB: I 2 14 0 11 2 D F 1 35 32 37 2D 39 36
35 31 0 *Mar 1 01:25:29.767: As4 MCB: Received response *!--- Response is ignored because the id
is 20. There have !--- been a few timeouts and id 24 (the last one sent) is expected.* *Mar 1
01:25:29.771: As4 MCB: **Resp ignored. ID Expected 24, got id 20** *Mar 1 01:25:30.623: As4 MCB:
Timeout in state WAIT_RESPONSE *!--- Send out new request (id 25).* *Mar 1 01:25:30.627: Async4
PPP: O MCB Request(1) id 25 len 9 *Mar 1 01:25:30.627: Async4 MCB: O 1 19 0 9 2 5 0 1 0 *Mar 1
01:25:30.631: As4 MCB: **O Request Id 25 Callback Type Client-Num delay 0** *!--- Client has cached
user response, and so the callback number is !--- returned right away.* *Mar 1 01:25:30.715:
Async4 PPP: **I MCB Response(2) id 25** len 17 *Mar 1 01:25:30.719: Async4 MCB: I 2 19 0 11 2 D F 1
35 32 37 2D 39 36 35 31 0 *Mar 1 01:25:30.723: As4 MCB: Received response *!--- Received client
callback number is 527-9651.* *Mar 1 01:25:30.723: As4 MCB: **Response CBK-Client-Num 2 13 15, addr
1-527-9651** *!--- Callback number acknowledged.* *Mar 1 01:25:30.727: Async4 PPP: **O MCB Ack(3) id
26** len 17 *Mar 1 01:25:30.731: Async4 MCB: O 3 1A 0 11 2 D F 1 35 32 37 2D 39 36 35 31 0 *Mar 1
01:25:30.731: As4 MCB: **O Ack Id 26 Callback Type Client-Num delay 15** *Mar 1 01:25:30.735: As4
MCB: **Negotiated MCB with peer** *!--- Client hangs up and begins to wait for callback. !--- This is
indicated by an Incoming (I) TERMREQ.* *Mar 1 01:25:30.815: As4 LCP: **I TERMREQ** [Open] id 5 len 4
*Mar 1 01:25:30.815: As4 LCP: O TERMACK [Open] id 5 len 4 *Mar 1 01:25:30.819: As4 MCB: Peer
terminating the link *Mar 1 01:25:30.819: As4 PPP: Phase is TERMINATING *Mar 1 01:25:30.819: As4
MCB: Link terminated by peer, Callback Needed *!--- Initiate callback to client; sleeps for ten
seconds.* *Mar 1 01:25:30.823: As4 MCB: **Initiate Callback for callmeback at 527-9651** using Async
*Mar 1 01:25:30.827: As4 MCB: Async-callback in progress *!--- Drop modem and B-channel for
initial call from client.* *Mar 1 01:25:31.499: CSM_PROC_IC5_OC6_CONNECTED:
CSM_EVENT_MODEM_ONHOOK at slot 0, port 3 *Mar 1 01:25:31.503: VDEV_DEALLOCATE: slot 0 and port 3
is deallocated *Mar 1 01:25:31.503: ISDN Se0:23: Event: Hangup call to call id 0xA %ISDN-6-
DISCONNECT: **Interface Serial0:18 disconnected from unknown , call lasted 41 seconds** *!--- Call is
completely disconnected.* *Mar 1 01:25:31.523: ISDN Se0:23: TX -> DISCONNECT pd = 8 callref =
0x8036 *Mar 1 01:25:31.523: Cause i = 0x8090 - Normal call clearing *Mar 1 01:25:31.583: ISDN
Se0:23: RX <- RELEASE pd = 8 callref = 0x36 *Mar 1 01:25:31.655: ISDN Se0:23: TX -> RELEASE_COMP
pd = 8 callref = 0x8036 %LINEPROTO-5-UPDOWN: Line protocol on Interface Async4, changed state to
down *Mar 1 01:25:31.851: TTY4: Async Int reset: Dropping DTR *Mar 1 01:25:33.695: As4 LCP:
TIMEout: Time = 0x4E521C State = TERMSent *Mar 1 01:25:33.699: As4 LCP: State is Closed *Mar 1
01:25:33.699: As4 PPP: Phase is DOWN *Mar 1 01:25:33.703: As4 PPP: Phase is ESTABLISHING,
Passive Open *Mar 1 01:25:33.707: As4 LCP: State is Listen %LINK-5-CHANGED: Interface Async4,
changed state to reset *Mar 1 01:25:33.879: As4 LCP: State is Closed *Mar 1 01:25:33.879: As4
PPP: Phase is DOWN *Mar 1 01:25:33.883: As4 IPCP: Remove route to 172.16.25.61 %LINK-3-UPDOWN:
Interface Async4, changed state to down *Mar 1 01:25:38.887: As4 LCP: State is Closed *Mar 1
01:25:38.887: As4 PPP: Phase is DOWN *!--- Cleanup from previous call is finished.* *Mar 1
01:25:40.863: CHAT4: **Matched chat script offhook to string offhook** *Mar 1 01:25:40.867: CHAT4:
Asserting DTR *!--- Modem goes offhook.* *Mar 1 01:25:40.867: CHAT4: Chat script offhook started
*Mar 1 01:25:40.871: CHAT4: Sending string: ATH1 *Mar 1 01:25:40.871: CHAT4: Expecting string:
OK *Mar 1 01:25:40.911: CSM_PROC_IDLE: CSM_EVENT_MODEM_OFFHOOK at slot 0, port 3 *Mar 1
01:25:40.963: CHAT4: Completed match for expect: OK *Mar 1 01:25:40.967: CHAT4: **Chat script
offhook finished, status = Success** *!--- Chat script "offhook" was successfully completed.* *Mar 1
01:25:40.967: CHAT4: **Matched chat script callback to string callback** *!--- Chat script "callback"
is initated.* *Mar 1 01:25:40.971: CHAT4: Asserting DTR *Mar 1 01:25:40.975: CHAT4: Chat script
callback started *!--- Reset modem to known state.* *Mar 1 01:25:40.975: CHAT4: Sending string:
ATZ *Mar 1 01:25:40.979: CSM_PROC_OC1_REQUEST_DIGIT: CSM_EVENT_MODEM_ONHOOK at slot 0, port 3
*Mar 1 01:25:40.983: VDEV_DEALLOCATE: slot 0 and port 3 is deallocated *Mar 1 01:25:40.979:
CHAT4: Expecting string: OK *Mar 1 01:25:42.123: CHAT4: Completed match for expect: OK *!--- Dial
the callback number of the client.* *Mar 1 01:25:42.127: CHAT4: Sending string: **ATDT \T<527-9651>**
*Mar 1 01:25:42.131: CHAT4: Expecting string: CONNECT *Mar 1 01:25:43.199: CSM_PROC_IDLE:
CSM_EVENT_MODEM_OFFHOOK at slot 0, port 3 *!--- Modem/ISDN needs to collect the digits from IOS
before it makes the call.* *Mar 1 01:25:43.327: DSX1_MAIL_FROM_NEAT: DC_READY_RSP: mid = 5, slot

= 2, unit = 1 *Mar 1 01:25:43.331: CSM_PROC_OC1_REQUEST_DIGIT: CSM_EVENT_DIGIT_COLLECT_READY at slot 0, port 3 *Mar 1 01:25:43.331: CSM_PROC_OC1_REQUEST_DIGIT: CSM_EVENT_ADDR_INFO_COLLECTED at slot 0, port 3 *Mar 1 01:25:44.327: DSX1_MAIL_FROM_NEAT: DC_FIRST_DIGIT_RSP: mid = 5, slot = 2, unit = 1 *Mar 1 01:25:44.331: CSM_PROC_OC2_COLLECT_1ST_DIGIT: CSM_EVENT_GET_1ST_DIGIT at slot 0, port 3 *Mar 1 01:25:47.331: DSX1_MAIL_FROM_NEAT: DC_ALL_DIGIT_RSP: mid = 5, slot = 2, unit = 1 *Mar 1 01:25:47.331: CSM_PROC_OC3_COLLECT_ALL_DIGIT: CSM_EVENT_GET_ALL_DIGITS at slot 0, port 3 *Mar 1 01:25:47.335: CSM_PROC_OC3_COLLECT_ALL_DIGIT: **called party num: (5279651) at slot 0, port 3 !--- Digits have been collected; ISDN call is made.** *Mar 1 01:25:47.339: process_pri_call making a voice_call. *Mar 1 01:25:47.351: ISDN Se0:23: TX -> SETUP pd = 8 callref = 0x0005 *Mar 1 01:25:47.355: **Bearer Capability i = 0x8090A2 !--- Bearer cap indicates call is an analog call.** *Mar 1 01:25:47.355: Channel ID i = 0xE1808397 *Mar 1 01:25:47.359: **Called Party Number i = 0xA1, '5279651'** *Mar 1 01:25:47.431: ISDN Se0:23: RX <- CALL_PROC pd = 8 callref = 0x8005 *Mar 1 01:25:47.435: Channel ID i = 0xA98397 *Mar 1 01:25:47.451: EVENT_FROM_ISDN::dchan_idb=0x7F8EE0, call_id=0xA005, ces=0x1 bchan=0x16, event=0x3, cause=0x0 *Mar 1 01:25:47.451: EVENT_FROM_ISDN:(A005): DEV_CALL_PROC at slot 0 and port 3 *Mar 1 01:25:47.455: CSM_PROC_OC4_DIALING: CSM_EVENT_ISDN_BCHAN_ASSIGNED at slot 0, port 3 *Mar 1 01:25:48.147: ISDN Se0:23: RX <- ALERTING pd = 8 callref = 0x8005 *Mar 1 01:25:48.151: Progress Ind i = 0x8388 - In-band info or appropriate now available *Mar 1 01:25:50.835: ISDN Se0:23: RX <- CONNECT pd = 8 callref = 0x8005 *Mar 1 01:25:50.851: EVENT_FROM_ISDN::dchan_idb=0x7F8EE0, call_id=0xA005, ces=0x1 bchan=0x16, event=0x4, cause=0x *Mar 1 01:25:50.855: EVENT_FROM_ISDN:(A005): DEV_CONNECTED at slot 0 and port 3 *Mar 1 01:25:50.859: CSM_PROC_OC5_WAIT_FOR_CARRIER: CSM_EVENT_ISDN_CONNECTED at slot 0, port 3 **!--- ISDN call is connected.** *Mar 1 01:25:50.867: ISDN Se0:23: **TX -> CONNECT_ACK** pd = 8 callref = 0x0005 *Mar 1 01:25:53.735: AAA/AUTHEN: free_user (0x7ADEAC) user='callmeback' ruser='' port='Async4' rem_addr='async/4084327528' authen_type=CHAP service=PPP priv=1 **!--- Modems have established carrier.** *Mar 1 01:26:13.487: CHAT4: Completed match for expect: CONNECT *Mar 1 01:26:13.491: CHAT4: Sending string: \c *Mar 1 01:26:13.491: CHAT4: Chat script callback finished, status = Success *Mar 1 01:26:15.415: TTY4: **DSR came up** *Mar 1 01:26:15.419: tty4: Modem: IDLE->READY *Mar 1 01:26:15.439: TTY4: EXEC creation *Mar 1 01:26:15.443: AAA/AUTHEN: create_user (0x7ADEA4) user='' ruser='' port='tty4' rem_addr='async/5279651' authen_type=ASCII service=LOGIN priv=1 *Mar 1 01:26:15.447: AAA/AUTHEN/START (2043462211): port='tty4' list='use-local' action=LOGIN service=LOGIN *Mar 1 01:26:15.451: AAA/AUTHEN/START (2043462211): found list use-local *Mar 1 01:26:15.451: AAA/AUTHEN/START (2043462211): Method=LOCAL *Mar 1 01:26:15.455: AAA/AUTHEN (2043462211): status = GETUSER **!--- PPP negotiation begins again.** *Mar 1 01:26:16.631: TTY4: Autoselect(2) sample 7E %LINK-3-UPDOWN: Interface Async4, changed state to up *Mar 1 01:26:18.663: As4 PPP: Treating connection as a dedicated line *Mar 1 01:26:18.663: As4 PPP: Phase is ESTABLISHING, Active Open *Mar 1 01:26:18.667: As4 LCP: O CONFREQ [Closed] id 5 len 25 *Mar 1 01:26:18.671: As4 LCP: ACCM 0x000A0000 (0x0206000A0000) *Mar 1 01:26:18.675: As4 LCP: AuthProto CHAP (0x0305C22305) *Mar 1 01:26:18.675: As4 LCP: MagicNumber 0x608DF70C (0x0506608DF70C) *Mar 1 01:26:18.679: As4 LCP: PFC (0x0702) *Mar 1 01:26:18.679: As4 LCP: ACFC (0x0802) *Mar 1 01:26:18.779: As4 LCP: I CONFACK [REQsent] id 5 len 25 *Mar 1 01:26:18.783: As4 LCP: ACCM 0x000A0000 (0x0206000A0000) *Mar 1 01:26:18.787: As4 LCP: AuthProto CHAP (0x0305C22305) *Mar 1 01:26:18.787: As4 LCP: MagicNumber 0x608DF70C (0x0506608DF70C) *Mar 1 01:26:18.791: As4 LCP: PFC (0x0702) *Mar 1 01:26:18.791: As4 LCP: ACFC (0x0802) *Mar 1 01:26:19.707: As4 LCP: I CONFREQ [ACKrcvd] id 3 len 20 *Mar 1 01:26:19.711: As4 LCP: ACCM 0x000A0000 (0x0206000A0000) *Mar 1 01:26:19.711: As4 LCP: MagicNumber 0x004B3EF5 (0x0506004B3EF5) *Mar 1 01:26:19.715: As4 LCP: PFC (0x0702) *Mar 1 01:26:19.715: As4 LCP: ACFC (0x0802) *Mar 1 01:26:19.719: As4 LCP: O CONFACK [ACKrcvd] id 3 len 20 *Mar 1 01:26:19.723: As4 LCP: ACCM 0x000A0000 (0x0206000A0000) *Mar 1 01:26:19.723: As4 LCP: MagicNumber 0x004B3EF5 (0x0506004B3EF5) *Mar 1 01:26:19.727: As4 LCP: PFC (0x0702) *Mar 1 01:26:19.727: As4 LCP: ACFC (0x0802) *Mar 1 01:26:19.731: As4 LCP: State is Open **!--- Reauthenticate the user.** *Mar 1 01:26:22.779: As4 PPP: **Phase is AUTHENTICATING**, by this end *Mar 1 01:26:22.783: As4 CHAP: O CHALLENGE id 6 len 28 from "isdn2-2" *Mar 1 01:26:22.887: As4 CHAP: I RESPONSE id 6 len 26 from "callmeback" *Mar 1 01:26:22.895: AAA/AUTHEN: create_user (0x8F1DAC) user='callmeback' ruser='' port='Async4' rem_addr='async/5279651' authen_type=CHAP service=PPP priv=1 *Mar 1 01:26:22.899: AAA/AUTHEN/START (2174906802): port='Async4' list='' action=LOGIN service=PPP *Mar 1 01:26:22.899: AAA/AUTHEN/START (2174906802): using "default" list *Mar 1 01:26:22.903: AAA/AUTHEN/START (2174906802): Method=LOCAL *Mar 1 01:26:22.903: AAA/AUTHEN (2174906802): status = PASS *Mar 1 01:26:22.907: AAA/AUTHOR/LCP As4: Authorize LCP *Mar 1 01:26:22.911: AAA/AUTHOR/LCP: Async4: (3262137315): user='callmeback' *Mar 1 01:26:22.911: AAA/AUTHOR/LCP: Async4: (3262137315): send AV service=ppp *Mar 1 01:26:22.915: AAA/AUTHOR/LCP: Async4: (3262137315): send AV protocol=lcp *Mar 1 01:26:22.915: AAA/AUTHOR/LCP: Async4 (3262137315): Method=LOCAL *Mar 1 01:26:22.923: AAA/AUTHOR (3262137315): Post authorization status =PASS_ADD *Mar 1 01:26:22.927: AAA/AUTHOR/LCP As4: Processing AV service=ppp *Mar 1 01:26:22.927: AAA/AUTHOR/LCP As4: Processing AV protocol=lcp *Mar 1 01:26:22.931: AAA/AUTHOR/LCP

As4: Processing AV service=ppp *Mar 1 01:26:22.931: AAA/AUTHOR/LCP As4: Processing AV protocol=lcp *Mar 1 01:26:22.931: AAA/AUTHOR/LCP As4: Processing AV callback-dialstring= *Mar 1 01:26:22.939: As4 CHAP: O SUCCESS id 6 len 4 *Mar 1 01:26:22.943: As4 PPP: Phase is UP *Mar 1 01:26:22.947: AAA/AUTHOR/FSM As4: (0): Can we start IPCP? *Mar 1 01:26:22.947: AAA/AUTHOR/FSM: Async4: (345798021): user='callmeback' *Mar 1 01:26:22.951: AAA/AUTHOR/FSM: Async4: (345798021): send AV service=ppp *Mar 1 01:26:22.951: AAA/AUTHOR/FSM: Async4: (345798021): send AV protocol=ip *Mar 1 01:26:22.955: AAA/AUTHOR/FSM: Async4 (345798021): Method=LOCAL *Mar 1 01:26:22.955: AAA/AUTHOR (345798021): Post authorization status = PASS_REPL *!--- Negotiate IPCP.* *Mar 1 01:26:22.959: AAA/AUTHOR/FSM As4: We can start IPCP *Mar 1 01:26:22.963: As4 IPCP: O CONFREQ [Closed] id 1 len 16 *Mar 1 01:26:22.967: As4 IPCP: CompressType VJ 15 slots (0x0206002D0F00) *Mar 1 01:26:22.967: As4 IPCP: Address 172.16.25.52 (0x0306AC101934) *Mar 1 01:26:23.019: As4 IPCP: I CONFREQ [REQsent] id 1 len 40 *Mar 1 01:26:23.023: As4 IPCP: CompressType VJ 15 slots CompressSlotID (0x0206002D0F01) *Mar 1 01:26:23.027: As4 IPCP: Address 0.0.0.0 (0x030600000000) *Mar 1 01:26:23.027: As4 IPCP: PrimaryDNS 0.0.0.0 (0x810600000000) *Mar 1 01:26:23.031: As4 IPCP: PrimaryWINS 0.0.0.0 (0x820600000000) *Mar 1 01:26:23.035: As4 IPCP: SecondaryDNS 0.0.0.0 (0x830600000000) *Mar 1 01:26:23.035: As4 IPCP: SecondaryWINS 0.0.0.0 (0x840600000000) *Mar 1 01:26:23.039: AAA/AUTHOR/IPCP As4: Start. Her address 0.0.0.0, we want 0.0.0.0 *Mar 1 01:26:23.039: AAA/AUTHOR/IPCP As4: Processing AV service=ppp *Mar 1 01:26:23.043: AAA/AUTHOR/IPCP As4: Processing AV protocol=ip *Mar 1 01:26:23.043: AAA/AUTHOR/IPCP As4: Authorization succeeded *Mar 1 01:26:23.047: AAA/AUTHOR/IPCP As4: Done. Her address 0.0.0.0, we want 0.0.0.0 *Mar 1 01:26:23.047: As4 IPCP: Using pool 'default' *Mar 1 01:26:23.051: As4 IPCP: Pool returned 172.16.25.60 *Mar 1 01:26:23.051: As4 IPCP: O CONFREQ [REQsent] id 1 len 28 *Mar 1 01:26:23.055: As4 IPCP: PrimaryDNS 0.0.0.0 (0x810600000000) *Mar 1 01:26:23.059: As4 IPCP: PrimaryWINS 0.0.0.0 (0x820600000000) *Mar 1 01:26:23.059: As4 IPCP: SecondaryDNS 0.0.0.0 (0x830600000000) *Mar 1 01:26:23.063: As4 IPCP: SecondaryWINS 0.0.0.0 (0x840600000000) *Mar 1 01:26:23.067: As4 IPCP: I CONFACK [REQsent] id 1 len 16 *Mar 1 01:26:23.067: As4 IPCP: CompressType VJ 15 slots (0x0206002D0F00) *Mar 1 01:26:23.071: As4 IPCP: Address 172.16.25.52 (0x0306AC101934) *Mar 1 01:26:23.139: As4 IPCP: I CONFREQ [ACKrcvd] id 2 len 16 *Mar 1 01:26:23.139: As4 IPCP: CompressType VJ 15 slots CompressSlotID (0x0206002D0F01) *Mar 1 01:26:23.143: As4 IPCP: Address 0.0.0.0 (0x030600000000) *Mar 1 01:26:23.147: AAA/AUTHOR/IPCP As4: Start. Her address 0.0.0.0, we want 172.16.25.60 *Mar 1 01:26:23.147: AAA/AUTHOR/IPCP As4: Processing AV service=ppp *Mar 1 01:26:23.151: AAA/AUTHOR/IPCP As4: Processing AV protocol=ip *Mar 1 01:26:23.151: AAA/AUTHOR/IPCP As4: Authorization succeeded *Mar 1 01:26:23.151: AAA/AUTHOR/IPCP As4: Done. Her address 0.0.0.0, we want 172.16.25.60 *Mar 1 01:26:23.155: As4 IPCP: O CONFNAK [ACKrcvd] id 2 len 10 *Mar 1 01:26:23.159: As4 IPCP: Address 172.16.25.60 (0x0306AC10193C) *Mar 1 01:26:23.255: As4 IPCP: I CONFREQ [ACKrcvd] id 3 len 16 *Mar 1 01:26:23.259: As4 IPCP: CompressType VJ 15 slots CompressSlotID (0x0206002D0F01) *Mar 1 01:26:23.263: As4 IPCP: Address 172.16.25.60 (0x0306AC10193C) *Mar 1 01:26:23.263: AAA/AUTHOR/IPCP As4: Start. Her address 172.16.25.60, we want 172.16.25.60 *Mar 1 01:26:23.267: AAA/AUTHOR/IPCP: Async4: (3819567164): user='callmeback' *Mar 1 01:26:23.271: AAA/AUTHOR/IPCP: Async4: (3819567164): send AV service=ppp *Mar 1 01:26:23.271: AAA/AUTHOR/IPCP: Async4: (3819567164): send AV protocol=ip *Mar 1 01:26:23.275: AAA/AUTHOR/IPCP: Async4: (3819567164): send AV addr*172.16.25.60 *Mar 1 01:26:23.275: AAA/AUTHOR/IPCP: Async4 (3819567164): Method=LOCAL *Mar 1 01:26:23.279: AAA/AUTHOR (3819567164): Post authorization status = PASS_REPL *Mar 1 01:26:23.283: AAA/AUTHOR/IPCP As4: Reject 172.16.25.60, using 172.16.25.60 *Mar 1 01:26:23.287: AAA/AUTHOR/IPCP As4: Processing AV service=ppp *Mar 1 01:26:23.291: AAA/AUTHOR/IPCP As4: Processing AV protocol=ip *Mar 1 01:26:23.291: AAA/AUTHOR/IPCP As4: Processing AV addr*172.16.25.60 *Mar 1 01:26:23.295: AAA/AUTHOR/IPCP As4: Authorization succeeded *Mar 1 01:26:23.295: AAA/AUTHOR/IPCP As4: Done. Her address 172.16.25.60, we want 172.16.25.60 *Mar 1 01:26:23.299: As4 IPCP: O CONFACK [ACKrcvd] id 3 len 16 *Mar 1 01:26:23.303: As4 IPCP: CompressType VJ 15 slots CompressSlotID (0x0206002D0F01) *Mar 1 01:26:23.303: As4 IPCP: Address 172.16.25.60 (0x0306AC10193C) *Mar 1 01:26:23.307: As4 IPCP: State is Open *Mar 1 01:26:23.323: As4 IPCP: Install route to 172.16.25.60 **%LINEPROTO-5-UPDOWN: Line protocol on Interface Async4, changed state to up** *!--- Client is connected.*

[Informations connexes](#)

- [Configurer le rappel asynchrone](#)
- [PPP Callback au-dessus du RNIS](#)
- [Configurer le PPP Callback pour le DDR](#)
- [Configurer le PPP Callback avec TACACS+](#)

- [Configuration de la fonction PPP Callback avec RADIUS](#)
- [Pages d'assistance sur les produits d'accès](#)
- [Pages d'assistance sur la technologie de numérotation](#)
- [Support technique - Cisco Systems](#)