



Preface

This preface describes the audience, organization, and conventions of this publication, and provides information on how to obtain related documentation.

Audience

This publication is for experienced network administrators who are responsible for configuring and maintaining Catalyst 6500 series switches and network managers who perform any of the following tasks:

- Managing network security
- Configuring firewalls
- Managing default and static routes and TCP and UDP services

This guide contains the commands available for use with the Cisco *Content Switching Module with SSL* (CSM-S). Use this guide with the *Catalyst 6500 Series Switch Content Switching Module with SSL Installation Note* and the *Catalyst 6500 Series Switch Content Switching Module with SSL Installation and Configuration Note*.

Organization

This publication is organized as follows:

Chapter	Title	Description
Chapter 1	Using Content Switching Module Commands	Introduces you to the CSM commands, access modes, and common port and protocol numbers.
Chapter 2	Content Switching Module with SSL Commands	Provides detailed descriptions of all CSM commands in an alphabetical listing.
Chapter 3	Commands Specific to the Content Switching Module with SSL	Provides detailed descriptions of all SSL commands used by the CSMS in an alphabetical listing.
Appendix A	Acronyms	Lists the acronyms used in this command reference.

Conventions

This document uses the following conventions:

Convention	Description
boldface font	Commands, command options, and keywords are in boldface .
<i>italic font</i>	Arguments for which you supply values are in <i>italics</i> .
[]	Elements in square brackets are optional. Default responses to system prompts are in square brackets.
{ x y z }	Alternative keywords are grouped in braces and separated by vertical bars. Braces can also be used to group keywords and/or arguments; for example, { interface <i>interface</i> type }.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
screen font	Terminal sessions and information the system displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font .
<i>italic screen font</i>	Arguments in the screen display for which you supply values are in <i>italic screen font</i> .
^	The symbol ^ represents the key labeled Control—for example, the key combination ^D in a screen display means hold down the Control key while you press the D key.
< >	Nonprinting characters, such as passwords are in angle brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

Notes use the following conventions:



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the publication.

Cautions use the following conventions:



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Related Documentation

For more detailed installation and configuration information for the Content Switching Module with SSL, refer to the following publications:

- *Release Notes for the Catalyst 6500 Series Switch Content Switching Module with SSL*
- *Catalyst 6500 Series Switch Content Switching Module with SSL Installation Note*
- *Catalyst 6500 Series Switch Content Switching Module with SSL Command Reference*
- *Regulatory Compliance and Safety Information for the Catalyst 6500 Series Switches*

For more detailed installation and configuration information for SSL services, refer to the following publications:

- *Release Notes for Catalyst 6500 Series SSL Services Module Software Release 2.x*
- *Catalyst 6500 Series Switch SSL Services Module Installation and Verification Note*
- *Catalyst 6500 Series Switch SSL Services Module Command Reference*
- *Catalyst 6500 Series Switch SSL Services Module System Messages*

Use this document in conjunction with the CSM documentation available online at the following site:

http://www.cisco.com/en/US/products/ps6077/tsd_products_support_model_home.html

Cisco provides CSM technical tips at the following site:

<http://www.cisco.com/en/US/products/hw/modules/ps2706/ps780/index.html>

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as an RSS feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service. Cisco currently supports RSS Version 2.0.

