



INDEX

Symbols

<cr> [1-8](#)
? command [1-8](#)

Numerics

802.1D [6-10](#)

A

AAL5CISCOPPP encapsulation [6-3](#)

AAL5MUX encapsulation [6-3](#)

AAL5NLPID encapsulation [6-4](#)

AAL5SNAP encapsulation [6-4](#)

access port

configuration (example) [21-29](#)

configuring [21-8](#)

activation

verifying for SIPs [5-5](#)

verifying for SPAs [5-7](#)

administratively down state [10-40](#)

Advanced Encryption Standard. See AES.

AES

configuration (example) [24-22, 25-23](#)

configuring [24-2, 25-2](#)

AIS [8-16](#)

alarm indication signal, see AIS

anti-replay window size, configuring [25-5](#)

aps reflector command [6-13](#)

asymmetric routing [21-6, 22-5](#)

ATM

AIS [8-16](#)

encapsulation [6-3](#)

FERF [8-16](#)

HCSE [8-16](#)

line coding errors [8-16](#)

LOF [8-16](#)

RAI [8-16](#)

service classes [6-4](#)

SPA system messages [8-16](#)

ATM-ACCOUNTING-INFORMATION-MIB [3-20](#)

atm bridge-enable command [6-13, 7-20](#)

ATM-MIB [3-20](#)

ATM-SOFT-PVC-MIB [3-20](#)

ATMSPA system messages [8-16](#)

ATM-TC-MIB [3-20](#)

ATM-TRACE-MIB [3-20](#)

AToM (Any Transport over ATM)

configuration guidelines, Cisco 7600 SIP-400 [4-31](#)

AToM (Any Transport over MPLS)

configuring on SIPs [4-30](#)

AToMoGRE [10-14](#)

automatic SPA FPD image upgrade

(example) [31-13](#)

cannot locate FPD image package (example) [31-13](#)

disabling [31-6](#)

re-enabling [31-6](#)

autonegotiation

configuring [10-8 to 10-10](#)

disabling

on fiber interfaces [10-9](#)

enabling on fiber interfaces [10-9](#)

average cell rate [6-4](#)

B

BCP. See Bridging Control Protocol

BERT pattern [18-33](#)

BFG

- configuration (example) [28-37](#)
- configuring [28-21](#)
- troubleshooting [30-27](#)

blade failure group. See BFG.

blank filler plate [8-26](#), [11-9](#), [19-18](#), [30-30](#)

- for empty subslots in an SSC [2-2](#)
- for empty subslots in a SIP [2-1](#)
- single-height size [2-3](#)

BPDU packet formats [6-12](#)

Bridge Protocol Data Unit (BPDU) [6-11](#)

Bridging Control Protocol

- configuring [15-16](#), [16-18](#), [17-21](#), [18-27](#)

C

CAC

- configuration [24-15](#)
- configuration (examples) [24-24](#)

Call Admission Control. See CAC

carriage return (<cr>) [1-8](#)

Catalyst 6509 switch (figure) [4-3](#)

CBR [6-4](#)

CEF [6-1](#), [7-1](#), [8-1](#)

CEF for PFC2

- See CEF

certificate autoenrollment

- configuration (example) [26-60](#)
- configuring [26-27](#)

certificate security attribute-based access control

- configuration (example) [26-62](#)
- configuring [26-42](#)

certificate to ISAKMP profile mapping

- configuration (examples) [24-23](#)

certificate to ISAKMP profile mapping, configuring [24-6](#)

Changing the speed of a Fast Ethernet SPA

- configuration (example) [10-45](#)

Cisco 7600 SIP-200

- description [3-3](#)
- dMLFR, configuring [4-5 to 4-11](#)
- dMLPPP, configuring [4-11 to 4-15](#)
- faceplate (figure) [4-4](#)
- features [3-3 to 3-8](#)
- restrictions [3-15](#)
- subslot numbering [4-4](#)

Cisco 7600 SIP-400

- description [3-3](#)
- features [3-9 to 3-12](#)
- restrictions [3-16](#)

Cisco 7600 SIP-600

- description [3-3](#)
- features [3-12 to 3-15](#)

Cisco 7600 SSC-400

- restrictions [3-19](#), [3-20](#)

CISCO-AAL5-MIB [3-20](#)

CISCO-ATM-CONN-MIB [3-20](#)

CISCO-ATM-RM-MIB [3-20](#)

CISCO-ATM TRAFFIC-MIB [3-20](#)

CISCO-CLASS-BASED-QOS-MIB [3-20](#)

Cisco Discovery Protocol (CDP) [10-10](#)

CISCO-ENTITY-ASSET-MIB [3-20](#)

CISCO-ENTITY-EXT-MIB [3-20](#), [3-21](#)

CISCO-ENTITY-FRU-CONTROL-MIB [3-20](#), [3-21](#)

Cisco IOS configuration changes, saving [1-12](#)

Cisco MIB Locator [6-16](#), [9-3](#), [12-6](#), [14-6](#), [14-7](#)

clear crypto sa command [30-24](#)

command line processing [1-6](#)

command modes, understanding [1-6 to 1-7](#)

commands

- context-sensitive help for abbreviating [1-8](#)
- default form, using [1-11](#)
- no form, using [1-11](#)
- show interfaces serial
- troubleshooting serial lines [19-4](#)

- command syntax
 - displaying (example) [1-8](#)
 - common part convergence sublayer [6-11](#)
 - conditions
 - status line, show interfaces serial command [19-3](#)
 - configuration example
 - BRE on a PVC [7-22](#)
 - configurations, saving [1-12](#)
 - configuration tasks, required
 - for the Fast Ethernet SPA [10-2](#)
 - for the Gigabit Ethernet SPA [10-2](#)
 - configure terminal command [5-8, 10-2](#)
 - configuring SPAs
 - Fast Ethernet [10-1](#)
 - Gigabit Ethernet [10-1](#)
 - console error messages
 - Cisco 7600 SSC-400 [30-2](#)
 - IPSec VPN SPA [30-2](#)
 - constant bit rate, see CBR
 - copy command [10-39](#)
 - CoS [25-17](#)
 - create on-demand command [6-13](#)
 - cRTP (Compressed Real-Time Protocol)
 - configuring [4-4](#)
 - crypto conditional debug support [30-27](#)
 - crypto-connect mode
 - configuring ports [21-4](#)
 - defined [20-6](#)
 - guidelines and restrictions [21-4](#)
 - crypto key generate rsa command [26-4](#)
-
- D**
- dCEF [4-8](#)
 - deactivation
 - verifying for SIPs [5-5](#)
 - verifying for SPAs [5-7](#)
 - debug atm bundle errors command [8-25](#)
 - debug atm bundle events command [8-25](#)
 - debug atm errors command [8-25](#)
 - debug atm events command [8-25](#)
 - debug atm oam command [8-25](#)
 - debug atm packet command [8-25](#)
 - debug crypto ace b2b command [30-27](#)
 - deny policy enhancements
 - configuration (example) [25-30](#)
 - configuring [25-21](#)
 - direct HTTP enrollment with CA servers
 - configuration (examples) [26-55](#)
 - configuring [26-16](#)
 - distinguished name-based crypto maps
 - configuration (example) [25-27](#)
 - configuring [25-13](#)
 - dMLFR (Multilink Frame Relay)
 - configuration guidelines
 - hardware-based [4-7](#)
 - software-based [4-7](#)
 - configuration tasks [4-8](#)
 - configuring [4-5](#)
 - overview [4-6](#)
 - dMLPPP (Multilink PPP)
 - configuration guidelines
 - hardware based [4-12](#)
 - software based [4-11](#)
 - configuration tasks [4-12](#)
 - LFI
 - configuring [4-14](#)
 - guidelines, hardware based [4-15](#)
 - guidelines, software based [4-14](#)
 - verifying [4-15](#)
 - with IPSec VPN SPA [21-21](#)
 - DMVPN (Dynamic Multipoint VPN)
 - configuring [27-2](#)
 - hub in configuration (example) [27-18](#)
 - spoke configuration (example) [27-20, 27-21](#)
 - dot1q encapsulation [10-8](#)
 - configuration (example) [10-43](#)
 - configuring [10-10](#)

DPD(Dead Peer Detection), configuring [24-17](#)

DSS (Destination sensitive services) [3-17](#)

dual priority queuing

configuring [4-48](#)

E

Easy VPN client, configuring [27-16](#)

Easy VPN remote RSA signature

configuring [27-17](#)

Easy VPN server

configuring [27-15](#)

enhanced [27-16](#)

router-side configuration (example) [27-22](#)

encapsulation

ARPA [10-8](#)

ATM [6-3](#)

configuring [10-8](#)

dot1q [10-8](#)

configuration (example) [10-43](#)

configuring [10-10](#)

SAP [10-8](#)

SNAP [10-7, 10-8](#)

encapsulation command [6-13](#)

encapsulation dot1q command [10-11](#)

encapsulation frame-relay mfr command [4-9](#)

encapsulation ppp command [4-14](#)

encrypted preshared key

configuration (example) [24-23](#)

encrypted preshared key, configuring [24-13](#)

ENTITY-MIB [3-20, 3-21](#)

EoMPLS [10-18](#)

configuration (example) [10-44](#)

ethernet oam command [10-24](#)

ethernet oam link-monitor frame-period threshold high command [10-29](#)

ethernet oam link-monitor frame-period threshold low command [10-29](#)

ethernet oam link-monitor frame-period window command [10-28](#)

ethernet oam link-monitor frame-seconds threshold high command [10-30](#)

ethernet oam link-monitor frame-seconds threshold low command [10-30](#)

ethernet oam link-monitor frame-seconds window command [10-29](#)

ethernet oam link-monitor frame threshold high command [10-28](#)

ethernet oam link-monitor frame threshold low command [10-28](#)

ethernet oam link-monitor frame window command [10-27](#)

ethernet oam link-monitor on command [10-26](#)

ethernet oam link-monitor receive-crc threshold high command [10-31](#)

ethernet oam link-monitor receive-crc threshold low command [10-31](#)

ethernet oam link-monitor receive-crc window command [10-30](#)

ethernet oam link-monitor supported command [10-25](#)

ethernet oam link-monitor symbol-period threshold high command [10-27](#)

ethernet oam link-monitor symbol-period threshold low command [10-27](#)

ethernet oam link-monitor symbol-period window command [10-27](#)

ethernet oam link-monitor transmit-crc threshold high command [10-32](#)

ethernet oam link-monitor transmit-crc threshold low command [10-32](#)

ethernet oam link-monitor transmit-crc window command [10-31](#)

ethernet oam remote-failure dying-gasp action error-disable-interface command [10-34](#)

F

far-end receive failure, see FERF

FEAC [18-7](#)

FERF [8-16](#)

filtering output, show and more commands [1-12](#)

flow control

support [10-18](#)
 verifying [10-18, 10-19](#)

FPD image packages

- cannot locate (example) [31-13](#)
- caution [31-4, 31-9](#)
- displaying default information [31-12](#)
- downloading [31-7 to 31-9](#)
- modifying the default path [31-9](#)
- overview [31-3](#)
- version number requirements [31-3](#)

FPD images

- displaying minimum and current versions [31-10](#)
- manually upgrading [31-7](#)
- troubleshooting upgrades [31-16 to 31-19](#)
- upgrade failure recovery (example) [31-17 to 31-18](#)
- upgrade scenarios [31-3](#)
- upgrading in production [31-5 to 31-6](#)
- verifying successful upgrade [31-18](#)
- verifying upgrade progress [31-12](#)

FPDs (field-programmable devices)

- description [31-1](#)

Frame Relay

- features, configuring on SIPs [4-5 to 4-17](#)

frame-relay intf-type dce command [4-8](#)

frame-relay multilink ack command [4-10](#)

frame-relay multilink bid command [4-8](#)

frame-relay multilink hello command [4-10](#)

frame-relay multilink lid command [4-10](#)

frame-relay multilink retry command [4-10](#)

FRF.16, See dMLFR

front door VRF (FVRF), defined [22-2](#)

FTP server, downloading FPD images to [31-7 to 31-9](#)

FVRF

- not supported on spoke [27-3](#)

FVRF, defined [22-2](#)

G

Generic Routing Encapsulation. See GRE tunneling.

giant packets [7-4](#)

global configuration mode, summary of [1-7](#)

GRE tunneling

- configuration (example) [21-40](#)
- configuring [21-22](#)
- takeover criteria [21-24](#)

H

hardware platforms

- See* platforms, supported

HCSE [8-16](#)

help command [1-8](#)

Hot Standby Router Protocol (HSRP)

- verifying configuration [10-6](#)

H-VPLS, configuring [10-21](#)

hw-module reset command [4-60](#)

hw-module slot subslot only command [22-34](#)

hw-module subslot command [10-40](#)

hw-module subslot shutdown command [5-6, 5-7, 5-8](#)

I

IEEE 802.1Q encapsulation [10-8](#)

- configuration (example) [10-43](#)
- configuring [10-10](#)

IF-MIB [3-21](#)

IKE policy

- troubleshooting [30-27](#)

inside port, configuring [21-7](#)

inside VRF (IVRF), defined [22-2](#)

interface

- basic configuration (example) [10-41](#)
- enabling [10-4](#)
- restarting [10-40](#)
- shutting down [10-40](#)
- verifying configuration [10-40 to 10-41](#)

interface address, specifying [10-4](#)

- interface configuration mode, summary of [1-7](#)
 - interface fastethernet command [10-2, 10-11](#)
 - interface gigabitethernet command [10-2, 10-11](#)
 - interface mfr command [4-8](#)
 - interface multilink command [4-13](#)
 - interface serial command [4-9, 4-14, 4-20](#)
 - interface status line
 - states, show interfaces serial command [19-3](#)
 - interface tengigabitethernet command [10-2, 10-11](#)
 - ip address command [4-13, 10-3, 10-11](#)
 - ip cef distributed command [4-8, 4-12](#)
 - IP multicast over a GRE tunnel
 - configuration (example) [21-44, 22-34](#)
 - configuring [21-26](#)
 - IP multicast over a VTI tunnel
 - configuration (example) [22-39](#)
 - IPSec anti-replay window size
 - configuring [25-5](#)
 - IPsec anti-replay window size
 - configuration (examples) [25-24](#)
 - IPsec manual keying [20-5, 21-7, 22-6](#)
 - IPsec NAT transparency, configuring [24-19](#)
 - IPsec preferred peer
 - configuration (examples) [25-26](#)
 - configuring [25-8](#)
 - IPsec prefragmentation
 - configuration (examples) [23-20](#)
 - IPsec security association (SA) idle timer
 - configuration (examples) [25-27](#)
 - configuring [25-12](#)
 - IPsec stateful failover
 - troubleshooting [30-25](#)
 - IPsec stateful failover using a blade failure group (BFG)
 - configuration (example) [28-37](#)
 - configuring [28-21](#)
 - IPsec stateful failover using HSRP and SSP
 - active chassis configuration (example) [28-29](#)
 - IPsec stateless failover using HSRP
 - active chassis configuration (example) [28-26](#)
 - configuring [28-3](#)
 - remote router configuration (example) [28-27, 28-30, 28-35](#)
 - IPsec stateless failover using HSRP and RRI, configuring [28-3](#)
 - IPsec VPN accounting
 - configuration (examples) [29-10](#)
 - configuring [29-5](#)
 - IPsec VPN monitoring
 - configuration (example) [29-11](#)
 - configuring [29-2](#)
 - IPSec VPN SPA
 - sequenced ACLs, configuring [25-21](#)
 - VPN running state, displaying [21-21](#)
 - IPsec VPN SPA
 - IPsec stateful failover using HSRP RRI and SSP, configuring [28-3](#)
 - IPsec stateless failover using HSRP RRI, configuring [28-3](#)
 - ISAKMP keyrings and peer filtering
 - configuration (example) [24-22](#)
 - configuring [24-4](#)
 - IVRF, defined [22-2](#)
-
- ## K
- keyboard shortcuts [1-6](#)
 - key rollover for certificate renewal
 - configuration (examples) [26-60](#)
 - configuring [26-31](#)
-
- ## L
- LAF [23-3](#)
 - LFI (Link Fragmentation and Interleaving)
 - configuring on SIPs [4-15](#)
 - over MLPPP, configuring [4-14 to 4-15](#)
 - lines
 - interface status
 - states, show interfaces serial command [19-3](#)

- serial
 - show interfaces serial command [19-4](#)
- local certificate storage location
 - configuration (example) [26-55](#)
- local certificate storage location, configuring [26-14](#)
- LOF [8-16](#)
- Look-Ahead Fragmentation. See LAF.
- loopback command [8-17](#)
- loopback diagnostic command [8-17, 8-19](#)
- loopback line command [8-21](#)
- loss of frame, see LOF

M

- MAC address
 - configuration (example) [10-42](#)
 - modifying [10-5](#)
 - verifying [10-5](#)
- Management Information Base (MIB)
 - downloading [6-16, 9-3, 12-6, 14-6](#)
 - supported on SPAs [9-3](#)
- manual certificate enrollment (TFTP and cut-and-paste)
 - configuration (examples) [26-57](#)
 - configuring [26-22](#)
- manual keying [20-5, 21-7, 22-6](#)
- match as command [3-17](#)
- match bgp-community command [3-18](#)
- match class-map command [3-17](#)
- match cos inner command [3-17](#)
- match discard-class command [3-17](#)
- match dscp command [3-14](#)
- match fr-dlci command [3-17](#)
- match input interface command [6-14](#)
- match input-interface command [3-17](#)
- match input vlan command [3-14, 3-17](#)
- match ip precedence command [3-14](#)
- match ip rtp command [3-17](#)
- match mac command [3-17](#)
- match mpls experimental command [3-14](#)
- match packet length command [3-17](#)
- match protocol command [3-17](#)
- match qos-group command [3-14, 3-17](#)
- match vlan command [3-14, 3-18](#)
- match vlan inner command [3-18](#)
- MBS [6-4](#)
- mGRE
 - enabling [27-3](#)
- MIB (Management Information Base)
 - on Cisco 7600 SIP-200 [3-20](#)
 - on Cisco 7600 SIP-400 [3-20](#)
- minimum burst size, see MBS
- MLFR (Multilink Frame Relay). See dMLFR.
- MLPPP. See dMLPPP.
- modes
 - See command modes
- modulus
 - of RSA key [26-4](#)
- MPB (Multipoint Bridging)
 - configuring [4-18](#)
 - on Cisco 7600 SIP-200 ATM SPAs [3-4](#)
 - on Cisco 7600 SIP-200 serial SPAs [3-4](#)
 - on Cisco 7600 SIP-400 [3-18](#)
- mpls l2 transport route command [3-17, 4-32](#)
- MPLS labels, and interface MTU size [10-7](#)
- mpls mtu command [10-7, 13-4](#)
- MPLSoGRE [10-12, 10-14](#)
- MPLSoGRE and mVPNogRE
 - configuration (example) [10-43](#)
- MTU (maximum transmission unit)
 - configuration (example) [10-42](#)
 - configuring [23-18](#)
 - default size [10-7](#)
 - interface MTU
 - additional overhead [10-7](#)
 - and MPLS labels [10-7](#)
 - configuration guidelines [10-7](#)
 - configuring [10-8](#)
 - description [10-6](#)

- verifying [10-8](#)
- IP MTU
 - description [10-6](#)
 - maximum size [10-7](#)
- MPLS MTU
 - description [10-6](#)
- tag MTU
 - description [10-6](#)
- types [10-6](#)
- mtu command [10-3, 10-8](#)
- Multicast over a GRE tunnel
 - configuration (example) [21-44, 22-34](#)
 - configuring [21-26](#)
- Multicast over a VTI tunnel
 - configuration (example) [22-39](#)
- Multilink Frame Relay. See dMLFR.
- multilink-group command [4-14](#)
- Multilink Point-to-Point Protocol (MLPPP). See dMLPPP.
- multiple RSA key pairs
 - configuration (example) [26-54](#)
 - configuring [26-3](#)
- multiple SPAs in a chassis
 - configuration (example) [28-24](#)
 - configuring [28-2](#)
- multipoint GRE
 - See mGRE [27-3](#)

N

- NAT keepalives
 - configuration (example) [24-24](#)
- negotiation auto command [10-10](#)
- no hw-module subslot shutdown command [5-7, 5-9](#)
- no negotiation auto command [10-9, 10-10](#)
- no power enable module command [5-4, 5-8](#)
- no shut command [10-4](#)
- no shutdown command [4-21](#)
- no upgrade fpd auto command [31-6](#)
- NVRAM (nonvolatile random-access memory) [10-39](#)

O

- OCS (Online Certificate Status Protocol)
 - configuration (example) [26-61](#)
 - configuring [26-38](#)
- OIR (online insertion and removal)
 - and shutting down or restarting interfaces [10-40](#)
 - for SIPs [2-1, 5-4](#)
 - for SPAs [2-3, 5-6, 8-26, 11-9, 19-18, 30-30](#)
 - for SSCs [2-2](#)
- OLD-CISCO-CHASSIS-MIB [3-20, 3-21](#)
- optics modules
 - qualified for SPAs (table) [2-6](#)
- OSMs, OC-12 ATM
 - bridging of RFC 1483 routed encapsulations [7-22](#)
 - overview [6-3](#)
- OUI in MAC address [6-11](#)
- outside port, configuring [21-7](#)
- oversubscription
 - Cisco 7600 SIP-400 [3-18, 5-3](#)

P

- packet flow, on Fast Ethernet or Gigabit Ethernet SPA [9-4](#)
- parameter command [26-18](#)
- PCR [6-4](#)
- peak cell rate, see PCR
- persistent self-signed certificates
 - configuration (examples) [26-63](#)
 - configuring [26-49](#)
- Per VLAN Spanning Tree (PVST) [6-11](#)
- PIM [21-26](#)
- ping command [8-16](#)
- PKI AAA authorization using the entire subject name
 - configuration (example) [26-62](#)
 - configuring [26-46](#)
- PKI query multiple servers during certificate revocation check

- configuration (example) [26-61](#)
- configuring [26-37](#)
- platforms, supported
 - release notes, identify using [1-13](#)
- power enable module command [5-5, 5-8](#)
- PPP (Point-to-Point Protocol)
 - with IPSec VPN SPA [21-21](#)
- ppp authentication chap command [4-14](#)
- ppp multilink command [4-14](#)
- ppp multilink fragment-delay command [4-13](#)
- ppp multilink interleave command [4-13, 4-14, 4-15](#)
- priority command [6-14](#)
- privileged EXEC mode, summary of [1-7](#)
- prompts, system [1-7](#)
- protected private key storage
 - configuration (example) [26-54](#)
 - configuring [26-5](#)
- PVST+ [6-11](#)
- PVST and PVST+ interoperability [6-11](#)
 - 802.1D [6-10](#)
 - common part convergence sublayer [6-11](#)
 - L2PT topologies [7-15](#)
 - line cards supported [6-11](#)
 - problem summarized [6-11](#)

Q

- QoS
 - configuration (examples) [25-28](#)
 - module, configuration (example) [25-28](#)
 - platform, configuration (example) [25-29](#)
- QoS (Quality of Service)
 - configuring on SIPs [4-33 to 4-60](#)
- QoS, configuring [25-15](#)
- query mode definition per trustpoint
 - configuration (example) [26-55](#)
 - configuring [26-11](#)
- query multiple servers during certificate revocation check
 - configuration (example) [26-61](#)

- configuring [26-37](#)
- question mark (?) command [1-8](#)

R

- RAI [8-16](#)
- release history
 - Gigabit Ethernet SPAs [9-1](#)
- release notes
 - See* platforms, supported
- remote alarm indication, *see* RAI
- Reverse Route Injection (RRI), configuring [25-3](#)
- RFC 1483, *Multiprotocol Encapsulation over ATM Adaptation Layer 5, Bridged and Routed* [3-8, 3-12](#)
- RFC 1483, *Multiprotocol Encapsulation over ATM Adaptation Layer 5, Multipoint Bridging* [3-4, 3-8, 3-18](#)
- RFC 1490, *Multiprotocol Interconnect over Frame Relay, Multipoint Bridging* [3-4, 3-8](#)
- RFC 1663, *PPP Reliable Transmission* [3-15](#)
- RFC 1889, *RTP*
 - A Transport Protocol for Real-Time Applications [4-4](#)
- RFC 3518, *Point-to-Point Protocol (PPP) Bridging Control Protocol (BCP)* [3-8, 3-12, 4-18](#)
- ROM monitor mode, summary of [1-7](#)
- routed port
 - configuration (example) [21-32](#)
 - configuring [21-11](#)
- RRI, configuring [25-3](#)
- RSA signature storage, configuring [27-17](#)
- running configuration, saving to NVRAM [10-39](#)
- Rx cell HCS error, *see* HCSE

S

- Safenet IPSec client support
 - configuration (example) [24-22](#)
 - configuring [24-4](#)
- SAP (Service Access Point) encapsulation [10-8](#)
- scalable EoMPLS [10-18](#)
- SCR [6-4](#)

- security associations
 - clearing [30-24](#)
- serial lines
 - troubleshooting
 - show interfaces serial command [19-4](#)
- set identity command [25-15](#)
- set mpls experimental command [4-32](#)
- SFP (small form-factor pluggable) optics
 - Cisco Systems qualification check [2-6](#)
 - qualified for SPAs (table) [2-6](#)
- shape adaptive command [6-15](#)
- shape average command [6-15](#)
- shape command [6-15](#)
- shape fecn-adapt command [6-15](#)
- shape peak command [6-15](#)
- show aps command [8-13](#)
- show aps group command [8-15](#)
- show atm class-link command [8-13](#)
- show atm ilmi-status [8-10](#)
- show atm ilmi-status command [8-11](#)
- show atm interface atm command [7-6, 8-7](#)
- show atm map command [8-11](#)
- show atm pvc command [7-8, 8-9](#)
- show atm pvc interface atm command [8-9](#)
- show atm svc interface atm command [8-10](#)
- show atm traffic command [8-12](#)
- show atm traffic shaping slot command [8-12](#)
- show atm vc command [8-8, 8-9, 8-10](#)
- show atm vc interface atm command [7-8](#)
- show atm vlan command [8-12](#)
- show atm vp command [8-8](#)
- show commands
 - for IPsec VPN SPA [30-6](#)
- show controllers atm command [6-15, 8-4, 8-5](#)
 - example [6-19](#)
- show controllers fastethernet command [10-19](#)
- show crypto ace redundancy [30-15](#)
- show crypto ace redundancy command [30-15](#)
- show crypto ca certificates [30-16](#)
- show crypto ca trustpoints command [30-17](#)
- show crypto engine accelerator statistic command [30-4](#)
- show crypto ipsec ha command [30-11](#)
- show crypto ipsec sa command [24-21, 30-9, 30-12](#)
- show crypto ipsec sa standby command [30-13](#)
- show crypto ipsec transform-set command [30-9](#)
- show crypto isakmp policy command [30-8](#)
- show crypto isakmp sa addr command [30-11](#)
- show crypto isakmp sa command [30-11](#)
- show crypto key mypublickey rsa command [30-15](#)
- show crypto key pubkey-chain rsa command [30-16](#)
- show crypto map command [30-9](#)
- show crypto redundancy linecard-group command [30-15](#)
- show crypto session [30-18](#)
- show crypto sockets command [30-18](#)
- show crypto vlan command [30-7, 30-8, 30-23](#)
- show diagbus command [3-21, 4-3, 6-18, 8-5, 30-3](#)
 - example [6-19](#)
- show ethernet oam discovery command [10-35](#)
- show ethernet oam statistics command [10-35](#)
- show ethernet oam status command [10-36](#)
- show ethernet oam summary command [10-36](#)
- show frame-relay multilink command [4-10](#)
- show history command [1-6](#)
- show hw-module slot command [4-3](#)
- show hw-module slot fpd command [30-6](#)
- show hw-module subslot command [4-4, 31-10](#)
- show hw-module subslot fpd command [8-3, 31-16](#)
- show hw-module subslot oir command [5-7](#)
- show idprom command [3-21, 3-22](#)
- show idprom module command [4-3, 4-4, 8-4](#)
- show interface atm command [8-6](#)
- show interface command [7-5](#)
- show interfaces atm command [7-4](#)
 - example [6-18](#)
- show interfaces command [6-18, 9-4](#)
- show interfaces fastethernet command [9-5](#)
- show interfaces gigabit ethernet command [10-8](#)
- show interfaces gigabitethernet command [10-5](#)

- show interfaces serial command
 - troubleshooting serial lines [19-4](#)
- show interfaces switchport command [4-22](#)
- show interfaces trunk command [4-22, 30-7](#)
- show interfaces tunnel [30-19](#)
- show ip interface command [5-7, 7-5, 8-7](#)
- show ip mroute command [30-23](#)
- show ip nhrp command [30-18](#)
- show module command [3-22, 4-3, 5-5](#)
- show mpls interface command [7-5](#)
- show ppp multilink command [4-15, 6-15](#)
- show redundancy linecard-group command [30-15](#)
- show running-config command [31-8](#)
- show sip-disk command [4-3](#)
- show ssp client command [30-14](#)
- show ssp packet command [30-14](#)
- show ssp peers command [30-14](#)
- show ssp redundancy command [30-14](#)
- show standby command [10-6](#)
- show upgrade package default command [31-12](#)
- show upgrade progress command [31-12](#)
- show version command [8-3](#)
- show vlan id command [8-13](#)
- show vlans command [10-11](#)
- shutdown command [4-20, 10-40](#)
- Simple Symmetric Transmission Protocol (SSTP) [6-11](#)
- single-SPA mode
 - configuring [21-27](#)
- SIP (SPA interface processor)
 - activation (example) [5-8](#)
 - blank filler plates [2-1](#)
 - chassis slot installation (figure) [4-3](#)
 - deactivating [5-4](#)
 - deactivation (example) [5-8](#)
 - definition [2-1](#)
 - features supported [3-3](#)
 - general characteristics [2-1](#)
 - hardware type, displaying [3-21 to 3-22](#)
 - reactivating [5-4](#)
 - release history [3-1](#)
 - resetting [4-60](#)
 - SPA compatibility (table) [2-3, 2-4, 2-5, 20-14](#)
 - subslots
 - description [2-1](#)
 - numbering [4-4](#)
 - specifying location in CLI [4-4](#)
 - supervisor engine support [4-2](#)
- SNAP (Subnetwork Access Protocol) encapsulation [10-7, 10-8](#)
- SONET MIB [3-21](#)
- source interface selection for outgoing traffic with certificate authority
 - configuration (example) [26-63](#)
 - configuring [26-48](#)
- SPA (shared port adapter)
 - activation (example) [5-8](#)
 - chassis slot orientation (figure) [2-3](#)
 - deactivating [5-6](#)
 - deactivation (example) [5-8](#)
 - definition [2-2](#)
 - double-height description [2-2](#)
 - FPD image packages
 - overview [31-3](#)
 - heights supported
 - (figure) [2-2](#)
 - description [2-2](#)
 - interfaces [2-3](#)
 - optics compatibility (table) [2-6](#)
 - reactivating [5-7](#)
 - single-height description [2-2](#)
 - SIP compatibility (table) [2-3, 2-4, 2-5, 20-14](#)
 - subslot numbering (figure) [4-3](#)
- SPA architecture
 - description [9-4](#)
 - POS SPA description [12-6 to 12-10](#)
- SPA hardware type, displaying [9-4](#)
- SPAN [29-4](#)
- Spanning-Tree Protocol (STP) [6-10](#)

SSC (SPA services card)

blank filler plates [2-2](#)definition [2-2](#)general characteristics [2-2](#)

states

interface status line, show interfaces serial command [19-3](#)subinterfaces, configuring [10-10 to 10-11](#)

subslots

description [2-1](#)numbering [4-4](#)specifying location in CLI [4-4](#)

supervisor engines

supported by SIPs [4-2](#)

sustained cell rate, see SCR

switchport command [4-20](#)switchport trunk allowed vlan command [4-21](#)

system error messages

Cisco 7600 SSC-400 [30-2](#)IPSec VPN SPA [30-2](#)**T**Tab key, command completion [1-8](#)TFTP server, downloading FPD images to [31-7 to 31-9](#)

transform sets

troubleshooting [30-27](#)

trunk port

configuration (example) [21-34](#)configuring [21-15](#)

trustpoint CA

configuration (example) [26-54](#)configuring [26-8](#)**U**UBR [6-4](#)

unspecified bit rate, see UBR

upgrade fpd auto command [31-6, 31-8, 31-13](#)upgrade fpd path command [31-7, 31-9](#)upgrade hw-module subslot command [31-7](#)user EXEC mode, summary of [1-7](#)**V**

variable bit rate. See VBR

VBR

non-real-time (VB-nrt) [6-4](#)real-time (VBR-rt) [6-5](#)VFI [4-24](#)

Virtual Tunnel Interface. See VTI.

VLANs (virtual LANs)

configuration (example) [10-43](#)configuring on a subinterface [10-10](#)verifying configuration [10-11](#)

VPLS

configuring [4-23](#)Multiple VCs per Spoke [4-24](#)VPN sessions, monitoring and managing [29-2](#)

VRF-aware IPsec. See VRF mode.

VRF instance, defined [22-2](#)VRF-lite [20-12](#)

VRF mode

configuration (examples) [22-22](#)configuring VTI [22-16](#)defined [22-1](#)front door VRF (FVRF) [22-2](#)guidelines and restrictions [22-4](#)inside VRF (IVRF) [22-2](#)

with chassis-to-chassis stateless failover

configuring [28-18](#)without tunnel protection [22-6](#)with tunnel protection [22-12](#)

VTI

configuring in VRF mode [22-16](#)defined [22-16](#)

W

WAN interfaces

- ATM configuration (example) [21-37](#)

- configuring [21-20](#)

- POS configuration (example) [21-38](#)

- serial port configuration (example) [21-39](#)

X

- xconnect command [3-17, 4-32](#)

