

send-lifetime

To set the time period during which an authentication key on a key chain is valid to be sent, use the **send-lifetime** command in key chain key configuration mode. To revert to the default value, use the **no** form of this command.

send-lifetime *start-time* { **infinite** | *end-time* | **duration** *seconds* }

no send-lifetime [*start-time* { **infinite** | *end-time* | **duration** *seconds* }]

Syntax Description		
	<i>start-time</i>	Beginning time that the key specified by the key command is valid to be sent. The syntax can be either of the following: <i>hh:mm:ss Month date year</i> <i>hh:mm:ss date Month year</i> <i>hh</i> —hours <i>mm</i> —minutes <i>ss</i> —seconds <i>Month</i> —first three letters of the month <i>date</i> —date (1-31) <i>year</i> —year (four digits) The default start time and the earliest acceptable date is January 1, 1993.
	infinite	Key is valid to be sent from the <i>start-time</i> value on.
	<i>end-time</i>	Key is valid to be sent from the <i>start-time</i> value until the <i>end-time</i> value. The syntax is the same as that for the <i>start-time</i> value. The <i>end-time</i> value must be after the <i>start-time</i> value. The default end time is an infinite time period.
	duration <i>seconds</i>	Length of time (in seconds) that the key is valid to be sent.

Defaults Forever (the starting time is January 1, 1993, and the ending time is infinite)

Command Modes Key chain key configuration

Command History	Release	Modification
	11.1	This command was introduced.

Usage Guidelines Specify a *start-time* value and one of the following values: **infinite**, *end-time*, or **duration** *seconds*.

We recommend running Network Time Protocol (NTP) or some other time synchronization method if you intend to set lifetimes on keys.

If the last key expires, authentication will continue and an error message will be generated. To disable authentication, you must manually delete the last valid key.

Examples

The following example configures a key chain called trees. The key named chestnut will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named birch will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or discrepancies in the set time of the router. There is a 30-minute leeway on each side to handle time differences.

```
interface ethernet 0
 ip rip authentication key-chain trees
 ip rip authentication mode md5
!
router rip
 network 172.19.0.0
 version 2
!
key chain trees
 key 1
 key-string chestnut
 accept-lifetime 13:30:00 Jan 25 1996 duration 7200
 send-lifetime 14:00:00 Jan 25 1996 duration 3600
 key 2
 key-string birch
 accept-lifetime 14:30:00 Jan 25 1996 duration 7200
 send-lifetime 15:00:00 Jan 25 1996 duration 3600
```

Related Commands

Command	Description
accept-lifetime	Sets the time period during which the authentication key on a key chain is received as valid.
key	Identifies an authentication key on a key chain.
key chain	Enables authentication for routing protocols.
key-string (authentication)	Specifies the authentication string for a key.
show key chain	Displays authentication key information.

set as-path

To modify an autonomous system path for BGP routes, use the **set as-path** command in route-map configuration mode. To not modify the autonomous system path, use the **no** form of this command.

```
set as-path {tag | prepend as-path-string}
```

```
no set as-path {tag | prepend as-path-string}
```

Syntax Description	tag	Converts the tag of a route into an autonomous system path. Applies only when redistributing routes into BGP.
	prepend <i>as-path-string</i>	Appends the string following the keyword prepend to the autonomous system path of the route that is matched by the route map. Applies to inbound and outbound BGP route maps.

Defaults Autonomous system path is not modified.

Command Modes Route-map configuration

Command History	Release	Modification
	11.0	This command was introduced.

Usage Guidelines The only global BGP metric available to influence the best path selection is the autonomous system path length. By varying the length of the autonomous system path, a BGP speaker can influence the best path selection by a peer further away.

By allowing you to convert the tag into an autonomous system path, the **set as-path tag** variation of this command modifies the autonomous system length. The **set as-path prepend** variation allows you to “prepend” an arbitrary autonomous system path string to BGP routes. Usually the local autonomous system number is prepended multiple times, increasing the autonomous system path length.

Examples The following example converts the tag of a redistributed route into an autonomous system path:

```
route-map set-as-path-from-tag
  set as-path tag
!
router bgp 100
  redistribute ospf 109 route-map set-as-path-from-tag
```

The following example prepends 100 100 100 to all the routes advertised to 10.108.1.1:

```
route-map set-as-path
  match as-path 1
  set as-path prepend 100 100 100
!
router bgp 100
```

```
neighbor 10.108.1.1 route-map set-as-path out
```

Related Commands	Command	Description
	match as-path	Matches a BGP autonomous system path access list.
	match community	Matches a BGP community.
	match interface (IP)	Distributes routes that have their next hop out one of the interfaces specified.
	match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
	match ip next-hop	Redistributes any routes that have a next hop router address passed by one of the access lists specified.
	match ip route-source	Redistributes routes that have been advertised by routers and access servers at the address specified by the access lists.
	match metric (IP)	Redistributes routes with the metric specified.
	match route-type (IP)	Redistributes routes of the specified type.
	match tag	Redistributes routes in the routing table that match the specified tags.
	route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
	set automatic-tag	Automatically computes the tag value.
	set community	Sets the BGP communities attribute.
	set level (IP)	Indicates where to import routes.
	set local-preference	Specifies a preference value for the autonomous system path.
	set metric (BGP, OSPF, RIP)	Sets the metric value for a routing protocol.
	set metric-type	Sets the metric type for the destination routing protocol.
	set next-hop	Specifies the address of the next hop.
	set origin (BGP)	Sets the BGP origin code.
	set tag (IP)	Sets a tag value of the destination routing protocol.
	set weight	Specifies the BGP weight for the routing table.

set automatic-tag

To automatically compute the tag value, use the **set automatic-tag** command in route-map configuration mode. To disable this function, use the **no** form of this command.

set automatic-tag

no set automatic-tag

Syntax Description

This command has no arguments or keywords.

Defaults

This command is disabled by default.

Command Modes

Route-map configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

You must have a match clause (even if it points to a “permit everything” list) if you want to set tags.

Use the **route-map** global configuration command, and the **match** and **set** route-map configuration commands, to define the conditions for redistributing routes from one routing protocol into another. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which redistribution is allowed for the current **route-map** command. The **set** commands specify the *set actions*—the particular redistribution actions to perform if the criteria enforced by the **match** commands are met. The **no route-map** command deletes the route map.

The **set** route-map configuration commands specify the redistribution *set actions* to be performed when all the match criteria of a route map are met. When all match criteria are met, all set actions are performed.

Examples

The following example configures the Cisco IOS software to automatically compute the tag value for the Border Gateway Protocol (BGP) learned routes:

```
route-map tag
  match as path 10
  set automatic-tag
!
router bgp 100
  table-map tag
```

Related Commands	Command	Description
	match as-path	Matches a BGP autonomous system path access list.
	match community	Matches a BGP community.
	match interface (IP)	Distributes any routes that have their next hop out one of the interfaces specified.
	match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
	match ip next-hop	Redistributes any routes that have a next hop router address passed by one of the access lists specified.
	match ip route-source	Redistributes routes that have been advertised by routers and access servers at the address specified by the access lists.
	match metric (IP)	Redistributes routes with the metric specified.
	match route-type (IP)	Redistributes routes of the specified type.
	match tag	Redistributes routes in the routing table that match the specified tags.
	route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
	set as-path	Modifies an autonomous system path for BGP routes.
	set community	Sets the BGP communities attribute.
	set level (IP)	Indicates where to import routes.
	set local-preference	Specifies a preference value for the autonomous system path.
	set metric (BGP, OSPF, RIP)	Sets the metric value for a routing protocol.
	set metric-type	Sets the metric type for the destination routing protocol.
	set next-hop	Specifies the address of the next hop.
	set tag (IP)	Sets a tag value of the destination routing protocol.
	set weight	Specifies the BGP weight for the routing table.
	show route-map	Displays all route maps configured or only the one specified.

set comm-list delete

To remove communities from the community0 attribute of an inbound or outbound update, use the **set comm-list delete command** in route-map configuration mode. To negate a previous **set comm-list delete** command, use the **no** form of this command.

set comm-list *community-list-number* | *community-list-name* **delete**

no set comm-list *community-list-number* | *community-list-name* **delete**

Syntax Description

<i>community-list-number</i>	A standard or expanded community list number. The range of standard community list numbers is from 1 to 99. The range of expanded community list number is from 100 to 500.
<i>community-list-name</i>	A standard or expanded community list name.

Defaults

No communities are removed.

Command Modes

Route-map configuration

Command History

Release	Modification
12.0	This command was introduced.
12.0(16)ST	Named community list support was integrated into Cisco IOS Release 12.0(16)ST.
12.1(9)E	Named community list support was integrated into Cisco IOS Release 12.1(9)E.
12.2(8)T	Named community list support was integrated into Cisco IOS Release 12.2(8)T.
12.0(22)S	The maximum number of expanded community lists was increased from 199 to 500 in Cisco IOS Release 12.0(22)S.
12.2(15)T	The maximum number of expanded community lists was increased from 199 to 500 in Cisco IOS Release 12.2(15)T.

Usage Guidelines

This **set** route-map configuration command removes communities from the community attribute of an inbound or outbound update using a route map to filter and determine the communities to be deleted. Depending upon whether the route map is applied to the inbound or outbound update for a neighbor, each community that passes the route map **permit** clause and matches the given community list will be removed from the community attribute being received from or sent to the Border Gateway Protocol (BGP) neighbor.

Each entry of a standard community list should list only one community when used with the **set comm-list delete** command. For example, in order to be able to delete communities 10:10 and 10:20, you must use the following format to create the entries:

```
ip community-list 500 permit 10:10
ip community-list 500 permit 10:20
```

The following format for a community list entry, while acceptable otherwise, does not work with the **set comm-list delete** command:

```
config ip community-list 500 permit 10:10 10:20
```

When both the **set community** *community-number* and **set comm-list delete** commands are configured in the same sequence of a route map attribute, the deletion operation (**set comm-list delete**) is performed before the set operation (**set community** *community-number*).

Examples

In the following example, the communities 100:10 and 100:20 (if present) will be deleted from updates received from 172.16.233.33. Also, except for 100:50, all communities beginning with 100: will be deleted from updates sent to 172.16.233.33.

```
router bgp 100
 neighbor 172.16.233.33 remote-as 120
 neighbor 172.16.233.33 route-map ROUTEMAPIN in
 neighbor 172.16.233.33 route-map ROUTEMAPOUT out
!
ip community-list 500 permit 100:10
ip community-list 500 permit 100:20
!
ip community-list 120 deny 100:50
ip community-list 120 permit 100:.*
!
route-map ROUTEMAPIN permit 10
 set comm-list 500 delete
!
route-map ROUTEMAPOUT permit 10
 set comm-list 120 delete
```

Related Commands

Command	Description
set community	Sets the BGP communities attribute.

set community

To set the BGP communities attribute, use the **set community** route map configuration command. To delete the entry, use the **no** form of this command.

```
set community { community-number [additive] [well-known-community] | none }
```

```
no set community { community-number [additive] [well-known-community] }
```

Syntax Description	
<i>community-number</i>	Specifies that community number. Valid values are from 1 to 4294967200, no-export , or no-advertise .
additive	(Optional) Adds the community to the already existing communities.
<i>well-known-community</i>	(Optional) Well know communities can be specified by using the following keywords: <ul style="list-style-type: none"> • internet • local-as • no-advertise • no-export
none	(Optional) Removes the community attribute from the prefixes that pass the route map.

Defaults No BGP communities attributes exist.

Command Modes Route-map configuration

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines You must have a match clause (even if it points to a “permit everything” list) if you want to set tags. Use the **route-map** global configuration command, and the **match** and **set** route map configuration commands, to define the conditions for redistributing routes from one routing protocol into another. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which redistribution is allowed for the current **route-map** command. The **set** commands specify the *set actions*—the particular redistribution actions to perform if the criteria enforced by the **match** commands are met. The **no route-map** command deletes the route map.

The **set** route map configuration commands specify the redistribution *set actions* to be performed when all of the match criteria of a route map are met. When all match criteria are met, all set actions are performed.

Examples

In the following example, routes that pass the autonomous system path access list 1 have the community set to 109. Routes that pass the autonomous system path access list 2 have the community set to no-export (these routes will not be advertised to any external BGP [eBGP] peers).

```
route-map set_community 10 permit
  match as-path 1
  set community 109
```

```
route-map set_community 20 permit
  match as-path 2
  set community no-export
```

In the following similar example, routes that pass the autonomous system path access list 1 have the community set to 109. Routes that pass the autonomous system path access list 2 have the community set to local-as (the router will not advertise this route to peers outside the local autonomous system).

```
route-map set_community 10 permit
  match as-path 1
  set community 109
```

```
route-map set_community 20 permit
  match as-path 2
  set community local-as
```

Related Commands

Command	Description
ip community-list	Creates a community list for BGP and control access to it.
match community	Matches a BGP community.
route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
set comm-list delete	Removes communities from the community attribute of an inbound or outbound update.
show ip bgp community	Displays routes that belong to specified BGP communities.

set dampening

To set the BGP route dampening factors, use the **set dampening** route map configuration command. To disable this function, use the **no** form of this command.

set dampening *half-life reuse suppress max-suppress-time*

no set dampening

Syntax Description		
<i>half-life</i>		Time (in minutes) after which a penalty is decreased. Once the route has been assigned a penalty, the penalty is decreased by half after the half life period (which is 15 minutes by default). The process of reducing the penalty happens every 5 seconds. The range of the half life period is from 1 to 45 minutes. The default is 15 minutes.
<i>reuse</i>		Unsuppresses the route if the penalty for a flapping route decreases enough to fall below this value. The process of unsuppressing routes occurs at 10-second increments. The range of the reuse value is from 1 to 20000; the default is 750.
<i>suppress</i>		Suppresses a route when its penalty exceeds this limit. The range is from 1 to 20000; the default is 2000.
<i>max-suppress-time</i>		Maximum time (in minutes) a route can be suppressed. The range is from 1 to 20000; the default is four times the <i>half-life</i> value. If the <i>half-life</i> value is allowed to default, the maximum suppress time defaults to 60 minutes.

Defaults This command is disabled by default.

Command Modes Route-map configuration

Command History	Release	Modification
	11.0	This command was introduced.

Usage Guidelines Use the **route-map** global configuration command, and the **match** and **set** route-map configuration commands, to define the conditions for redistributing routes from one routing protocol into another. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which redistribution is allowed for the current **route-map** command. The **set** commands specify the *set actions*—the particular redistribution actions to perform if the criteria enforced by the **match** commands are met. The **no route-map** command deletes the route map.

When a BGP peer is reset, the route is withdrawn and the flap statistics cleared. In this instance, the withdrawal does not incur a penalty even though route flap dampening is enabled.

Examples

The following example sets the half life to 30 minutes, the reuse value to 1500, the suppress value to 10000; and the maximum suppress time to 120 minutes:

```
route-map tag
  match as-path 10
  set dampening 30 1500 10000 120
!
router bgp 100
  neighbor 172.16.233.52 route-map tag in
```

Related Commands

Command	Description
match as-path	Matches a BGP autonomous system path access list.
match community	Matches a BGP community.
match interface (IP)	Distributes routes that have their next hop out one of the interfaces specified.
match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
match ip next-hop	Redistributes any routes that have a next hop router address passed by one of the access lists specified.
match ip route-source	Redistributes routes that have been advertised by routers and access servers at the address specified by the access lists.
match metric (IP)	Redistributes routes with the metric specified.
match route-type (IP)	Redistributes routes of the specified type.
match tag	Redistributes routes in the routing table that match the specified tags.
route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
set automatic-tag	Automatically computes the tag value.
set community	Sets the BGP communities attribute.
set ip next-hop	Specifies the address of the next hop.
set level (IP)	Indicates where to import routes.
set local-preference	Specifies a preference value for the autonomous system path.
set metric (BGP, OSPF, RIP)	Sets the metric value for a routing protocol.
set metric-type	Sets the metric type for the destination routing protocol.
set origin (BGP)	Sets the BGP origin code.
set tag (IP)	Sets the value of the destination routing protocol.
set weight	Specifies the BGP weight for the routing table.
show route-map	Displays all route maps configured or only the one specified.

set default interface

To indicate where to output packets that pass a match clause of a route map for policy routing and have no explicit route to the destination, use the **set default interface** command in route-map configuration mode. To delete an entry, use the **no** form of this command.

```
set default interface type number [...type number]
```

```
no set default interface type number [...type number]
```

Syntax Description

<i>type</i>	Interface type, used with the interface number, to which packets are output.
<i>number</i>	Interface number, used with the interface type, to which packets are output.

Defaults

This command is disabled by default.

Command Modes

Route-map configuration

Command History

Release	Modification
11.0	This command was introduced.
12.3(7)T	This command was updated for use in configuring IPv6 policy-based routing (PBR).

Usage Guidelines

An ellipsis (...) in the command syntax indicates that your command input can include multiple values for the *type* and *number* arguments.

Use this command to provide certain users a different default route. If the Cisco IOS software has no explicit route for the destination, then it routes the packet to this interface. The first interface specified with the **set default interface** command that is up is used. The optionally specified interfaces are tried in turn.

Use the **ip policy route-map** interface configuration command, the **route-map** global configuration command, and the **match** and **set** route-map configuration commands to define the conditions for policy routing packets. The **ip policy route-map** command identifies a route map by name. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which policy routing occurs. The **set** commands specify the *set actions*—the particular routing actions to perform if the criteria enforced by the **match** commands are met.

In PBR for IPv6, use the **ipv6 policy route-map** or **ipv6 local policy route-map** command with match and set route map configuration commands to define conditions for policy routing packets.

The set clauses can be used in conjunction with one another. They are evaluated in the following order:

1. **set ip next-hop**
2. **set interface**
3. **set ip default next-hop**

4. set default interface

Examples

In the following example, packets that have a Level 3 length of 3 to 50 bytes and for which the software has no explicit route to the destination are output to Ethernet interface 0:

```
interface serial 0
 ip policy route-map brighton
!
route-map brighton
 match length 3 50
 set default interface ethernet 0
```

Related Commands

Command	Description
ip policy route-map	Identifies a route map to use for policy routing on an interface.
ipv6 local policy route-map	Identifies a route map to use for local IPv6 PBR.
ipv6 policy route-map	Configures IPv6 PBR on an interface.
match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
match ipv6 address	Specifies an IPv6 access list to use to match packets for PBR for IPv6.
match length	Bases policy routing on the Level 3 length of a packet.
route-map	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
set default interface	Indicates where to output packets that pass a match clause of a route map for policy routing and have no explicit route to the destination.
set interface	Indicates where to output packets that pass a match clause of route map for policy routing.
set ip default next-hop verify-availability	Indicates where to output packets that pass a match clause of a route map for policy routing and for which the Cisco IOS software has no explicit route to a destination.
set ipv6 default next-hop	Specifies an IPv6 default next hop to which matching packets will be forwarded.
set ip next-hop	Indicates where to output packets that pass a match clause of a route map for policy routing.
set ipv6 next-hop (PBR)	Indicates where to output IPv6 packets that pass a match clause of a route map for policy routing.
set ipv6 precedence	Sets the precedence value in the IPv6 packet header.

set extcommunity

To set Border Gateway Protocol (BGP) extended community attributes, use the **set extcommunity** command in route-map configuration mode. To delete the entry, use the **no** form of this command.

```
set extcommunity {rt extended-community-value [additive] | soo extended-community-value/}
```

```
no set extcommunity {rt extended-community-value [additive] | soo extended-community-value/}
```

Syntax Description

rt	Specifies the route target (RT) extended community attribute.
soo	Specifies the site of origin (SOO) extended community attribute.
extended-community-value	Specifies the value to be set. The value can be one of the following combinations: <ul style="list-style-type: none"> autonomous-system-number:network-number ip-address:network-number <p>The colon is used to separate the autonomous system number and network number or IP address and network number.</p>
additive	(Optional) Adds a route target to the existing route target list without replacing any existing route targets.

Defaults

Specifying new route targets with the **rt** keyword replaces existing route targets by default, unless the **additive** keyword is used. The use of the **additive** keyword adds the new route target to the existing route target list but does not replace any existing route targets.

Command Modes

Route-map configuration

Command History

Release	Modification
12.1	This command was introduced.

Usage Guidelines

Extended community attributes are used to configure, filter, and identify routes for virtual routing and forwarding instances (VRFs) and Multiprotocol Label Switching (MPLS) Virtual Private Networks (VPNs).

The **set extcommunity** command is used to configure set clauses that use extended community attributes in route maps. All of the standard rules of match and set clauses apply to the configuration of extended community attributes.

The route target (RT) extended community attribute is configured with the **rt** keyword. This attribute is used to identify a set of sites and VRFs that may receive routes that are tagged with the configured route target. Configuring the route target extended attribute with a route allows that route to be placed in the per-site forwarding tables that are used for routing traffic that is received from corresponding sites.

The site of origin (SOO) extended community attribute is configured with the **soo** keyword. This attribute uniquely identifies the site from which the Provider Edge (PE) router learned the route. All routes learned from a particular site must be assigned the same SOO extended community attribute, whether a site is connected to a single PE router or multiple PE routers. Configuring this attribute prevents routing loops from occurring when a site is multihomed. The SOO extended community attribute is configured on the interface and is propagated into BGP through redistribution. The SOO can be applied to routes that are learned from VRFs. The SOO should not be configured for stub sites or sites that are not multihomed.

Examples

The following example sets the route target to extended community attribute 100:2 for routes that are permitted by the route map:

```
Router(config)# access-list 2 permit 192.168.78.0 255.255.255.0
Router(config)# route-map MAP_NAME permit 10
Router(config-route-map)# match ip-address 2
Router(config-route-map)# set extcommunity rt 100:2
```

The following example sets the route target to extended community attribute 100:3 for routes that are permitted by the route map. The use of the **additive** keyword adds route target 100:3 to the existing route target list but does not replace any existing route targets.

```
Router(config)# access-list 3 permit 192.168.79.0 255.255.255.0
Router(config)# route-map MAP_NAME permit 10
Router(config-route-map)# match ip-address 3
Router(config-route-map)# set extcommunity rt 100:3 additive
```



Note

Configuring route targets with the **set extcommunity** command will replace existing route targets, unless the **additive** keyword is used.

The following example sets the site of origin to extended community attribute 100:4 for routes that are permitted by the route map:

```
Router(config)# access-list 4 permit 192.168.80.0 255.255.255.0
Router(config)# route-map MAP_NAME permit 10
Router(config-route-map)# match ip-address 4
Router(config-route-map)# set extcommunity soo 100:4
```

Related Commands

Command	Description
ip extcommunity-list	Creates an extended community list and controls access to it.
match extcommunity	Matches a BGP VPN extended community list.
route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
route-target	Creates a route target extended community for a VRF.
show ip extcommunity-list	Displays routes that are permitted by the extended community list.
show route-map	Displays all route maps configured or only the one specified.

set extcommunity cost

To create a set clause to apply the cost community attribute to routes that pass through a route map, use the **set extcommunity cost** command in route-map configuration mode. To delete the cost community set clause, use the **no** form of this command.

set extcommunity cost [**igp**] *community-id cost-value*

no set extcommunity cost [**igp**] *community-id cost-value*

Syntax Description

igp	The IGP point of insertion (POI). The configuration of this keyword forces the cost community to be evaluated after the IGP distance to the next hop has been compared.
<i>community-id</i>	The ID for the configured extended community. The range is from 0 to 255.
<i>cost-value</i>	The configured cost that is set for matching paths in the route map. The range is from 0 to 4294967295.

Defaults

- The default cost value is applied to routes that are not configured with the cost community attribute when cost community filtering is enabled. The default *cost-value* is half of the maximum value (4294967295) or 2147483647.
- The IGP POI is applied by default a POI is not specified.

Command Modes

Route-map configuration

Command History

Release	Modification
12.0(24)S	This command was introduced into Cisco IOS Release 12.0(24)S.
12.3(2)T	This command was integrated.
12.2(18)S	This command was integrated.
12.0(27)S	<ul style="list-style-type: none"> Support for mixed EIGRP MPLS VPN network topologies that contain back door routes was introduced into Cisco IOS Release 12.0(27)S.
12.3(8)T	<ul style="list-style-type: none"> Support for mixed EIGRP MPLS VPN network topologies that contain back door routes was introduced into Cisco IOS Release 12.3(8)T.
12.2(25)S	<ul style="list-style-type: none"> Support for mixed EIGRP MPLS VPN network topologies that contain back door routes was introduced into Cisco IOS Release 12.2(25)S.

Usage Guidelines

The cost community attribute is applied to internal routes by configuring the **set extcommunity cost** command in a route map. The cost community set clause is configured with a cost community ID number (0-255) and a cost community number value (0-4294967295). The path with the lowest cost community number is preferred. In the case where two paths have been configured with the same cost community value, the path selection process will then prefer the path with the lower community ID.

The BGP Cost Community feature can be configured only within the same autonomous-system or confederation. The cost community is a non-transitive extended community. The cost community is passed to internal BGP (iBGP) and confederation peers only and is not passed to external BGP (eBGP) peers. The cost community allows you to customize the local preference and best path selection process for specific paths. The cost extended community attribute is propagated to iBGP peers when extended community exchange is enabled with the **neighbor send-community** command.

The following commands can be used to apply the route map with the cost community set clause:

- **aggregate-address**
- **neighbor default-originate route-map {in | out}**
- **neighbor route-map**
- **network route-map**
- **redistribute route-map**

Multiple cost community set clauses may be configured with the **set extcommunity cost** command in a single route map block or sequence. However, each set clause must be configured with a different ID value for each point of insertion (POI).

Aggregate routes and multipaths are supported by the BGP Cost Community feature. The cost community attribute can be applied to either type of route. The cost community attribute is passed to the aggregate or multipath route from component routes that carry the cost community attribute. Only unique IDs are passed, and only the highest cost of any individual component route will be applied to the aggregate on a per-ID basis. If multiple component routes contain the same ID, the highest configured cost is applied to the route. If one or more component routes does not carry the cost community attribute or if the component routes are configured with different IDs, then the default value (2147483647) will be advertised for the aggregate or multipath route.



Note

The BGP cost community attribute must be supported on all routers in an autonomous system or confederation before cost community filtering is configured. The cost community should be applied consistently throughout the local autonomous system or confederation to avoid potential routing loops.

Support for EIGRP MPLS VPN Back Door Links

The “pre-bestpath” point of insertion (POI) has been introduced in the BGP Cost Community feature to support mixed EIGRP VPN network topologies that contain VPN and backdoor links. This POI is applied automatically to EIGRP routes that are redistributed into BGP. The “pre-best path” POI carries the EIGRP route type and metric. This POI influences the best path calculation process by influencing BGP to consider this POI before any other comparison step. No configuration is required. This feature is enabled automatically for EIGRP VPN sites when a supporting is installed to a PE, CE, or back door router.

Examples

The following example configuration shows the configuration of the **set extcommunity cost** command. The following example applies the cost community ID of 1 and cost community value of 100 to routes that are permitted by the route map. This configuration will cause the best path selection process to prefer this route over other equal cost paths that were not permitted by this route map sequence.

```
Router(config)# router bgp 50000
Router(config-router)# neighbor 10.0.0.1 remote-as 50000
Router(config-router)# neighbor 10.0.0.1 update-source Loopback 0
Router(config-router)# address-family ipv4
Router(config-router-af)# neighbor 10.0.0.1 activate
Router(config-router-af)# neighbor 10.0.0.1 route-map COST1 in
```

```

Router(config-router-af)# neighbor 10.0.0.1 send-community both
Router(config-router-af)# exit
Router(config)# route-map COST1 permit 10
Router(config-route-map)# match ip-address 1
Router(config-route-map)# set extcommunity cost 1 100

```

Related Commands

Command	Description
aggregate-address	Creates an aggregate entry in a BGP or multicast BGP database.
bgp bestpath cost-community ignore	Configures a router that is running BGP to not evaluate the cost community attribute during the best path selection process.
neighbor default-originate	Allows a BGP speaker (the local router) to send the default route 0.0.0.0 to a neighbor for use as a default route.
neighbor route-map	Applies a route map to incoming or outgoing routes.
network (BGP and multiprotocol BGP)	Specifies the networks to be advertised by the BGP and multiprotocol BGP routing processes.
redistribute (IP)	Redistributes routes from one routing domain into another routing domain.
show ip bgp	Displays entries in the BGP routing table.
show route-map	Displays all route maps configured or only the one specified.

set interface

To indicate where to output packets that pass a match clause of a route map for policy routing, use the **set interface** command in route-map configuration mode. To delete an entry, use the **no** form of this command.

```
set interface type number [...type number]
```

```
no set interface type number [...type number]
```

Syntax Description

<i>type</i>	Interface type, used with the interface number, to which packets are output.
<i>number</i>	Interface number, used with the interface type, to which packets are output.

Defaults

This command is disabled by default.

Command Modes

Route-map configuration

Command History

Release	Modification
11.0	This command was introduced.
12.3(7)T	This command was updated for use in configuring IPv6 policy-based routing (PBR).

Usage Guidelines

An ellipsis (...) in the command syntax indicates that your command input can include multiple values for the *type* and *number* arguments.

Use the **ip policy route-map** interface configuration command, the **route-map** global configuration command, and the **match** and **set** route-map configuration commands to define the conditions for policy routing packets. The **ip policy route-map** command identifies a route map by name. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which policy routing occurs. The **set** commands specify the *set actions*—the particular routing actions to perform if the criteria enforced by the **match** commands are met.

In PBR for IPv6, use the **ipv6 policy route-map** or **ipv6 local policy route-map** command with match and set route map configuration commands to define conditions for policy routing packets.

If the first interface specified with the **set interface** command is down, the optionally specified interfaces are tried in turn.

The set clauses can be used in conjunction with one another. They are evaluated in the following order:

1. **set ip next-hop**
2. **set interface**
3. **set ip default next-hop**
4. **set default interface**

A useful next hop implies an interface. As soon as a next hop and an interface are found, the packet is routed.

Specifying the **set interface null 0** command is a way to write a policy that the packet be dropped and an “unreachable” message be generated.

Examples

In the following example, packets with a Level 3 length of 3 to 50 bytes are output to Ethernet interface 0:

```
interface serial 0
  ip policy route-map testing
!
route-map testing
  match length 3 50
  set interface ethernet 0
```

In the following example for IPv6, packets with a Level 3 length of 3 to 50 bytes are output to Ethernet interface 0:

```
interface serial 0
  ipv6 policy route-map testing
!
route-map testing
  match length 3 50
  set interface ethernet 0
```

Related Commands

Command	Description
ipv6 local policy route-map	Configures PBR for IPv6 for originated packets.
ip policy route-map	Identifies a route map to use for policy routing on an interface.
ipv6 policy route-map	Configures IPv6 policy-based routing (PBR) on an interface.
match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
match ipv6 address	Specifies an IPv6 access list to use to match packets for PBR for IPv6.
match length	Bases policy routing on the Level 3 length of a packet.
route-map	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
set default interface	Indicates where to output packets that pass a match clause of a route map for policy routing and have no explicit route to the destination.
set interface	Indicates where to output packets that pass a match clause of route map for policy routing.
set ip default next-hop verify-availability	Indicates where to output packets that pass a match clause of a route map for policy routing and for which the Cisco IOS software has no explicit route to a destination.
set ipv6 default next-hop	Specifies an IPv6 default next hop to which matching packets will be forwarded.
set ip next-hop	Indicates where to output packets that pass a match clause of a route map for policy routing.

Command	Description
set ipv6 next-hop (PBR)	Indicates where to output IPv6 packets that pass a match clause of a route map for policy routing.
set ipv6 precedence	Sets the precedence value in the IPv6 packet header.

set ip default next-hop

To indicate where to output packets that pass a match clause of a route map for policy routing and for which the Cisco IOS software has no explicit route to a destination, use the **set ip default next-hop** command in route-map configuration mode. To delete an entry, use the **no** form of this command.

```
set ip default next-hop ip-address [...ip-address]
```

```
no set ip default next-hop ip-address [...ip-address]
```

Syntax Description	<i>ip-address</i>	IP address of the next hop to which packets are output. The next hop must be an adjacent router.
---------------------------	-------------------	--

Defaults	This command is disabled by default.
-----------------	--------------------------------------

Command Modes	Route-map configuration
----------------------	-------------------------

Command History	Release	Modification
	11.0	This command was introduced.

Usage Guidelines	An ellipsis (...) in the command syntax indicates that your command input can include multiple values for the <i>ip-address</i> argument.
-------------------------	---

Use this command to provide certain users a different default route. If the software has no explicit route for the destination in the packet, then it routes the packet to this next hop. The first next hop specified with the **set ip default next-hop** command needs to be adjacent to the router. The optional specified IP addresses are tried in turn.

Use the **ip policy route-map** interface configuration command, the **route-map** global configuration command, and the **match** and **set** route-map configuration commands to define the conditions for policy routing packets. The **ip policy route-map** command identifies a route map by name. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which policy routing occurs. The **set** commands specify the *set actions*—the particular routing actions to perform if the criteria enforced by the **match** commands are met.

The set clauses can be used in conjunction with one another. They are evaluated in the following order:

1. **set ip next-hop**
2. **set interface**
3. **set ip default next-hop**
4. **set default interface**

**Note**

The **set ip next-hop** and **set ip default next-hop** are similar commands but have a different order of operations. Configuring the **set ip next-hop** command causes the system to use policy routing first and then use the routing table. Configuring the **set ip default next-hop** command causes the system to use the routing table first and then policy route the specified next hop.

Examples

The following example provides two sources with equal access to two different service providers. Packets arriving on asynchronous interface 1 from the source 10.1.1.1 are sent to the router at 172.16.6.6 if the software has no explicit route for the destination of the packet. Packets arriving from the source 10.2.2.2 are sent to the router at 172.17.7.7 if the software has no explicit route for the destination of the packet. All other packets for which the software has no explicit route to the destination are discarded.

```
access-list 1 permit ip 10.1.1.1 0.0.0.0
access-list 2 permit ip 10.2.2.2 0.0.0.0
!
interface async 1
 ip policy route-map equal-access
!
route-map equal-access permit 10
 match ip address 1
 set ip default next-hop 172.16.6.6
route-map equal-access permit 20
 match ip address 2
 set ip default next-hop 172.17.7.7
route-map equal-access permit 30
 set default interface null0
```

Related Commands

Command	Description
ip policy route-map	Identifies a route map to use for policy routing on an interface.
match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
match length	Bases policy routing on the Level 3 length of a packet.
route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
set default interface	Indicates where to output packets that pass a match clause of a route map for policy routing and have no explicit route to the destination.
set interface	Indicates where to output packets that pass a match clause of route map for policy routing.
set ip next-hop	Indicates where to output packets that pass a match clause of a route map for policy routing.

set ip next-hop

To indicate where to output packets that pass a match clause of a route map for policy routing, use the **set ip next-hop** command in route-map configuration mode. To delete an entry, use the **no** form of this command.

```
set ip next-hop {ip-address [...ip-address] | recursive ip-address }
```

```
no set ip next-hop ip-address [...ip-address]
```

Syntax Description

<i>ip-address</i>	IP address of the next hop to which packets are output. It must be the address of an adjacent router.
recursive <i>ip-address</i>	IP address of the recursive next-hop router.
Note	The next-hop IP address must be assigned separately from the recursive next-hop IP address.

Defaults

This command is disabled by default.

Command Modes

Route-map configuration

Command History

Release	Modification
11.0	This command was introduced.
12.0(28)S	The recursive keyword was added.
12.3(14)T	This command was integrated into Cisco IOS Release 12.3(14)T.

Usage Guidelines

An ellipsis (...) in the command syntax indicates that your command input can include multiple values for the *ip-address* argument.

Use the **ip policy route-map** interface configuration command, the **route-map** global configuration command, and the **match** and **set** route-map configuration commands to define the conditions for policy routing packets. The **ip policy route-map** command identifies a route map by name. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which policy routing occurs. The **set** commands specify the *set actions*—the particular routing actions to perform if the criteria enforced by the **match** commands are met.

If the interface associated with the first next hop specified with the **set ip next-hop** command is down, the optionally specified IP addresses are tried in turn.

The set clauses can be used in conjunction with one another. They are evaluated in the following order:

1. **set ip next-hop**
2. **set interface**
3. **set ip default next-hop**

4. set default interface



Note

The **set ip next-hop** and **set ip default next-hop** are similar commands but have a different order of operations. Configuring the **set ip next-hop** command causes the system to use policy routing first and then use the routing table. Configuring the **set ip default next-hop** command causes the system to use the routing table first and then policy route the specified next hop.

Examples

In the following example, packets with a Level 3 length of 3 to 50 bytes are output to the router at IP address 10.14.2.2:

```
interface serial 0
 ip policy route-map thataway
!
route-map thataway
 match length 3 50
 set ip next-hop 10.14.2.2
```

In the following example, the IP address of 10.3.3.3 is set as the recursive next-hop address:

```
route-map map_recurse
 set ip next-hop recursive 10.3.3.3
```

Related Commands

Command	Description
ip policy route-map	Identifies a route map to use for policy routing on an interface.
match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
match length	Bases policy routing on the Level 3 length of a packet.
route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
set default interface	Indicates where to output packets that pass a match clause of a route map for policy routing and have no explicit route to the destination.
set interface	Indicates where to output packets that pass a match clause of route map for policy routing.
set ip default next-hop verify-availability	Indicates where to output packets that pass a match clause of a route map for policy routing and for which the Cisco IOS software has no explicit route to a destination.

set ip next-hop (BGP)

To indicate where to output packets that pass a match clause of a route map for policy routing, use the **set ip next-hop** command in route-map configuration mode. To delete an entry, use the **no** form of this command.

```
set ip next-hop ip-address [... ip-address] [peer-address]
```

```
no set ip next-hop ip-address [... ip-address] [peer-address]
```

Syntax Description	
<i>ip-address</i>	IP address of the next hop to which packets are output. It need not be an adjacent router.
peer-address	(Optional) Sets the next hop to be the BGP peering address.

Defaults This command is disabled by default.

Command Modes Route-map configuration

Command History	Release	Modification
	11.0	This command was introduced.
	12.0	The peer-address keyword was added.

Usage Guidelines An ellipsis (...) in the command syntax indicates that your command input can include multiple values for the *ip-address* argument.

Use the **ip policy route-map** interface configuration command, the **route-map** global configuration command, and the **match** and **set** route-map configuration commands to define the conditions for policy routing packets. The **ip policy route-map** command identifies a route map by name. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which policy routing occurs. The **set** commands specify the *set actions*—the particular routing actions to perform if the criteria enforced by the **match** commands are met.

If the first next hop specified with the **set ip next-hop** command is down, the optionally specified IP addresses are tried in turn.

When the **set ip next-hop** command is used with the **peer-address** keyword in an inbound route map of a BGP peer, the next hop of the received matching routes will be set to be the neighbor peering address, overriding any third-party next hops. So the same route map can be applied to multiple BGP peers to override third-party next hops.

When the **set ip next-hop** command is used with the **peer-address** keyword in an outbound route map of a BGP peer, the next hop of the advertised matching routes will be set to be the peering address of the local router, thus disabling the next hop calculation. The **set ip next-hop** command has finer granularity

than the (per-neighbor) **neighbor next-hop-self** command, because you can set the next hop for some routes, but not others. The **neighbor next-hop-self** command sets the next hop for all routes sent to that neighbor.

The set clauses can be used in conjunction with one another. They are evaluated in the following order:

1. **set ip next-hop**
2. **set interface**
3. **set ip default next-hop**
4. **set default interface**

Examples

In the following example, three routers are on the same FDDI LAN (with IP addresses 10.1.1.1, 10.1.1.2, and 10.1.1.3). Each is in a different autonomous system. The **set ip next-hop peer-address** command specifies that traffic from the router (10.1.1.3) in remote autonomous system 300 for the router (10.1.1.1) in remote autonomous system 100 that matches the route map is passed through the router bgp 200, rather than sent directly to the router (10.1.1.1) in autonomous system 100 over their mutual connection to the LAN.

```
router bgp 200
neighbor 10.1.1.3 remote-as 300
neighbor 10.1.1.3 route-map set-peer-address out
neighbor 10.1.1.1 remote-as 100
route-map set-peer-address permit 10
set ip next-hop peer-address
```

Related Commands

Command	Description
ip policy route-map	Identifies a route map to use for policy routing on an interface.
match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
match length	Bases policy routing on the Level 3 length of a packet.
neighbor next-hop-self	Disables next hop processing of BGP updates on the router.
route-map (IP)	Defines the conditions for redistributing routes from one routing protocol to another, or enables policy routing.
set default interface	Indicates where to output packets that pass a match clause of a route map for policy routing and that have no explicit route to the destination.
set interface	Indicates where to output packets that pass a match clause of a route map for policy routing.
set ip default next-hop	Indicates where to output packets that pass a match clause of a route map for policy routing and for which the Cisco IOS software has no explicit route to a destination.

set ip next-hop verify-availability

To configure policy routing to verify the reachability of the next hop of a route map before the router performs policy routing to that next hop, use the **set ip next-hop verify-availability** command in route-map configuration mode. To disable this function, use the **no** form of this command.

set ip next-hop verify-availability [*next-hop-address sequence track object*]

no set ip next-hop verify-availability [*next-hop-address sequence track object*]

Syntax Description

<i>next-hop-address</i>	(Optional) IP address of the next hop to which packets will be forwarded.
<i>sequence</i>	(Optional) Sequence of next hops. The acceptable range is from 1 to 65535.
track	(Optional) The tracking method is track.
<i>object</i>	(Optional) Object number that the tracking subsystem is tracking. The acceptable range is from 1 to 500.

Defaults

This command is disabled.

Command Modes

Route-map configuration

Command History

Release	Modification
12.0(3)T	This command was introduced.
12.3(4)T	The optional track keyword and <i>next-hop-address</i> , <i>sequence</i> , and <i>object</i> arguments were added.

Usage Guidelines

The **set ip next-hop verify-availability** command can be used in the following two ways:

- With policy-based routing (PBR) to verify next hop reachability using Cisco Discovery Protocol (CDP).
- With optional arguments to support object tracking using Internet Control Message Protocol (ICMP) ping or an HTTP GET request to verify if a remote device is reachable.

Using CDP

This command is used to verify that the next hop is reachable before the router tries to policy route to it.

This command has the following characteristics:

- It causes some performance degradation.
- CDP must be configured on the interface.
- The next hop must be a Cisco device with CDP enabled.
- It is supported in process switching and Cisco Express Forwarding (CEF) policy routing, but is not available in distributed CEF (dCEF) because of the dependency of the CDP neighbor database.

If the router is policy routing packets to the next hop and the next hop is down, the router will try unsuccessfully to use Address Resolution Protocol (ARP) for the next hop (which is down). This behavior will continue indefinitely.

To prevent this situation from occurring, use the **set ip next-hop verify-availability** command to configure the router to verify that the next hop of the route map is a CDP neighbor before routing to that next hop.

This command is optional because some media or encapsulations do not support CDP, or it may not be a Cisco device that is sending traffic to the router.

If this command is set and the next hop is not a CDP neighbor, then the router looks to the subsequent next hop, if there is one. If there is no next hop, the packets are not policy routed.

If this command is not set, the packets are either successfully policy routed or remain forever unrouted.

If you want to selectively verify availability of only some next hops, you can configure different route map entries (under the same route map name) with different criteria (using access list matching or packet size matching), and then use the **set ip next-hop verify-availability** command selectively.

Using Object Tracking

With optional arguments to support object tracking, this command allows PBR to make decisions based on the following criteria:

- ICMP ping reachability to a remote device.
- Application running on a remote device (for example, the device responds to an HTTP GET request).
- A route exists in the Routing Information Base (RIB) (for example, policy route only if 10.2.2.0/24 is in the RIB).
- Interface state (for example, packets received on E0 should be policy routed out E1 only if E2 is down).

Object tracking functions in the following manner. PBR will inform the tracking process that it is interested in tracking a certain object. The tracking process will in turn notify PBR when the state of the object changes. This notification is done via registries and is event driven.

The tracking subsystem is responsible for tracking the state of an object. The object can be an IP address that is periodically being pinged by the tracking process. The state of the object (up or down) is stored in a track report data structure. The tracking process will create the tracking object report. Then the exec process that is configuring the route map can query the tracking process to determine if a given object exists. If the object exists, the tracking subsystem can start tracking it and read the initial state of the object. If the object changes state, the tracking process will notify all the clients that are tracking this process that the state of the object has changed. So, the route map structure that PBR is using can be updated to reflect the current state of the object in the track report. This interprocess communication is done by means of registries and the shared track report.



Note

If the CDP and object tracking commands are mixed, the tracked next hops will be tried first.

Examples

Using CDP

The following example configures CEF-based Policy Routing. In this example Policy routing is configured to verify that next hop 50.0.0.8 of route map named test is a CDP neighbor before the router tries to policy route to it. Note that CDP must be enabled on all devices referenced by the set ip next-hop verify-availability command.

If the first packet is being policy routed via route map named test sequence 10, the subsequent packets of the same flow always take the same route map named test sequence 10, not route map named test sequence 20, because they all match or pass access list 1 check.

```
ip cef
interface ethernet0/0/1
  ip route-cache flow
  ip policy route-map test
route-map test permit 10
  match ip address 1
  set ip precedence priority
  set ip next-hop 50.0.0.8
  set ip next-hop verify-availability
route-map test permit 20
```

Using Object Tracking

The following example shows the configuration to use to track an object:

```
! Configure the objects to be tracked.
! Object 123 will be up if the router can ping 10.1.1.1.
! Object 124 will be up if the router can ping 10.2.2.2.
rtr 1
  type echo protocol ipicmpecho 10.1.1.1
rtr schedule 1 start-time now life forever
!
rtr 2
  type echo protocol ipicmpecho 10.2.2.2
rtr schedule 2 start-time now life forever
!
track 123 rtr 1 reachability
track 124 rtr 2 reachability
!
! Enable policy routing using route-map alpha on Ethernet 0.
interface ethernet 0
  ip address 10.4.4.254 255.255.255.0
  ip policy route-map alpha
!
! 10.1.1.1 is via this interface
interface ethernet 1
  ip address 10.1.1.254 255.255.255.0

! 10.2.2.2 is via this interface
interface ethernet 2
  ip address 10.2.2.254 255.255.255.0
!
! Configure a route-map to set the next-hop to 10.1.1.1 if object 123 is up. If object 123
! is down, the next hop will be set to 10.2.2.2 if object 124 is up. If object 124 is also
! down, then policy routing fails and unicast routing will route the packet.
route-map alpha
  set ip next-hop verify-availability 10.1.1.1 10 track 123
  set ip next-hop verify-availability 10.2.2.2 20 track 124
```

Related Commands

Command	Description
show route-map	Displays the configured route maps.
show route-map ipc	Displays counts of the one-way route map IPC messages sent from the RP to the VIP when NetFlow policy routing is configured.
show track	Displays information about objects that are tracked by the tracking process.
track	Tracks the state of an interface, an ip route, or a response time reporter.

■ set ip next-hop verify-availability

set ip precedence

To set the precedence value in the IP header, use the **set ip precedence** command in route-map configuration mode. To instruct the router to leave the precedence value alone, use the **no** form of this command.

set ip precedence *number* | *name*

no set ip precedence

Syntax Description

number | *name* Number or name that sets the precedence bits in the IP header. The number and its corresponding name are as follows, from least important to most important:

Number	Name
0	routine
1	priority
2	immediate
3	flash
4	flash-override
5	critical
6	internet
7	network

Defaults

This command has no default behavior.

Command Modes

Route-map configuration

Command History

Release	Modification
11.0	This command was introduced.

Usage Guidelines

You can set the precedence using either a number or the corresponding name.



Note

Setting the precedence bit affects weighted fair queuing (WFQ). It acts as a multiplier on the WFQ weighting, using a formula of 4096 divided by the IP Precedence value plus 1. For more information, see the **fair-queue** command.

The way the network gives priority (or some type of expedited handling) to the marked traffic is through the application of WFQ or weighted random early detection (WRED) at points downstream in the network. Typically, you would set IP precedence at the edge of the network (or administrative domain) and have queuing act on it thereafter. WFQ can speed up handling for high precedence traffic at congestion points. WRED ensures that high precedence traffic has lower loss rates than other traffic during times of congestion.

The mapping from keywords such as **routine** and **priority** to a precedence value is useful only in some instances. That is, the use of the precedence bit is evolving. The customer can define the meaning of a precedence value by enabling other features that use the value. In the case of Cisco high-end Internet quality of service (QoS), IP precedences can be used to establish classes of service that do not necessarily correspond numerically to better or worse handling in the network. For example, IP Precedence 2 can be given 90 percent of the bandwidth on output links in the network, and IP Precedence 6 can be given 5 percent using the distributed weight fair queueing (DWFQ) implementation on the Versatile Interface Processors (VIPs).

Use the **route-map** global configuration command with **match** and **set** route-map configuration commands to define the conditions for redistributing routes from one routing protocol into another, or for policy routing. Each **route-map** command has a list of **match** and **set** commands associated with it. The match commands specify the match criteria—the conditions under which redistribution or policy routing is allowed for the current **route-map** command. The **set** commands specify the set actions—the particular redistribution or policy routing actions to perform if the criteria enforced by the match commands are met. The **no route-map** command deletes the route map.

The **set** route-map configuration commands specify the redistribution set actions to be performed when all the match criteria of a route map are met. When all match criteria are met, all set actions are performed.

Examples

The following example sets the IP Precedence value to 5 (critical) for packets that pass the route map match:

```
interface serial 0
 ip policy route-map texas
!
route-map texas
 match length 68 128
 set ip precedence 5
```

Related Commands

Command	Description
fair-queue (WFQ)	Enables WFQ for an interface.
ip policy route-map	Identifies a route map to use for policy routing on an interface.
route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.

set level (IP)

To indicate where to import routes, use the **set level** command in route-map configuration mode. To delete an entry, use the **no** form of this command.

```
set level {level-1 | level-2 | level-1-2 | stub-area | backbone}
```

```
no set level {level-1 | level-2 | level-1-2 | stub-area | backbone}
```

Syntax Description		
level-1		Imports routes into a Level 1 area.
level-2		Imports routes into a Level 2 subdomain.
level-1-2		Imports routes into Level 1 and Level 2.
stub-area		Imports routes into an Open Shortest Path First (OSPF) not-so-stubby area (NSSA) area.
backbone		Imports routes into an OSPF backbone area.

Defaults

This command is disabled by default.

For Intermediate System-to-Intermediate System (IS-IS) destinations, the default value is **level-2**. For OSPF destinations, the default value is **backbone**.

Command Modes

Route-map configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Use the **route-map** global configuration command, and the **match** and **set** route-map configuration commands, to define the conditions for redistributing routes from one routing protocol into another. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which redistribution is allowed for the current **route-map** command. The **set** commands specify the *set actions*—the particular redistribution actions to perform if the criteria enforced by the **match** commands are met. The **no route-map** command deletes the route map.

The **set** route-map configuration commands specify the redistribution *set actions* to be performed when all the match criteria of a route map are met. When all match criteria are met, all set actions are performed.

Examples

In the following example, routes will be imported into the Level 1 area:

```
route-map name
 set level level-1
```

Related Commands	Command	Description
	match as-path	Matches a BGP autonomous system path access list.
	match community	Matches a BGP community.
	match interface (IP)	Distributes routes that have their next hop out one of the interfaces specified.
	match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
	match ip next-hop	Redistributes any routes that have a next hop router address passed by one of the access lists specified.
	match ip route-source	Redistributes routes that have been advertised by routers and access servers at the address specified by the access lists.
	match metric (IP)	Redistributes routes with the metric specified.
	match route-type (IP)	Redistributes routes of the specified type.
	match tag	Redistributes routes in the routing table that match the specified tags.
	route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
	set automatic-tag	Automatically computes the tag value.
	set community	Sets the BGP communities attribute.
	set ip next-hop	Specifies the address of the next hop.
	set level (IP)	Indicates where to import routes.
	set local-preference	Specifies a preference value for the autonomous system path.
	set metric (BGP, OSPF, RIP)	Sets the metric value for a routing protocol.
	set metric-type	Sets the metric type for the destination routing protocol.
	set origin (BGP)	Sets the BGP origin code.
	set tag (IP)	Sets the value of the destination routing protocol.

set local-preference

To specify a preference value for the autonomous system path, use the **set local-preference** command in route-map configuration mode. To delete an entry, use the **no** form of this command.

set local-preference *number-value*

no set local-preference *number-value*

Syntax Description	<i>number-value</i>	Preference value. An integer from 0 to 4294967295.
Defaults	Preference value of 100	
Command Modes	Route-map configuration	
Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines

The preference is sent only to all routers in the local autonomous system.

You must have a match clause (even if it points to a “permit everything” list) if you want to set tags.

Use the **route-map** global configuration command, and the **match** and **set** route-map configuration commands, to define the conditions for redistributing routes from one routing protocol into another. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which redistribution is allowed for the current **route-map** command. The **set** commands specify the *set actions*—the particular redistribution actions to perform if the criteria enforced by the **match** commands are met. The **no route-map** command deletes the route map.

The **set** route-map configuration commands specify the redistribution *set actions* to be performed when all the match criteria of a route map are met. When all match criteria are met, all set actions are performed.

You can change the default preference value with the **bgp default local-preference** command.

Examples

The following example sets the local preference to 100 for all routes that are included in access list 1:

```
route-map map-preference
 match as-path 1
 set local-preference 100
```

Related Commands	Command	Description
	bgp default local-preference	Changes the default local preference value.
	match as-path	Matches a BGP autonomous system path access list.
	match community	Matches a BGP community.
	match interface (IP)	Distributes routes that have their next hop out one of the interfaces specified.
	match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
	match ip next-hop	Redistributes any routes that have a next hop router address passed by one of the access lists specified.
	match ip route-source	Redistributes routes that have been advertised by routers and access servers at the address specified by the access lists.
	match metric (IP)	Redistributes routes with the metric specified.
	match route-type (IP)	Redistributes routes of the specified type.
	match tag	Redistributes routes in the routing table that match the specified tags.
	route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
	set automatic-tag	Automatically computes the tag value.
	set community	Sets the BGP communities attribute.
	set ip next-hop	Specifies the address of the next hop.
	set level (IP)	Indicates where to import routes.
	set local-preference	Specifies a preference value for the autonomous system path.
	set metric (BGP, OSPF, RIP)	Sets the metric value for a routing protocol.
	set metric-type	Sets the metric type for the destination routing protocol.
	set origin (BGP)	Sets the BGP origin code.
	set tag (IP)	Sets the value of the destination routing protocol.

set metric (BGP, OSPF, RIP)

To set the metric value for a routing protocol, use the **set metric** command in route-map configuration mode. To return to the default metric value, use the **no** form of this command.

set metric *metric-value*

no set metric *metric-value*

Syntax Description	<i>metric-value</i>	Metric value; an integer from –294967295 to 294967295. This argument applies to all routing protocols except Enhanced Interior Gateway Routing Protocol (EIGRP).
---------------------------	---------------------	--

Defaults	The dynamically learned metric value.
-----------------	---------------------------------------

Command Modes	Route-map configuration
----------------------	-------------------------

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines	We recommend that you consult your Cisco technical support representative before changing the default value.
-------------------------	--

Use the **route-map** global configuration command, and the **match** and **set** route-map configuration commands, to define the conditions for redistributing routes from one routing protocol into another. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which redistribution is allowed for the current **route-map** command. The **set** commands specify the *set actions*—the particular redistribution actions to perform if the criteria enforced by the **match** commands are met. The **no route-map** command deletes the route map.

The **set** route-map configuration commands specify the redistribution *set actions* to be performed when all the match criteria of a route map are met. When all match criteria are met, all set actions are performed.

Examples	The following example sets the metric value for the routing protocol to 100:
-----------------	--

```
route-map set-metric
 set metric 100
```

Related Commands	Command	Description
	match as-path	Matches a BGP autonomous system path access list.
	match community	Matches a BGP community.

Command	Description
match interface (IP)	Distributes routes that have their next hop out one of the interfaces specified.
match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
match ip next-hop	Redistributes any routes that have a next hop router address passed by one of the access lists specified.
match ip route-source	Redistributes routes that have been advertised by routers and access servers at the address specified by the access lists.
match metric (IP)	Redistributes routes with the metric specified.
match route-type (IP)	Redistributes routes of the specified type.
match tag	Redistributes routes in the routing table that match the specified tags.
route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
set automatic-tag	Automatically computes the tag value.
set community	Sets the BGP communities attribute.
set ip next-hop	Specifies the address of the next hop.
set level (IP)	Indicates where to import routes.
set local-preference	Specifies a preference value for the autonomous system path.
set metric (BGP, OSPF, RIP)	Sets the metric value for a routing protocol.
set metric-type	Sets the metric type for the destination routing protocol.
set origin (BGP)	Sets the BGP origin code.
set tag (IP)	Sets the value of the destination routing protocol.

set metric (EIGRP)

To set the metric value for Enhanced Interior Gateway Routing Protocol (EIGRP) in a route map, use the **set metric** route-map configuration command. To return to the default metric value, use the **no** form of this command.

set metric *bandwidth delay reliability loading mtu*

no set metric *bandwidth delay reliability loading mtu*

Syntax Description	
<i>bandwidth</i>	Metric value or EIGRP bandwidth of the route in kbps. The range is from 0 to 4294967295.
<i>delay</i>	Route delay (in tens of microseconds). It can be in the range from 0 to 4294967295.
<i>reliability</i>	Likelihood of successful packet transmission expressed as a number from 0 to 255. The value 255 means 100 percent reliability; 0 means no reliability.
<i>loading</i>	Effective bandwidth of the route expressed as a number from 0 to 255 (255 is 100 percent loading).
<i>mtu</i>	Minimum maximum transmission unit (MTU) size of the route, in bytes. It can be in the range from 0 to 4294967295.

Defaults No metric will be set in the route map.

Command Modes Route-map configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines We recommend you consult your Cisco technical support representative before changing the default value.

Use the **route-map** global configuration command, and the **match** and **set** route-map configuration commands, to define the conditions for redistributing routes from one routing protocol into another. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which redistribution is allowed for the current **route-map** command. The **set** commands specify the *set actions*—the particular redistribution actions to perform if the criteria enforced by the **match** commands are met. The **no route-map** command deletes the route map.

The **set** route-map configuration commands specify the redistribution *set actions* to be performed when all of the match criteria for a router are met. When all match criteria are met, all set actions are performed.

Examples

The following example sets the bandwidth to 10,000, the delay to 10, the reliability to 255, the loading to 1, and the MTU to 1500:

```
set metric 10000 10 255 1 1500
```

set metric-type

To set the metric type for the destination routing protocol, use the **set metric-type** command in route-map configuration mode. To return to the default, use the **no** form of this command.

```
set metric-type {internal | external | type-1 | type-2}
```

```
no set metric-type {internal | external | type-1 | type-2}
```

Syntax Description	internal	Intermediate System-to-Intermediate System (IS-IS) internal metric, or IGP metric as the MED for BGP.
	external	IS-IS external metric.
	type-1	Open Shortest Path First (OSPF) external Type 1 metric.
	type-2	OSPF external Type 2 metric.

Defaults This command is disabled by default.

Command Modes Route-map configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines Use the **route-map** global configuration command with **match** and **set** route-map configuration commands to define the conditions for redistributing routes from one routing protocol into another. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which redistribution is allowed for the current **route-map** command. The **set** commands specify the *set actions*—the particular redistribution actions to perform if the criteria enforced by the **match** commands are met. The **no route-map** command deletes the route map.

The **set** route-map configuration commands specify the redistribution *set actions* to be performed when all the match criteria of a route map are met. When all match criteria are met, all set actions are performed.



Note This command is not supported for redistributing routes into Border Gateway Protocol (BGP).

Examples The following example sets the metric type of the destination protocol to OSPF external Type 1:

```
route-map map-type
 set metric-type type-1
```

Related Commands	Command	Description
	match as-path	Matches a BGP autonomous system path access list.
	match community	Matches a BGP community.
	match interface (IP)	Distributes routes that have their next hop out one of the interfaces specified.
	match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
	match ip next-hop	Redistributes any routes that have a next hop router address passed by one of the access lists specified.
	match ip route-source	Redistributes routes that have been advertised by routers and access servers at the address specified by the access lists.
	match metric (IP)	Redistributes routes with the metric specified.
	match route-type (IP)	Redistributes routes of the specified type.
	match tag	Redistributes routes in the routing table that match the specified tags.
	route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
	set automatic-tag	Automatically computes the tag value.
	set community	Sets the BGP communities attribute.
	set ip next-hop	Specifies the address of the next hop.
	set level (IP)	Indicates where to import routes.
	set local-preference	Specifies a preference value for the autonomous system path.
	set metric (BGP, OSPF, RIP)	Sets the metric value for a routing protocol.
	set metric-type	Sets the metric type for the destination routing protocol.
	set origin (BGP)	Sets the BGP origin code.
	set tag (IP)	Sets the value of the destination routing protocol.
	set weight	Specifies the BGP weight for the routing table.

set metric-type internal

To set the Multi Exit Discriminator (MED) value on prefixes advertised to external BGP (eBGP) neighbors to match the Interior Gateway Protocol (IGP) metric of the next hop, use the **set metric-type internal** command in route-map configuration mode. To return to the default, use the **no** form of this command.

set metric-type internal

no set metric-type internal

Syntax Description This command has no arguments or keywords.

Defaults This command is disabled by default.

Command Modes Route-map configuration

Command History	Release	Modification
	10.3	This command was introduced.

Usage Guidelines This command will cause BGP to advertise a MED value that corresponds to the IGP metric associated with the next hop of the route. This command applies to generated, internal BGP (iBGP)-, and eBGP-derived routes.

If this command is used, multiple BGP speakers in a common autonomous system can advertise different MED values for a particular prefix. Also, note that if the IGP metric changes, BGP will readvertise the route every 10 minutes.

Use the **route-map** global configuration command and the **match** and **set** route-map configuration commands to define the conditions for redistributing routes from one routing protocol into another. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which redistribution is allowed for the current **route-map** command. The **set** commands specify the *set actions*—the particular redistribution actions to perform if the criteria enforced by the **match** commands are met. The **no route-map** command deletes the route map.

The **set** route-map configuration commands specify the redistribution *set actions* to be performed when all of the match criteria of the route map are met. When all match criteria are met, all set actions are performed.



Note

This command is not supported for redistributing routes into Border Gateway Protocol (BGP).

Examples In the following example, the MED value for all the advertised routes to neighbor 172.16.2.3 is set to the corresponding IGP metric of the next hop:

■ set metric-type internal

```
router bgp 109
 network 172.16.0.0
 neighbor 172.16.2.3 remote-as 200
 neighbor 172.16.2.3 route-map setMED out
!
route-map setMED permit 10
 match as-path 1
 set metric-type internal
!
ip as-path access-list 1 permit .*
```

Related Commands

Command	Description
route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.

set next-hop

To specify the address of the next hop, use the **set next-hop** command in route-map configuration mode. To delete an entry, use the **no** form of this command.

```
set next-hop next-hop
```

```
no set next-hop next-hop
```

Syntax Description	<i>next-hop</i>	IP address of the next hop router.
--------------------	-----------------	------------------------------------

Defaults	Default next hop address.
----------	---------------------------

Command Modes	Route-map configuration
---------------	-------------------------

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines

You must have a match clause (even if it points to a “permit everything” list) if you want to set tags. Use the **route-map** global configuration command, and the **match** and **set** route-map configuration commands, to define the conditions for redistributing routes from one routing protocol into another. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which redistribution is allowed for the current **route-map** command. The **set** commands specify the *set actions*—the particular redistribution actions to perform if the criteria enforced by the **match** commands are met. The **no route-map** command deletes the route map.

The **set** route-map configuration commands specify the redistribution *set actions* to be performed when all the match criteria of the router are met. When all match criteria are met, all set actions are performed.

Examples

In the following example, routes that pass the access list have the next hop set to 172.160.70.24:

```
route-map map_hop
 match address 5
 set next-hop 172.160.70.24
```

Related Commands	Command	Description
	match as-path	Matches a BGP autonomous system path access list.
	match community	Matches a BGP community.
	match interface (IP)	Distributes routes that have their next hop out one of the interfaces specified.

Command	Description
match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
match ip next-hop	Redistributes any routes that have a next hop router address passed by one of the access lists specified.
match ip route-source	Redistributes routes that have been advertised by routers and access servers at the address specified by the access lists.
match metric (IP)	Redistributes routes with the metric specified.
match route-type (IP)	Redistributes routes of the specified type.
match tag	Redistributes routes in the routing table that match the specified tags.
route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
set automatic-tag	Automatically computes the tag value.
set community	Sets the BGP communities attribute.
set ip next-hop	Specifies the address of the next hop.
set level (IP)	Indicates where to import routes.
set local-preference	Specifies a preference value for the autonomous system path.
set metric (BGP, OSPF, RIP)	Sets the metric value for a routing protocol.
set metric-type	Sets the metric type for the destination routing protocol.
set origin (BGP)	Sets the BGP origin code.
set tag (IP)	Sets the value of the destination routing protocol.
set weight	Specifies the BGP weight for the routing table.

set origin (BGP)

To set the BGP origin code, use the **set origin** command in route-map configuration mode. To delete an entry, use the **no** form of this command.

```
set origin {igp | egp as-number | incomplete}
```

```
no set origin {igp | egp as-number | incomplete}
```

Syntax Description

igp	Remote Interior Gateway Protocol (IGP) system.
egp	Local Exterior Gateway Protocol (EGP) system.
<i>as-number</i>	Remote autonomous system number. This is an integer from 0 to 65535.
incomplete	Unknown heritage.

Defaults

Default origin, based on route in main IP routing table

Command Modes

Route-map configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

You must have a match clause (even if it points to a “permit everything” list) if you want to set tags.

Use the **route-map** global configuration command, and the **match** and **set** route-map configuration commands, to define the conditions for redistributing routes from one routing protocol into another. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which redistribution is allowed for the current **route-map** command. The **set** commands specify the *set actions*—the particular redistribution actions to perform if the criteria enforced by the **match** commands are met. The **no route-map** command deletes the route map.

The **set** route-map configuration commands specify the redistribution *set actions* to be performed when all of the match criteria of a route map are met. When all match criteria are met, all set actions are performed.

Examples

The following example sets the origin of routes that pass the route map to IGP:

```
route-map set_origin
 match as-path 10
 set origin igp
```

Related Commands	Command	Description
	match as-path	Matches a BGP autonomous system path access list.
	match community	Matches a BGP community.
	match interface (IP)	Distributes routes that have their next hop out one of the interfaces specified.
	match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
	match ip next-hop	Redistributes any routes that have a next hop router address passed by one of the access lists specified.
	match ip route-source	Redistributes routes that have been advertised by routers and access servers at the address specified by the access lists.
	match metric (IP)	Redistributes routes with the metric specified.
	match route-type (IP)	Redistributes routes of the specified type.
	match tag	Redistributes routes in the routing table that match the specified tags.
	route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
	set automatic-tag	Automatically computes the tag value.
	set community	Sets the BGP communities attribute.
	set ip next-hop	Specifies the address of the next hop.
	set level (IP)	Indicates where to import routes.
	set local-preference	Specifies a preference value for the autonomous system path.
	set metric (BGP, OSPF, RIP)	Sets the metric value for a routing protocol.
	set metric-type	Sets the metric type for the destination routing protocol.
	set origin (BGP)	Sets the BGP origin code.
	set tag (IP)	Sets the value of the destination routing protocol.
	set weight	Specifies the BGP weight for the routing table.

set tag (IP)

To set a tag value of the destination routing protocol, use the **set tag** command in route-map configuration mode. To delete the entry, use the **no** form of this command.

set tag *tag-value*

no set tag *tag-value*

Syntax Description

<i>tag-value</i>	Name for the tag. Integer from 0 to 4294967295.
------------------	---

Defaults

If not specified, the default action is to *forward* the tag in the source routing protocol onto the new destination protocol.

Command Modes

Route-map configuration

Command History

Release	Modification
10.0	This command was introduced.

Usage Guidelines

Use the **route-map** global configuration command, and the **match** and **set** route-map configuration commands, to define the conditions for redistributing routes from one routing protocol into another. Each **route-map** command has a list of **match** and **set** commands associated with it. The **match** commands specify the *match criteria*—the conditions under which redistribution is allowed for the current **route-map** command. The **set** commands specify the *set actions*—the particular redistribution actions to perform if the criteria enforced by the **match** commands are met. The **no route-map** command deletes the route map.

The **set** route-map configuration commands specify the redistribution *set actions* to be performed when all the match criteria of a route map are met. When all match criteria are met, all set actions are performed.

Examples

The following example sets the tag value of the destination routing protocol to 5:

```
route-map tag
 set tag 5
```

Related Commands

Command	Description
match as-path	Matches a BGP autonomous system path access list.
match community	Matches a BGP community.
match interface (IP)	Distributes routes that have their next hop out one of the interfaces specified.

Command	Description
match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
match ip next-hop	Redistributes any routes that have a next hop router address passed by one of the access lists specified.
match ip route-source	Redistributes routes that have been advertised by routers and access servers at the address specified by the access lists.
match metric (IP)	Redistributes routes with the metric specified.
match route-type (IP)	Redistributes routes of the specified type.
match tag	Redistributes routes in the routing table that match the specified tags.
route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
set automatic-tag	Automatically computes the tag value.
set community	Sets the BGP communities attribute.
set ip next-hop	Specifies the address of the next hop.
set level (IP)	Indicates where to import routes.
set local-preference	Specifies a preference value for the autonomous system path.
set metric (BGP, OSPF, RIP)	Sets the metric value for a routing protocol.
set metric-type	Sets the metric type for the destination routing protocol.
set origin (BGP)	Sets the BGP origin code.
set tag (IP)	Sets the value of the destination routing protocol.
set weight	Specifies the BGP weight for the routing table.

set traffic-index

To indicate how to classify packets that pass a match clause of a route map for Border Gateway Protocol (BGP) policy accounting, use the **set traffic-index** command in route-map configuration mode. To delete an entry, use the **no** form of this command.

set traffic-index *bucket-number*

no set traffic-index *bucket-number*

Syntax Description	<i>bucket-number</i> Number that represents a bucket into which packet and byte statistics are collected for a specific traffic classification. The range is from 1 to 64.
---------------------------	--

Defaults	Routing traffic is not classified.
-----------------	------------------------------------

Command Modes	Route-map configuration
----------------------	-------------------------

Command History	Release	Modification
	12.0(9)S	This command was introduced.
	12.0(17)ST	This command was integrated into Cisco IOS Release 12.0(17)ST.
	12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T.
	12.0(22)S	Support for 64 buckets was added for the Cisco 12000 series Internet router.
	12.3(4)T	This command was integrated into Cisco IOS Release 12.3(4)T and support for 64 buckets was added for all platforms.

Usage Guidelines	Use the set traffic-index route-map configuration command, the route-map global configuration command, and the match route-map configuration command to define the conditions for BGP policy accounting. The match commands specify the <i>match criteria</i> —the conditions under which policy routing occurs. The set traffic-index command specifies the <i>set actions</i> —the particular routing actions to perform if the criteria specified by the match commands are met.
-------------------------	---

Examples	In the following example, an index for BGP policy accounting is set according to autonomous system path criteria:
-----------------	---

```
route-map buckets permit 10
  match as-path 1
  set traffic-index 1
```

Related Commands

Command	Description
bgp-policy	Enables BGP policy accounting or policy propagation on an interface.
route-map	Defines the conditions for redistributing routes from one routing protocol to another, or enables policy routing.

set weight

To specify the BGP weight for the routing table, use the **set weight** command in route-map configuration mode. To delete an entry, use the **no** form of this command.

set weight number

no set weight *number*

Syntax Description	<i>number</i>	Weight value. It can be an integer ranging from 0 to 65535.
--------------------	---------------	---

Defaults The weight is not changed by the specified route map.

Command Modes Route-map configuration

Command History	Release	Modification
	10.0	This command was introduced.

Usage Guidelines The implemented weight is based on the first matched autonomous system path. Weights indicated when an autonomous system path is matched override the weights assigned by global **neighbor** commands. In other words, the weights assigned with the **set weight** route-map configuration command override the weights assigned using the **neighbor weight** command.

Examples The following example sets the BGP weight for the routes matching the autonomous system path access list to 200:

```
route-map set-weight
 match as-path 10
 set weight 200
```

Related Commands	Command	Description
	match as-path	Matches a BGP autonomous system path access list.
	match community	Matches a BGP community.
	match interface (IP)	Distributes routes that have their next hop out one of the interfaces specified.
	match ip address	Distributes any routes that have a destination network number address that is permitted by a standard or extended access list, and performs policy routing on packets.
	match ip next-hop	Redistributes any routes that have a next hop router address passed by one of the access lists specified.

Command	Description
match ip route-source	Redistributes routes that have been advertised by routers and access servers at the address specified by the access lists.
match metric (IP)	Redistributes routes with the metric specified.
match route-type (IP)	Redistributes routes of the specified type.
match tag	Redistributes routes in the routing table that match the specified tags.
route-map (IP)	Defines the conditions for redistributing routes from one routing protocol into another, or enables policy routing.
set automatic-tag	Automatically computes the tag value.
set community	Sets the BGP communities attribute.
set ip next-hop	Specifies the address of the next hop.
set level (IP)	Indicates where to import routes.
set local-preference	Specifies a preference value for the autonomous system path.
set metric (BGP, OSPF, RIP)	Sets the metric value for a routing protocol.
set metric-type	Sets the metric type for the destination routing protocol.
set origin (BGP)	Sets the BGP origin code.
set tag (IP)	Sets the value of the destination routing protocol.
set weight	Specifies the BGP weight for the routing table.

set-attached-bit

To specify constraints for when a Level 1 - Level 2 (L1L2) router should set its attached-bit, use the **set-attached-bit route-map** command in router configuration mode. To disable this function, use the **no** form of this command.

set-attached-bit route-map *map-tag*

no set-attached-bit route-map *map-tag*

Syntax Description	route-map <i>map-tag</i>	(Required) Identifier of a configured route map. If the specified route map is matched, the router continues to set its attached-bit.
---------------------------	---------------------------------	---

Defaults	This command is disabled by default.
-----------------	--------------------------------------

Command Modes	Router configuration
----------------------	----------------------

Command History	Release	Modification
	12.2	This command was introduced.
	12.2(4)B	This command was integrated into Cisco IOS Release 12.2(4)B.
	12.2(14)S	This command was integrated into Cisco IOS Release 12.2(14)S.

Usage Guidelines

In the current IS-IS implementation, as specified in ISO 10589, L1L2 routers set their Level 1 (L1) link-state packet (LSP) attached-bit when they see other areas in their own domain, or see other domains. However, in some network topologies, adjacent L1L2 routers in different areas may lose connectivity to the Level 2 (L2) backbone. Level 1 (L1) routers may then send traffic destined outside of the area or domain to L1L2 routers that may not have such connectivity.

To allow more control over the attached-bit setting for L1L2 routers, enter the **set-attached-bit** command in router configuration mode. The route map can specify one or more CLNS routes. If at least one of the match address route-map clauses matches a route in the L2 CLNS routing table, and if all other requirements for setting the attached-bit are met, the L1L2 router will continue to set the attached-bit in its L1 LSP. If the requirements are not met or no match address route-map clauses match a route in the L2 CLNS routing table, the attached-bit will not be set.



Note

Wildcarded matches are not supported. For each route-map statement, an exact route lookup of the specified route will be performed. The first matched route will have other match statements applied.

Examples

In the following example, the attached-bit will stay set when the router matches 49.00aa in the L2 CLNS routing table.

```
clns filter-set L2_backbone_connectivity permit 49.00aa
route-map check-for-L2_backbone_connectivity
```

■ set-attached-bit

```

match clns address L2_backbone_connectivity
router isis
  set-attached-bit route-map check-for-L2_backbone_connectivity
end
show clns route 49.00aa

```

```

Known via "isis", distance 110, metric 30, Dynamic Entry
Routing Descriptor Blocks:
  via tr2, Serial0
    isis, route metric is 30, route version is 58

```

Related Commands

Command	Description
route-map	Defines the conditions for redistributing routes from one routing protocol into another.
show clns route	Displays one or all of the destinations to which a router knows how to route CLNS packets.

set-overload-bit

To configure the router to signal other routers not to use it as an intermediate hop in their shortest path first (SPF) calculations, use the **set-overload-bit** command in router configuration mode. To remove the designation, use the **no** form of this command.

```
set-overload-bit [on-startup {seconds | wait-for-bgp}] [suppress {[interlevel] [external]}]
```

```
no set-overload-bit
```

Syntax Description		
on-startup	(Optional) Sets the overload bit upon the system starting up. The overload bit remains set for the number of <i>seconds</i> configured or until BGP has converged, depending on the subsequent argument or keyword specified.	
<i>seconds</i>	(Optional) When the on-startup keyword is configured, causes the overload bit to be set upon system startup and remain set for the specified number of seconds. The range is from 5 to 86400 seconds.	
wait-for-bgp	(Optional) When the on-startup keyword is configured, causes the overload bit to be set upon system startup and remain set until BGP has converged.	
suppress	(Optional) Causes the type of prefix identified by the subsequent keyword or keywords to be suppressed.	
interlevel	(Optional) When the suppress keyword is configured, prevents the IP prefixes learned from another IS-IS level from being advertised.	
external	(Optional) When the suppress keyword is configured, prevents the IP prefixes learned from other protocols from being advertised.	

Defaults The overload bit is not set.

Command Modes Router configuration

Command History	Release	Modification
	11.2	This command was introduced.
	11.3(2)	The on-startup keyword and the <i>seconds</i> argument were added.
	12.0(7)S	The wait-for-bgp keyword was added.
	12.1(9)	The wait-for-bgp keyword was added.
	12.2(2)	The wait-for-bgp keyword was added.
	12.0(21)ST	The suppress , interlevel , and external keywords were added.
	12.2(8)	The suppress , interlevel , and external keywords were added.

Usage Guidelines

This command forces the router to set the overload bit (also known as the hippity bit) in its nonpseudonode link-state packets (LSPs). Normally, the setting of the overload bit is allowed only when a router runs into problems. For example, when a router is experiencing a memory shortage, it might be that the link-state database is not complete, resulting in an incomplete or inaccurate routing table. By setting the overload bit in its LSPs, other routers can ignore the unreliable router in their SPF calculations until the router has recovered from its problems.

The result will be that no paths through this router are seen by other routers in the IS-IS area. However, IP and Connectionless Network Service (CLNS) prefixes directly connected to this router will still be reachable.

This command can be useful when you want to connect a router to an IS-IS network but do not want real traffic flowing through it under any circumstances. Examples situations are as follows:

- A test router in the lab, connected to a production network.
- A router configured as an LSP flooding server, for example, on a nonbroadcast multiaccess (NBMA) network, in combination with the mesh group feature.
- A router that is aggregating virtual circuits (VCs) used only for network management. In this case, the network management stations must be on a network directly connected to the router with the **set-overload-bit** command configured.

Unless you specify the **on-startup** keyword, this command sets the overload bit immediately.

In addition to setting the overload bit, you might want to suppress certain types of IP prefix advertisements from LSPs. For example, allowing IP prefix propagation between Level 1 and Level 2 effectively makes a node a transit node for IP traffic, which might be undesirable. The **suppress** keyword used with the **interlevel** or **external** keyword (or both) accomplishes that suppression while the overload bit is set.

Examples

The following example sets the overload bit upon startup and until BGP has converged, and suppresses redistribution between IS-IS levels and suppresses redistribution from external routing protocols while the overload bit is set:

```
interface Ethernet0
 ip address 10.1.1.1 255.255.255.0
 ip router isis
router isis
 net 49.0001.0000.0000.0001.00
 set-overload-bit on-startup wait-for-bgp suppress interlevel external
router bgp 100
```