



# Supported Devices Table for Cisco netManager 1.1

---

Revised: August 19, 2008

## Important Information About Product Configurations

Cisco netManager is available in two product configurations: Cisco netManager IP Infrastructure and Cisco netManager Unified Communications. Cisco netManager IP Infrastructure provides standards-based monitoring of network devices, services, or applications on TCP/IP and Windows. Cisco netManager Unified Communications includes all features of Cisco netManager along with the additional capability to provide visibility into, and monitoring of, Cisco Unified Communications devices. See the *Quick Start Guide for Cisco netManager* for licensing information.

This document applies to both Cisco netManager IP Infrastructure and Cisco netManager Unified Communications. The ability to view and monitor Cisco Unified Communication devices depends upon the type of licensing you have. See the *Quick Start Guide for Cisco netManager* for licensing options.



**Note**

---

We sometimes update the printed and electronic documentation after original publication. Therefore, you should also review the documentation on Cisco.com for any updates.

---



---

**Americas Headquarters:**  
**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**

© 2008 Cisco Systems, Inc. All rights reserved.

# Devices Supported by Cisco netManager 1.1

This release supports the following new devices:

- Cisco Unified Communications Manager 6.1, 7.0(1)
- Cisco Unified Communications Manager Business Edition 6.1, 7.0(1)
- Cisco Unity Connection 7.0
- Cisco Unity Express 3.0, 3.1
- Cisco IP Communicator 2.1, 3.0
- Cisco Unified Contact Center Express 7.0
- SIP capability on Cisco Unified Communications Manager Express
- Cisco Unified Personal Communicator 1.2
- Cisco Unified Presence Server 7.0
- Cisco 1861 Integrated Services Router
- Cisco ASR 1000 Series Aggregation Services Routers (1002, 1004, and 1006)
- Cisco MCS Unified Communications Manager Appliance families H2, H3, I2, and I3
- Cisco Unified Communications Manager Express with SIP capability
- SIP capability on gateways
- Cisco Firewall Services Module cat6500FirewallSm with OID 1.3.6.1.4.1.9.1.522.
- A number of Cisco routers and switches.

The following tables contain a detailed list of the devices supported by Cisco netManager:

- [Table 1, Routers and Routing Systems on page 3](#)
- [Table 2, Switches on page 7](#)
- [Table 3, Cisco Interfaces and Modules on page 11](#)
- [Table 4, Cisco Security and VPN Devices on page 11](#)
- [Table 5, Voice and Unified Communications on page 13](#)

When you install Cisco netManager, you also install device support for all of the devices listed in this document.



## Note

The ability to view and monitor Cisco Unified Communication devices depends upon the type of licensing you have. See the *Quick Start Guide for Cisco netManager* for licensing options.

Keep these points in mind when you view the device support table:

- The devices listed in this document might be categorized differently in the Cisco netManager display.
- This list contains the Cisco model names of all devices that are supported by Cisco netManager. Variants to the generic device (device model names that have unique extensions) are not supported unless they are specifically listed. The device support tables provide SysObjectIDs to help you verify which devices are supported.

**Table 1**      **Routers and Routing Systems**

<b>Series</b>	<b>Devices Supported</b>	<b>SysObjectID</b>
Cisco 7600 Series Routers	7603	1.3.6.1.4.1.9.1.401
	7603S	1.3.6.1.4.1.9.1.862
	7604	1.3.6.1.4.1.9.1.658
	7606	1.3.6.1.4.1.9.1.402
	7606S	1.3.6.1.4.1.9.1.863
	7609	1.3.6.1.4.1.9.1.509
	7609S	1.3.6.1.4.1.9.1.864
	7613	1.3.6.1.4.1.9.1.528
	7613s	1.3.6.1.4.1.9.1.984
Cisco 3800 Series Integrated Services Routers	3825	1.3.6.1.4.1.9.1.543
	3845	1.3.6.1.4.1.9.1.544
Cisco MC3810 Multiservice Access Concentrators	MC3810	1.3.6.1.4.1.9.1.157
	Mc3810V3	1.3.6.1.4.1.9.1.286
Cisco 3700 Series Multiservice Access Routers	3725	1.3.6.1.4.1.9.1.414
	3745	1.3.6.1.4.1.9.1.436
Cisco 3600 Series Multiservice Platforms	3620	1.3.6.1.4.1.9.1.122
	Pro3620	1.3.6.1.4.1.9.1.123
	3631Co	1.3.6.1.4.1.9.1.425
	3640	1.3.6.1.4.1.9.1.110
	3640A	1.3.6.1.4.1.9.1.415
	Pro3640	1.3.6.1.4.1.9.1.124
	SC3640	1.3.6.1.4.1.9.1.189
	3660	1.3.6.1.4.1.9.1.205
	3661Ac	1.3.6.1.4.1.9.1.338
	3661Dc	1.3.6.1.4.1.9.1.339
	3662Ac	1.3.6.1.4.1.9.1.340
	3662Dc	1.3.6.1.4.1.9.1.341
	3662AcCo	1.3.6.1.4.1.9.1.342
	3662DcCo	1.3.6.1.4.1.9.1.343
Cisco 2800 Series Integrated Services Routers	2801	1.3.6.1.4.1.9.1.619
	2811	1.3.6.1.4.1.9.1.576
	2821	1.3.6.1.4.1.9.1.577
	2851	1.3.6.1.4.1.9.1.578

**Table 1**      *Routers and Routing Systems (continued)*

<b>Series</b>	<b>Devices Supported</b>	<b>SysObjectID</b>
Cisco 2600 Series Multiservice Platforms	2610	1.3.6.1.4.1.9.1.185
	2610M	1.3.6.1.4.1.9.1.418
	2610XM	1.3.6.1.4.1.9.1.466
	2611	1.3.6.1.4.1.9.1.186
	2611M	1.3.6.1.4.1.9.1.419
	2611XM	1.3.6.1.4.1.9.1.467
	2612	1.3.6.1.4.1.9.1.187
	2613	1.3.6.1.4.1.9.1.195
	2620	1.3.6.1.4.1.9.1.208
	2620XM	1.3.6.1.4.1.9.1.468
	2621	1.3.6.1.4.1.9.1.209
	2621XM	1.3.6.1.4.1.9.1.469
	2650	1.3.6.1.4.1.9.1.319
	2650XM	1.3.6.1.4.1.9.1.470
	2651	1.3.6.1.4.1.9.1.320
	2651XM	1.3.6.1.4.1.9.1.471
	2691	1.3.6.1.4.1.9.1.413
Cisco 1800 Series Integrated Services Routers	1801	1.3.6.1.4.1.9.1.638
	1801M	1.3.6.1.4.1.9.1.783
	1802	1.3.6.1.4.1.9.1.639
	1803	1.3.6.1.4.1.9.1.640
	1811	1.3.6.1.4.1.9.1.641
	1805	1.3.6.1.4.1.9.1.981
	1812	1.3.6.1.4.1.9.1.642
	1841	1.3.6.1.4.1.9.1.620
	1861BCueK9	1.3.6.1.4.1.9.1.902
	1861FCueK9	1.3.6.1.4.1.9.1.903
	18612Bri	1.3.6.1.4.1.9.1.904
	18614Fxo	1.3.6.1.4.1.9.1.905
	1861SRSTCUE2B	1.3.6.1.4.1.9.1.939
	1861SRSTCUE4F	1.3.6.1.4.1.9.1.940

**Table 1**      **Routers and Routing Systems (continued)**

<b>Series</b>	<b>Devices Supported</b>	<b>SysObjectID</b>
Cisco 1700 Series Modular Access Routers	1701 ADSL	1.3.6.1.4.1.9.1.550
	1710	1.3.6.1.4.1.9.1.200
	1711	1.3.6.1.4.1.9.1.538
	1712	1.3.6.1.4.1.9.1.539
	1718	1.3.6.1.4.1.9.1.594
	1720	1.3.6.1.4.1.9.1.201
	1721	1.3.6.1.4.1.9.1.444
	1750	1.3.6.1.4.1.9.1.216
	1730Iad8Fxs	1.3.6.1.4.1.9.1.327
	1730Iad16Fxs	1.3.6.1.4.1.9.1.328
	1751	1.3.6.1.4.1.9.1.326
	1760	1.3.6.1.4.1.9.1.416

**Table 1**      *Routers and Routing Systems (continued)*

<b>Series</b>	<b>Devices Supported</b>	<b>SysObjectID</b>
Cisco 800 Series Routers	801	1.3.6.1.4.1.9.1.212
	802	1.3.6.1.4.1.9.1.213
	802J	1.3.6.1.4.1.9.1.295
	803	1.3.6.1.4.1.9.1.214
	804	1.3.6.1.4.1.9.1.215
	804J	1.3.6.1.4.1.9.1.296
	805	1.3.6.1.4.1.9.1.245
	806	1.3.6.1.4.1.9.1.384
	811	1.3.6.1.4.1.9.1.395
	813	1.3.6.1.4.1.9.1.396
	815	1.3.6.1.4.1.9.1.733
	826	1.3.6.1.4.1.9.1.322
	826QuadV	1.3.6.1.4.1.9.1.321
	827	1.3.6.1.4.1.9.1.284
	827H	1.3.6.1.4.1.9.1.446
	827QuadV	1.3.6.1.4.1.9.1.270
	828	1.3.6.1.4.1.9.1.382
	831	1.3.6.1.4.1.9.1.497
	836	1.3.6.1.4.1.9.1.499
	837	1.3.6.1.4.1.9.1.495
	851	1.3.6.1.4.1.9.1.566
	857	1.3.6.1.4.1.9.1.567
	861	1.3.6.1.4.1.9.1.834
	866	1.3.6.1.4.1.9.1.835
	867	1.3.6.1.4.1.9.1.836
	871	1.3.6.1.4.1.9.1.571
	876	1.3.6.1.4.1.9.1.568
	877	1.3.6.1.4.1.9.1.569
	877M	1.3.6.1.4.1.9.1.782
	878	1.3.6.1.4.1.9.1.570
	881	1.3.6.1.4.1.9.1.837
	881G	1.3.6.1.4.1.9.1.838
	881SRST	1.3.6.1.4.1.9.1.840
881B Integrated Access Device	1.3.6.1.4.1.9.1.841	
881F Integrated Access Device	1.3.6.1.4.1.9.1.839	
886	1.3.6.1.4.1.9.1.842	

**Table 1** Routers and Routing Systems (continued)

Series	Devices Supported	SysObjectID
Cisco ASR 1000 Series Aggregation Services Routers	1002	1.3.6.1.4.1.9.1.923
	1004	1.3.6.1.4.1.9.1.924
	1006	1.3.6.1.4.1.9.1.925

**Table 2** Switches

Series	Devices Supported	SysObjectID
Cisco Catalyst 6500 Series Switches	6506	1.3.6.1.4.1.9.1.282
	6509	1.3.6.1.4.1.9.1.283
	6509-NEB	1.3.6.1.4.1.9.1.310
	6509-NEBA	1.3.6.1.4.1.9.1.534
	WSC6509	1.3.6.1.4.1.9.1.510
	WSC6513	1.3.6.1.4.1.9.1.400, 1.3.6.1.4.1.9.1.896
	WSC6503	1.3.6.1.4.1.9.1.449
	WSC6504E	1.3.6.1.4.1.9.1.657
	Cisco Virtual Switching System (WS-C6513)	
Cisco ME 4900 Series Ethernet Switch	Me492410GE	1.3.6.1.4.1.9.1.788
Cisco Catalyst 4500 Series Switches	4550-3	1.3.6.1.4.1.9.1.698
	4550-6	1.3.6.1.4.1.9.1.699
	4550-7	1.3.6.1.4.1.9.1.700
	4550-10	1.3.6.1.4.1.9.1.701
	4500	1.3.6.1.4.1.9.1.14
	Pro4500	1.3.6.1.4.1.9.1.66
	4503	1.3.6.1.4.1.9.1.503
	4503E	1.3.6.1.4.1.9.1.874
	4506	1.3.6.1.4.1.9.1.502
	4506E	1.3.6.1.4.1.9.1.875
	4507	1.3.6.1.4.1.9.1.501
	4507RE	1.3.6.1.4.1.9.1.876
	4510	1.3.6.1.4.1.9.1.537
	4510RE	1.3.6.1.4.1.9.1.877
	Cisco Catalyst 4000 Series Switches	4948
4948-10GE		1.3.6.1.4.1.9.1.659
4908gL3		1.3.6.1.4.1.9.1.298
4908gL3Dc		1.3.6.1.4.1.9.1.387
4900-M		1.3.6.1.4.1.9.1.917

**Table 2**      **Switches (continued)**

<b>Series</b>	<b>Devices Supported</b>	<b>SysObjectID</b>
Cisco Catalyst 3750 Series Switches	371098HP001	1.3.6.1.4.1.9.1.625
	3750E-24PD-E	1.3.6.1.4.1.9.1.792
	3750E-24TD-E	1.3.6.1.4.1.9.1.790
	3750E-48PD-E	1.3.6.1.4.1.9.1.791
	3750GE-12SF	1.3.6.1.4.1.9.1.530
	3750GE-12SFPDC	1.3.6.1.4.1.9.1.668
	3750G-16TD	1.3.6.1.4.1.9.1.591
	3750G-24TS1U	1.3.6.1.4.1.9.1.624
	3750G-48PS	1.3.6.1.4.1.9.1.603
	3750G-48TS	1.3.6.1.4.1.9.1.604
	3750-24	1.3.6.1.4.1.9.1.511
	3750-24FS	1.3.6.1.4.1.9.1.656
	3750-24PS	1.3.6.1.4.1.9.1.602
	3750-24T	1.3.6.1.4.1.9.1.514
	3750-24TS	1.3.6.1.4.1.9.1.513
	3750-24WS	1.3.6.1.4.1.9.1.644
	3750-24WS25	1.3.6.1.4.1.9.1.778
	3750G-24WS-S50	1.3.6.1.4.1.9.1.779
	3750-48	1.3.6.1.4.1.9.1.512
	3750-48PS	1.3.6.1.4.1.9.1.535
3750-stack	1.3.6.1.4.1.9.1.516	
WS-C3750G-24PS	1.3.6.1.4.1.9.1.747	
Cisco Catalyst 3750 Metro Series Switches	ME-C3750-24TE-M	1.3.6.1.4.1.9.1.574

**Table 2**      **Switches (continued)**

<b>Series</b>	<b>Devices Supported</b>	<b>SysObjectID</b>
Cisco Catalyst 3560 Series Switches	3560-8PC	1.3.6.1.4.1.9.1.797
	3560-24PS	1.3.6.1.4.1.9.1.563
	3560-24TS	1.3.6.1.4.1.9.1.633
	3560-48PS	1.3.6.1.4.1.9.1.564
	3560-48TS	1.3.6.1.4.1.9.1.634
	3560E-12D-S	1.3.6.1.4.1.9.1.930
	3560E-12SD-E	1.3.6.1.4.1.9.1.956
	3560E-24PD-E	1.3.6.1.4.1.9.1.795
	3560E-48PD-E	1.3.6.1.4.1.9.1.796
	3560E-24TD-E	1.3.6.1.4.1.9.1.793
	3560E-48TD-E	1.3.6.1.4.1.9.1.794
	3560G-24PS	1.3.6.1.4.1.9.1.614
	3560G-24TS	1.3.6.1.4.1.9.1.615
	3560G-48PS	1.3.6.1.4.1.9.1.616
	3560G-48TS	1.3.6.1.4.1.9.1.617
Cisco Catalyst 3550 Series Switches	3550-24	1.3.6.1.4.1.9.1.366
	3550-48	1.3.6.1.4.1.9.1.367
	3550-12G	1.3.6.1.4.1.9.1.431
	3550-12T	1.3.6.1.4.1.9.1.368
	3550-24Dc	1.3.6.1.4.1.9.1.452
	3550-24Mmf	1.3.6.1.4.1.9.1.453
	3550-24-PWR	1.3.6.1.4.1.9.1.485
Cisco Catalyst 2970 Series Switches	2970-24	1.3.6.1.4.1.9.1.527
	2970-48TS	1.3.6.1.4.1.9.1.605
	2970G-24TS-E	1.3.6.1.4.1.9.1.561

**Table 2**      **Switches (continued)**

<b>Series</b>	<b>Devices Supported</b>	<b>SysObjectID</b>
Cisco Catalyst 2960 Series Switches	2960-24	1.3.6.1.4.1.9.1.694
	2960-24LT	1.3.6.1.4.1.9.1.951
	2960-24PC	1.3.6.1.4.1.9.1.950
	2960-24S	1.3.6.1.4.1.9.1.929
	2960-24TCS	1.3.6.1.4.1.9.1.928
	2960-24TT	1.3.6.1.4.1.9.1.716
	2960-48	1.3.6.1.4.1.9.1.695
	2960-48TT	1.3.6.1.4.1.9.1.717
	2960-48TCS	1.3.6.1.4.1.9.1.927
	2960G-24	1.3.6.1.4.1.9.1.696
	2960G-48	1.3.6.1.4.1.9.1.697
	2960-8TC	1.3.6.1.4.1.9.1.798
	2960G-8TC	1.3.6.1.4.1.9.1.799
	2960PD-8TT-L	1.3.6.1.4.1.9.1.952
Cisco Catalyst 2955 Series Switches	2955C-12	1.3.6.1.4.1.9.1.489
	2955S-12	1.3.6.1.4.1.9.1.508
	2955T-12	1.3.6.1.4.1.9.1.488
Cisco Catalyst 2950 Series Switches	2950-12	1.3.6.1.4.1.9.1.323
	2950-24	1.3.6.1.4.1.9.1.324
	2950C-24	1.3.6.1.4.1.9.1.325
	2950G-12	1.3.6.1.4.1.9.1.427
	2950G-24	1.3.6.1.4.1.9.1.428
	2950G-48	1.3.6.1.4.1.9.1.429
	2950G-24-DC	1.3.6.1.4.1.9.1.472
	2950S-24	1.3.6.1.4.1.9.1.430
	2950SX-24	1.3.6.1.4.1.9.1.480
	2950SX-48	1.3.6.1.4.1.9.1.560
	2950T-24	1.3.6.1.4.1.9.1.359
	2950T-48	1.3.6.1.4.1.9.1.559
Cisco Catalyst 2950 LRE Series Switches	2950-G-24-LRE	1.3.6.1.4.1.9.1.484
	2950-ST-8-LRE	1.3.6.1.4.1.9.1.483
	2950-ST-24-LRE	1.3.6.1.4.1.9.1.482
	2950-ST-24-LRE-997	.1.3.6.1.4.1.9.1.551

**Table 2** *Switches (continued)*

<b>Series</b>	<b>Devices Supported</b>	<b>SysObjectID</b>
Cisco Catalyst 2940 Series Switches	2948G-L3	1.3.6.1.4.1.9.1.275
	2948G-L3DC	1.3.6.1.4.1.9.1.386
	2940-8TF	1.3.6.1.4.1.9.1.542
	2940-8TT	1.3.6.1.4.1.9.1.540
Cisco Catalyst 2900 Series Switches	2918-24TT	1.3.6.1.4.1.9.1.965
	2918-24TC	1.3.6.1.4.1.9.1.966
	2918-48TT	1.3.6.1.4.1.9.1.967
	2918-48TC	1.3.6.1.4.1.9.1.968
Cisco Catalyst 500 Series Switches	WS-CE500-24TT	1.3.6.1.4.1.9.1.724
Cisco 500 Series LRE CPE Devices	CS500	1.3.6.1.4.1.9.1.9
Cisco 500 Series Content Engines	CE-510	1.3.6.1.4.1.9.1.505

**Table 3** *Cisco Interfaces and Modules*

<b>Series</b>	<b>Devices Supported</b>	<b>SysObjectID</b>
<b>Network Modules</b>		
Supervisor Engine 720	WS-SUP720	1.3.6.1.4.1.9.1.557
Cisco Catalyst 6500 Series Supervisor Engine II	—	—
Cisco Catalyst 6000 Series Module Switch Feature Card (MSFC)	WS-F6K-MSFC2	1.3.6.1.4.1.9.1.301
	WS-F6KMSFC	1.3.6.1.4.1.9.1.258
Cisco 2600 Series Content Engine Module	CE2636	1.3.6.1.4.1.9.1.454
<b>Voice Modules and Interface Cards</b>		
Cisco Unity Express Network Module	NM-CUE	1.3.6.1.4.1.9.1.622
Cisco Unity Express Advanced Integration Module	AIM-CUE	1.3.6.1.4.1.9.1.623
	CU500	1.3.6.1.4.1.9.1.868

**Table 4** *Cisco Security and VPN Devices*

<b>Series</b>	<b>Devices Supported</b>	<b>SysObjectID</b>
Cisco Catalyst 6500 Series Firewall Services Module	Catalyst 6500	1.3.6.1.4.1.9.1.522
Cisco PIX 500 Series Firewalls	506E	1.3.6.1.4.1.9.1.450
	515E	1.3.6.1.4.1.9.1.451
	520	1.3.6.1.4.1.9.1.391
	525	1.3.6.1.4.1.9.1.392
	535	1.3.6.1.4.1.9.1.393

**Table 4 Cisco Security and VPN Devices**

<b>Series</b>	<b>Devices Supported</b>	<b>SysObjectID</b>
Cisco ASA 5500 Series Adaptive Security Appliances	5510	1.3.6.1.4.1.9.1.669
	5520	1.3.6.1.4.1.9.1.670
	5520sc	1.3.6.1.4.1.9.1.671
	5540	1.3.6.1.4.1.9.1.672
	5540sc	1.3.6.1.4.1.9.1.673
	5505	1.3.6.1.4.1.9.1.745
Cisco IDS 4200 Series Intrusion Detection System Sensors	4210	1.3.6.1.4.1.9.1.643
	4215	1.3.6.1.4.1.9.1.645
	4235	1.3.6.1.4.1.9.1.646
	4240	1.3.6.1.4.1.9.1.647
	4250	1.3.6.1.4.1.9.1.649
	4250SX	1.3.6.1.4.1.9.1.650
	4250XL	1.3.6.1.4.1.9.1.651
Cisco IPS 4200 Series Intrusion Prevention System Sensors	4255	1.3.6.1.4.1.9.1.652
Cisco VPN 3000 Series Concentrator	C3005	1.3.6.1.4.1.3076.1.2.1.1.2.1
	C3015	1.3.6.1.4.1.3076.1.2.1.1.1.2
	C3030	
	C3060	
	C3080	
	C3015	1.3.6.1.4.1.3076.1.2.1.1.1.1
	C3030	
	C3060	
C3080		
Cisco VPN 3002	VPN 3002 Hardware Client	1.3.6.1.4.1.3076.1.2.1.1.3.1

**Table 5**      **Voice and Unified Communications**

**Note** The ability to view and monitor Cisco Unified Communication devices depends upon the type of licensing you have. See the *Quick Start Guide for Cisco netManager* for licensing options.

Series/Application	Devices/Application Versions	SysObjectID
Cisco 7800 Series Media Convergence Servers	7815I	1.3.6.1.4.1.9.1.582
<b>Note</b> These media servers are supported only when running Cisco Unified Communications Manager or Cisco MeetingPlace Express or Cisco Unity.	7816H	1.3.6.1.4.1.9.1.900
	7816I	1.3.6.1.4.1.9.1.898
	7825H	1.3.6.1.4.1.9.1.583
	7825I	1.3.6.1.4.1.9.1.746
	7828H	1.3.6.1.4.1.9.1.901
	7828I	1.3.6.1.4.1.9.1.899
	MCS7835H	1.3.6.1.4.1.9.1.584
	MCS7835I	1.3.6.1.4.1.9.1.585
	MCS7845H	1.3.6.1.4.1.9.1.586
	MCS7845I	1.3.6.1.4.1.9.1.587
	Cisco Unified MeetingPlace Express	MPX
Cisco Unified Communications 500 Series for Small Business	UC-500	1.3.6.1.4.1.9.1.839
Cisco Unified Communications 520 for Small Business	UC520s8U4FXOK9	1.3.6.1.4.1.9.1.878
	UC520s8U4FXOWK9	1.3.6.1.4.1.9.1.879
	UC520s8U2BRIK9	1.3.6.1.4.1.9.1.880
	UC520s8U2BRIWK9	1.3.6.1.4.1.9.1.881
	UC520s16U4FXOK9	1.3.6.1.4.1.9.1.882
	UC520s16U4FXOWK9	1.3.6.1.4.1.9.1.883
	UC520s16U2BRIK9	1.3.6.1.4.1.9.1.884
	UC520s16U2BRIWK9	1.3.6.1.4.1.9.1.885
	UC520m32U8FXOK9	1.3.6.1.4.1.9.1.886
	UC520m32U8FXOWK9	1.3.6.1.4.1.9.1.888
	UC520m48U12FXOK9	1.3.6.1.4.1.9.1.890
	UC520m48U6BRIK9	1.3.6.1.4.1.9.1.892
	UC520m48U1T1E1FK9	1.3.6.1.4.1.9.1.894
UC520m48U1T1E1BK9	1.3.6.1.4.1.9.1.895	

**Table 5** Voice and Unified Communications (continued)

**Note** The ability to view and monitor Cisco Unified Communication devices depends upon the type of licensing you have. See the *Quick Start Guide for Cisco netManager* for licensing options.

Series/Application	Devices/Application Versions	SysObjectID
Cisco VG200 Gateway	VG200	1.3.6.1.4.1.9.1.279
	VG248	1.3.6.1.4.1.9.1.404
<b>Unified Communications Applications</b>		
Cisco Unified Communications Manager	4.x, 5.x, and 6.x	N/A
Cisco Unified Communications Manager Express	4.x	
Cisco Unified Contact Center Express Edition	4.6	
Cisco Unified MeetingPlace Express	2.0	
Cisco Unified Personal Communicator	2.0	
Cisco Unified Presence	2.0	
Cisco Unified Survivable Remote Site Telephony	5.x	
Cisco Unity	4.x, 5.x	
Cisco Unity Connection	1.x	
	<b>Note</b> Cisco Unity Connection 2.0 is not supported.	
Cisco Unity Express	2.x	
Cisco Unified Communications Manager Business Edition:		
• Cisco Unified Communications Manager	6.0	
• Cisco Unity Connection	2.0	

**Table 5**      **Voice and Unified Communications (continued)**

**Note** The ability to view and monitor Cisco Unified Communication devices depends upon the type of licensing you have. See the *Quick Start Guide for Cisco netManager* for licensing options.

Series/Application	Devices/Application Versions	SysObjectID
<b>IP Phones</b>		
	Cisco IP Communicator 2.1	N/A
	Cisco Telepresence Phone	
	Third Party Basic/Advanced SIP phones <b>Note</b> RFC 3261-compliant third party SIP phones configured as Basic or Advanced SIP in Unified Communications Manager	
Cisco Unified IP Phones 7900 Series	7902 7905 7910 7911 7912 7920 7931 7935 7936 7940 7941 7942 7945 7960 7961 7962 7965 7970 7971 7975 7985 7941GE 7961GE 7971GE	

**Table 6** *Cisco Wireless LAN Products*

<b>Series</b>	<b>Devices Supported</b>	<b>SysObjectID</b>
Cisco Aironet Access Point Series	350 IOS	1.3.6.1.4.1.9.1.552
	1100	1.3.6.1.4.1.9.1.507
	1130	1.3.6.1.4.1.9.1.618
	1200	1.3.6.1.4.1.9.1.474
	1210	1.3.6.1.4.1.9.1.525
	1240	1.3.6.1.4.1.9.1.685
Cisco Wireless LAN Controllers	440x	1.3.6.1.4.1.14179.1.1.4.3
	C2006	1.3.6.1.4.1.14179.1.1.4.2
	2106	1.3.6.1.4.1.9.1.828
	Integrated service router series 2800,3800 with Wireless LAN Controller Network Module	1.3.6.1.4.1.9.1.818