



INDEX

A

- AC power [2-7](#)
 - connecting to [3-2](#)
- ACS Appliance
 - context diagram [1-2](#)
 - hardware description [1-2](#)
 - system description [1-1](#)
- ACS Solution Engine
 - administering [4-1, B-1](#)
- add-guiadmin command [D-3](#)
- Administering Cisco Secure ACS Solution Engine [4-1](#)

B

- back panel
 - for Quanta (1113) version [1-5](#)
- backup command [D-3](#)

C

- Cabling [2-7](#)
- cabling
 - connecting a console [3-10](#)
 - connecting during installation [3-10](#)
- command reference [D-1](#)
 - CLI conventions [D-1](#)
 - command privileges [D-1](#)
 - syntax, checking [D-2](#)
 - system help [D-2](#)
- configuration
 - initial [3-10](#)
 - initial procedure [3-11](#)

- verifying [3-16](#)
- conventions
 - command line interface [D-1](#)
- creating a safe environment [2-7](#)
- CSAgent [4-25](#)

D

- dbpassword
 - set database password command [D-11](#)
- description
 - ACS Appliance [1-1](#)
- download command [D-4](#)

E

- electrostatic discharge, protecting against [2-5](#)
- Ethernet Connector [1-7](#)
- exit command [D-4](#)
- exportgroups command [D-5](#)

G

- GUI Administrator
 - adding [4-18](#)

H

- hard drive
 - for Quanta (1113) version [1-3, A-2](#)
- hardware description
 - for Quanta (1113) version [1-2](#)
- help

system, displaying [D-2](#)
 help command [D-6](#)
 hostname, setting [4-23](#)
 humidity, operating [A-1](#)

I

initial configuration [3-10](#)
 installation
 cables, connecting [3-10](#)
 installing in a rack [3-2](#)
 next steps [3-21](#)
 powering on WLSE [3-10](#)
 power source, connecting to [3-10](#)
 preparation [2-1](#)
 preparing for
 LAN options, precautions for [2-8](#)
 modems, precautions for [2-8](#)
 telecommunications, precautions for [2-8](#)
 IP address
 reconfiguring [4-20](#)

L

LAN options, precautions for [2-8](#)
 logging off [4-3](#)
 logging on [4-2](#)
 login credentials, characteristics [4-25](#)
 logs, obtaining support [4-9](#)

M

migrating from Windows [B-20](#)
 modems, precautions for [2-8](#)

N

network, setting up [2-9](#)

NIC, connecting cables [3-10](#)
 ntpsync command [D-7](#)

P

password
 recovering from loss of [4-25](#)
 resetting [4-17, 4-18](#)
 set password command [D-13](#)
 patch
 overview [B-13](#)
 process [B-15](#)
 powering on the WLSE [3-10](#)
 precautions for rack-mounting [2-8](#)

R

rack-mounting
 procedure for [3-2](#)
 rack-mounting, precautions for [2-8](#)
 rebooting [4-3](#)
 recovery
 CD ROM [4-25](#)
 password [4-25](#)
 recovery management [4-25](#)
 re-imaging hard drive [4-27](#)
 restart command [D-9](#)

S

safety
 electrostatic discharge [2-5](#)
 general precautions [2-4](#)
 installation [2-6](#)
 preventing EMI [2-5](#)
 warnings and cautions [2-1](#)
 with electricity [2-4](#)
 serial console connection [3-10](#)

Services, stopping system [4-4](#)
 set admin command [D-11](#)
 set dbpasswd command [D-12](#)
 set domain command [D-12](#)
 set hostname command [D-12](#)
 set ip command [D-12](#)
 set passwd command [D-13](#)
 set timeout command [D-14](#)
 show command [D-14](#)
 shutdown command [D-14](#)
 shutting down [4-2](#)
 specifications, technical [A-1](#)
 start command [D-15](#)
 starting, system services [4-5](#)
 Status, determining system [4-3](#)
 stop command [D-15](#)
 support command [D-16](#)
 support tool [4-9](#)
 syntax of commands, checking [D-2](#)
 system administration [4-1](#)
 system domain, setting [4-23](#)

T

technical specifications [A-1](#)
 telecommunications, precautions for [2-8](#)
 temperature, operating [A-1](#)
 time and date, setting [4-21](#)
 Time and Date, setting with NTP [4-22](#)
 timeout, setting manually [4-21](#)
 turning on the WLSE [3-10](#)

U

upgrade
 applying [B-18](#)
 distribution server requirements [B-14](#)
 overview [B-13](#)

 process [B-15](#)
 transferring [B-16](#)
 upgrade command [D-18](#)
 upgrading the ACS Appliance [B-1](#)

W

warnings
 AC power disconnection [2-2](#)
 battery handling [2-3](#)
 circuit breaker [2-2](#)
 comply with electrical codes [2-3](#)
 definition [2-2](#)
 equipment installations [2-3](#)
 faceplates and cover panels [2-3](#)
 ground conductor [2-3](#)
 installation [2-2](#)
 lightning activity [2-2](#)
 main disconnecting device [2-3](#)
 more than one power supply [2-3](#)
 product disposal [2-3](#)
 regarding
 ground conductor, defeating [2-6](#)
 installation area [2-6](#)
 lightning activity [3-10](#)
 short circuits [2-7](#)
 restricted area [2-3](#)
 SELV circuit [2-3](#)
 TN power [2-2](#)
 translations of [2-1](#)
 Windows, migrating from [B-20](#)
 Windows services [C-1](#)

