



## APPENDIX **O**

# Deployment User Interface Reference

---

The following topics describe the windows and dialog boxes that are related to configuration deployment:

- [Deployment Manager Window \(Non-Workflow Mode\)](#), page O-1
- [Deployment Manager Window \(Workflow Mode\)](#), page O-4
- [Deployment Schedules Tab, Deployment Manager](#), page O-9
- [Deployment Job Dialog Boxes](#), page O-12
- [Configuration Archive Window](#), page O-37

## Deployment Manager Window (Non-Workflow Mode)

Use the Deployment Manager window to manage deployment jobs and schedules. You can display a list of deployment jobs, view job details, deploy and redeploy configurations to devices, abort deployment jobs, roll back to previous configurations on selected devices, and create schedules to automatically generate deployment jobs.

### Navigation Path

Click the **Deployment Manager** button on the Main toolbar or select **Tools > Deployment Manager**.

**Related Topics**

- [Viewing Deployment Status and History for Jobs and Schedules, page 19-30](#)
- [Deploying Configurations in Non-Workflow Mode, page 19-32](#)
- [Previewing Configurations, page 19-43](#)
- [Redeploying Configurations to Devices, page 19-43](#)
- [Aborting Deployment Jobs, page 19-45](#)
- [Rolling Back Configurations to Devices Using the Deployment Manager, page 19-58](#)
- [Creating or Editing Deployment Schedules, page 19-46](#)
- [Suspending or Resuming Deployment Schedules, page 19-47](#)

**Field Reference****Table O-1** Deployment Manager Window (Non-Workflow Mode)

Element	Description
<b>Deployment Job Tab</b>	This tab shows individual deployment jobs. Select a job in the upper pane to view its details in the tabs in the lower pane.
Name	The name of the job.
Last Action	The date and time that the job or status was changed based on the time zone of the server, not the time zone of the client.
Status	The state of each job. For a description of the states, see <a href="#">Job States in Non-Workflow Mode, page 19-5</a> .
Changed By	The name of the user who modified the job.
Description	The description of the job. Double-click the icon to see the description.
Type	The type of job with respect to scheduling. A <b>one time</b> job was not created from a regularly recurring job, whereas a <b>recurring</b> job was.
Deploy button	Click this button to deploy the generated CLI commands to the selected devices or files. The Deploy Saved Changes dialog box opens (see <a href="#">Deploy Saved Changes Dialog Box, page O-13</a> ).

**Table O-1**      **Deployment Manager Window (Non-Workflow Mode) (Continued)**

Refresh button	<p>Click this button to reload job information from the Security Manager server. If the message <i>Auto Refresh is On</i> is displayed below the table, the job list is automatically refreshed periodically.</p> <p><b>Note</b>    The auto refresh setting is configured in the administration settings for deployment. To change settings, select <b>Tools &gt; Security Manager Administration &gt; Deployment</b>.</p>
Redeploy button	Click this button to redeploy the selected job, which deploys the generated CLI commands to the selected devices or files. The Redeploy Job dialog box opens (see <a href="#">Redeploy a Job Dialog Box, page O-31</a> ).
Abort button	Click this button to abort the selected job if it is in the Deploying state. The Abort Deployment Job dialog box opens (see <a href="#">Abort the Job Dialog Box, page O-30</a> ).
Rollback button	Click this button to roll back the configuration of devices in the job to the previous configuration. The Deployment Rollback dialog box opens (see <a href="#">Rollback a Job Dialog Box, page O-33</a> ).
<b>Summary tab</b>	Displays summary information about the status of the selected deployment job, such as the status of the job, the name of the deployment job, the number of devices included in the job, the number of devices deployed successfully, and number of device deployed with errors.

**Table O-1** Deployment Manager Window (Non-Workflow Mode) (Continued)

<b>Details tab</b>	<p>Displays detailed information for the selected job. The table lists each device included in the job, whether deployment succeeded or failed, and a summary of the number of warnings, errors, or failures for the device. Select a device in the table to view the results for that device:</p> <ul style="list-style-type: none"> <li>• Double-click the icon in the Config column to view the configuration (see <a href="#">Config Version Viewer (Preview Configuration) Dialog Box, page O-24</a>). If you deleted the device from the inventory, the configuration and transcript might not be available.</li> <li>• If you were deploying to the device, double-click the icon in the Transcripts column to view a transcript of the commands sent to the device and the device's responses.</li> <li>• When you select a device, the Messages box in the lower left contains a summary of the messages generated for the deployment. Select an item to view its description to the right. You might have to enlarge the window to make the Description box visible. If applicable, there might also be information on the actions you can take to resolve the problems.</li> </ul>
<b>Deployment Schedules tab</b>	<p>Use this tab to schedule regular deployment jobs. For detailed information about this tab, see <a href="#">Deployment Schedules Tab, Deployment Manager, page O-9</a>.</p>

## Deployment Manager Window (Workflow Mode)

Use the Deployment Manager window to manage deployment jobs and schedules. You can display a list of deployment jobs, view job details, deploy and redeploy configurations to devices, abort deployment jobs, roll back to previous configurations on selected devices, and create schedules to automatically generate deployment jobs. You can also track changes made to deployment jobs and schedules.

### Navigation Path

Click the **Deployment Manager** button on the Main toolbar or select **Tools > Deployment Manager**.

**Related Topics**

- [Viewing Deployment Status and History for Jobs and Schedules](#), page 19-30
- [Deploying Configurations in Workflow Mode](#), page 19-34
- [Creating and Editing Deployment Jobs](#), page 19-36
- [Submitting Deployment Jobs](#), page 19-39
- [Approving and Rejecting Deployment Jobs](#), page 19-39
- [Deploying a Deployment Job in Workflow Mode](#), page 19-41
- [Discarding Deployment Jobs](#), page 19-42
- [Previewing Configurations](#), page 19-43
- [Redeploying Configurations to Devices](#), page 19-43
- [Aborting Deployment Jobs](#), page 19-45
- [Rolling Back Configurations to Devices Using the Deployment Manager](#), page 19-58

**Field Reference****Table O-2** *Deployment Manager Window (Workflow Mode)*

<b>Element</b>	<b>Description</b>
<b>Deployment Job Tab</b>	This tab shows individual deployment jobs. Select a job in the upper pane to view its details in the tabs in the lower pane.
Name	The name of the job.
Last Action	The date and time that the job or status was changed based on the time zone of the server, not the time zone of the client.
Status	The state of each job. For a description of the states, see <a href="#">Job States in Workflow Mode</a> , page 19-7.
Changed By	The name of the user who modified the job.
Description	The description of the job. Double-click the icon to see the description.
Create button	Click this button to create a new job. The Create a Job dialog box opens (see <a href="#">Deployment—Create or Edit a Job Dialog Box</a> , page O-15).

Table O-2 Deployment Manager Window (Workflow Mode) (Continued)

Element	Description
Open button	Click this button to open the selected job. The Edit a Job dialog box opens (see <a href="#">Deployment—Create or Edit a Job Dialog Box</a> , page O-15).
Close button	Click this button to close and save all changes made while the selected job was open. You can close a job when it is in the Edit Open or the Submit Open state. Normally, you do not need to close a job, because you will typically submit, approve, deploy, or schedule the job for deployment. However, if the Security Manager server is suddenly unavailable or your login session times out, a job might be left in the Edit Open state. If this happens, you can close it manually by selecting it and clicking Close.
Submit button	<p>Click this button to submit the selected job for approval. You can submit a job when it is in the Edit or the Edit Open state. The Submit Deployment Job dialog box opens (see <a href="#">Submit Deployment Job Dialog Box</a>, page O-25).</p> <p>This button is active only if you are using Workflow mode with a deployment job approver.</p>
Reject button	<p>Click this button to reject the selected job if you are not satisfied with the configurations generated for the devices. You can reject jobs only in workflow mode with a deployment job approver. After a job is rejected, it can be opened for editing or discarded.</p> <p>You are prompted to enter an optional comment to explain why you are rejecting the job.</p>
Approve button	<p>Click this button to approve the selected job. After a job is approved, it can be deployed.</p> <p>You are prompted to enter an optional comment to explain why you are approving the job.</p>

Table O-2 Deployment Manager Window (Workflow Mode) (Continued)

Element	Description
Discard button	<p>Click this button to discard the selected job. You can discard a job when it is in any state except Deployed, Deployment Failed, or Aborted. Once discarded, the job cannot be edited, submitted, approved, or deployed. The job state is shown as discarded until the job is purged from the system either automatically as set on the Workflow settings page or manually (for more information, see <a href="#">Workflow Page, page A-56</a>).</p> <p>You are prompted to enter an optional comment to explain why you are discarding the job.</p>
Refresh button	<p>Click this button to reload job information from the Security Manager server. If the message <i>Auto Refresh is On</i> is displayed beneath the table, the job list is automatically refreshed periodically.</p> <p><b>Note</b> The auto refresh setting is configured in the administration settings for deployment: select <b>Tools &gt; Security Manager Administration &gt; Deployment</b>.</p>
Deploy button	<p>Click this button to deploy the job, which deploys the generated CLI commands to the selected devices or files.</p> <p>If the job is in the Approved state, the Deploy Job dialog box opens (see <a href="#">Deploy Job Dialog Box, page O-27</a>).</p> <p>If the job is in the deployed, failed, or aborted state then the Redeploy Job dialog box opens (see <a href="#">Redeploy a Job Dialog Box, page O-31</a>).</p>
Abort button	<p>Click this button to abort the selected job if it is in the Deploying state. A warning asks you to confirm the action.</p>
Rollback button	<p>Click this button to deploy the previously deployed configuration to the devices in the selected job. The Deployment Rollback dialog box opens (see <a href="#">Rollback a Job Dialog Box, page O-33</a>).</p>
<b>Summary tab</b>	<p>Displays summary information about the status of the selected deployment job, such as the status of the job, the name of the deployment job, the number of devices included in the job, the number of devices deployed successfully, and the number of devices deployed with errors.</p>

Table O-2 Deployment Manager Window (Workflow Mode) (Continued)

Element	Description
<b>Details tab</b>	<p>Displays detailed information for the selected job. The table lists each device included in the job, whether deployment succeeded or failed, and a summary of the number of warnings, errors, or failures for the device. Select a device in the table to view the results for that device:</p> <ul style="list-style-type: none"> <li>• Double-click the icon in the Config column to view the configuration (see <a href="#">Config Version Viewer (Preview Configuration) Dialog Box, page O-24</a>). If you deleted the device from the inventory, the configuration and transcript might not be available.</li> <li>• If you were deploying to the device, double-click the icon in the Transcripts column to view a transcript of the commands sent to the device and the device's responses.</li> <li>• When you select a device, the Messages box in the lower left contains a summary of the messages generated for the deployment. Select an item to view its description to the right. You might have to enlarge the window to make the Description box visible. If applicable, there might also be information on the actions you can take to resolve the problems.</li> </ul>
<b>History tab</b>	<p>Displays a log of the changes that have been made to the selected job. The information includes the state changes, the user who made the change, the date and time of the change (based on the Security Manager server time), and any comments the user entered to document the change.</p>
<b>Deployment Schedules Tab</b>	<p>Use this tab to schedule regular deployment jobs. For detailed information about this tab, see <a href="#">Deployment Schedules Tab, Deployment Manager, page O-9</a>.</p>

# Deployment Schedules Tab, Deployment Manager

Use the Deployment Schedules tab on the Deployment Manager window to create regularly recurring deployment jobs. Whenever the scheduled deployment time occurs, Security Manager creates a specific deployment job based on the scheduled job.

## Navigation Path

Click the **Deployment Manager** button on the Main toolbar or select **Tools > Deployment Manager**, and then click the **Deployment Schedules** tab in the upper pane.

## Related Topics

- [Creating or Editing Deployment Schedules, page 19-46](#)
- [Suspending or Resuming Deployment Schedules, page 19-47](#)

## Field Reference

**Table O-3** *Deployment Schedules Tab, Deployment Manager Window*

Element	Description
<b>Deployment Schedule Table</b>	This table shows deployment job schedules. Select a schedule in the table to view its details in the tabs in the lower pane.
Name	Name of the job schedule. Jobs created from this schedule use this name plus a time stamp.
Status	The status of the schedule: Whether the schedule is active, suspended, or discarded. Jobs are created only for active schedules. <ul style="list-style-type: none"> <li>• <b>Edit</b>—In Workflow mode, the schedule is being created. You can open it and change its settings.</li> <li>• <b>Active</b>—Deployment jobs will be created according to this schedule.</li> <li>• <b>Suspended</b>—The schedule was suspended and no jobs are being created by it. You can restart the schedule by selecting it and clicking <b>Resume</b>.</li> <li>• <b>Discarded</b>—In Workflow mode, the schedule was deleted. It remains in the table, but you cannot restart or edit it.</li> </ul>

**Table O-3** *Deployment Schedules Tab, Deployment Manager Window (Continued)*

Recurrence	How often deployment jobs will be created from this schedule.
Next Run	The date and time a deployment job will next be created from this schedule.
Last Run	The date and time of the most recent deployment job created from this schedule.
Description	The description of the job schedule. Double-click the icon to see the description.
Create button	Click this button to create a deployment job schedule. The Schedule dialog box opens where you can create the schedule (see <a href="#">Schedule Dialog Box, page O-35</a> ).
Open button	Click this button to open the selected schedule. The Schedule dialog box opens where you can view or modify the schedule (see <a href="#">Schedule Dialog Box, page O-35</a> ). Modifying the schedule does not change its status.  In Workflow mode, you can open a schedule only if it is in the Edit state.
Close button (Workflow mode only)	Click this button to close and save all changes made while the schedule was open. You can close a schedule when it is in the Edit Open or the Submit Open state. Typically, you will have to close schedules only if the Security Manager server becomes unavailable while you have a schedule open.
Submit button (Workflow mode only)	Click this button to submit the selected schedule for approval if you are operating in Workflow mode with an approver. You can submit a schedule when it is in the Edit or the Edit Open state. You are prompted for an optional comment to explain the submission, and an e-mail is generated to the approver in Workflow mode.
Reject button (Workflow mode only)	Click this button to reject the selected schedule. You are prompted for an optional comment to explain the rejection, and an e-mail is generated to the approver and submitter in Workflow mode.
Approve button (Workflow mode only)	Click this button to approve the selected schedule. You are prompted for an optional comment to explain the approval, and an e-mail is generated to the approver and submitter in Workflow mode.

**Table O-3** Deployment Schedules Tab, Deployment Manager Window (Continued)

<p>Discard button (Workflow mode only)</p>	<p>Click this button to discard the selected schedule. You can discard a schedule when it is in any state except Active. You are prompted for an optional comment to explain the discard, and an e-mail is generated to the approver and submitter in Workflow mode.</p> <p>The schedule state is shown as Discarded until the schedule is purged from the system. The schedule is purged either automatically as set on the Workflow page (select <b>Tools &gt; Security Manager Administration &gt; Workflow</b>) or manually (by clicking <b>Purge</b> on the Workflow page).</p>
<p>Refresh button</p>	<p>Click this button to reload schedule information from the Security Manager server. If the message <i>Auto Refresh is On</i> is displayed beneath the table, the schedule list is automatically refreshed periodically.</p> <p><b>Note</b> The auto refresh setting is configured in the administration settings for deployment. To change settings, select <b>Tools &gt; Security Manager Administration &gt; Deployment</b>.</p>
<p>Suspend button</p>	<p>Click this button to suspend the selected schedule. Suspending the schedule does not delete the schedule, but it prevents the creation of deployment jobs based on it. You are prompted for a comment to explain the suspension, and an e-mail is generated to the approver in Workflow mode.</p>
<p>Resume button</p>	<p>Click this button to reactivate a suspended schedule. You are prompted for a comment to explain the suspension, and an e-mail is generated to the approver in Workflow mode.</p>
<p><b>Summary tab</b></p>	<p>Displays summary information about the selected schedule. Besides the fields shown in the table, summary information includes the number of devices included in the schedule and the user ID of the person who last changed the schedule.</p>
<p><b>Devices tab</b></p>	<p>Displays the devices that are included in the selected schedule. These are the devices to which configurations are deployed when a deployment job is created from the schedule. To change the device list, click <b>Open</b>, then click <b>Add Devices</b> on the Schedule dialog box.</p>

**Table O-3** *Deployment Schedules Tab, Deployment Manager Window (Continued)*

<b>History tab</b>	Displays a log of the changes that have been made to the selected schedule. The information includes the state changes, the user who made the change, the date and time of the change (based on the Security Manager server time), and any comments the user entered to document the change.
<b>Jobs tab</b>	<p>Displays a list of the deployment jobs that have been created based on the selected schedule. Information includes the name of the job, the date and time the job was created based on server time (not the client time), and the job status. If you select a job, and click the <b>Deployment Job</b> tab, the selected job is highlighted and you can view the job details.</p> <p>For information on job status, see these topics:</p> <ul style="list-style-type: none"> <li>• <a href="#">Job States in Workflow Mode, page 19-7</a></li> <li>• <a href="#">Job States in Non-Workflow Mode, page 19-5</a></li> </ul>

## Deployment Job Dialog Boxes

The following topics provide details about the dialog boxes used when you create or deploy deployment jobs or schedules:

- [Deploy Saved Changes Dialog Box, page O-13](#)
- [Deployment—Create or Edit a Job Dialog Box, page O-15](#)
- [Edit Deploy Method Dialog Box, page O-19](#)
- [Add Other Devices Dialog Box, page O-21](#)
- [Warning - Partial VPN Deployment Dialog Box, page O-22](#)
- [Config Version Viewer \(Preview Configuration\) Dialog Box, page O-24](#)
- [Submit Deployment Job Dialog Box, page O-25](#)
- [Deployment Workflow Commentary Dialog Box, page O-26](#)
- [Deploy Job Dialog Box, page O-27](#)
- [Deployment Status Details Dialog Box, page O-28](#)
- [Abort the Job Dialog Box, page O-30](#)

- [Redeploy a Job Dialog Box, page O-31](#)
- [Rollback a Job Dialog Box, page O-33](#)
- [Schedule Dialog Box, page O-35](#)

## Deploy Saved Changes Dialog Box

Use the Deploy Saved Changes dialog box in non-Workflow mode to select specific devices for deployment.



### Caution

---

You must configure at least one policy on a device before deploying to that device. If you deploy to a device without assigning at least one policy, the device's current configuration is overwritten with a blank configuration.

---

### Navigation Path

Do one of the following in non-Workflow mode:

- Select **File > Submit and Deploy** or click the Submit and Deploy Changes button on the toolbar.
- Select **File > Deploy**.
- Click the **Deployment Manager** button on the Main toolbar and click the **Deployment Jobs** tab if it is not active. Click **Deploy**.

Security Manager validates all of the policy changes that were made since the last deployment. If the validation results in errors, either click **Cancel** and resolve the errors before attempting to deploy again or click **OK** to proceed to the Deploy Saved Changes dialog box.

### Related Topics

- [Deploying Configurations in Non-Workflow Mode, page 19-32](#)
- [Previewing Configurations, page 19-43](#)
- [Job States in Non-Workflow Mode, page 19-5](#)

## Field Reference

Table O-4 Deploy Saved Changes Dialog Box

Element	Description
Device Selector	<p>The device selector lists all devices for which policy changes were made but not yet deployed. By default, all changed devices are selected for the deployment job. To remove devices from the deployment job, deselect the check box for the device.</p> <p>To preview the configuration for a device, right-click the device and select <b>Preview Config</b>.</p> <p>Also consider the following:</p> <ul style="list-style-type: none"> <li>• If you select a subset of devices that are part of a VPN and click <b>OK</b>, a warning appears. See <a href="#">Warning - Partial VPN Deployment Dialog Box, page O-22</a>.</li> <li>• You cannot select devices that were included in other deployment jobs that are in an active state (Edit, Edit Open, and Approved). You can select devices that were included in other deployment jobs that are in the Deployed, Failed, Discarded, or Aborted states.</li> <li>• In Catalyst 6500/7600 devices, Firewall service modules (FWSMs) and Intrusion Detection System service modules (IDSMS) contain virtual devices. Security Manager considers the module and the virtual devices to be separate devices.</li> <li>• Some changes to the FWSM might require the Catalyst 6500/7600 Multiservice function card (MSFC) to be updated as well. If you select an FWSM that has these types of changes, Security Manager notifies you that you must include the MSFC in the deployment job, and it will select the MSFC device for you automatically. However, if the MSFC is already included in another active deployment job, you cannot include the MSFC in the current deployment job. You must remove the MSFC from the other deployment job, discard the other deployment job, or include the FWSM in the other deployment job.</li> </ul>

**Table O-4**      **Deploy Saved Changes Dialog Box (Continued)**

Edit deploy method button	Click this button to change the deployment method for the devices in the job (that is, whether you are deploying the configuration to the device or to a configuration file). The Edit Deploy Method dialog box opens (see <a href="#">Edit Deploy Method Dialog Box, page O-19</a> ).
Add other devices button	Click this button to add devices whose configurations have not changed to the deployment job. The Add Other Devices dialog box opens (see <a href="#">Add Other Devices Dialog Box, page O-21</a> ).
Deploy button	Click this button to start the deployment job for the selected devices, which generates the required configuration files and applies them according to your selected deployment method. The Deployment Status Details dialog box opens to display the status of the job (see <a href="#">Deployment Status Details Dialog Box, page O-28</a> ).

## Deployment—Create or Edit a Job Dialog Box

Use the Deployment—Create a Job or Edit a Job dialog boxes to create or edit a deployment job in Workflow mode. Deployment jobs are used to deploy your policy configurations to the devices.

### Navigation Path

Do one of the following from the Deployment Jobs tab on the Deployment Manager window.

- Click **Create** to create a new job.
- Select an editable job and click **Open**.

### Related Topics

- [Creating and Editing Deployment Jobs, page 19-36](#)
- [Working with Deployment and the Configuration Archive, page 19-29](#)
- [Job States in Workflow Mode, page 19-7](#)
- [Deployment Manager Window \(Workflow Mode\), page O-4](#)

## Field Reference

**Table O-5** Create a Job Dialog Box

Element	Description
<b>Job Name and Description</b>	
Name	The name for the deployment job. Each job must have a unique name. Because the job name enables you to distinguish one job from another, you should assign a name that reflects the contents of the job.  You cannot change the name when editing a job.
Description	(Optional) A description for the deployment job.  You cannot change the description when editing a job.

Table O-5 Create a Job Dialog Box (Continued)

Select Devices	
Device Selector	<p>All devices on which policy changes were made but were not yet deployed. Select the check box next to the device to include in the deployment job. By default, all devices with policy changes are selected. You can deselect any of the selected devices if you do not want them included in the current job.</p> <p><b>Note</b> Modifying a subset of devices that are part of a VPN might make the VPN inoperable. If you select a subset of devices that are part of a VPN, then click <b>OK</b>, you will get a warning. See <a href="#">Warning - Partial VPN Deployment Dialog Box, page O-22</a>.</p> <p>Also consider the following:</p> <ul style="list-style-type: none"><li>• You cannot select devices that were included in other deployment jobs that are in an active state (Edit, Edit Open, Submitted, Submitted Open, Approved, or Rejected). You can select devices that were included in other deployment jobs that are in the Deployed, Failed, Discarded, or Aborted states.</li><li>• In Catalyst 6500/7600 devices, Firewall service modules (FWSMs) and Intrusion Detection System service modules (IDSMS) contain virtual devices. Security Manager considers the module and the virtual devices to be separate devices.</li><li>• Some changes to the FWSM might require the Catalyst 6500/7600 Multiservice function card (MSFC) to be updated as well. If you select an FWSM that has these types of changes, Security Manager notifies you that you must include the MSFC in the deployment job, and it selects the MSFC device for you. However, if the MSFC is already included in another active deployment job, you cannot include the MSFC in the current deployment job. You must remove the MSFC from the other deployment job, discard the other deployment job, or include the FWSM in the other deployment job.</li></ul>

**Table O-5 Create a Job Dialog Box (Continued)**

Edit deploy method button	Click this button to change the deployment method for the devices in the job (that is, whether you are deploying the configuration to the device or to a configuration file). The Edit Deploy Method dialog box opens (see <a href="#">Edit Deploy Method Dialog Box, page O-19</a> ).
Add other devices button	Click this button to add devices whose configurations have not changed to the deployment job. The Add Other Devices dialog box opens (see <a href="#">Add Other Devices Dialog Box, page O-21</a> ).
<b>Job State—Fields displayed when workflow is turned on without an approver.</b>	
Close the job	Saves the job so that you can make additional changes later.
Approve the job	Saves and simultaneously approves the job, which you can deploy later. These fields appear if you select this option: <ul style="list-style-type: none"> <li>• Comments—Comments about the job approval.</li> <li>• Submitter—The e-mail address of the person submitting the job for approval. Notifications of job state changes are sent to this address, which is initially the e-mail address associated with the user account you used to log into Security Manager.</li> </ul>

**Table O-5** Create a Job Dialog Box (Continued)

Deploy the job	<p>Saves and simultaneously approves and deploys the job. These fields appear if you select this option:</p> <ul style="list-style-type: none"> <li>• <b>Options</b>—Whether to Deploy Now or Schedule. If you select Schedule, additional fields appear where you can specify the date and time when the job should be run. The time is in 24-hour format and is based on the time zone of the Security Manager server, which is not necessarily the same time zone that you are currently in. The target time must be at least five minutes in the future.</li> <li>• <b>Comments</b>—Comments about the deployment job.</li> <li>• <b>Send Deployment Status Notification</b>—Whether Security Manager should send e-mail notifications whenever the job status changes.</li> </ul> <p>If you select this option, enter the e-mail addresses of the people who should receive notifications in the Job Completion Recipients field. If you enter multiple addresses, separate them with commas. The field initially contains the default approver and your e-mail addresses.</p>
<b>Job State—Fields displayed when workflow is turned on with an approver.</b>	
Submit the job	Whether to submit the job for approval. By default this check box is selected.
Approver E-mail	The e-mail address of the approver if you are submitting the job for approval. The default approver e-mail address is entered in the field, but you can change it.
Comments	Comments you want to send to the approver, if any.
Submitter E-mail	The e-mail address of the submitter. The field initially contains the e-mail address associated with the user account you used to log in, but you can change it to another address.

## Edit Deploy Method Dialog Box

Use the Edit Deploy Method dialog box to specify whether to deploy the generated configurations directly to the devices in the network or to create configuration files in a directory on the Security Manager server.

**Navigation Path**

Click **Edit Deploy Method** in the Create or Edit a Job (Workflow mode) or Deploy Saved Changes (non-Workflow mode) dialog boxes.

**Related Topics**

- [Understanding Deployment Methods, page 19-11](#)
- [Creating and Editing Deployment Jobs, page 19-36](#)
- [Deploying Configurations in Non-Workflow Mode, page 19-32](#)
- [Deployment—Create or Edit a Job Dialog Box, page O-15](#)
- [Deploy Saved Changes Dialog Box, page O-13](#)

**Field Reference**

**Table O-6** *Edit Deploy Method Dialog Box*

Element	Description
Device	The name of the device.
Method	<p>The deployment method to use:</p> <ul style="list-style-type: none"> <li>• <b>Device</b>—Deploys the configuration directly to the device or to the transport mechanism specified for the device. For more information, see <a href="#">Deploying to a Device, page 19-11</a>.</li> <li>• <b>File</b>—Deploys the configuration file to a directory on the Security Manager server. If you select File, specify the directory to which you want to deploy the configuration file in the Destination column. For more information, see <a href="#">Deploying to a File, page 19-14</a>.</li> </ul> <p><b>Note</b> To set the deployment method for more than one device at a time, select the desired rows, right-click and select <b>Edit Selected Deploy Method</b>. The Edit Selected Deploy Method dialog box opens where you can make your selections.</p>
Destination	If you selected File in the Method field, enter the directory to which you want to deploy the configuration file. Click <b>Browse</b> to select from a list of available directories.

**Table O-6**      **Edit Deploy Method Dialog Box (Continued)**

Preview Config button	Click this button to display the proposed configuration changes for the selected device. You can compare it to the last deployed configuration or the current running configuration. For more information, see <a href="#">Config Version Viewer (Preview Configuration) Dialog Box, page O-24</a> .
Out of Bound Change Behavior	<p>Click the radio button corresponding to the action you want Security Manager to take regarding changes made directly on the device using the CLI:</p> <ul style="list-style-type: none"> <li>• Overwrite changes and show warning—When configurations are deployed, Security Manager uploads the device’s current configuration and compares it against the configuration it has in its database. If changes were made to the device manually, Security Manager continues with the deployment and displays a warning notifying you of this action.</li> <li>• Cancel deployment—When configurations are deployed, Security Manager uploads the device’s current configuration and compares it against the configuration it has in its database. If changes were made to the device manually, Security Manager cancels the deployment and displays a warning notifying you of this action.</li> <li>• Do not check for changes—Security Manager does not check for changes and deploys the changes to the device.</li> </ul> <p>The default is set under Tools &gt; Security Manager Administration &gt; Deployment.</p>

## Add Other Devices Dialog Box

Use the Add Other Devices dialog box to select devices for the deployment job or schedule. The devices in the list might not have active policy changes. When you are creating a job, you might want to add devices that do not have policy changes if a device was manually modified and you want to return the device to its previous configuration (the configuration stored in the Security Manager database).

**Navigation Path**

To open this dialog box, do one of the following:

- From the Create or Edit a Job dialog boxes, click **Add other devices**.
- From the Deploy Saved Changes dialog box, click **Add other devices**.
- From the Schedule dialog box, click **Add devices**.

**Related Topics**

- [Deployment—Create or Edit a Job Dialog Box, page O-15](#)
- [Creating and Editing Deployment Jobs, page 19-36](#)
- [Including Devices in Deployment Jobs or Schedules, page 19-10](#)
- [Deploy Saved Changes Dialog Box, page O-13](#)
- [Deploying Configurations in Non-Workflow Mode, page 19-32](#)
- [Creating or Editing Deployment Schedules, page 19-46](#)
- [Deploying Configurations in Non-Workflow Mode, page 19-32](#)

**Field Reference**

**Table O-7**      *Add Other Devices Dialog Box*

Element	Description
Available Devices	<p>The list of all devices in the inventory whether or not they contain proposed policy changes. Select the devices to include in the job or schedule and click &gt;&gt; to move the devices to the Selected Devices field.</p> <p>You can display a subset of devices based on the filtering criteria you define. For more information, see <a href="#">Filtering Items in Selectors, page 3-20</a>.</p>
Selected Devices	<p>The list of devices you selected for inclusion in the job or schedule. To remove devices, select them and click &lt;&lt;.</p>

## Warning - Partial VPN Deployment Dialog Box

Use the Partial VPN Deployment dialog box to select other devices that are part of a VPN to which you are deploying configurations.

When you create a deployment job and the job contains devices in a VPN, you must select all of the devices in the VPN. If you select a subset of devices and try to deploy to only those devices, this dialog box appears so that you can select the other devices that are part of the VPN.

### Navigation Path

- Workflow mode—If you select a subset of devices in a VPN in the Create or Edit a Job dialog box, this dialog box appears when you click **OK**.
- Non-Workflow mode—If you select a subset of devices in a VPN in the Deploy Saved Changes dialog box, this dialog box appears when you click **Deploy**.

### Related Topics

- [Deployment—Create or Edit a Job Dialog Box, page O-15](#)
- [Creating and Editing Deployment Jobs, page 19-36](#)
- [Deploy Saved Changes Dialog Box, page O-13](#)
- [Deploying Configurations in Non-Workflow Mode, page 19-32](#)

### Field Reference

**Table O-8** *Partial VPN Deployment Warning Dialog Box*

Element	Description
VPN	The name of the VPN.
Missing Devices	All the devices in the VPN that were not selected for deployment.
Is Device in Other Job	Whether the missing device is part of another deployment job.
Deploy to All Devices in VPN button	Click this button to deploy to all devices in the VPN. You can deploy to all devices in the VPN only if the devices are not in other deployment jobs.
Deploy to Selected Devices button	Click this button to deploy only to the devices selected in the Create or Edit a Job or Deploy Saved Changes dialog boxes.

## Config Version Viewer (Preview Configuration) Dialog Box

Use the Config Version Viewer dialog box to display the proposed changes, last deployed configuration, or current running configuration for a device.

If you preview the configuration for a virtual sensor, the preview that you see is for the parent device, not the virtual sensor, because the configuration for a virtual sensor is stored on the parent device.



### Note

---

Before opening the Config Version Viewer dialog box, Security Manager validates the configuration. If any errors or warnings occur, the Preview Messages dialog box appears. The dialog box lists all of the messages, including their severity and possible solutions. Click **OK** to continue to the Config Version Viewer dialog box.

---

### Navigation Path

There are many ways to preview a configuration. You can select a device from the Device selector and select **Tools > Preview Configuration**, or you can click the **Preview Config** button in several dialog boxes. For more information on previewing configurations, see [Previewing Configurations, page 19-43](#).

### Related Topics

- [Previewing Configurations, page 19-43](#)

## Field Reference

**Table O-9** *Config Version Viewer (Preview Configuration) Dialog Box*

Element	Description
Proposed Config Type	The type of configuration you want to view. For example, you can view the full configuration or just the delta (the changes from the last deployed configuration). The proposed configuration is displayed in the left pane.
Compare to Version	Choose a configuration to compare against the proposed configuration. The selected configuration is displayed in the right pane. <ul style="list-style-type: none"> <li>• None—Leaves the reference configuration blank.</li> <li>• Last Deployed—Displays the last configuration that was deployed to the device and compares it with the proposed configuration.</li> <li>• Running Config—Displays the current configuration running on the device and compares it with the proposed configuration. The device must be accessible to obtain the running configuration.</li> </ul>
First Difference button	Moves the cursor to the first difference noted between the proposed and reference configurations.
Previous Difference button	Moves the cursor to the previous difference noted between the proposed and reference configurations.
Current Difference button	Centers the currently selected difference on the page.
Next Difference button	Moves the cursor to the next difference noted between the proposed and reference configurations.
Last Difference button	Moves the cursor to the last difference noted between the proposed and reference configurations.
Print button	Prints the configuration.

## Submit Deployment Job Dialog Box

When workflow is turned on with a deployment job approver, jobs must be submitted for approval before policy changes can be deployed to devices.

**Navigation Path**

To access this dialog box, do one of the following:

- From the Create a Job dialog box, select the **Submit the job** check box.
- From the Deployment Manager window, select the job on the Deployment Jobs tab and click **Submit**.

**Related Topics**

- [Submitting Deployment Jobs, page 19-39](#)
- [Deployment—Create or Edit a Job Dialog Box, page O-15](#)
- [Deployment Manager Window \(Workflow Mode\), page O-4](#)
- [Job States in Workflow Mode, page 19-7](#)

**Field Reference**

**Table O-10**      **Submit Deployment Job Dialog Box**

Element	Description
Approver	The e-mail address of the person to be notified of your submission. The default approver e-mail address is entered in the field, but you can change it.
Comment	(Optional) Comments you want to send to the approver, if any.
Submitter	The e-mail address of the person submitting the deployment job. The field initially contains the e-mail address associated with the username you used to log into Security Manager, but you can change it to another e-mail address.

## Deployment Workflow Commentary Dialog Box

When you perform an action in the Deployment Manager while working in Workflow mode, you are prompted to enter a comment to describe the action. The comments are preserved in the history for the job or schedule.

The title of the dialog box indicates the action you are taking. Enter an optional comment and click **OK** to perform the action.

### Navigation Path

In Workflow mode, select a job or schedule in the Deployment Manager and click the appropriate button to perform the desired action.

## Deploy Job Dialog Box

Use the Deploy Job dialog box to start an approved deployment job in Workflow mode.



### Caution

---

You must configure at least one policy on a device before deploying to that device. If you deploy to a device without assigning at least one policy, the device's current configuration is overwritten with a blank configuration.

---

### Navigation Path

In Workflow mode, from the Deployment Manager window, select the approved job on the Deployment Jobs tab and click **Deploy**.

### Related Topics

- [Deployment Manager Window \(Workflow Mode\), page O-4](#)
- [Deploying Configurations in Workflow Mode, page 19-34](#)
- [Job States in Workflow Mode, page 19-7](#)

## Field Reference

Table O-11 Deploy Job Dialog Box

Element	Description
Options	<p>How you want to run the job. Select Schedule to run the job at some point in the future. Select Deploy Now to run the job immediately.</p> <p>If you select Schedule, date and time fields appear.</p> <ul style="list-style-type: none"> <li>• Click the calendar icon to pick the day on which to run the job.</li> <li>• In the Time field, enter the time to start the job in 24-hour clock format. The time must be in time zone of the Security Manager server, which is not necessarily the same as your time zone. The time must be at least 5 minutes in the future.</li> </ul>
Comments	(Optional) An explanation of why you are deploying the job.
Require Deployment Status Notifications	Whether Security Manager should send an e-mail when the job status changes.
Job Completion Recipients	If you elect to send status notifications, enter the recipient's e-mail address. The field initially contains the e-mail address associated with the user account you used to log in. You can enter multiple addresses by separating them with commas.

## Deployment Status Details Dialog Box

The Deployment Status Details dialog box appears while configurations are being deployed to selected devices. It displays summary information about the job, status about the deployment to each device, and messages indicating why the deployment failed.

In the Deployment Details table, select a row corresponding to a device to display deployment status messages for that device.


**Note**

You can click **Close** to close this dialog box and continue working in Security Manager while deployment continues.

**Navigation Path**

From the Deploy Saved Changes dialog box, click **Deploy**.

**Related Topics**

- [Deploy Saved Changes Dialog Box, page O-13](#)
- [Deployment Job Approval, page 19-9](#)
- [Deploying Configurations in Non-Workflow Mode, page 19-32](#)

**Field Reference**

**Table O-12**      **Deployment Status Details Dialog Box**

Element	Description
<b>Deployment Status Details</b>	
Progress Status Bar	A visual representation and percentage of devices that were successfully updated.
Status	The status of the deployment. The possible states are Deploying, Aborted, Successful, and Failed. For descriptions of these states, see <a href="#">Job States in Non-Workflow Mode, page 19-5</a> .
Deployment Job Name	The name of the deployment job.
Devices To Be Deployed	The total number of devices in the deployment job.
Devices Deployed Successfully	The number of devices that were updated successfully.
Devices Deployed With Errors	The number of devices that failed to be updated.
<b>Deployment Details</b>	
This table lists the devices that are included in the deployment job.	
Device	The name of the device.
Status	The status of the deployment to the device. For descriptions of these states, see <a href="#">Job States in Non-Workflow Mode, page 19-5</a> .
Summary	The number of warnings, errors, and failures for the device.
Method	The method of deployment to the device. Possible methods are File and Device.
Config	The device configuration file. Double click the icon to preview the configuration for a device. For more information, see <a href="#">Config Version Viewer (Preview Configuration) Dialog Box, page O-24</a> .

**Table O-12**      **Deployment Status Details Dialog Box (Continued)**

Transcript	The commands Security Manager issued to the device and the responses from the device during deployment if you are deploying to the device (instead of deploying to a file). Double-click the icon to see the transcript for a device.
Messages	The warning, error, and failure messages, as indicated by the severity icon.  When you select an item, the Description box to the right describes the message in detail. The Action box to the right provides information on how you can correct the problem.
Refresh button	Click this button to update the status information.
Abort button	Click this button to abort the deployment job. You can abort deployment jobs only while they are in the Deploying, Scheduled, or Rolling Back state. Aborting a job stops deployment of configuration files to pending devices, but has no effect on devices to which deployments are in progress (commands are being written to a device) or to which deployment has already completed successfully.

## Abort the Job Dialog Box

You can manually halt a job that is in the Deploying state. Only pending deployments to devices are halted. Successful deployments and those that are in progress are not affected by the abort operation.

If you want to abort the job, click **OK**.

### Navigation Path

From the Deployment Manager window, select the job (which must be in the Deploying state) and click **Abort**. You can also abort a job from the Deployment Status dialog box.

### Related Topics

- [Aborting Deployment Jobs, page 19-45](#)
- [Deployment Manager Window \(Non-Workflow Mode\), page O-1](#)
- [Deployment Manager Window \(Workflow Mode\), page O-4](#)

- [Job States in Non-Workflow Mode, page 19-5](#)
- [Job States in Workflow Mode, page 19-7](#)

## Redeploy a Job Dialog Box

You can redeploy a deployment job if you want to. This is especially valuable for jobs in the Failed or Aborted states. You can redeploy to all devices in the job, or you can select specific devices (such as the devices to which deployment failed).

### Navigation Path

Do one of the following:

- (Non-Workflow mode) From the Deployment Manager window, select the job and click **Redeploy**.
- (Workflow mode) From the Deployment Manager window, select the job and click **Deploy**.

### Related Topics

- [Redeploying Configurations to Devices, page 19-43](#)
- [Job States in Non-Workflow Mode, page 19-5](#)
- [Job States in Workflow Mode, page 19-7](#)
- [Understanding Deployment Methods, page 19-11](#)

### Field Reference

**Table O-13**      *Redeploy a Job Dialog Box*

Element	Description
Selection	Whether to include the device in the redeployment job. By default, all the devices with the status Failed are selected.
Name	The name of the device.

**Table O-13**      **Redeploy a Job Dialog Box (Continued)**

Method	The deployment method to use:
Destination	<ul style="list-style-type: none"> <li>• <b>Device</b>—Deploys the configuration directly to the device or to the transport mechanism specified for the device. For more information, see <a href="#">Deploying to a Device, page 19-11</a>.</li> <li>• <b>File</b>—Deploys the configuration file to a directory on the Security Manager server. If you select File, specify the directory to which you want to deploy the configuration file in the Destination column. Click <b>Browse</b> to select from a list of available directories. For more information, see <a href="#">Deploying to a File, page 19-14</a>.</li> </ul> <p><b>Note</b> To set the deployment method for more than one device at a time, select the desired rows, right-click and select <b>Edit Selected Deploy Method</b>. The Edit Selected Deploy Method dialog box opens where you can make your selections.</p>
Previous status	The status of the previous deployment.
Last Updated By	The name of the deployment job that updated the device.
Preview Config button	Click this button to display the proposed configuration changes for the selected device. You can compare it to the last deployed configuration or the current running configuration. For more information, see <a href="#">Config Version Viewer (Preview Configuration) Dialog Box, page O-24</a> .

**Table O-13**      **Redeploy a Job Dialog Box (Continued)**

Out of Bound Change Behavior	<p>Click the radio button corresponding to the action you want Security Manager to take regarding changes made directly on the device using the CLI:</p> <ul style="list-style-type: none"><li>• Overwrite changes and show warning—When configurations are deployed, Security Manager uploads the device’s current configuration and compares it against the configuration it has in its database. If changes were made to the device manually, Security Manager continues with the deployment and displays a warning notifying you of this action.</li><li>• Cancel deployment—When configurations are deployed, Security Manager uploads the device’s current configuration and compares it against the configuration it has in its database. If changes were made to the device manually, Security Manager cancels the deployment and displays a warning notifying you of this action.</li><li>• Do not check for changes—Security Manager does not check for changes and deploys the changes to the device.</li></ul> <p>The default is set under Tools &gt; Security Manager Administration &gt; Deployment.</p>
------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## Rollback a Job Dialog Box

Use the Rollback a Job dialog box to revert the configurations of the devices in the job to their last good configurations. You might want to roll back configurations if you determine that there is something wrong with the new configurations.

If there are no previous configurations for a device in the configuration archive, you cannot roll back the configuration. You can roll back configurations only to configurations that were deployed to the device, not to a file. Besides using the Deployment Manager to roll back to the last good configuration, you can use the Configuration Archive to roll back to any past configuration.

**Caution**

It is usually a better idea to fix the configuration in Security Manager and deploy the fixed configuration, because rolling back a configuration creates a situation where the configuration defined in Security Manager is not the same one running on the device. After rollback, you should rediscover policies on the device to make the device configuration and its configuration in Security Manager consistent. Roll back configurations only in extreme circumstances. Before proceeding, read [Understanding Configuration Rollback, page 19-50](#).

**Navigation Path**

From the Deployment Manager window, select the job (which must be in the Deployed or Failed states) on the Deployment Jobs tab and click **Rollback**. You might be prompted with a warning; click **OK** when prompted to confirm the operation and open the Rollback a Job dialog box.

**Related Topics**

- [Rolling Back Configurations to Devices Using the Deployment Manager, page 19-58](#)
- [Aborting Deployment Jobs, page 19-45](#)
- [Deployment Manager Window \(Non-Workflow Mode\), page O-1](#)
- [Deployment Manager Window \(Workflow Mode\), page O-4](#)
- [Job States in Non-Workflow Mode, page 19-5](#)
- [Job States in Workflow Mode, page 19-7](#)

**Field Reference****Table O-14**     **Rollback a Job Dialog Box**

Element	Description
Selection	Whether to include the device in the rollback job. By default, all the devices with the status Succeeded are selected.
Name	The name of the device.
Method	The deployment method, File or Device. You can select only devices that use the Device method when rolling back configurations.

**Table O-14**      **Rollback a Job Dialog Box (Continued)**

Previous Status	The status of the previous deployment.
Last Updated By	The name of the deployment job that updated the device.
Preview Config button	Click this button to display the proposed configuration changes for the selected device. You can compare it to the last deployed configuration or the current running configuration. For more information, see <a href="#">Config Version Viewer (Preview Configuration) Dialog Box, page O-24</a> .

## Schedule Dialog Box

Use the Schedule dialog box to create a regularly recurring deployment job.

### Navigation Path

Select **Tools > Deployment Manager** to open the Deployment Manager window, click the Deployment Schedules tab in the upper pane, and do one of the following:

- Click **Create** to create a new schedule.
- Select a schedule and click **Open** to view or modify its properties.

### Related Topics

- [Creating or Editing Deployment Schedules, page 19-46](#)
- [Suspending or Resuming Deployment Schedules, page 19-47](#)

### Field Reference

**Table O-15**      **Schedule Dialog Box**

Element	Description
<b>Schedule Name Group</b>	This group defines the name of the job and the job's notification requirements.
Name	The name of the job. When individual deployment jobs are created from this schedule, a time stamp is added to the job name.
Description	The description of the purpose of the job.

**Table O-15**      **Schedule Dialog Box (Continued)**

Approver Email (Workflow only)	The e-mail address of the person who should approve the schedule.
Comments (Workflow only)	(Optional) Information to help the approver evaluate the schedule when you save this schedule.
Submitter Email (Workflow only)	The e-mail address of the person who is submitting this schedule for approval. This field initially contains the e-mail address associated with the user account you used to log into Security Manager, but you can change it.
Require Deployment Status Notifications (Workflow only)	Whether to send e-mail messages for any change in the job status for the job schedule or any job created from it. Messages are sent to the approver and the submitter.
<b>Recurrence Pattern Group</b>	The fields in this group define the job schedule.
Start Date	The first day of the schedule. Click the calendar icon to select the date from a calendar.
Time (Start)	The time of day to run the schedule. The time is in 24-hour format and is based on the server time zone, not the client time zone.
Recurrence	How often to create a deployment job based on this schedule: <ul style="list-style-type: none"> <li>• One time—Run this job once on the day specified as the start date at the specified start time.</li> <li>• Hourly—Run this job on an hourly schedule. Specify the number of hours between deployment jobs.</li> <li>• Daily—Run this job on a daily schedule. Specify the number of days between deployment jobs.</li> <li>• Weekly—Run this job on the specified days of the week.</li> <li>• Monthly—Run this job on a monthly schedule. Select the day of the month to run the job, and the number of months between deployment jobs.</li> </ul>

**Table O-15**      **Schedule Dialog Box (Continued)**

End Date and Time	The expiration date and time for the schedule. Deployment jobs are not created after this time.
<b>Devices To Deploy Group</b>	<p>This table lists the devices that are included in the deployment job. To add devices to the list, or to remove them from it, click <b>Add devices</b>, which opens the Add Other Devices dialog box (see <a href="#">Add Other Devices Dialog Box, page O-21</a>).</p> <p>If Security Manager is configured to use user-login credentials for accessing devices, your username and password are captured during schedule creation. If you change your password, you will need to recreate the schedule.</p>

## Configuration Archive Window

The Configuration Archive stores configuration versions for each device managed by Security Manager. If you delete a device from Security Manager, all of the device's configurations are also deleted from the Configuration Archive.

You can use Configuration Archive to:

- View the transcript of a configuration deployment for a selected device.
- View and compare configuration versions.
- View CLI differences between deployed configuration versions.
- Roll back to an earlier configuration version, provided that the configuration originated from the device. You should roll back configurations only under extreme circumstances. For more information, see these topics:
  - [Understanding Configuration Rollback, page 19-50](#)
  - [Using Rollback to Deploy Archived Configurations, page 19-60](#)
- Add the current running configuration for a device to the archive.

You can sort the list of configuration versions for a device by clicking on the column heading that you want to sort on. Clicking the column heading toggles between sorting the rows in ascending or descending order. You can also control the fields displayed by right-clicking on any column heading and selecting or deselecting the desired column names under the Show Columns command.

**Navigation Path**

Select **Tools > Configuration Archive**.

**Related Topics**

- [Configuration Archive Page](#), page A-3
- [Viewing and Comparing Archived Configuration Versions](#), page 19-49
- [Understanding Configuration Rollback](#), page 19-50
- [Using Rollback to Deploy Archived Configurations](#), page 19-60
- [Understanding Rollback for Devices in Multiple Context Mode](#), page 19-52
- [Understanding Rollback for Failover Devices](#), page 19-53
- [Understanding Rollback for Catalyst 6500/7600](#), page 19-53
- [Understanding Rollback for IPS and IOS IPS](#), page 19-54
- [Adding Configuration Versions from a Device to the Configuration Archive](#), page 19-48

**Field Reference**

**Table O-16**      **Configuration Archive Window**

Element	Description
Device Selector Filter	<p>Lists the devices in the device inventory. Select a device to see the configuration versions for the device that are available in the archive. These are displayed in the right pane.</p> <p>You can display a subset of devices based on the filtering criteria you define. For more information, see <a href="#">Filtering Items in Selectors</a>, page 3-20.</p>
Version ID	<p>The version number of the configuration version. By default, this column is not displayed. To display it, right click any column heading and select <b>Show Columns &gt; Version ID</b>.</p>
Created On	<p>The date and time that the configuration version was archived.</p>

**Table O-16** Configuration Archive Window (Continued)

Created By	<p>The user ID or system ID associated with adding the configuration version to the archive.</p> <p>If there are two names in the form <i>username1(username2)</i>, the first name is the user who initiated the request, and the name in parentheses is the system identity user. For more information on the system identity trust user, see <a href="#">Defining the System Identity User, page 2-47</a>.</p>
Archival Source	The origin of the archiving event (for example, User Request, Deployment, Discovery).
Creation Comment	A description about how or why the configuration version was created.
Transcript Icon	When double-clicked, displays a transcript of a configuration version that was deployed to a device. A transcript is the record of all messages exchanged between Security Manager and a device during device communication activities such as deployment and configuration rollback. It includes commands sent and received between Security Manager and the device.
View button	Click this button to display the selected configuration in the Config Version Viewer window (see <a href="#">Configuration Version Viewer, page O-40</a> ), where you can also compare the configuration to other configuration versions.

**Table O-16**      **Configuration Archive Window (Continued)**

Rollback button	<p>Click this button to roll the device configuration back to the selected configuration version, provided that the configuration originated from the device. You should roll back configurations only under extreme circumstances. For more information see these topics:</p> <ul style="list-style-type: none"> <li>• <a href="#">Understanding Configuration Rollback, page 19-50</a></li> <li>• <a href="#">Using Rollback to Deploy Archived Configurations, page 19-60</a></li> </ul>
Add from Device button	<p>Click this button to have Security Manager retrieve the current running configuration from the device and add it as a configuration version to the archive. This is useful for any device whose configuration might have been changed directly in its CLI.</p> <p>For more information on adding configuration versions, see <a href="#">Adding Configuration Versions from a Device to the Configuration Archive, page 19-48</a>.</p>

## Configuration Version Viewer

Use the Config Version Viewer window (when opened from the Configuration Archive) to view previous configurations for a device and to compare them to other archived configurations. You can compare any version to any other version in the archive for a selected device. The selected version appears in the left pane, and you can select another version for comparison from the list on the upper right of this window. For more information on viewing and comparing versions, see [Viewing and Comparing Archived Configuration Versions, page 19-49](#).

### Navigation Path

Select **Tools > Configuration Archive**, select a device whose configuration you want to view, select the configuration, and click **View**.

### Related Topics

- [Configuration Archive Window, page O-37](#)
- [Transcript Viewer Window, page O-42](#)

- [Viewing and Comparing Archived Configuration Versions](#), page 19-49
- [Adding Configuration Versions from a Device to the Configuration Archive](#), page 19-48

### Field Reference

**Table O-17** Configuration Version Viewer Window (Configuration Archive)

Element	Description
Version ID	<p>The configuration version to display in the left pane:</p> <ul style="list-style-type: none"> <li>• Previous—Display the version in the sequence before the one currently selected.</li> <li>• Next—Display the version in the sequence after the one currently selected.</li> <li>• Last—Display the last version in the list.</li> <li>• Specific Date and Time—Display the version created on that date and time.</li> </ul>
Compare with version	<p>(Optional) The configuration version to compare to the version selected in the left pane. The configuration is displayed in the right pane, with differences summarized and color coded as explained by the caption below the pane.</p>
Config Type	<p>The types of configurations that are available for viewing. The types differ based on the type of device. The types might indicate Full or Delta, which have the following meaning:</p> <ul style="list-style-type: none"> <li>• Full Configuration—The full configuration for the selected device as saved in the Configuration Archive. You can compare full configurations for a device.</li> <li>• Delta Configuration—The file that is generated by Security Manager during deployment and that represents policy changes between the configuration selected in the Version ID field and the most recently deployed version.</li> </ul> <p><b>Note</b> Configuration versions resulting from out-of-band changes (for example, in the CLI) can be added to Configuration Archive using <b>Add from Device</b>, but no delta configuration file is generated.</p>

**Table O-17** Configuration Version Viewer Window (Configuration Archive) (Continued)

First Difference button	Moves the cursor to the first difference noted between the configuration versions.
Previous Difference button	Moves the cursor to the previous difference noted between the configuration versions.
Current Difference button	Using the cursor, focuses on the currently selected difference in the window.
Next Difference button	Moves the cursor to the next difference noted between the configuration versions.
Last Difference button	Moves the cursor to the last difference noted between the configuration versions.
Transcript View button	Click this button to open the transcript viewer window, which displays the device communication transcript associated with this configuration.
Print button	Click this button to print the configuration.

## Transcript Viewer Window

Use the Transcript Viewer window to view the record of all messages exchanged between Security Manager and a device during device communication activities such as deployment and configuration rollback. For more information, see [Viewing and Comparing Archived Configuration Versions, page 19-49](#).

### Navigation Path

- Configuration Archive—Select **Tools > Configuration Archive** to open the Configuration Archive, select the device for which you want to view a transcript and double-click the **Transcript** icon in the row for the desired configuration version.
- Deployment Manager—Select **Tools > Deployment Manager** to open the Deployment Manager, select the deployment job that includes the desired device deployment, select the Details tab in the lower pane, and double-click the **Transcript** icon in the row for the desired device.

**Related Topics**

- [Configuration Archive Window, page O-37](#)
- [Configuration Version Viewer, page O-40](#)
- [Viewing and Comparing Archived Configuration Versions, page 19-49](#)
- [Deployment Manager Window \(Non-Workflow Mode\), page O-1](#)
- [Deployment Manager Window \(Workflow Mode\), page O-4](#)

**Field Reference****Table O-18** *Transcript Viewer Window*

<b>Element</b>	<b>Description</b>
Version ID	The configuration version for which you are viewing transcripts: <ul style="list-style-type: none"> <li>• Previous—Display the transcripts for the version in the sequence before the one currently selected.</li> <li>• Next—Display the transcripts for the version in the sequence after the one currently selected.</li> <li>• Last—Display the transcripts for the last version in the list.</li> <li>• Specific Date and Time—Display the transcripts for the version created on that date and time.</li> </ul>
Transcript Type	The type of transcript that you want to view. Some configuration versions have more than one transcript associated with them. Use this field to select which transcript to view.
Transcript Window	Displays the selected transcript. You can select text and copy it to the clipboard for pasting in a text editor.
View button	Click this button to display the related configuration in the Config Version Viewer window (see <a href="#">Configuration Version Viewer, page O-40</a> ).
Print button	Click this button to print the transcript.

■ Configuration Archive Window