



INDEX

Numerics

- 4-port 10-Gbps Fibre Channel switching modules
 - description [1-33](#)
- figure [1-33](#)
- 12-port 4-Gbps Fibre Channel switching modules
 - description [1-32](#)
 - figure [1-32](#)
- 14/2-port Multiprotocol Services module. See MPS-14/2
- 16-port switching modules
 - description [1-35](#)
 - figure [1-35](#)
 - LEDs (table) [1-34, 1-37](#)
- 24-port 4-Gbps Fibre Channel switching modules
 - description [1-31](#)
 - figure [1-31](#)
- 32-port Fibre Channel Advanced Services Module. See ASM
- 32-port Fibre Channel Storage Services Module. See SSM
- 32-port switching modules
 - description [1-34](#)
 - figure [1-35](#)
 - LEDs (table) [1-34, 1-37](#)
- 48-port 4-Gbps Fibre Channel switching modules
 - connectors [1-31](#)
 - description [1-31](#)
 - figure [1-31](#)
 - LEDs (figure) [1-31](#)

A

- AC power
 - installing (MDS 9509 Director) [2-57](#)

- providing (MDS 9506 Director) [2-30, 2-32](#)
- providing (MDS 9509 Director) [2-30, 2-32](#)
- providing (MDS 9513 Director) [2-29](#)
- removing (MDS 9509 Director) [2-56](#)
- removing (MDS 9513 Director) [2-52](#)

airflow specifications [B-4](#)

ASM

- description [1-45](#)
- figure [1-45](#)
- LEDs (table) [1-46](#)

audience

- description [xv](#)

B

backplane

- description [1-8](#)

batteries on CSM [2-50](#)

binary images

- downloading [1-45, 1-47](#)

C

cabinet installation guidelines [2-2](#)

cabinets

- perforated, requirements [A-3](#)
- requirements [A-1](#)
- See also racks
- solid wall requirements [A-4](#)
- space requirements [A-2](#)

cabling

- COM1 port [C-3](#)
- console port [C-2](#)

- MGMT 10/100/1000 Ethernet port [C-5](#)
- MGMT 10/100 Ethernet port [C-6](#)
- requirements [3-2](#)
- SFP transceivers [3-14, 3-15](#)
- Caching Services Module. See CSM
- chassis
 - grounding [2-23](#)
 - installing guidelines [2-3](#)
 - unpacking [2-5](#)
- chassis (MDS 9506 Director)
 - description [1-7](#)
 - features [1-7](#)
 - figure [1-7](#)
 - grounding (figure) [2-27](#)
 - installing in a rack (procedure) [2-15](#)
 - preinstallation [2-2](#)
 - serial number location [D-3](#)
- chassis (MDS 9509 Director)
 - description [1-6](#)
 - features [1-6](#)
 - figure [1-6](#)
 - grounding [2-26](#)
 - installing in a rack (procedure) [2-11](#)
 - power supplies [2-11](#)
 - preinstallation [2-2](#)
 - serial number location [D-2](#)
- chassis (MDS 9513 Director)
 - description [1-3](#)
 - features [1-3](#)
 - figure [1-4, 1-5](#)
 - installing in a rack (procedure) [2-7](#)
 - power supplies [1-9, 2-7, 2-28](#)
 - preinstallation [2-2](#)
 - serial number location [D-2](#)
- Cisco MDS 9500 Series Multilayer Directors
 - description [1-1](#)
- clock modules
 - description [1-8, 2-76](#)
 - installing (MDS 9506 Director) [2-86](#)
 - installing (MDS 9509 Director) [2-83](#)
 - installing (MDS 9513 Director) [2-79](#)
 - installing in MDS 9506 Director (procedure) [2-86](#)
 - installing in MDS 9509 Director (procedure) [2-79, 2-83](#)
 - removing (MDS 9506 Director) [2-84](#)
 - removing (MDS 9509 Director) [2-80](#)
 - removing (MDS 9513 Director) [2-76, 2-77](#)
 - removing from MDS 9506 Director (procedure) [2-83](#)
 - removing from MDS 9509 Director (procedure) [2-77, 2-80](#)
- COM1 port
 - cabling [C-3](#)
 - connecting [3-4](#)
 - pinouts (table) [C-3](#)
 - support [3-4](#)
 - support (note) [3-4](#)
- CompactFlash cards
 - installing [2-76](#)
 - LED on supervisor module [1-22](#)
 - removing [2-75](#)
 - Supervisor-1 modules [1-21](#)
 - Supervisor-2 modules [1-17](#)
 - Supervisor-2 modules, LEDs [1-18](#)
- connecting
 - COM1 port [3-4](#)
 - console port [3-2](#)
 - Fibre Channel ports [3-9](#)
 - MGMT 10/100/1000 [3-6](#)
 - MGMT 10/100 Ethernet port [3-7](#)
- console port
 - cabling [C-2](#)
 - connecting [3-2](#)
 - pinouts [C-2](#)
- contact and site information [D-6](#)
- crossbar fan modules
 - description [1-15](#)
- crossbar modules
 - Cisco MDS 9513 support [1-23](#)

- description [1-23](#)
- installing [2-48](#)
- location [1-23](#)
- removing [2-47](#)
- supervisor association [1-23](#)

crossbar switching fabric

- description [1-20](#)
- dual fabric configurations [1-15, 1-20](#)
- mesh design [1-15](#)
- Supervisor-2 modules [1-15](#)

CSM

- batteries [2-50](#)
- description [1-49](#)
- installing [2-45](#)
- internal (figure) [1-50](#)
- LEDs (table) [1-51](#)
- maintaining [2-50](#)
- powering off [2-44](#)
- removing [2-44](#)
- requirement (note) [2-44](#)

CUP [1-38](#)

customer service, contacting [D-1](#)

CWDM transceivers

- description [1-53](#)
- SFP transceiver specifications [B-27](#)

D

DC power

- installing (MDS 9509 Director) [2-62](#)
- providing (MDS 9506 Director) [2-34](#)
- providing (MDS 9509 Director) [2-33](#)
- removing (MDS 9509 Director) [2-61](#)

documentation

- additional publications [xvii](#)

downloading software images

- ASM-SFN image [1-45](#)
- SSM image [1-47](#)

E

- electrostatic discharge (ESD) [2-19](#)
- environmental specifications [B-1](#)

Ethernet port

- MGMT 10/100 [3-7](#)
- MGMT 10/100/1000 [3-6](#)

F

fan modules

- crossbar fan modules, description [1-15](#)
- description [1-14](#)
- failure (caution) [1-15](#)
- LEDs [1-15](#)
- removing and installing [2-68](#)

Fiber Connectivity [1-38](#)

fiber optic cables, maintaining [3-16](#)

Fibre Channel/Gigabit Ethernet SFP transceivers [1-53](#)

Fibre Channel ports

- connecting [3-9](#)
- connecting with LC-type cables (figure) [3-15](#)

G

Generation 1 modules

- services modules [1-38](#)
- switching modules [1-30](#)

Generation 2 modules

- switching modules [1-30](#)

Gigabit Ethernet/Fibre Channel SFP transceiver specifications [B-25](#)

grounding

- attaching the ESD wrist strap [2-19](#)
- best practices [2-17](#)
- chassis [2-23](#)
- establishing the system ground [2-22](#)
- required tools and equipment [2-22](#)

H

hardware compatibility matrix (table) [1-25](#)

heat dissipation

 Cisco MDS 9506 Director [B-15](#)

 Cisco MDS 9509 Director [B-7, B-10](#)

high availability

 features [1-1](#)

I

installing

 chassis (MDS 9506 Director) [2-2](#)

 chassis (MDS 9509 Director) [2-2](#)

 chassis (MDS 9513 Director) [2-2](#)

 CompactFlash cards [2-76](#)

 crossbar modules [2-48](#)

 EIA shelf brackets [A-5](#)

 equipment required [2-4](#)

 guidelines [2-3](#)

 power supplies (Cisco MDS 9513 Director) [2-54](#)

 power supplies (MDS 9509 Director) [2-57, 2-62](#)

 rack mount brackets [A-10](#)

 rack-mounting guidelines [A-6](#)

 services modules [2-38](#)

 SFP transceiver cables [3-15](#)

 SFP transceivers (note) [3-13](#)

 shelf brackets [A-10](#)

 supervisor modules [2-38, 2-40](#)

 switching modules [2-38](#)

 Telco shelf brackets [A-5](#)

 X2 transceivers [3-11](#)

installing SFP transceivers [3-14](#)

IPS modules

 IPS-4 modules (figure) [1-44](#)

 IPS-4 modules, description [1-43](#)

 IPS-8 modules, description [1-43](#)

 IPS-8 modules, figure [1-43](#)

 LEDs (table) [1-44](#)

IP Storage Services module. See IPS modules

L

LC-type cables

 connecting to Fibre Channel ports [3-15](#)

 figure [3-15](#)

LEDs

 ASM (table) [1-46](#)

 clock modules [1-8, 1-15](#)

 CSM (table) [1-51](#)

 fan modules [1-15](#)

 IPS modules (table) [1-44](#)

 MDS 9513 Director power supplies (table) [1-10](#)

 MPS-14/2 (table) [1-40, 1-42](#)

 Supervisor-2 modules (table) [1-18](#)

 switching modules (table) [1-34, 1-37](#)

M

maintaining

 CSM [2-50](#)

 CSM disk drives [2-51](#)

 fiber optic cables [3-16](#)

 SFP transceivers [3-16](#)

maintenance records [D-1](#)

MDS 9506 Director

 description [1-7](#)

 grounding location (figure) [2-27](#)

 heat dissipation [B-15](#)

 installing clock modules (procedure) [2-86](#)

 installing in a rack (procedure) [2-15](#)

 power supply LEDs (table) [1-8, 1-14](#)

 removing clock modules (procedure) [2-83](#)

MDS 9509 Director

 description [1-6](#)

 figure [1-6](#)

 grounding location (figure) [2-26](#)

- heat dissipation [B-7, B-10](#)
- installing clock modules (procedure) [2-79, 2-83](#)
- installing in a rack (procedure) [2-11](#)
- power supply LEDs (table) [1-8, 1-14](#)
- removing clock modules (procedure) [2-77, 2-80](#)

MDS 9513 Director

- installing in a rack (procedure) [2-7](#)

MGMT 10/100/1000 Ethernet port

- cabling [C-5](#)
- pinouts [C-5](#)

MGMT 10/100/1000 port

- connecting [3-6](#)

MGMT 10/100 Ethernet port

- cabling [C-6](#)
- connecting [3-7](#)
- pinouts [C-6](#)

modules

- chassis compatibility [1-25](#)
- specifications [B-4](#)
- weight [B-5](#)

MPS-14/2

- description
- LEDs (table) [1-40, 1-42](#)
- software release requirements [1-41, 1-45](#)

N

NEBS [2-19](#)

network connections, preparing [3-2](#)

new and changed information (table) [xi](#)

O

open racks, standard (requirements) [A-4](#)

organization

- description [xv](#)

P

PEMs

- installing [2-64](#)
- removing [2-64](#)

physical specifications (table) [B-2](#)

pinouts

- COM 1 port [C-3](#)
- console port [C-2](#)
- MGMT 10/100/1000 Ethernet port [C-5](#)
- MGMT 10/100 Ethernet port [C-6](#)

plugs supported for power supplies [C-8](#)

port

- MGMT 10/100/1000 [3-6](#)
- on supervisor module [1-21](#)

port indexes

- availability [1-26](#)
- description [1-26](#)
- Generation 1 limitations [1-26](#)
- Generation 2 (example) [1-29](#)
- Generation 2 maximum [1-29](#)
- Generation combination (example) [1-28](#)
- Generation combination limitations [1-28](#)

port interfaces

- Supervisor-2 modules [1-17](#)

power cord, jumper [C-13](#)

power cords, length [C-8](#)

powering up the switch [2-36](#)

power supplies

- chassis (MDS 9509 Director) [2-11](#)
- chassis (MDS 9513 Director) [2-7, 2-28](#)
- circuits [2-4](#)
- description [1-9](#)
- installing (Cisco MDS 9506 Director) [2-67](#)
- installing (Cisco MDS 9513 Director) [2-54](#)
- installing (MDS 9509 Director) [2-57, 2-62](#)
- LEDs [1-10](#)
- LEDs (table) [1-10](#)
- MDS 9506 Director LEDs (table) [1-8, 1-14](#)

MDS 9509 Director LEDs (table) [1-8, 1-14](#)
 MDS 9513 Director [1-9](#)
 MDS 9513 Director (figure) [1-9](#)
 removing (Cisco MDS 9506 Director) [2-67](#)
 removing (MDS 9509 Director) [2-56, 2-61](#)
 removing (MDS 9513 Director) [2-52](#)
 starting up the switch [2-28](#)
 supported plugs [C-8](#)
 power supplies (Cisco MDS 9506 Director)
 removing and installing PEMs [2-64](#)
 specifications [B-13](#)
 power supplies (Cisco MDS 9509 Director)
 specifications [B-6, B-9](#)
 power supplies (MDS 9506 Director)
 description [1-13](#)
 power supplies (MDS 9509 Director)
 description [1-11](#)
 pre-installation
 guidelines [2-2](#)
 rack mount brackets [A-6](#)

R

rack-mount installation options [2-2](#)
 racks
 EIA installing [A-9](#)
 open, requirements [A-4](#)
 required equipment [A-7](#)
 requirements [A-1](#)
 See also cabinets.
 space requirements [A-2](#)
 Telco installing [A-8](#)
 Telco requirements [A-5](#)
 records
 chassis and module information [D-7](#)
 contact and site information [D-6](#)
 site planning and maintenance [D-1](#)
 removing
 CompactFlash cards [2-75](#)

crossbar modules [2-47](#)
 CSM [2-44](#)
 power supplies (MDS 9509 Director) [2-56, 2-61](#)
 power supplies (MDS 9513 Director) [2-52](#)
 services modules [2-45](#)
 SFP transceiver cables [3-14](#)
 SFP transceivers [3-12](#)
 shelf brackets [A-11](#)
 supervisor modules [2-39](#)
 switching modules [2-45](#)
 X2 transceivers [3-11](#)

S

serial number
 location (MDS 9506 Director) [D-3](#)
 location (MDS 9509 Director) [D-2](#)
 location (MDS 9513 Director) figure [D-2](#)
 services modules
 ASM [1-45](#)
 CSM [1-49](#)
 description [1-38](#)
 Generation 1 modules [1-38](#)
 installing [2-38, 2-45](#)
 IPS modules [1-43](#)
 MPS-14/2 module [1-41](#)
 MSFM-18/4 module [1-38](#)
 MSM-18/4 module [1-38](#)
 removing [2-45](#)
 specifications [B-4](#)
 SSM [1-47](#)

- SFP transceivers
 - cabling [3-14, 3-15](#)
 - CWDM [1-53, B-27](#)
 - description [1-53, 3-12, B-21](#)
 - Fibre Channel [1-53](#)
 - Fibre Channel/Gigabit Ethernet [1-53](#)
 - Fibre Channel/Gigabit Ethernet supported [B-25](#)
 - Fibre Channel specifications [B-22](#)
 - Fibre Channel supported [B-22](#)
 - Gigabit Ethernet [1-53](#)
 - installing [3-14](#)
 - latches supported [3-12](#)
 - removing [3-12](#)
 - specifications [B-21](#)
- shelf bracket
 - Cisco MDS 9500, installation [A-12](#)
 - installing Telco/EIA [A-5](#)
- shelf brackets
 - description [A-12](#)
- site planning preparation checklist [D-4](#)
- specifications
 - airflow [B-4](#)
 - cables [C-1](#)
 - environmental [B-1](#)
 - heat dissipation for Cisco MDS 9506 Director [B-15](#)
 - heat dissipation for Cisco MDS 9509 Director [B-7, B-10](#)
 - MDS 9513 Director [B-6](#)
 - modules [B-4](#)
 - physical (MDS 9506 Director) [B-3](#)
 - pinouts [C-1](#)
 - power, MDS 9506 Director [B-13](#)
 - power, MDS 9509 Director [B-6, B-9](#)
 - SFP transceivers [B-21](#)
- SSM
 - alarm LEDs [1-47](#)
 - description [1-47](#)
 - figure [1-47](#)
 - LEDs (table) [1-48](#)
 - power-on LEDs [1-47](#)
 - ready LEDs [1-47](#)
 - self-test passed LEDs [1-47](#)
 - self-test running LEDs [1-47](#)
- Supervisor-1 modules
 - CompactFlash cards [1-21](#)
 - control and management [1-20](#)
 - Ethernet port [3-7](#)
 - features [1-19](#)
 - figure [1-20](#)
 - LEDs [1-22](#)
 - LEDs (figure) [1-22](#)
 - LEDs (table) [1-22](#)
 - memory options [1-21](#)
 - nondisruptive restart [1-20](#)
 - processor [1-21](#)
 - redundant central arbiter [1-20](#)
 - support (note) [1-19](#)
 - warm switchover [1-20](#)
- Supervisor-2
 - Ethernet port [3-6](#)
- Supervisor-2 modules
 - CompactFlash cards [1-17](#)
 - CompactFlash cards LEDs [1-18](#)
 - control and management [1-16](#)
 - description [1-15](#)
 - features [1-16](#)
 - figure [1-16](#)
 - integrated crossbar switching fabric [1-15](#)
 - LEDs [1-18](#)
 - LEDs (figure) [1-18](#)
 - LEDs (table) [1-18](#)
 - LEDs description [1-18](#)
 - memory options [1-17](#)
 - nondisruptive restart [1-16](#)
 - port interfaces [1-17](#)
 - processor [1-17](#)
 - redundant central arbiter [1-16](#)
 - warm switchover [1-16](#)

supervisor module

port interfaces [1-21](#)

supervisor modules

description [1-15](#)

installing [2-38, 2-40](#)

removing [2-39](#)

specifications [B-4](#)

switching modules

- 12-port 4-Gbps Fibre Channel switching modules [1-32](#)
- 16-port 2-Gbps Fibre Channel (figure) [1-35](#)
- 24-port 4-Gbps Fibre Channel switching modules [1-31](#)
- 32-port 2-Gbps Fibre Channel (figure) [1-34](#)
- 48-port 4-Gbps Fibre Channel switching modules [1-31](#)
- 4-port 10-Gbps Fibre Channel switching modules [1-33](#)
- description [1-30](#)
- downloading binary image [1-45, 1-47](#)
- features [1-36](#)
- Generation 1 modules [1-30](#)
- Generation 2 modules [1-30](#)
- installing [2-38, 2-45](#)
- LEDs (table) [1-34, 1-37](#)
- removing [2-45](#)
- specifications [B-4](#)

system grounding [2-17](#)

X

X2 transceivers

- description [1-52, B-18](#)
- installing [3-11](#)
- removing [3-11](#)
- supported (table) [B-19](#)

T

Telco racks (requirements) [A-5](#)

transceivers

- description [1-52](#)
- supported SFP transceivers [1-52](#)
- supported X2 transceiver [1-52](#)

troubleshooting

- contacting customer service [D-1](#)

W

weight of modules [B-5](#)

