



Send documentation comments to mdsfeedback-doc@cisco.com.

CHAPTER 11

N Commands

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. See the “Command Modes” section to determine the appropriate mode for each command. For more information, refer to the *Cisco MDS 9000 Family Configuration Guide*.

- [ntp](#), page 11-2

[Send documentation comments to mdsfeedback-doc@cisco.com.](mailto:mdsfeedback-doc@cisco.com)

ntp

To configure NTP settings on the switch, use the **ntp** command in configuration mode.

ntp {*peer hostname* | **server** | **tstamp-check**}

Syntax Description		
peer <i>hostname</i>	The hostname/IP address of the NTP peer (Max Size - 80).	
server	The hostname/IP address of the NTP server (Max Size - 80).	
tstamp-check	Enables or disables the Timestamp Check.	

Defaults This command has no default settings.

Command Modes Configuration mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples This example forms a server association with a server.

```
switch(config)# ntp server 10.10.10.10
switch(config)#
```

This example forms a peer association with a peer. You can specify multiple associations.

```
switch(config)# ntp peer 10.20.10.0
switch(config)#
```