



## Preface

---

This preface describes the audience, organization, and conventions of the *Cisco Nexus 7000 Series NX-OS Quality of Service Command Reference, Release 4.0*. It also provides information on how to obtain related documentation.

This chapter includes the following sections:

- [Audience, page vii](#)
- [Organization, page vii](#)
  - [Document Conventions, page vii](#)
  - [Related Documentation, page viii](#)
  - [Obtaining Documentation and Submitting a Service Request, page ix](#)

## Audience

This publication is for experienced users who configure and maintain NX-OS devices.

## Organization

Chapter and Title	Description
<a href="#">Chapter 1, “Cisco NX-OS Quality of Service Commands”</a>	Describes the Cisco NX-OS quality of service commands.

## Document Conventions

Convention	Description
<b>boldface font</b>	Commands and keywords are in boldface.
	Arguments for which you supply values are in italics.

[ ]	Elements in square brackets are optional.
[ x   y   z ]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
screen font	
<b>boldface screen font</b>	
<i>italic screen font</i>	
< >	Nonprinting characters, such as passwords, are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

**Note**

Means reader *take note*

**Caution**

*reader be careful*

**Tip**

*the following information will help you solve a problem*

## Related Documentation

### Release Notes

### NX-OS Configuration Guides

*Cisco Nexus 7000 Series NX-OS Getting Started with Virtual Device Contexts, Release 4.0*

*Cisco Nexus 7000 Series NX-OS Fundamentals Configuration Guide, Release 4.0*

*Cisco Nexus 7000 Series NX-OS Interfaces Configuration Guide, Release 4.0*

*Cisco Nexus 7000 Series NX-OS Layer 2 Switching Configuration Guide, Release 4.0*

*Cisco Nexus 7000 Series NX-OS Quality of Service Configuration Guide, Release 4.0*

*Cisco Nexus 7000 Series NX-OS Unicast Routing Configuration Guide, Release 4.0*  
*Cisco Nexus 7000 Series NX-OS Multicast Routing Configuration Guide, Release 4.0*  
*Cisco Nexus 7000 Series NX-OS Security Configuration Guide, Release 4.0*  
*Cisco Nexus 7000 Series NX-OS Virtual Device Context Configuration Guide, Release 4.0*  
*Cisco Nexus 7000 Series NX-OS Software Upgrade Guide, Release 4.0*  
*Cisco Nexus 7000 Series NX-OS Licensing Guide, Release 4.0*  
*Cisco Nexus 7000 Series NX-OS High Availability and Redundancy Guide, Release 4.0*  
*Cisco Nexus 7000 Series NX-OS System Management Configuration Guide, Release 4.0*  
*Cisco Nexus 7000 Series NX-OS XML Management Interface User Guide, Release 4.0*  
*Cisco Nexus 7000 Series NX-OS System Messages Reference*  
*Cisco Nexus 7000 Series NX-OS MIB Quick Reference*

## **NX-OS Command References**

## **Other Software Document**

*Cisco Nexus 7000 Series NX-OS Troubleshooting Guide, Release 4.0*

# **Obtaining Documentation and Submitting a Service Request**

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the \_\_\_\_\_ as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

