



A

AAA

- configuring [4-107](#)

- managing [4-101](#)

- aaa accounting command [4-106](#)

- aaa authorization command [4-105](#)

- aaa authorization exec tacacs+ local command [4-106](#)

- aaa new-model command [4-104, 4-107](#)

abbreviations

- char, variable field [A-3](#)

- chars, variable field [A-3](#)

- dec, variable field [A-3](#)

- hex, variable field [A-3](#)

- inet, variable field [A-3](#)

accessing

- CMS [2-2](#)

- command modes [2-25](#)

- member switches [5-6, 5-28](#)

- MIB files [2-35](#)

- MIB objects [2-34, 2-35](#)

- MIB variables [2-35](#)

- accounting in TACACS+ [4-102](#)

adding

- Ethernet VLAN to database [5-25](#)

- member switches to standby group [3-24](#)

- secure addresses [4-52, 4-54](#)

- static addresses [4-55, 4-57](#)

- switches to cluster [3-12](#)

address

- count, secure [4-60](#)

- resolution [4-47](#)

- security violations [4-59](#)

- see also addresses

addresses

dynamic

- accelerated aging [4-83](#)

- aging time [4-50, 4-51](#)

- default aging [4-83](#)

- described [4-49](#)

- removing [4-52](#)

MAC

- adding secure [4-52](#)

- aging time [4-50](#)

- discovering [4-47, 4-50](#)

- tables, managing [4-49](#)

- secure
 - adding [4-52, 4-54](#)
 - described [4-49, 4-52](#)
 - removing [4-55](#)
 - static
 - adding [4-55, 4-57](#)
 - configuring (EtherChannel) [4-57](#)
 - described [4-49, 4-55](#)
 - removing [4-58](#)
 - Address Management window [4-50](#)
 - Address Resolution Protocol (ARP)
 - see ARP table
 - address table
 - aging time, configuring [4-51](#)
 - dynamic addresses, removing [4-52](#)
 - MAC [4-49](#)
 - secure addresses
 - adding [4-54](#)
 - removing [4-55](#)
 - static addresses
 - adding [4-57](#)
 - removing [4-58](#)
 - administrative information, displaying [3-33](#)
 - advertisements, VTP [5-9](#)
 - aggregation
 - enterprise workgroup [1-6](#)
 - small to medium business workgroup [1-7](#)
 - aging, accelerating [4-83](#)
 - aging time, changing address [4-50, 4-51](#)
 - alarms group, in RMON [2-38](#)
 - allowed-VLAN list [5-34](#)
 - AppleTalk Remote Access (ARA) [4-105](#)
 - Apply button [2-4](#)
 - ARP table
 - address resolution [4-47](#)
 - illustrated [4-48](#)
 - managing [4-47](#)
 - authentication, enabling NTP [4-26](#)
 - authentication in TACACS+ [4-102](#)
 - authorization in TACACS+ [4-102](#)
 - autonegotiation
 - connecting to devices without [3-41](#)
 - mismatches [7-1](#)
-
- ## B
- bandwidth, graphing [2-19](#)
 - BPDU message interval [4-92](#)
 - broadcast client mode, configuring [4-26](#)
 - broadcast messages, configuring for [4-26](#)
 - broadcast storm control
 - disabling [4-21](#)
 - enabling [4-18, 4-20](#)
 - broadcast traffic and protected ports [4-101](#)
 - buttons, CMS window [2-4](#)
 - bytes, graphing [6-2](#)

C

- C2900/C3500 traps [3-63, 4-45](#)
- cabling, redundant [3-17](#)
- Cancel button [2-4](#)
- candidates
 - adding [3-12](#)
 - automatically discovering [3-6](#)
 - changing management VLAN for [3-37](#)
 - displaying all [3-14](#)
 - requirements [3-3](#)
 - suggested [3-6](#)
 - why not added [3-13](#)
- Caution described [xvii](#)
- caveats
 - password and privilege level [3-11](#)
- CDP
 - configuring [4-62, 4-63](#)
 - disabling for routing device [4-67, 4-68](#)
 - discovering candidates with [3-6](#)
- Cisco Discovery Protocol
 - see CDP
- Cisco Systems access page [3-29](#)
- CiscoWorks, as an example of CMS [2-36](#)
- Class of Service
 - see CoS
- CLI
 - accessing [1-5](#)
 - command modes [2-25](#)
 - error messages [2-31](#)
 - managing cluster members with [2-29](#)
 - using [2-24](#)
- client mode, VTP [5-8](#)
- Cluster Builder
 - changing the polling interval [3-31](#)
 - device and link icons [2-7](#)
 - illustrated [3-13](#)
 - interface [2-5](#)
 - label meanings [2-9](#)
 - menu options [2-7](#)
 - overview [1-5](#)
 - pop-up menus [2-11, 2-12](#)
 - saving configuration changes [3-33](#)
 - starting [2-20](#)
 - toolbar icons [2-6](#)
 - using [2-9](#)
- Cluster management described [3-1](#)
- Cluster Management Suite
 - see CMS
- Cluster Management Suite (CMS) [2-35](#)
- Cluster Manager
 - menu options [2-15](#)
 - overview [1-4](#)
 - pop-up menus [2-17, 2-18](#)
 - toolbar icons [2-19](#)
 - using [2-14](#)

- clusters
 - accessing 3-5
 - adding switches to 3-12, 3-14
 - configuring 3-5, 3-8
 - creating 2-9
 - creating performance graphs 6-1
 - described 3-1, 5-4
 - disqualification code 3-13
 - host name changes 3-10
 - inventory, displaying 3-33
 - management tasks 3-27
 - management VLAN, changing 3-35
 - managing 2-29, 2-37, 3-1
 - password changes 3-11
 - planning 3-2
 - redundancy 3-2, 3-17
 - removing switches from 3-12, 3-14
 - settings, configuring initial 3-30
 - see also candidates, command switch,
member switches, standby groups
- cluster setup command 3-14
- cluster tree 2-19
- Cluster View
 - device and link icons 2-7
 - device menu options 2-14
 - displaying 3-13
 - interface 2-5
 - menu options 2-7
 - overview 1-5
 - toolbar icons 2-6
 - using 2-13
- CMS 2-35
 - accessing 2-2, 3-28
 - overview 1-4
 - privilege level 2-28
 - using 2-3
 - windows, using 2-3
- colors
 - devices in CMS 2-9
- command-line error messages 2-31
- command-line interface
 - see CLI
- command modes 2-25, 2-26
- commands
 - ? 2-30
 - aaa accounting 4-106
 - aaa authorization 4-105
 - aaa authorization exec tacacs+ local 4-106
 - abbreviating 2-30
 - cluster setup 3-14
 - copy running-config startup-config 2-34
 - default 2-31
 - dir flash 2-33
 - help 2-30
 - list of available 2-27, 2-30
 - name 3-22
 - no 2-31
 - preempt 3-22
 - rcommand 2-29

- redisplaying [2-30](#)
- redundancy-enable [3-22](#)
- resetting to defaults [2-31](#)
- show cluster candidates [3-14](#)
- show cluster members [2-29, 3-14](#)
- spanning-tree root guard [4-99](#)
- stp-list [4-80](#)
- undoing [2-31](#)
- command switch
 - and management [1-5](#)
 - and managing with SNMP [2-37](#)
 - configuration conflicts [7-14](#)
 - defined [1-3, 3-1](#)
 - enabling [3-5, 4-10](#)
 - privilege levels [2-29](#)
 - recovery
 - from failure [3-19, 7-8](#)
 - from failure without HSRP [3-19](#)
 - from lost member connectivity [7-14](#)
 - redundant (standby) [3-17](#)
 - removing from standby group [3-25](#)
 - replacing
 - with another switch [7-12](#)
 - with cluster member [7-9](#)
 - requirements [3-3](#)
 - standby [3-17, 3-18, 3-20](#)
 - see also candidates, member switches
- command variables, listing [2-30](#)
- community strings
 - added to new members [3-10](#)
 - configuring [3-10, 3-60, 4-42](#)
 - SNMP [2-37, 3-10](#)
- compatibility
 - cluster [3-2](#)
 - feature [4-2](#)
- config trap [3-63, 4-45](#)
- configuration
 - changes
 - saving [3-33](#)
 - conflicts, managing [4-2, 7-14](#)
 - default VLAN [5-21](#)
 - files, saving to an external server [2-33](#)
 - guidelines
 - port [3-41](#)
 - VLANs [5-20](#)
 - VTP [5-10](#)
 - VTP version [5-11](#)
 - saving to Flash memory [2-34](#)
 - VTP, default [5-12](#)
 - see also configuring
- configuring
 - 802.1p class of service [5-37](#)
 - AAA [4-107](#)
 - aging time [4-51](#)
 - broadcast messages [4-26](#)
 - broadcast storm control [4-19](#)
 - CDP [4-62, 4-63](#)
 - clusters [3-5, 3-8](#)

- cluster settings, initial [3-30](#)
- community strings [3-10, 3-60, 4-42](#)
- date and time [4-22](#)
- daylight saving time [4-23](#)
- DNS [4-39](#)
- duplex [3-38, 3-49](#)
- flooding controls [4-18](#)
- flow control [3-49](#)
- hello time [4-92](#)
- hops [4-64](#)
- HSRP groups [3-22](#)
- IP information [4-26](#)
- load sharing [5-45, 5-48](#)
- login authentication [4-104](#)
- management VLAN [3-37](#)
- multicast router port [4-79](#)
- native VLANs [5-36](#)
- NTP [4-24](#)
- passwords [2-27](#)
- Port Fast [3-38](#)
- ports [3-42](#)
 - multiple mixed [3-43](#)
 - protected port [4-100](#)
 - through Cluster Manager [2-17, 3-38](#)
 - through VSM [2-21](#)
- privilege levels [2-27](#)
- redundant clusters [3-17](#)
- RMON groups [2-38](#)
- SNMP [3-59, 4-41](#)
- speed [3-38, 3-41, 3-49](#)
- standalone switches [4-9](#)
- standby group [3-22](#)
- standby groups [3-19, 3-22](#)
- static addresses (EtherChannel) [4-57](#)
- STP [4-80](#)
 - path costs [5-48](#)
 - port priorities [5-45](#)
 - root guard [4-98, 4-99](#)
- switches
 - member [2-29](#)
 - overview [4-1](#)
 - standalone [4-9](#)
- TACACS+ [4-101](#)
- trap managers [3-63, 4-44](#)
- trunk port [5-31](#)
- trunks [5-30, 5-33](#)
- VLANs [5-1, 5-5, 5-20, 5-24](#)
- voice ports [4-108](#)
- VTP [5-10, 5-12](#)
 - VTP client mode [5-15](#)
 - VTP server mode [5-14](#)
 - VTP transparent mode [5-6, 5-16](#)
- configuring a multicast router port [4-76](#)
- conflicts
 - configuration [4-2, 7-14](#)
 - upgrade [3-55](#)
- consistency checks in VTP version 2 [5-10](#)
- conventions

- command [xvi](#)
 - for examples [xvi](#)
 - Note and Caution [xvii](#)
 - text [xvi](#)
 - copy running-config startup-config command [2-34](#)
 - CoS [3-39](#)
 - configuring [5-37](#)
 - configuring priority queues [5-42](#)
 - defining [5-39](#)
-
- D**
- database, VTP [5-19, 5-24](#)
 - date, setting [4-22](#)
 - daylight saving time [4-23](#)
 - default configuration
 - VLANs [5-21](#)
 - VTP [5-12](#)
 - defaults, resetting to [2-31](#)
 - default settings, changing [4-3](#)
 - deleting VLAN from database [5-27](#)
 - deployment examples [1-6](#)
 - destination-based forwarding [4-14](#)
 - destination-based port groups [4-12, 4-57](#)
 - device arrangement [3-32](#)
 - device pop-up menu [2-18](#)
 - DHCP [4-29](#)
 - configuring
 - DHCP server [4-32](#)
 - DNS [4-33](#)
 - example [4-37](#)
 - relay device [4-34](#)
 - TFTP server [4-33](#)
 - dir flash command [2-33](#)
 - disabling
 - broadcast storm control [4-21](#)
 - port security [4-62](#)
 - SNMP [4-42](#)
 - SNMP agent [3-60](#)
 - STP [4-83, 4-84](#)
 - Switch Port Analyzer (SPAN) [4-18](#)
 - trunking on a port [5-34](#)
 - trunk port [5-34](#)
 - VTP [5-16](#)
 - VTP version 2 [5-18](#)
 - disqualification code [3-13](#)
 - DNS
 - configuring [4-39](#)
 - described [4-39](#)
 - enabling [4-41](#)
 - documentation, related [xvii](#)
 - domain name
 - described [4-39](#)
 - specifying [4-39, 4-40, 5-10](#)
 - Domain Name System server
 - see DNS
 - domains for VLAN management [5-7](#)
 - DTP [5-33](#)

duplex

- configuration guidelines [3-41](#)

- configuring [3-49](#)

dynamic addresses

- see addresses

Dynamic Host Configuration Protocol

- see DHCP

Dynamic Trunk Protocol (DTP) [5-33](#)

Eegress port scheduling [5-38](#)eligible switches [3-20](#)

enable password

- see passwords

enable secret password

- see passwords

enabling

- broadcast storm control [4-18, 4-20](#)

- command switch [3-5, 4-10](#)

- DNS [4-41](#)

- HSRP [3-22](#)

- NTP authentication [4-26](#)

- Port Fast [4-95, 4-97](#)

- port security [4-58, 4-61](#)

- SNMP [4-42](#)

- SNMP agent [3-60](#)

- STP Port Fast [4-95, 4-97](#)

- Switch Port Analyzer (SPAN) [4-15, 4-17](#)

- traps [3-63](#)

- UplinkFast [4-87](#)

- VTP version 2 [5-17](#)

encapsulation [5-37](#)enterprise workgroup aggregation [1-6](#)error messages [2-31](#)errors, graphing [6-2](#)

EtherChannel port groups

- configuring static address for [4-57](#)

- creating [4-11, 4-15](#)

Ethernet VLAN

- adding to database [5-25](#)

- defaults and ranges [5-21](#)

- modifying [5-26](#)

events group, in RMON [2-38](#)

examples

- conventions for [xvi](#)

- deployment [1-6](#)

extended discovery [4-63](#)

Ffacility codes [A-1](#)Fast EtherChannel port groups, creating [4-11](#)Fast Ethernet trunks [5-29](#)FDDI-Net VLAN defaults and ranges [5-22](#)FDDI VLAN defaults and ranges [5-21](#)

features

- configuration conflicts between [2-25](#)
- default settings [4-2](#)
- incompatible [4-2](#)
- IOS [1-2](#)

Flash memory, files in [2-33, 2-34](#)

flooding controls

- configuring [4-18](#)
- illustrated [4-19](#)

flow control, configuring [3-49](#)

forwarding

- controlling (SNMP) [2-37](#)
- delay [4-89, 4-93](#)
- port groups [4-12](#)
- restrictions [4-14](#)
- source-based, illustrated [4-12](#)
- see also broadcast storm control

forwarding window, static address [4-55](#)

FTP, accessing MIB files with [2-35](#)

G

get-next-request operation [2-36, 2-37](#)

get-request operation [2-36, 2-37](#)

get-response operation [2-37](#)

Gigabit Ethernet

- ports, configuring flow control on [3-50](#)
- settings [3-42](#)
- trunks [5-29](#)

global configuration mode [2-26](#)

graphing bytes [6-2](#)

graphs

- bandwidth [2-19](#)
- link utilization [6-1](#)
- percent utilization [6-2](#)
- poll result [2-36](#)

H

hardware

- supported switches [1-3](#)

hello BPDU interval [4-92](#)

hello time

- changing [4-92](#)
- defined [4-89](#)

help, getting [2-20, 2-30](#)

Help button [2-4](#)

history group, in RMON [2-38](#)

home page, VSM [4-10](#)

hops, configuring [4-64](#)

host names

- abbreviations appended to [3-21](#)
- changes to [3-10](#)
- changing [3-32](#)
- to address mappings [4-39](#)

Hot Standby Router Protocol

- see HSRP

HSRP [3-17](#), [3-22](#)

see also standby group

icons

Cluster Builder [2-7](#)

Cluster Manager toolbar [2-19](#)

Cluster View [2-7](#)

IEEE 802.1Q

configuration considerations [5-30](#)

interaction with other features [5-30](#)

native VLAN for untagged traffic [5-36](#)

overview [5-29](#)

IEEE 802.1Q trunks [5-30](#)

IGMP snooping [4-64](#)

configuring a multicast router port [4-69](#)

disabling [4-66](#)

enabling [4-66](#)

joining a multicast group [4-70](#)

leaving a multicast group [4-76](#)

Immediate Leave [4-68](#)

defined [4-68](#)

disable [4-69](#)

enable [4-69](#)

ingress port scheduling [5-37](#)

interface configuration mode [2-27](#)

interfaces

Cluster Builder [2-5](#)

Cluster View [2-5](#)

IOS supported [1-4](#)

Internet Group Management Protocol

see IGMP snooping

inventory, displaying [3-33](#)

IOS

see software and upgrading [3-2](#)

IP addresses

and admittance to standby groups [3-20](#)

candidate [3-4](#)

discovering [4-47](#)

management VLAN [3-4](#)

point of access [3-1](#)

in redundant clusters [3-18](#)

removing [4-29](#)

see also IP information

IP information

assigning [4-28](#)

configuring [4-26](#)

displaying [3-33](#)

removing [4-29](#)

IP Management window [4-27](#)

IP setup program [7-10](#), [7-12](#)

IPX server time-out, and Port Fast [4-95](#)

L

LEDs, monitoring [3-39](#), [3-41](#)

line configuration mode [2-27](#)

link

- graph, illustrated [6-3](#)
- utilization graphs [6-1](#)

link icons, Cluster Builder and Cluster View [2-7](#)link information, displaying [3-34](#)

load sharing

- STP, described [5-43](#)
- using STP path cost [5-46](#)
- using STP port priorities [5-44](#)

location of displayed switches [3-32](#)location of switches, displaying [3-33](#)login authentication, configuring [4-104](#)

M

MAC addresses

- adding secure [4-52](#)
- aging time [4-50](#)
- discovering [4-47, 4-50](#)

MAC address tables, managing [4-49](#)management interface features [2-1](#)management options [1-4](#)

management VLAN

- changes, understanding [3-4](#)
- changing [3-4, 3-34](#)
- configuring [3-37](#)
- described [5-4](#)
- IP address [3-4](#)

Management VLAN window [3-36](#)

map

- see also network map

membership mode, VLAN port [5-3](#)

member switches

- accessing [5-6, 5-28](#)
- adding
 - with Cluster Builder [3-12](#)
 - from the command line [3-14](#)
 - to standby group [3-24](#)

assigning host names to [3-10](#)defined [1-3](#)displaying inventory of [3-33](#)managing [2-29](#)order [3-31](#)passwords, inherited [3-11](#)recovering from lost connectivity [7-14](#)

removing

- from standby group [3-25](#)

upgrading [3-57, 3-58](#)

see also candidates, command switch

menu options

- Cluster Builder [2-7](#)
- Cluster Manager [2-15](#)
- Cluster View [2-7, 2-14](#)
- VSM [2-22](#)

see also pop-up menus

messages, CLI error [2-31](#)

message severity levels
description [A-2](#)
table [A-2](#)

MIB files, accessing [2-35](#)

MIB objects, accessing [2-34](#)

MIB variables, accessing [2-35](#)

mismatches, autonegotiation [7-1](#)

mnemonic code [A-2](#)

Mode button [2-21, 3-39, 3-40](#)

model numbers, displaying [3-33](#)

modes
command [2-25](#)
VLAN port membership [5-3](#)
VTP
see VTP modes

Modify button [2-4](#)

modules
installed, displaying [3-33](#)

monitoring
devices with Cluster Manager [2-14](#)
LEDs [3-39, 3-41](#)
ports [3-38, 4-15](#)
traffic [4-15](#)
VTP [5-18](#)

multicast groups
joining [4-70](#)
leaving [4-76](#)

multicast traffic, and protected ports [4-101](#)

N

name command [3-22](#)

NAT [3-9](#)

native VLANs [5-36](#)

NCPs [4-105](#)

Network Address Translation
see NAT

Network Control Protocols (NCPs) [4-105](#)

network map
creating [3-30](#)
saving [3-30](#)

Network Time Protocol. See NTP

no commands, using [2-31](#)

Note described [xvii](#)

NTP
authentication, enabling [4-26](#)
broadcast-client mode [4-26](#)
client [4-25](#)
configuring [4-24](#)
described [4-24](#)
illustrated [4-25](#)

O

OK button [2-4](#)

online help, displaying [2-4](#)

order, switch [3-31](#)

P

- packets
 - graphing [6-2](#)
- parallel links [5-43](#)
- passwords
 - candidate switch [3-6](#)
 - changing [4-11](#)
 - community strings [4-42](#)
 - member switch, inherited [3-11](#)
 - recovery of [3-19, 7-6](#)
 - setting [2-27](#)
 - TACACS+ server [4-102](#)
 - VTP domain [5-11](#)
- path cost [4-96, 4-97, 5-46](#)
- polling interval [3-31](#)
- poll results, graphing [2-36](#)
- pop-up menus
 - Cluster Builder candidate [2-11](#)
 - Cluster Builder link [2-12](#)
 - Cluster Builder member [2-12](#)
 - Cluster Manager device [2-18](#)
 - Cluster Manager port [2-17](#)
- port-connection information, displaying [3-34](#)
- Port Fast
 - configuring [3-38](#)
 - enabling [4-95, 4-97](#)
- port groups
 - and trunks [5-31](#)
 - configuring [3-38](#)
 - configuring static addresses (EtherChannel) [4-57](#)
 - creating EtherChannel [4-11, 4-15](#)
 - destination-based [4-12, 4-57](#)
 - forwarding [4-12](#)
 - restrictions on forwarding [4-14](#)
 - source-based [4-12, 4-57](#)
 - see also ports
- port membership modes, VLAN [5-3](#)
- port-monitoring conflicts with trunks [5-30](#)
- port pop-up menu [2-17](#)
- ports
 - configuration guidelines [3-41](#)
 - configuring
 - through Cluster Manager [3-38, 3-42](#)
 - multiple mixed [3-43](#)
 - with port pop-up menu [2-17](#)
 - protected ports [4-100](#)
 - trunk [5-31](#)
 - voice [4-108](#)
 - through VSM [2-21](#)
- Gigabit Ethernet
 - configuring flow control on [3-50](#)
 - monitoring [3-38, 5-30](#)
 - priority [4-98, 5-37, 5-44](#)
 - protected ports [4-100](#)
 - secure [4-60, 5-31](#)

- security
 - described [4-58](#)
 - disabling [4-62](#)
 - enabling [4-61](#)
 - speed, setting and checking [3-38, 3-41](#)
 - static-access [5-3, 5-5, 5-28](#)
 - STP parameters, changing [4-93](#)
 - trunk
 - configuring [5-31](#)
 - disabling [5-34](#)
 - trunks [5-3, 5-29](#)
 - VLAN, displaying [3-50](#)
 - VLAN assignments [5-5, 5-28](#)
 - see also port groups
 - port scheduling [5-37](#)
 - preempt command [3-22](#)
 - priority
 - assigning standby [3-22](#)
 - modifying switch [4-91](#)
 - port
 - described [5-37](#)
 - modifying [4-96, 4-98](#)
 - standby group member [3-20](#)
 - privileged EXEC mode [2-26](#)
 - privilege levels
 - command switch [2-29](#)
 - inherited [3-11](#)
 - mapping on member switches [2-29, 3-11](#)
 - setting [2-27](#)
 - specifying [2-28](#)
 - web-based management application [2-2](#)
 - properties, displaying switch [3-33](#)
 - protected ports, configuring [4-100](#)
 - publications, related [xvii](#)
-
- Q**
- QoS
 - egress port scheduling [5-38](#)
 - ingress port scheduling [5-37, 5-42](#)
-
- R**
- rcommand [2-29](#)
 - recovery procedures [7-4](#)
 - redundancy
 - cluster [3-2, 3-17](#)
 - STP [4-83](#)
 - path cost [5-46](#)
 - port priority [5-44](#)
 - UplinkFast [4-84](#)
 - redundancy-enable command [3-22](#)
 - remote devices without autonegotiation,
 - connecting to [3-42](#)
 - remove vlan-list parameter [5-34](#)
 - removing
 - dynamic address entries [4-52](#)
 - IP information [4-29](#)

- secure addresses [4-55](#)
 - standby group from network [3-26](#)
 - static addresses [4-55, 4-58](#)
 - switches from a standby group [3-25](#)
 - Requested and Actual settings [3-41](#)
 - RMON
 - configuring [4-108](#)
 - supported groups [2-38](#)
 - root guard [4-98, 4-99](#)
-
- S**
- saving
 - cluster configuration [3-33](#)
 - network map [3-30](#)
 - secure address count [4-60](#)
 - secure addresses
 - adding [4-52, 4-54](#)
 - described [4-52](#)
 - removing [4-55](#)
 - secure ports
 - address-security violations [4-59](#)
 - disabling [4-62](#)
 - enabling [4-58, 4-61](#)
 - maximum secure address count [4-60](#)
 - and trunks [5-31](#)
 - security
 - port [4-58](#)
 - TACACS+ [4-102](#)
 - violations, address [4-59](#)
 - Serial Line Internet Protocol (SLIP) [4-105](#)
 - serial numbers, displaying [3-33](#)
 - server, domain name [4-41](#)
 - server mode, VTP [5-8](#)
 - server time-out, and Port Fast [4-95](#)
 - set-request operation [2-36, 2-37](#)
 - setting
 - see configuring
 - settings
 - cluster, initial [3-30](#)
 - default, changing [4-3](#)
 - duplex [3-38, 3-41, 3-49](#)
 - multiple mixed port [3-43](#)
 - port, monitoring [3-39](#)
 - Requested and Actual [3-41](#)
 - speed [3-49](#)
 - user, changing [3-31](#)
 - setup program [7-10, 7-12](#)
 - severity levels
 - description [A-2](#)
 - table [A-2](#)
 - show cluster candidates command [3-14](#)
 - show cluster members command [2-29, 3-14](#)
 - SLIP [4-105](#)
 - small to medium-sized business workgroup
 - aggregation [1-7](#)
 - SNMP [3-59](#)
 - accessing MIB variables with [2-35](#)
 - agent [3-60](#)

- community strings
 - changes to [3-10](#)
 - configuring [3-60, 4-42](#)
 - configuring for
 - cluster members [3-59](#)
 - single switches [4-41](#)
 - disabling [3-60](#)
 - enabling [3-60](#)
 - enabling and disabling [4-42](#)
 - management, using [2-34](#)
 - managing clusters with [2-37](#)
 - network management platforms [1-5](#)
 - RMON groups [2-38](#)
 - trap managers, configuring [3-63, 4-44](#)
 - trap types [3-63, 3-64, 4-45](#)
- SNMP Configuration window, displaying [2-20](#)
- SNMP Manager, illustrated [3-61, 3-62](#)
- software
- recovery procedures [7-5](#)
 - reloading [3-59](#)
 - requirements for
 - changing management VLAN [3-36](#)
 - joining standby groups [3-20](#)
 - to support clustering [3-2](#)
 - upgrading switch [3-51](#)
 - version numbers, displaying [3-33](#)
 - see also upgrading
- Software Upgrade window [2-20](#)
- source-based forwarding [4-14](#)
- source-based port groups [4-12, 4-57](#)
- SPAN
- described [4-15](#)
 - disabling [4-18](#)
 - enabling [4-17](#)
 - ports, restrictions [4-2](#)
- Spanning-Tree Protocol
- see STP
- spanning-tree rootguard command [4-99](#)
- speed, setting [3-38, 3-41, 3-49](#)
- splash screen, displaying at startup [3-31](#)
- standalone switches
- configuring [4-9](#)
- Standby Command Configuration window [3-20, 3-21](#)
- standby command switch requirements [3-20](#)
- standby group
- adding switches to [3-24](#)
 - configuration guidelines [3-22](#)
 - configuring [3-17, 3-19, 3-22](#)
 - priority, configuring [3-20](#)
 - removing from network [3-26](#)
 - removing switches from [3-25](#)
- startup configuration, copying to PC or server [3-52](#)
- static-access ports
- assigning to VLAN [5-5, 5-28](#)
 - described [5-5](#)
 - VLAN membership combinations [5-3](#)
- static addresses

- adding [4-55, 4-57](#)
 - configuring for EtherChannel port groups [4-57](#)
 - described [4-49, 4-55](#)
 - removing [4-58](#)
 - see also static address
 - static address forwarding restrictions [4-14](#)
 - static address forwarding window [4-55](#)
 - statistics, VTP [5-18](#)
 - statistics group, in RMON [2-38](#)
 - status, monitoring port [3-38](#)
 - STP
 - BPDU message interval [4-92](#)
 - configuring [4-80](#)
 - disabling [4-83, 4-84](#)
 - forwarding delay timer [4-93](#)
 - hello BPDU interval [4-92](#)
 - implementation type [4-90](#)
 - load sharing
 - overview [5-43](#)
 - using path costs [5-46](#)
 - using port priorities [5-44](#)
 - number of supported instances [5-2](#)
 - parameters [4-80](#)
 - path cost
 - changing [4-97](#)
 - configuring [5-48](#)
 - Port Fast
 - enabling [4-95, 4-97](#)
 - port grouping parameters [4-13, 5-31](#)
 - port parameters, changing [4-93](#)
 - port priority [4-98, 5-45](#)
 - redundant connectivity [4-83](#)
 - redundant links with UplinkFast [4-84](#)
 - root guard [4-98, 4-99](#)
 - supported number of spanning-tree instances [4-80](#)
 - switch priority [4-91](#)
 - UplinkFast [4-84, 4-87](#)
 - VLAN parameters described [4-87](#)
 - stp-list parameter [4-80](#)
 - Sun Microsystems
 - URL for required plug-in [4-9](#)
 - switches
 - see candidates, command switch, member switches
 - Switch Port Analyzer (SPAN)
 - disabling [4-18](#)
 - enabling [4-15, 4-17](#)
 - illustrated [4-16](#)
 - switchport command [5-33](#)
 - system date and time [4-22](#)
-
- T**
 - tables
 - message severity levels [A-2](#)
 - variable fields [A-3](#)
 - TACACS+
 - AAA accounting commands [4-106](#)

- AAA authorization commands [4-105](#)
 - configuring [4-101](#)
 - initializing [4-104](#)
 - server, creating [4-103](#)
- tacacs-server host command [4-103](#)
- tacacs-server retransmit command [4-103, 4-107](#)
- tacacs-server timeout command [4-103](#)
- Telnet, starting from browser [2-33](#)
- TFTP server, upgrading multiple switches with [3-52](#)
- time
 - daylight saving [4-23](#)
 - setting [4-22](#)
- time zones [4-22](#)
- TLV [5-10](#)
- Token Ring VLANs
 - overview [5-20](#)
 - TrBRF [5-10, 5-22](#)
 - TrCRF [5-10, 5-23](#)
- toolbar icons
 - Cluster Builder [2-6](#)
 - Cluster Manager [2-19](#)
 - Cluster View [2-6](#)
- topology [3-30](#)
 - see also network map
- traceback reports [A-4](#)
- traffic
 - forwarding, and protected ports [4-100](#)
 - monitoring [4-15](#)
 - reducing flooded [4-18](#)
 - transmit queue [5-38](#)
- transparent mode, VTP [5-8, 5-16](#)
- trap managers
 - adding [4-44, 4-47](#)
 - configuring [3-63, 4-44](#)
 - supported [3-63](#)
- traps [2-37, 3-63, 4-45](#)
- TrBRF VLAN defaults and ranges [5-22](#)
- TrCRF VLAN defaults and ranges [5-23](#)
- troubleshooting
 - IOS [7-1](#)
 - with CiscoWorks2000 [2-36](#)
- trunk ports
 - configuring [5-31](#)
 - disabling [5-34](#)
- trunks
 - allowed-VLAN list [5-34](#)
 - configuration conflicts [5-30](#)
 - configuring [5-33](#)
 - disabling [5-34](#)
 - IEEE 802.1Q [5-30](#)
 - interacting with other features [5-30](#)
 - load sharing using
 - STP path costs [5-46](#)
 - STP port priorities [5-44](#)
 - native VLAN for untagged traffic [5-36](#)
 - overview [5-29](#)
 - parallel [5-46](#)
 - VLAN, overview [5-29](#)

VLAN membership combinations [5-4](#)
 TTY traps [3-63, 4-45](#)

U

UDLD [4-100](#)
 unicast traffic, and protected ports [4-101](#)
 UniDirectional Link Detection
 see UDLD
 Unrecognized Type-Length-Value (TLV)
 support [5-10](#)
 upgrading
 1900 and 2820 member switches [3-58](#)
 2900, 2950, and 3500 member switches [3-57](#)
 conflicts while [3-55](#)
 multiple switches with TFTP [3-52](#)
 software
 with CLI [3-55](#)
 with VSM [3-59](#)
 standalone switches [3-55](#)
 switch software [3-51](#)
 UplinkFast
 enabling [4-87](#)
 redundant links [4-84](#)
 user EXEC mode [2-26](#)
 user settings [3-31](#)
 User Settings window, displaying [2-20](#)
 utilization graphs [6-1](#)

V

variable fields
 definition [A-3](#)
 table [A-3](#)
 version-dependent transparent mode [5-10](#)
 virtual IP address
 HSRP [3-18](#)
 standby group member [3-21](#)
 see also IP addresses
 VLAN
 port membership modes [5-3](#)
 trunks, overview [5-29](#)
 VLAN database mode [2-26](#)
 VLAN ID, discovering [4-47, 4-50](#)
 VLAN membership
 combinations [5-3](#)
 described [5-4](#)
 displaying [3-50](#)
 modes [5-3](#)
 port group parameters [4-13](#)
 traps [3-63, 4-45](#)
 see also dynamic ports VLAN membership
 VLAN membership combinations [5-3](#)
 VLAN Membership window [2-20](#)
 VLANs
 802.1Q considerations [5-30](#)
 adding to database [5-25](#)
 aging dynamic addresses [4-83](#)

- allowed on trunk [5-34](#)
- changing [5-26](#)
- configuration guidelines [5-20](#)
- configuring [5-1](#), [5-5](#), [5-24](#)
- default configuration [5-21](#)
- deleting from database [5-27](#)
- described [5-1](#)
- displaying [3-50](#)
- illustrated [5-2](#)
- MAC addresses [4-50](#)
- modifying [5-26](#)
- native, configuring [5-36](#)
- number supported [5-2](#)
- static-access ports [5-5](#), [5-26](#), [5-28](#)
- STP parameters, changing [4-87](#)
- supported [5-2](#)
- Token Ring [5-20](#)
- trunks configured with other features [5-30](#)
 - see also trunks
- VTP database and [5-19](#)
- VTP modes [5-8](#)
- See also management VLAN
- voice ports, configuring [4-108](#)
- VSM
 - accessing [4-9](#)
 - conflicts while upgrading [3-55](#)
 - home page [2-21](#), [4-10](#)
 - menu options [2-22](#)
 - overview [1-4](#)
 - privilege level [2-28](#)
 - using [2-20](#)
- VTP
 - advertisements [5-9](#)
 - configuration guidelines [5-10](#)
 - configuring [5-12](#)
 - consistency checks [5-10](#)
 - database [5-19](#), [5-24](#)
 - default configuration [5-12](#)
 - described [5-6](#)
 - disabling [5-16](#)
 - domain names [5-10](#)
 - domains [5-7](#)
 - modes
 - client [5-8](#)
 - configuring [5-15](#)
 - server [5-8](#), [5-14](#)
 - transitions [5-8](#)
 - transparent [5-6](#), [5-8](#), [5-16](#)
 - monitoring [5-18](#)
 - statistics [5-18](#)
 - Token Ring support [5-10](#)
 - transparent mode, configuring [5-16](#)
 - traps [3-63](#), [4-45](#)
 - using [5-6](#)
 - version, determining [5-11](#)
 - version 1 [5-10](#)

version 2

configuration guidelines [5-11](#)

disabling [5-18](#)

enabling [5-17](#)

overview [5-10](#)

VLAN parameters [5-19](#)

W

web-based management, using [2-2](#)

Weighted Round Robin

see WRR

WRR

configuring [5-43](#)

defining [5-39](#)

description [5-39](#)

X

Xmodem protocol [7-5](#)

