



Repacking a Switch

This appendix describes how to return your Catalyst 4500 E-series switch to the factory and how to repack your switch in preparation for shipping. [Table B-1](#) lists the packaging dimensions and weights for the Catalyst 4500 E-series chassis.

Table B-1 Chassis Packaging Dimensions and Weights

Chassis	Packaging Dimensions (L x W x D)	Weight (Approximate)
Catalyst 4503-E	23.25 x 21.00 x 19.75 in. (59.05 x 21.25 x 50.16 cm)	75 lb (34.02 kg)
Catalyst 4506-E	26.50 x 23.50 x 19.75 in. (67.31 x 59.69 x 50.16 cm)	110 lb (49.89 kg)
Catalyst 4507R-E	28.25 x 23.50 x 19.75 in. (71.76 x 59.69 x 50.16 cm)	108 lb (48.99 kg)
Catalyst 4510R-E	33.00 x 24.38 x 24.25 in. (83.82 x 61.92 x 61.60 cm)	161 lb (73.03 kg)
Catalyst 4507R+E	28.25 x 23.50 x 19.75 in. (71.76 x 59.69 x 50.16 cm)	108 lb (48.99 kg)
Catalyst 4510R+E	33.00 x 24.38 x 24.25 in. (83.82 x 61.92 x 61.60 cm)	161 lb (73.03 kg)

**Tip**

For additional information about the Cisco Catalyst 4500 E-series switches (including configuration examples and troubleshooting information), see the documents listed on this page:

<http://www.cisco.com/en/US/products/hw/switches/ps4324/index.html>

To repack the switch using the original packaging material, follow these steps:

- Step 1** Slide the pieces of the packing foam over the Catalyst 4500 E-series switch. (See [Figure B-1](#).)
- Step 2** Place the accessory kit in the box or poly bag provided.
- Step 3** Place the switch (with packing foam pieces) into the packing carton.
- Step 4** Fold in the top flaps of the packing carton and seal with packing tape.

Figure B-1 Catalyst 4500 E-Series Switch Packing Material

