



# Catalyst 6500 Series Switch and ROM Monitor Commands

---

## A Commands

[alias, page 2-2](#)

## B Commands

[boot, page 2-4](#)

## C Commands

[cd, page -5](#)  
[clear acllog, page -6](#)  
[clear alias, page -7](#)  
[clear arp, page -8](#)  
[clear banner motd, page -9](#)  
[clear boot auto-config, page -10](#)  
[clear boot device, page -11](#)  
[clear boot system, page -12](#)  
[clear cam, page -13](#)  
[clear cam notification, page -14](#)  
[clear channel statistics, page -15](#)  
[clear config, page -16](#)  
[clear config pvlan, page -18](#)  
[clear cops, page -19](#)  
[clear counters, page -21](#)  
[clear crypto key rsa, page -22](#)  
[clear dot1x config, page -23](#)

[clear dot1x guest-vlan, page -24](#)  
[clear gmrp statistics, page -25](#)  
[clear gvrp statistics, page -26](#)  
[clear igmp statistics, page -27](#)  
[clear ip alias, page -28](#)  
[clear ip dns domain, page -29](#)  
[clear ip dns server, page -30](#)  
[clear ip permit, page -31](#)  
[clear ip route, page -33](#)  
[clear kerberos clients mandatory, page -34](#)  
[clear kerberos credentials forward, page -35](#)  
[clear kerberos creds, page -36](#)  
[clear kerberos realm, page -37](#)  
[clear kerberos server, page -38](#)  
[clear key config-key, page -39](#)  
[clear l2protocol-tunnel cos, page -40](#)  
[clear l2protocol-tunnel statistics, page -41](#)  
[clear lacp-channel statistics, page -42](#)  
[clear lda, page -43](#)  
[clear localuser, page -45](#)  
[clear log, page -46](#)  
[clear log command, page -47](#)  
[clear logging buffer, page -48](#)  
[clear logging level, page -49](#)  
[clear logging server, page -51](#)  
[clear mls cef, page -52](#)  
[clear mls entry, page -53](#)  
[clear mls entry cef adjacency, page -55](#)  
[clear mls exclude protocol, page -56](#)  
[clear mls multicast statistics, page -57](#)  
[clear mls nde flow, page -58](#)  
[clear mls statistics, page -59](#)  
[clear mls statistics entry, page -61](#)  
[clear module password, page -63](#)  
[clear multicast router, page -64](#)  
[clear ntp server, page -65](#)  
[clear ntp timezone, page -66](#)  
[clear pbf, page -67](#)

[clear pbf-map, page -68](#)  
[clear port broadcast, page -70](#)  
[clear port cops, page -71](#)  
[clear port host, page -72](#)  
[clear port qos cos, page -73](#)  
[clear port security, page -74](#)  
[clear pvlan mapping, page -75](#)  
[clear qos acl, page -76](#)  
[clear qos config, page -78](#)  
[clear qos cos-dscp-map, page -79](#)  
[clear qos dscp-cos-map, page -80](#)  
[clear qos ipprec-dscp-map, page -81](#)  
[clear qos mac-cos, page -82](#)  
[clear qos map, page -83](#)  
[clear qos policed-dscp-map, page -85](#)  
[clear qos policer, page -86](#)  
[clear qos statistics, page -88](#)  
[clear radius, page -89](#)  
[clear rcp, page -90](#)  
[clear rgmp statistics, page -91](#)  
[clear security acl, page -92](#)  
[clear security acl capture-ports, page -94](#)  
[clear security acl log flow, page -95](#)  
[clear security acl map, page -96](#)  
[clear snmp access, page -98](#)  
[clear snmp access-list, page -99](#)  
[clear snmp community, page -100](#)  
[clear snmp community-ext, page -101](#)  
[clear snmp group, page -102](#)  
[clear snmp ifalias, page -103](#)  
[clear snmp notify, page -104](#)  
[clear snmp targetaddr, page -105](#)  
[clear snmp targetparams, page -106](#)  
[clear snmp trap, page -107](#)  
[clear snmp user, page -108](#)  
[clear snmp view, page -109](#)  
[clear spantree detected-protocols, page -110](#)  
[clear spantree mst, page -111](#)

[clear spantree portcost, page -112](#)  
[clear spantree portinstancecost, page -113](#)  
[clear spantree portinstancepri, page -115](#)  
[clear spantree portpri, page -116](#)  
[clear spantree portvlancost, page -117](#)  
[clear spantree portvlanpri, page -119](#)  
[clear spantree root, page -120](#)  
[clear spantree statistics, page -122](#)  
[clear spantree uplinkfast, page -124](#)  
[clear tacacs key, page -125](#)  
[clear tacacs server, page -126](#)  
[clear timezone, page -127](#)  
[clear top, page -128](#)  
[clear trunk, page -129](#)  
[clear vlan, page -130](#)  
[clear vlan counters, page -132](#)  
[clear vlan mapping, page -133](#)  
[clear vmps rcp, page -135](#)  
[clear vmps server, page -136](#)  
[clear vmps statistics, page -137](#)  
[clear vtp pruneeligible, page -138](#)  
[clear vtp statistics, page -139](#)  
[commit, page -140](#)  
[commit lda, page -142](#)  
[configure, page -143](#)  
[confreg, page -145](#)  
[context, page -147](#)  
[copy, page -149](#)

## D Commands

[delete, page -155](#)  
[dev, page -156](#)  
[dir—ROM monitor, page -157](#)  
[dir—switch, page -158](#)  
[disable, page -160](#)  
[disconnect, page -161](#)  
[download, page -162](#)

## E Commands

[enable, page -166](#)

## F Commands

[format, page -167](#)

[frame, page -169](#)

[fsck, page -170](#)

## H Commands

[history—ROM monitor, page -172](#)

[history—switch, page -173](#)

## L Commands

[l2trace, page -174](#)

## M Commands

[meminfo, page -177](#)

## P Commands

[ping, page -178](#)

[pwd, page -181](#)

## Q Commands

[quit, page -182](#)

## R Commands

[repeat, page -185](#)

[reset—ROM monitor, page -187](#)

[reset—switch, page -188](#)

[restore counters, page -191](#)  
[rollback, page -192](#)

## S Commands

[session, page -193](#)  
[slip, page -1107](#)  
[squeeze, page -1108](#)  
[stack, page -1109](#)  
[switch, page -1110](#)  
[switch console, page -1111](#)  
[switch fabric, page -1112](#)  
[sync, page -1113](#)  
[sysret, page -1114](#)

## set Commands

[set, page -194](#)  
[set accounting commands, page -195](#)  
[set accounting connect, page -196](#)  
[set accounting exec, page -197](#)  
[set accounting suppress, page -199](#)  
[set accounting system, page -200](#)  
[set accounting update, page -202](#)  
[set acllog ratelimit, page -203](#)  
[set aclmerge algo, page -204](#)  
[set aclmerge bdd, page -205](#)  
[set alias, page -206](#)  
[set arp, page -207](#)  
[set authentication enable, page -209](#)  
[set authentication login, page -211](#)  
[set authorization commands, page -213](#)  
[set authorization enable, page -215](#)  
[set authorization exec, page -217](#)  
[set banner lcd, page -219](#)  
[set banner motd, page -220](#)  
[set banner telnet, page -221](#)  
[set boot auto-config, page -222](#)

set boot config-register, page -223

set boot config-register auto-config, page -226

set boot device, page -229

set boot sync now, page -231

set boot system flash, page -232

set cam, page -234

set cam notification, page -236

set cdp, page -239

set channelprotocol, page -241

set channel vlancost, page -243

set config acl nvram, page -245

set config mode, page -246

set cops, page -248

set crypto key rsa, page -250

set default portstatus, page -251

set dot1q-all-tagged, page -252

set dot1x, page -253

set enablepass, page -256

set errdisable-timeout, page -257

set errordetection, page -259

set feature agg-link-partner, page -261

set feature dot1x-radius-keepalive, page -262

set feature mdg, page -263

set garp timer, page -264

set gmrp, page -265

set gmrp fwdall, page -266

set gmrp registration, page -267

set gmrp timer, page -268

set gvrp, page -270

set gvrp applicant, page -271

set gvrp dynamic-vlan-creation, page -272

set gvrp registration, page -273

set gvrp timer, page -275

set igmp, page -277

set igmp fastblock, page -278

set igmp fastleave, page -279

set igmp flooding, page -280

set igmp leave-query-type, page -281

set igmp mode, page -282

set igmp ratelimit, page -283

set igmp querier, page -285

set igmp v3-processing, page -287

set inlinepower defaultallocation, page -288

set interface, page -289

set ip alias, page -292

set ip dns, page -293

set ip dns domain, page -294

set ip dns server, page -295

set ip fragmentation, page -296

set ip http port, page -297

set ip http server, page -298

set ip permit, page -299

set ip redirect, page -301

set ip route, page -302

set ip unreachable, page -304

set kerberos clients mandatory, page -305

set kerberos credentials forward, page -306

set kerberos local-realm, page -307

set kerberos realm, page -308

set kerberos server, page -309

set kerberos srvtab entry, page -310

set kerberos srvtab remote, page -312

set key config-key, page -313

set l2protocol-tunnel cos, page -314

set l2protocol-tunnel trunk, page -315

set lacp-channel system-priority, page -316

set lcperroraction, page -317

set lda, page -318

set length, page -321

set localuser, page -322

set logging buffer, page -324

set logging console, page -325

set logging history, page -326

set logging level, page -327

set logging server, page -330

set logging session, page -332

set logging telnet, page -333  
set logging timestamp, page -334  
set logout, page -335  
set mls agingtime, page -336  
set mls bridged-flow-statistics, page -339  
set mls cef load-balance, page -340  
set mls cef per-prefix-statistics, page -341  
set mls exclude protocol, page -342  
set mls flow, page -343  
set mls nde, page -345  
set mls rate, page -349  
set mls statistics protocol, page -350  
set mls verify, page -351  
set module, page -353  
set module name, page -355  
set module power, page -356  
set module shutdown, page -357  
set msfcautostate, page -358  
set msmautostate, page -360  
set multicast router, page -361  
set ntp broadcastclient, page -362  
set ntp broadcastdelay, page -363  
set ntp client, page -364  
set ntp server, page -365  
set ntp summertime, page -366  
set ntp timezone, page -368  
set password, page -369  
set pbf, page -370  
set pbf-map, page -372  
set port arp-inspection, page -374  
set port auxiliaryvlan, page -375  
set port broadcast, page -377  
set port channel, page -379  
set port cops, page -382  
set port debounce, page -383  
set port disable, page -385  
set port dot1q-all-tagged, page -386  
set port dot1qtunnel, page -388

[set port dot1x, page -390](#)  
[set port duplex, page -393](#)  
[set port enable, page -394](#)  
[set port errdisable-timeout, page -395](#)  
[set port flowcontrol, page -396](#)  
[set port gmrp, page -398](#)  
[set port gvrp, page -399](#)  
[set port host, page -401](#)  
[set port inlinepower, page -402](#)  
[set port jumbo, page -403](#)  
[set port l2protocol-tunnel, page -404](#)  
[set port lacp-channel, page -406](#)  
[set port macro, page -408](#)  
[set port membership, page -411](#)  
[set port name, page -413](#)  
[set port negotiation, page -414](#)  
[set port protocol, page -415](#)  
[set port qos, page -417](#)  
[set port qos autoqos, page -419](#)  
[set port qos cos, page -421](#)  
[set port qos policy-source, page -422](#)  
[set port qos trust, page -424](#)  
[set port qos trust-device, page -426](#)  
[set port qos trust-ext, page -427](#)  
[set port rsvp dsbm-election, page -428](#)  
[set port security, page -429](#)  
[set port speed, page -432](#)  
[set port sync-restart-delay, page -433](#)  
[set port trap, page -434](#)  
[set port unicast-flood, page -435](#)  
[set port voice interface dhcp, page -437](#)  
[set power redundancy, page -439](#)  
[set prompt, page -440](#)  
[set protocolfilter, page -441](#)  
[set pvlan, page -442](#)  
[set pvlan mapping, page -444](#)  
[set qos, page -446](#)  
[set qos acl default-action, page -447](#)

set qos acl ip, page -449

set qos acl ipx, page -454

set qos acl mac, page -457

set qos acl map, page -459

set qos autoqos, page -461

set qos bridged-microflow-policing, page -462

set qos cos-dscp-map, page -463

set qos drop-threshold, page -464

set qos dscp-cos-map, page -466

set qos ipprec-dscp-map, page -467

set qos mac-cos, page -469

set qos map, page -470

set qos policed-dscp-map, page -473

set qos policer, page -474

set qos policy-source, page -477

set qos rsvp, page -479

set qos rxq-ratio, page -481

set qos statistics export, page -483

set qos statistics export aggregate, page -484

set qos statistics export destination, page -485

set qos statistics export interval, page -486

set qos statistics export port, page -487

set qos txq-ratio, page -488

set qos wred, page -490

set qos wrr, page -492

set radius attribute, page -494

set radius deadtime, page -495

set radius key, page -496

set radius retransmit, page -497

set radius server, page -498

set radius timeout, page -499

set rcp username, page -500

set rgmp, page -501

set rspan, page -502

set security acl adjacency, page -505

set security acl arp-inspection, page -506

set security acl capture-ports, page -508

set security acl feature ratelimit, page -509

[set security acl ip, page -510](#)  
[set security acl ipx, page -516](#)  
[set security acl log, page -519](#)  
[set security acl mac, page -520](#)  
[set security acl map, page -522](#)  
[set snmp, page -524](#)  
[set snmp access, page -525](#)  
[set snmp access-list, page -527](#)  
[set snmp buffer, page -529](#)  
[set snmp chassis-alias, page -530](#)  
[set snmp community, page -531](#)  
[set snmp community-ext, page -533](#)  
[set snmp extendedrmon netflow, page -535](#)  
[set snmp group, page -536](#)  
[set snmp ifalias, page -537](#)  
[set snmp notify, page -538](#)  
[set snmp rmon, page -539](#)  
[set snmp rmonmemory, page -540](#)  
[set snmp targetaddr, page -541](#)  
[set snmp targetparams, page -543](#)  
[set snmp trap, page -545](#)  
[set snmp user, page -548](#)  
[set snmp view, page -550](#)  
[set span, page -552](#)  
[set spantree backbonefast, page -555](#)  
[set spantree bpdu-filter, page -556](#)  
[set spantree bpdu-guard, page -557](#)  
[set spantree bpdu-skewing, page -558](#)  
[set spantree channelcost, page -559](#)  
[set spantree channelvlancost, page -561](#)  
[set spantree defaultcostmode, page -562](#)  
[set spantree disable, page -564](#)  
[set spantree enable, page -566](#)  
[set spantree fwddelay, page -568](#)  
[set spantree global-default, page -570](#)  
[set spantree guard, page -572](#)  
[set spantree hello, page -574](#)  
[set spantree link-type, page -576](#)

set spantree macreduction, page -577

set spantree maxage, page -578

set spantree mode, page -580

set spantree mst, page -582

set spantree mst config, page -583

set spantree mst link-type, page -585

set spantree mst maxhops, page -586

set spantree mst vlan, page -587

set spantree portcost, page -588

set spantree portfast, page -590

set spantree portfast bpdu-filter, page -592

set spantree portfast bpdu-guard, page -593

set spantree portinstancecost, page -594

set spantree portinstancepri, page -596

set spantree portpri, page -598

set spantree portvlancost, page -599

set spantree portvlanpri, page -602

set spantree priority, page -604

set spantree root, page -606

set spantree uplinkfast, page -609

set summertime, page -611

set system baud, page -613

set system contact, page -614

set system core-dump, page -615

set system core-file, page -616

set system countrycode, page -617

set system crossbar-fallback, page -618

set system highavailability, page -619

set system highavailability versioning, page -620

set system location, page -622

set system modem, page -623

set system name, page -624

set system supervisor-update, page -625

set system switchmode allow, page -627

set system syslog-dump, page -629

set system syslog-file, page -630

set tacacs attempts, page -631

set tacacs directedrequest, page -632

- set tacacs key, page -633
- set tacacs server, page -634
- set tacacs timeout, page -635
- set test diagfail-action, page -636
- set test diaglevel, page -637
- set time, page -638
- set timezone, page -639
- set traffic monitor, page -640
- set trunk, page -641
- set udd, page -644
- set udd aggressive-mode, page -646
- set udd interval, page -647
- set vlan, page -648
- set vlan mapping, page -652
- set vmpls downloadmethod, page -654
- set vmpls downloadserver, page -655
- set vmpls server, page -656
- set vmpls state, page -658
- set vtp, page -659
- set vtp pruneeligible, page -661

## show Commands

- show accounting, page -662
- show aclog, page -665
- show aclmerge, page -666
- show alias, page -667
- show arp, page -668
- show authentication, page -669
- show authorization, page -670
- show banner, page -671
- show boot, page -672
- show boot device, page -673
- show cam, page -674
- show cam agingtime, page -676
- show cam count, page -677
- show cam msfc, page -678
- show cam notification, page -679

[show cdp, page -682](#)  
[show channel, page -685](#)  
[show channel group, page -690](#)  
[show channel hash, page -694](#)  
[show channel mac, page -695](#)  
[show channelprotocol, page -696](#)  
[show channel traffic, page -697](#)  
[show config, page -698](#)  
[show config mode, page -704](#)  
[show config qos acl, page -705](#)  
[show cops, page -706](#)  
[show counters, page -709](#)  
[show crypto key, page -715](#)  
[show default, page -716](#)  
[show dot1q-all-tagged, page -717](#)  
[show dot1x, page -718](#)  
[show dvlan statistics, page -719](#)  
[show environment, page -720](#)  
[show errdisable-timeout, page -725](#)  
[show errordetection, page -726](#)  
[show fabric channel, page -727](#)  
[show file, page -730](#)  
[show flash, page -731](#)  
[show garp timer, page -734](#)  
[show gmrp configuration, page -735](#)  
[show gmrp statistics, page -736](#)  
[show gmrp timer, page -737](#)  
[show gvrp configuration, page -738](#)  
[show gvrp statistics, page -740](#)  
[show ifindex, page -742](#)  
[show igmp flooding, page -743](#)  
[show igmp leave-query-type, page -744](#)  
[show igmp mode, page -745](#)  
[show igmp querier information, page -746](#)  
[show igmp ratelimit-info, page -747](#)  
[show igmp statistics, page -748](#)  
[show imagemib, page -750](#)  
[show interface, page -751](#)

[show ip alias, page -753](#)  
[show ip dns, page -754](#)  
[show ip http, page -756](#)  
[show ip permit, page -758](#)  
[show ip route, page -760](#)  
[show kerberos, page -762](#)  
[show l2protocol-tunnel statistics, page -764](#)  
[show lacp-channel, page -766](#)  
[show lcperroraction, page -770](#)  
[show lda, page -771](#)  
[show localuser, page -775](#)  
[show log, page -776](#)  
[show log command, page -778](#)  
[show logging, page -779](#)  
[show logging buffer, page -781](#)  
[show mac, page -782](#)  
[show microcode, page -785](#)  
[show mls, page -786](#)  
[show mls acl-route, page -788](#)  
[show mls cef interface, page -789](#)  
[show mls cef mac, page -791](#)  
[show mls cef summary, page -792](#)  
[show mls entry, page -794](#)  
[show mls entry cef, page -800](#)  
[show mls entry netflow-route, page -804](#)  
[show mls exclude protocol, page -806](#)  
[show mls multicast, page -807](#)  
[show mls nde, page -812](#)  
[show mls netflow-route, page -813](#)  
[show mls pbr-route, page -814](#)  
[show mls statistics, page -815](#)  
[show mls verify, page -819](#)  
[show module, page -820](#)  
[show moduleinit, page -823](#)  
[show msfcautostate, page -825](#)  
[show msmautostate, page -826](#)  
[show multicast group, page -827](#)  
[show multicast group count, page -829](#)

[show multicast protocols status, page -830](#)  
[show multicast router, page -831](#)  
[show multicast v3-group, page -833](#)  
[show netstat, page -834](#)  
[show ntp, page -841](#)  
[show pbf, page -843](#)  
[show pbf-map, page -845](#)  
[show port, page -846](#)  
[show port arp-inspection, page -854](#)  
[show port auxiliaryvlan, page -855](#)  
[show port broadcast, page -857](#)  
[show port capabilities, page -859](#)  
[show port cdp, page -864](#)  
[show port channel, page -866](#)  
[show port cops, page -872](#)  
[show port counters, page -874](#)  
[show port debounce, page -876](#)  
[show port dot1q-all-tagged, page -877](#)  
[show port dot1q-ethertype, page -878](#)  
[show port dot1qtunnel, page -879](#)  
[show port dot1x, page -880](#)  
[show port errdisable-timeout, page -882](#)  
[show port flowcontrol, page -884](#)  
[show port inlinepower, page -886](#)  
[show port jumbo, page -887](#)  
[show port l2protocol-tunnel, page -888](#)  
[show port lacp-channel, page -889](#)  
[show port mac, page -892](#)  
[show port mac-address, page -894](#)  
[show port negotiation, page -896](#)  
[show port prbs, page -897](#)  
[show port protocol, page -898](#)  
[show port qos, page -899](#)  
[show port rsvp, page -902](#)  
[show port security, page -903](#)  
[show port spantree, page -906](#)  
[show port status, page -907](#)  
[show port sync-restart-delay, page -908](#)

[show port tdr, page -909](#)  
[show port trap, page -911](#)  
[show port trunk, page -912](#)  
[show port unicast-flood, page -914](#)  
[show port voice, page -915](#)  
[show port voice active, page -918](#)  
[show port voice fdl, page -922](#)  
[show port voice interface, page -924](#)  
[show proc, page -925](#)  
[show protocolfilter, page -929](#)  
[show pvlan, page -930](#)  
[show pvlan capability, page -932](#)  
[show pvlan mapping, page -934](#)  
[show qos acl editbuffer, page -936](#)  
[show qos acl info, page -937](#)  
[show qos acl map, page -939](#)  
[show qos acl resource-usage, page -941](#)  
[show qos bridged-microflow-policing, page -942](#)  
[show qos info, page -943](#)  
[show qos mac-cos, page -949](#)  
[show qos maps, page -951](#)  
[show qos policer, page -954](#)  
[show qos policy-source, page -956](#)  
[show qos rsvp, page -957](#)  
[show qos statistics, page -958](#)  
[show qos statistics export info, page -960](#)  
[show qos status, page -961](#)  
[show radius, page -962](#)  
[show rcp, page -964](#)  
[show reset, page -965](#)  
[show rgmp group, page -966](#)  
[show rgmp statistics, page -967](#)  
[show rspan, page -968](#)  
[show running-config, page -970](#)  
[show security acl, page -973](#)  
[show security acl arp-inspection, page -976](#)  
[show security acl capture-ports, page -977](#)  
[show security acl feature ratelimit, page -978](#)

[show security acl log, page -979](#)  
[show security acl map, page -982](#)  
[show security acl resource-usage, page -983](#)  
[show snmp, page -984](#)  
[show snmp access, page -986](#)  
[show snmp access-list, page -988](#)  
[show snmp buffer, page -989](#)  
[show snmp community, page -990](#)  
[show snmp context, page -992](#)  
[show snmp counters, page -993](#)  
[show snmp engineid, page -997](#)  
[show snmp group, page -998](#)  
[show snmp ifalias, page -1000](#)  
[show snmp notify, page -1001](#)  
[show snmp rmonmemory, page -1003](#)  
[show snmp targetaddr, page -1004](#)  
[show snmp targetparams, page -1006](#)  
[show snmp user, page -1008](#)  
[show snmp view, page -1010](#)  
[show span, page -1012](#)  
[show spantree, page -1014](#)  
[show spantree backbonefast, page -1018](#)  
[show spantree blockedports, page -1019](#)  
[show spantree bpdu-filter, page -1021](#)  
[show spantree bpdu-guard, page -1022](#)  
[show spantree bpdu-skewing, page -1023](#)  
[show spantree conflicts, page -1025](#)  
[show spantree defaultcostmode, page -1027](#)  
[show spantree guard, page -1028](#)  
[show spantree mapping, page -1030](#)  
[show spantree mistp-instance, page -1032](#)  
[show spantree mst, page -1034](#)  
[show spantree mst config, page -1036](#)  
[show spantree portfast, page -1038](#)  
[show spantree portinstancecost, page -1039](#)  
[show spantree portvlancost, page -1040](#)  
[show spantree statistics, page -1041](#)  
[show spantree summary, page -1048](#)

[show spantree uplinkfast, page -1051](#)  
[show startup-config, page -1053](#)  
[show summertime, page -1056](#)  
[show system, page -1057](#)  
[show system highavailability, page -1061](#)  
[show system supervisor-update, page -1062](#)  
[show system switchmode, page -1063](#)  
[show tacacs, page -1064](#)  
[show tech-support, page -1066](#)  
[show test, page -1069](#)  
[show time, page -1074](#)  
[show timezone, page -1075](#)  
[show top, page -1076](#)  
[show top report, page -1078](#)  
[show traffic, page -1080](#)  
[show traffic, page -1080](#)  
[show trunk, page -1081](#)  
[show udd, page -1084](#)  
[show users, page -1086](#)  
[show version, page -1087](#)  
[show vlan, page -1090](#)  
[show vlan counters, page -1095](#)  
[show vmpls, page -1097](#)  
[show vmpls mac, page -1099](#)  
[show vmpls statistics, page -1100](#)  
[show vmpls vlan, page -1102](#)  
[show vtp domain, page -1103](#)  
[show vtp statistics, page -1105](#)

## T Commands

[telnet, page -1115](#)  
[test cable-diagnostics, page -1116](#)  
[test snmp trap, page -1118](#)  
[traceroute, page -1119](#)

## U Commands

[unalias, page -1122](#)

[undelete, page -1123](#)

[unset=varname, page -1124](#)

## V Commands

[varname=, page -1125](#)

[verify, page -1126](#)

## W Commands

[wait, page -1127](#)

[whichboot, page -1128](#)

[write, page -1129](#)

[write tech-support, page -1132](#)

