



CHAPTER 48

Configuring RMON

This chapter describes how to configure Remote Monitoring (RMON) on the Catalyst 6500 series switches.



Note

For complete syntax and usage information for the commands that are used in this chapter, refer to the *Catalyst 6500 Series Switch Command Reference* publication.

This chapter consists of these sections:

- [Understanding How RMON Works, page 48-1](#)
- [Enabling RMON on the Switch, page 48-2](#)
- [Viewing the RMON Data, page 48-2](#)
- [Supported RMON and RMON2 MIB Objects, page 48-3](#)

Understanding How RMON Works

RMON is an Internet Engineering Task Force (IETF) standard monitoring specification that allows the various network agents and console systems to exchange network monitoring data. The supervisor engine software provides embedded support for these components of the RMON specification (see the [“Supported RMON and RMON2 MIB Objects”](#) section on page 48-3 for details):

- The following RMON groups are defined in RFC 1757:
 - Statistics (RMON group 1) for Ethernet, Fast Ethernet, Fast EtherChannel, and Gigabit Ethernet switch ports (uses 140 bytes of supervisor engine RAM per port)
 - History (RMON group 2) for Ethernet, Fast Ethernet, Fast EtherChannel, and Gigabit Ethernet switch ports (uses 3 KB of supervisor engine RAM for the first 50 buckets; each additional bucket uses another 56 bytes)
 - Alarm (RMON group 3; each alarm configured uses 1.3 KB of supervisor engine RAM)
 - Event (RMON group 9; each event configured uses 1.3 KB of supervisor engine RAM)
- The following RMON2 groups are defined in RFC 2021:
 - UsrHistory (RMON2 group 18)
 - ProbeConfig (RMON2 group 19)

The embedded RMON agent allows the switch to monitor network traffic from all ports simultaneously at Layer 2 without requiring a dedicated monitoring probe or network analyzer. For more information on RMON, visit:

<http://www.cisco.com/en/US/docs/internetworking/technology/handbook/RMON.html>

Enabling RMON on the Switch



Note

RMON is disabled by default.

To enable RMON, perform this task in privileged mode:

	Task	Command
Step 1	Enable RMON on the switch.	set snmp rmon enable
Step 2	Verify that RMON is enabled.	show snmp

This example shows how to enable RMON on the switch and how to verify that RMON is enabled:

```

Console> (enable) set snmp rmon enable
SNMP RMON support enabled.
Console> (enable) show snmp
RMON:                               Enabled
Extended RMON:                       Extended RMON module is not present
Traps Enabled:
Port, Module, Chassis, Bridge, Repeater, Vtp, Auth, ippermit, Vmps, config, entity, stpx
Port Traps Enabled: 1/1-2,4/1-48,5/1
Community-Access      Community-String
-----
read-only              Everyone
read-write             Administrators
read-write-all       Root
Trap-Rec-Address
-----
172.16.10.10          read-write
172.16.10.20          read-write-all
Console> (enable)

```

Viewing the RMON Data

Access to the RMON data is available only on a network management system (NMS) that supports RFC 1757 and RFC 2021 (see the “Using CiscoWorks2000” section on page 46-6). You cannot access the RMON data through the switch CLI; however, the CLI **show** commands provide similar information.

Supported RMON and RMON2 MIB Objects

Table 48-1 lists the RMON and RMON2 MIB objects that are supported by the supervisor engine software.

Table 48-1 Supervisor Engine RMON and RMON2 Support

Object Identifier (OID) and Description	Source
...mib-2(1).rmon(16).statistics(1).etherStatsTable(1) Counters for packets, octets, broadcasts, errors, etc.	RFC 1757 (RMON-MIB)
...mib-2(1).rmon(16).history(2).historyControlTable(1)	RFC 1757 (RMON-MIB)
...mib-2(1).rmon(16).history(2).etherHistoryTable(2) Periodically samples and saves statistics group counters for later retrieval.	RFC 1757 (RMON-MIB)
...mib-2(1).rmon(16).alarm(3) A threshold that can be set on critical RMON variables for network management.	RFC 1757 (RMON-MIB)
...mib-2(1).rmon(16).event(9) Generates SNMP traps when an Alarms group threshold is exceeded and logs the events.	RFC 1757 (RMON-MIB)
...mib-2(1).rmon(16).usrHistory(18) Extends history beyond RMON1 link-layer statistics to include any RMON, RMON2, MIB-I, or MIB-II statistic.	RFC 2021 (RMON2-MIB)
...mib-2(1).rmon(16).probeConfig(19) Displays a list of agent capabilities and configurations.	RFC 2021 (RMON2-MIB)

