



# Preface

---

Revised: February 10, 2012, OL-22192-02

## Organization

This guide includes the following chapters and appendixes:

Chapter or Appendix Title	Description
<a href="#">Chapter 1, “Cisco TrustSec Overview”</a>	Describes the elements and processes that create the Cisco TrustSec network.
<a href="#">Chapter 2, “Configuring the Cisco TrustSec Solution”</a>	Provides an overview of configuration tasks required to implement a Cisco TrustSec Network.
<a href="#">Chapter 3, “Configuring Identities, Connections, and SGTs”</a>	Provides NDAC and TrustSec seed device configuration procedures.
<a href="#">Chapter 4, “Configuring SGT Exchange Protocol over TCP (SXP) and Layer 3 Transport”</a>	Provides SGT over TCP Protocol (SXP) configuration procedures.
<a href="#">Chapter 5, “Configuring SGACL Policies”</a>	Provides Security Group ACL configuration procedures from the switch CLI.
<a href="#">Chapter 6, “Configuring Endpoint Admission Control”</a>	Provides 802.1X, MAB, and WebAuth configuration procedures for a TrustSec context.
<a href="#">Chapter 7, “Cisco TrustSec Command Summary”</a>	Provides a list of Cisco TrustSec CLI commands with brief descriptions.
<a href="#">Appendix A, “Notes for Catalyst 3750, 3560, and 2960 Series Switches”</a>	Describes constraints, limitations, or considerations pertaining to TrustSec implementation of Catalyst 3750 and 3560 Series Switches.
<a href="#">Appendix B, “Notes for Catalyst 4500 Series Switches”</a>	Describes constraints, limitations, or considerations pertaining to TrustSec implementation of Catalyst 4500 Series Switches.
<a href="#">Appendix C, “Notes for Catalyst 6500 Series Switches”</a>	Describes constraints, limitations, or considerations pertaining to TrustSec implementation of Catalyst 6500 Series Switches.

# Conventions

This document uses the following conventions:

Convention	Indication
<b>bold font</b>	Commands and keywords and user-entered text appear in <b>bold font</b> .
<i>italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
[ ]	Elements in square brackets are optional.
{ x   y   z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[ x   y   z ]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<code>courier font</code>	Terminal sessions and information the system displays appear in <code>courier font</code> .
< >	Nonprinting characters such as passwords are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



## Note

Means *reader take note*.



## Tip

Means *the following information will help you solve a problem*.



## Caution

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.



## Timesaver

Means *the described action saves time*. You can save time by performing the action described in the paragraph.



## Warning

Means ***reader be warned***. In this situation, you might perform an action that could result in **bodily injury**.

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

