



## **GLOSSARY**

Revised: December 9, 2008, OL-15637-04

### **A**

<b>ABBR</b>	abbreviated
<b>ACQ</b>	all calls query
<b>ADDR</b>	address
<b>AIN</b>	Advanced Intelligent Network
<b>ALT</b>	alternate
<b>ALWD</b>	allowed
<b>ANI</b>	automatic number identification
<b>ANNC</b>	announcement
<b>ANSI</b>	American National Standards Institute
<b>ARQ</b>	admission request
<b>AS</b>	application server
<b>ASC</b>	ascending
<b>ASCII</b>	Standard Code for Information Interchange
<b>AT</b>	access tandem
<b>ATM</b>	Asynchronous Transfer Mode

### **B**

<b>BKWD</b>	backward
<b>BLV</b>	business line verification

### **C**

<b>CA</b>	California
-----------	------------

<b>CA</b>	Call Agent
<b>CAC</b>	carrier access code
<b>CAP</b>	competitive access provider
<b>CAS</b>	channel associated signaling
<b>CASC</b>	cyclic ascending
<b>CC</b>	country code
<b>CD-ROM</b>	compact disk-read only memory
<b>CdPN</b>	called party number
<b>CDP</b>	custom dial plan
<b>CDSC</b>	cyclic descending
<b>CHAR</b>	character
<b>CHG</b>	charge
<b>CLDPTY</b>	called party
<b>CLI</b>	command-line interface
<b>CLLI</b>	Common Language Location Identifier
<b>CND</b>	calling number delivery
<b>COMM</b>	communication
<b>CoS</b>	class of service
<b>COT</b>	continuity test
<b>CPN</b>	calling party number
<b>CTRL</b>	control
<b>CTX</b>	Centrex

**D**

<b>DA</b>	directory assistance
<b>DBM</b>	database management
<b>DDD</b>	direct distance or domestic dialing
<b>DEL</b>	delete

<b>DEST</b>	destination
<b>DIGMAN</b>	digital manipulation
<b>DN</b>	directory number
<b>DNIS</b>	dialed number identification service
<b>DOW</b>	day of week
<b>DOY</b>	day of year
<b>DP</b>	dial plan
<b>DP-ID</b>	dial-plan identification
<b>DPC</b>	destination point code
<b>DSC</b>	descending order
<b>DT</b>	CAS DTMF endpoints
<b>DTMF</b>	dual tone multifrequency
<b>E</b>	
<b>EMEA</b>	Europe, Middle East, and Asia
<b>EMG</b>	emergency
<b>EMS</b>	Element Management System
<b>ENUM</b>	electronic number mapping
<b>EPOM</b>	Extensible Provisioning and Operations Manager
<b>F</b>	
<b>FA</b>	faulty
<b>FA-RB</b>	faulty remotely blocked
<b>FAS</b>	facility associated signaling
<b>FGD</b>	Feature Group D
<b>FS</b>	Feature Server

**G**

<b>GAP</b>	generic address parameter
<b>GRP</b>	group
<b>GTD</b>	Generic Transparency Descriptor
<b>GW</b>	gateway

**H**

<b>HNPA</b>	home numbering plan area
-------------	--------------------------

**I**

<b>IAM</b>	initial address message
<b>ID</b>	identification
<b>IDDD</b>	international direct dial domestic
<b>INFO</b>	information
<b>INTL</b>	international
<b>INTL-OPR</b>	international operator
<b>ISDN</b>	Integrated Services Digital Network
<b>ISUP</b>	ISDN user part
<b>IT</b>	ISUP trunk
<b>ITP</b>	IP transfer point
<b>ITU</b>	International Telecommunication Union
<b>IVR</b>	interactive voice response

**L**

<b>LATA</b>	local access transport area
<b>LB</b>	loop-back
<b>LCR</b>	least cost routing
<b>LECOSS</b>	local exchange carrier operations support system

<b>LNP</b>	local number portability
<b>LRN</b>	local routing number
<b>LRU</b>	least recently used
<b>LS</b>	load sharing
<b>LSA</b>	local service area
<b>M</b>	
<b>MAX</b>	maximum
<b>MF</b>	multifrequency
<b>MGCP</b>	Media Gateway Control Protocol
<b>MGW</b>	media gateway
<b>MIN</b>	minimum
<b>MLHG</b>	multi-line hunt group
<b>MO</b>	MF operator trunk
<b>MRU</b>	most recently used
<b>MS</b>	CAS MF endpoints
<b>MSG</b>	message
<b>MT</b>	MF terminating trunk
<b>N</b>	
<b>NA</b>	not applicable
<b>NANP</b>	North American Numbering Plan
<b>NAS</b>	network access server
<b>NAT</b>	national
<b>NAT-OPR</b>	national operator
<b>NCT</b>	network continuity test
<b>NDC</b>	national destination code
<b>NF</b>	non-faulty

<b>NF-RB</b>	non-faulty remotely blocked
<b>NFAS</b>	non-facility associated signaling
<b>NLB</b>	network loop-back
<b>NOA</b>	nature of address
<b>NPA</b>	numbering plan area
<b>NS0</b>	network specific (111 1000)
<b>NS1</b>	network specific (111 1001)
<b>NS2</b>	network specific (111 1010)
<b>NS3</b>	network specific (111 1011)
<b>NS4</b>	network specific (111 1100)
<b>NS5</b>	network specific (111 1101)
<b>NS6</b>	network specific (111 1110)
<b>NTWK</b>	network
<b>NUM</b>	number

## O

<b>OBCSM</b>	originating basic call state machine
<b>OCN</b>	original called number
<b>ODD</b>	odd-numbered
<b>ODR</b>	origin dependent routing
<b>OLI</b>	originating line information
<b>OPER</b>	operational
<b>OPR</b>	operator

## P

<b>PBX</b>	private branch exchange
<b>PC</b>	point code
<b>PCS</b>	personal communications services

<b>PFX</b>	prefix
<b>PIC</b>	point in call, presubscribed interexchange carrier
<b>PKG</b>	package
<b>POP</b>	point of presence
<b>POTS</b>	plain old telephone service
<b>PSTN</b>	public switched telephone network

## **Q**

<b>QOR</b>	query on release
<b>QOS</b>	quality of service

## **R**

<b>RACF</b>	remote activation of call forwarding
<b>RAND</b>	random
<b>RDN</b>	Redirecting Number Information Element
<b>REL</b>	release
<b>RID</b>	route identification
<b>RN</b>	routing number
<b>RPF</b>	registration and profiling tool
<b>RR</b>	round robin
<b>RRQ</b>	registration request

## **S**

<b>S1</b>	severity 1
<b>S2</b>	severity 2
<b>S3</b>	severity 3
<b>S4</b>	severity 4
<b>SAC</b>	service access code

<b>SCP</b>	service control point
<b>SEL</b>	selection
<b>SEQ</b>	sequential
<b>SIP</b>	Session Initiation Protocol
<b>SP</b>	service provider
<b>SS7</b>	Signaling System 7
<b>SUB</b>	subscriber
<b>SUB-OPR</b>	subscriber operator
<b>SUPP</b>	supported

**T**

<b>TAC</b>	Technical Assistance Center
<b>TBCSM</b>	terminating basic call system manager
<b>TCL</b>	tool command language
<b>TDM</b>	telecommunications data link monitor
<b>TG</b>	trunk group
<b>TGN</b>	trunk group number
<b>TM</b>	trunk member
<b>TMR</b>	timer
<b>TNS</b>	transit network selection
<b>TOD</b>	time of day
<b>TSAP</b>	transport service access point
<b>TW</b>	time weather call

**U**

<b>UAN</b>	universal access number
<b>URL</b>	uniform resource locator

**US** United States  
**USA** United States of America

**V**

**VARCHAR** variable character  
**VSC** Vertical Service Code

