



Voice Menu Codes

This section contains a quick-reference list of the voice configuration menu options for the Cisco ATA.

This section contains the following tables:

- [Cisco ATA Voice Menu Codes—Information Options, page B-1](#)
- [Cisco ATA Voice Menu Codes—Configuration Parameters, page B-2](#)
- [Cisco ATA Voice Menu Codes—Software Upgrade, page B-4](#)



Note

Follow each voice menu code with #.



Note

The term *Cisco ATA* refers to both the Cisco ATA 186 and the Cisco ATA 188, unless otherwise stated.

[Table B-1](#) lists codes to return basic Cisco ATA information.

Table B-1 Cisco ATA Voice Menu Codes—Information Options

Option	Voice Menu Code	Description
Build information	123123	Build date of the Cisco ATA software
Review IP address	21	Returns IP address of the Cisco ATA
Review MAC address	24	Returns media access control (MAC) address of the Cisco ATA
Review network route IP address	22	Returns IP address of the network route
Review subnet mask	23	Returns subnet mask of the network route
Version number	123	Returns version number of the Cisco ATA software

Table B-2 lists configuration codes.

Table B-2 Cisco ATA Voice Menu Codes—Configuration Parameters

Option	Voice Menu Code	Description
Alternate NTP IP address	78	IP address of the alternate NTP server
Audio mode	312	Allows finer control of the audio component to suit certain user applications
Call features	314	Subscribed features statically enabled by the user
Caller ID method	316	Specifies the signal format when generating the Caller ID format to use
TFTP Configuration Interval	80002	Interval (in seconds) between configuration updates when TFTP configuration is used,
Connection mode	311	Controls the connection mode of the call signaling protocol
Dynamic Host Configuration Protocol (DHCP)	20	Controls whether the Cisco ATA can automatically obtain configuration parameters from a server over the network
DNS 1 IP	916	IP address of the primary DNS server
DNS 2 IP	917	IP address of the secondary DNS server
Encrypt key	320	Encrypts the configuration file on the TFTP server
Gatekeeper/proxy server IP address	5	H.323 gatekeeper IP address
H.323 protocol	38	Selects the signaling protocol
IP address	1	IP address of the Cisco ATA
LBR codec	300	Low bit rate codec selection
Login ID 0	46	Alternate user ID used for authentication
Login ID 1	47	Alternate user ID used for authentication
Media port	202	Specifies which base port the Cisco ATA uses to receive RTP media streams
Network route address	2	Network router address
NPrintf address	81	IP address of a host to which all Cisco ATA debug messages are sent
NTP server address	141	IP address of the NTP server
Num Tx frames	35	Number of frames transmitted per packet
Paid features	315	Features subscribed to by the user
Polarity	304	Controls connect and disconnect polarity
PWD 0	4	Password associated with the primary phone line (UID0 or LoginID0)
PWD 1	14	Password associated with the secondary phone line (UID1 or LoginID1)

Table B-2 Cisco ATA Voice Menu Codes—Configuration Parameters (continued)

Option	Voice Menu Code	Description
Rx codec	36	Selects the audio codec type to use to decode received data. The call-receiving station automatically adjusts to the call-initiating station's audio codec type if the call-receiving station supports that audio codec.
Set password	7387277	Configuration interface password
Signal timers	318	Timeout values controlling the starting or stopping of a signaling event
H.323 max number of redirects	205	Maximum number of redirections the Cisco ATA will attempt to reach a callee when making a call
Subnet mask	10	Specifies the subnet mask for the Cisco ATA
TFTP URL	905	IP address of the TFTP server when TFTP configuration is used
Timezone	302	Specifies offset to GMT—used to time-stamp incoming calls for caller ID
ToConfig	80001	Identifies unconfigured or already-configured Cisco ATAs
Trace Fflags	313	Enables logging of debug information
Tx Codec	37	Selects transmitting audio codec preference
UDP TOS bits	255	Determines the precedence and delay of UDP IP packets
UID 0	3	User ID (telephone number) for the PHONE 1 port
UID 1	13	User ID (telephone number) for the PHONE 2 port
Use login ID	93	Determines which pair (UIDx, PWDx or LoginIDx, PWDx) to use for authentication
Use TFTP	305	Enables TFTP as configuration method

Table B-3 lists codes used in the software upgrade process. For information about these codes, see Chapter 8, “Upgrading the Cisco ATA Signaling Image.”

Table B-3 Cisco ATA Voice Menu Codes—Software Upgrade

Option	Voice Menu Code	Description
Upgrade software	100	Used in the software process to enter the IP address of the PC
Upgrade language to English	101	When upgrading software, changes or upgrades the voice prompt language to English