



Device Configuration

Cisco CallManager allows you to configure the following devices in your telephony network:

- Cisco voice-mail ports
- CTI route points
- Device profiles
- Gatekeepers
- Gateways
- Phones

This section covers the following topics:

- [Adding Devices to Cisco CallManager, page 36-2](#)
- [Restarting or Resetting a Device, page 36-2](#)

Adding Devices to Cisco CallManager

Before you can use devices, such as gateways and Cisco IP phones in your IP telephony network, you must add them to the Cisco CallManager configuration database.

Refer to these sections for assistance in adding telephony devices to the Cisco CallManager configuration database:

- [Adding a CTI Route Point, page 37-2](#)
- [Adding a Gatekeeper, page 40-2](#)
- [Adding Gateways to Cisco CallManager, page 41-2](#)
- [Adding a Phone, page 42-4](#)
- [Adding Phone Button Templates, page 43-2](#)
- [Adding Cisco Voice Mail Ports, page 38-12](#)

Restarting or Resetting a Device

At any time, you can restart or reset a device by clicking the Reset button on the device pane or by clicking the Reset icon on the Find and List pane associated with the device, if available. You can restart a device without shutting it down by clicking the **Restart** button. You can shut down a device and bring it back up again by clicking the **Reset** button. If you want to return to the previous window without resetting or restarting the device, click **Close**.



Note

Restarting or resetting a gateway drops any calls in progress using that gateway. Other devices wait until calls are complete before restarting or resetting.
