



Device Configuration

Cisco CallManager allows you to configure the following devices in your telephony network:

- Cisco voice-mail ports
- CTI route points
- Device profiles
- Gatekeepers
- Gateways
- Phones

This section covers the following topics:

- [Adding Devices to Cisco CallManager, page 40-1](#)
- [Restarting or Resetting a Device, page 40-2](#)

Adding Devices to Cisco CallManager

Before you can use devices, such as gateways and Cisco IP Phones in your IP telephony network, you must add them to the Cisco CallManager configuration database. You can add several of these devices by using the Add a New Device window. Refer to these sections for assistance in adding those telephony devices:

- [Adding a CTI Route Point, page 41-2](#)
- [Adding a Gatekeeper, page 43-4](#)
- [Adding Gateways to Cisco CallManager, page 44-1](#)

- [Adding a Phone, page 45-5](#)
- [Adding Cisco Voice-Mail Ports, page 35-4](#)
- [Adding a Trunk, page 46-3](#)

Restarting or Resetting a Device

At any time, you can restart or reset a device by clicking the Reset button in the device window or by clicking the Reset icon in the Find and List window that is associated with the device, if available. You can restart a device without shutting it down by clicking the **Restart** button. You can shut down a device and bring it back up again by clicking the **Reset** button. If you want to return to the previous window without resetting or restarting the device, click **Close**.



Note

Restarting or resetting a gateway drops any calls in progress that are using that gateway. Other devices wait until calls complete before restarting or resetting.
