



---

## A

### adding

- Catalyst 6000 FXS ports [7-19](#)
- Catalyst 6000 FXS ports to Cisco CallManager [7-26](#)
- IP services to phone template [3-6](#)
- lines to existing phones [3-31](#)
- lines to phone template [3-5](#)
- manager assistant [6-11](#)
- phones [3-24](#)
- phone template [3-3](#)
- speed dial settings to phone template [3-6](#)
- user device profiles [5-1, 5-13](#)
- users [4-1](#)
- users to Cisco CallManager [4-8](#)
- VG200 FXS or FXO gateways to Cisco CallManager [7-15](#)
- VG200 gateways and ports [7-2](#)
- VG200 T1-CAS, T1-PRI, or E1-PRI gateways to Cisco CallManager [7-15](#)

auto-registration [9-1](#)

---

## B

### BAT

- browser requirements [1-3](#)
- default location of log files [8-14, 10-1](#)
- error messages [10-2](#)
- installation overview [2-1](#)
- installing [2-3](#)
- log files [10-1](#)
- logging on [1-4](#)
- online help [1-4](#)
- overview [1-1](#)
- specifications [1-2](#)
- starting [1-3](#)
- stopping [1-5](#)
- troubleshooting [10-1, 10-2](#)
- uninstalling [2-8](#)
- upgrading [2-2](#)
- using [1-3](#)
- version [1-4](#)
- viewing log files [10-2](#)

### BAT.xlt

- create CSV for CTI ports [3-9](#)
- create CSV for CTI ports-users [3-9](#)
- create CSV for H.323 clients [3-9](#)

- create CSV for H.323 clients-user [3-9](#)
- create CSV for manager assistant associations [6-5](#)
- create CSV for phones [3-9](#)
- create CSV for phones-users [3-9](#)
- create CSV for users [4-3, 4-13](#)
- create CSV for VGC phones [3-9](#)
- create CSV for VGC phones-users [3-9](#)
- create CSV for VGC virtual phones [3-9](#)
- create CSV for VGC virtual phones-users [3-9](#)
- creating Catalyst 6000 FXS ports [7-23](#)
- file location [2-3](#)
- browser requirements [1-3](#)

---

## C

### Cisco CallManager

- adding Catalyst 6000 FXS ports [7-26](#)
- adding CTI ports [3-24](#)
- adding H.323 clients [3-24](#)
- adding phones [3-24, 3-26](#)
- adding phones and users [3-26](#)
- adding users [4-8](#)
- adding VG200 FXS or FXO gateways [7-15](#)
- adding VG200 T1-CAS, T1-PRI, or E1-PRI gateways [7-15](#)
- adding VGC phones [3-24](#)
- auto-registration must be enabled for TAPS [9-1](#)

- Cisco Catalyst 6000 FXS ports
  - adding or updating ports [7-19](#)
  - adding ports [7-19](#)
  - adding to Cisco CallManager [7-26](#)
  - creating BAT template [7-20](#)
  - creating CSV file [7-21](#)
  - deleting ports [7-30](#)
  - deleting template [7-34](#)
  - field descriptions [7-57](#)
  - limit of 500 [7-23](#)
  - overview [7-1, 7-19](#)
  - updating [7-29](#)

### Cisco CRA

- required for TAPS [9-2](#)
- troubleshooting TAPS [10-6](#)
- uninstalling TAPS [2-9](#)
- uploading TAPS [2-7](#)

### Cisco IP IVR

- required for TAPS [9-2](#)

### Cisco VG200

- adding gateways and ports [7-2](#)
- adding to Cisco CallManager (FXS or FXO) [7-15](#)
- adding to Cisco CallManager (T1-CAS, T1-PRI, or E1-PRI) [7-15](#)
- configure using CLI prior to adding gateways in BAT [7-1](#)
- copying a template [7-16](#)
- creating a template [7-3](#)
- creating CSV file for FXS or FXO [7-7](#)

- creating CSV file for T1-CAS, T1-PRI, or E1-PRI [7-9](#)
- delete only selected gateways [7-17](#)
- deleting BAT template [7-34](#)
- deleting gateways [7-17](#)
- field descriptions for E1-PRI [7-44](#)
- field descriptions for FXO [7-37](#)
- field descriptions for FXS [7-35](#)
- field descriptions for T1-CAS [7-39](#)
- field descriptions for T1-PRI [7-44](#)
- overview [7-1](#)
- updating endpoint identifiers [7-7](#)
- Cisco VGC phones
  - adding VGC phones-users to Cisco CallManager [3-26](#)
  - adding VGC phone-users to Cisco CallManager [3-26](#)
  - creating CSV file [3-7](#)
  - updating phone records [3-32](#)
- Cisco VGC virtual phones
  - adding VGC virtual phones-users to Cisco CallManager [3-26](#)
  - adding VGC virtual phone-users to Cisco CallManager [3-26](#)
  - creating CSV file [3-7](#)
- CLI [7-1](#)
- Client Matter Codes
  - BAT considerations [7-3](#)
  - BAT settings for inserting CSV file (table) [7-16](#)
  - configuration checklist (table) [7-2](#)
  - creating a CSV file (BAT.xlt) [7-4](#)
  - creating custom CSV file (text-based) [7-5](#)
  - CSV file settings (table) [7-12](#)
  - deleting code settings (BAT) [7-8](#)
  - inserting CSV file in BAT [7-14](#)
  - updating existing CSV file [7-7](#)
- command line interface [7-1](#)
- configuring
  - user device profiles [5-1](#)
- copying
  - Catalyst 6000 FXS ports template [7-28](#)
  - gateway directory number template [7-33](#)
  - phone template [3-29](#)
  - VG200 template [7-16](#)
- create dummy MAC address [3-15](#), [3-25](#), [3-27](#)
- creating
  - Catalyst 6000 FXS ports template [7-20](#)
  - CSV file for Catalyst 6000 FXS ports [7-21](#)
  - CSV file for user device profile [5-4](#)
  - CSV file for VG200 FXS or FXO [7-7](#)
  - CSV file for VG200 T1-CAS, T1-PRI, or E1-PRI [7-9](#)
  - phone template [3-3](#)
  - template for gateway directory number [7-32](#)
  - user device profiles template [5-2](#)
  - VG200 template [7-3](#)
- CSV
  - Catalyst 6000 FXS ports [7-21](#)
  - creating a BAT.xlt for manager assistant associations [6-5](#)

- creating a BAT.xlt for users [4-3, 4-13](#)
- creating a text-based file for Catalyst 6000 FXS ports [7-25](#)
- creating a text-based file for manager assistant associations [6-8](#)
- creating a text-based file for phones, phones-users combination, IP telephony devices and IP telephony devices-users combination [3-16](#)
- creating a text-based file for update users [4-15](#)
- creating a text-based file for user device profiles [5-7](#)
- creating a text-based file for users [4-5](#)
- creating a text-based file for VG200 gateways and ports [7-12](#)
- creating custom manager assistant files [6-7](#)
- creating for user device profile [5-4](#)
- CTI ports [3-7](#)
- H.323 clients [3-7](#)
- manager assistant associations [6-4](#)
- no blank lines [3-11, 5-5](#)
- phone [3-7](#)
- required location for saving files [4-6, 4-16, 5-8, 6-9](#)
- retaining stored values [4-17](#)
- text file for phones [3-16, 7-12, 7-25](#)
- tips for creating text-based CSV for Manager-Assistant Association [6-10](#)
- tips for creating text-based CSV for user device profiles [5-9](#)
- tips for creating text-based CSV for user device profiles with two lines [5-10](#)
- tips for creating text-based CSV for users [4-7, 4-16](#)
- tips for creating text-based file for CTI Ports or CTI Ports-users [3-17](#)
- tips for creating text-based file for H.323 clients or H.323 clients-users, [3-17](#)
- tips for creating text-based file for phones, phones-users, IP telephony devices, or IP telephony devices-users [3-17](#)
- tips for creating text-based file for VGC phones or VGC phones-users [3-17](#)
- tips for creating text-based file for VGC virtual phones or VGC virtual phones-users, [3-17](#)
- using BAT.xlt for Catalyst 6000 FXS ports [7-23](#)
- using BAT.xlt for phones [3-9](#)
- using BAT.xlt for phone-user combination [3-9](#)
- using BAT.xlt for telephony devices [3-9](#)
- using BAT.xlt for telephony devices-user combination [3-9](#)
- using BAT.xlt for update users [4-12](#)
- using BAT.xlt for users [4-2](#)
- VG200 for FXS or FXO [7-7](#)
- VG200 for T1-CAS, T1-PRI, or E1-PRI [7-9](#)
- VGC phones [3-7](#)
- VGC virtual phones [3-7](#)
- CTI ports
  - adding CTI ports-users combination to Cisco CallManager [3-26](#)
  - associating new port to existing user [3-7](#)
  - creating CSV file [3-7](#)

- deleting [3-39](#)
- directory number must match number of lines
  - in template [3-8](#)
- enable authentication proxy rights [3-28](#)
- enable CTI application use [3-24](#), [3-28](#)
- using BAT.xlt to create CSV [3-9](#)
- using BAT.xlt to create CSV for CTI
  - ports-users combination [3-9](#)
- using dummy MAC address option [3-25](#), [3-27](#)

custom file

- deleting phones [3-39](#)
- updating phones [3-32](#)

---

## D

deleting

- assistants [6-18](#)
- Catalyst 6000 FXS ports [7-30](#)
- Catalyst 6000 FXS ports template [7-34](#)
- CTI ports [3-39](#)
- gateway directory number template [7-34](#)
- H.323 clients [3-39](#)
- IP telephony devices [3-39](#)
- manager assistant [6-15](#)
- managers [6-17](#)
- phones [3-39](#)
- phones using custom files [3-39](#)
- selected VG200 gateways [7-17](#)
- user device profiles [5-17](#)
- users [4-20](#)

- VG200 gateways [7-17](#)
- VG200 template [7-34](#)

directory number

- creating gateway template [7-32](#)
- securing from TAPS [9-7](#)

downloading

- phone configuration using TAPS [9-11](#)

dummy MAC address [3-15](#), [3-25](#), [3-27](#), [3-37](#)

---

## E

E1-PRI

- adding VG200 gateways to Cisco
  - CallManager [7-15](#)
- creating the CSV file for VG200
  - gateways [7-9](#)
- field descriptions for VG200 [7-44](#)

enable authentication proxy rights

- adding users [4-9](#)
- for CTI ports and users [3-28](#)
- for phones and users [3-28](#)

enable CTI application use

- adding users [4-9](#)
- CTI ports [3-24](#)
- CTI ports and users [3-28](#)
- phones [3-24](#)
- phones and users [3-28](#)

endpoint identifiers, updating [7-7](#)

error messages, BAT [10-2](#)

## Exported Fields

All Phone Details [8-6](#)All User Device Profile Details [8-12](#)Default Phone [8-5](#)

## exporting

phone records [8-4](#)user device profile records [8-11](#)user records [8-8](#)Export to BAT Format button does not work in  
BAT.xlt file [10-3](#)

## F

## field descriptions

adding or updating lines [3-51](#)adding or updating lines to UDP  
template [5-18](#)Catalyst 6000 FXS ports [7-57](#)gateway directory number template [7-59](#)ground start [7-37](#)loop start [7-37](#)phone template [3-42](#), [3-57](#)VG200 - E1-PRI [7-44](#)VG200 - FXO [7-37](#)VG200 - FXS [7-35](#)VG200 - T1-CAS [7-39](#)VG200 - T1-PRI [7-44](#)

## Forced Authorization Codes

BAT considerations [7-3](#)BAT settings for inserting CSV file  
(table) [7-16](#)configuration checklist (table) [7-2](#)creating a CSV file (BAT.xlt) [7-4](#)creating custom CSV file (text-based) [7-5](#)CSV file settings (table) [7-12](#)deleting code settings (BAT) [7-8](#)inserting CSV file in BAT [7-14](#)updating existing CSV file [7-7](#)

## FXO

adding VG200 gateways to Cisco  
CallManager [7-15](#)field descriptions [7-37](#)

## FXS

adding Catalyst 6000 ports to Cisco  
CallManager [7-26](#)adding or updating ports for Catalyst 6000  
ports [7-19](#)adding VG200 gateways to Cisco  
CallManager [7-15](#)creating BAT template for Catalyst 6000  
ports [7-20](#)creating CSV file for Catalyst 6000  
ports [7-21](#), [7-23](#)creating CSV file for VG200 gateways [7-7](#)creating the CSV file for VG200  
gateways [7-7](#)deleting Catalyst 6000 ports [7-30](#)field descriptions for Catalyst 6000  
ports [7-57](#)

field descriptions for VG200 [7-35](#)

updating Catalyst 6000 ports [7-29](#)

---

## G

### gateway

Cisco Catalyst 6000 FXS ports [7-1](#)

Cisco VG200 overview [7-1](#)

### gateway directory number

copying template [7-33](#)

deleting template [7-34](#)

field descriptions for template [7-59](#)

template [7-32](#)

### gateway directory number template

required if you specified directory numbers [7-32](#)

### ground start, field descriptions [7-37](#)

---

## H

### H.323 clients

adding H.323 Client-users to Cisco CallManager [3-26](#)

creating CSV file [3-7](#)

deleting [3-39](#)

### halting TAPS [9-7](#)

### help [1-4](#)

---

### installing

BAT/TAPS [2-3](#)

BAT/TAPS prerequisites [2-3](#)

completing TAPS installation [2-7](#)

no backward template migration [2-2](#)

no template migration when upgrading from release 3.0(3) [2-2](#)

overview [2-1](#)

TAPS [2-5](#)

TAPS after BAT has already been installed [2-5](#)

TAPS prerequisites [2-5](#)

template migration during upgrade [2-2](#)

### instructions, TAPS for end-users [9-11](#)

### IPMA

adding manager assistant [6-11](#)

BAT.xlt [6-5](#)

creating CSV file [6-4](#)

creating custom manager assistant files [6-7](#)

creating text-based CSV file [6-8](#)

deleting assistants [6-18](#)

deleting manager assistant [6-15](#)

deleting managers [6-17](#)

manager and assistant line configurations [6-12](#)

setting up phones and Lines [6-1](#)

---

**L**

## lines

- adding or updating [3-5](#)
- field descriptions for adding or updating [3-51](#)
- field descriptions for adding or updating to UDP template [5-18](#)
- maximum number [3-5](#)
- updating [3-35, 5-15, 5-16](#)

## log files

- BAT [10-1](#)
- explanation of file naming convention [8-14, 10-2](#)
- export log files [8-14](#)
- viewing [10-2](#)

logging on to BAT [1-4](#)loop start,field descriptions [7-37](#)

---

**M**

## MAC address

- dummy MAC address [3-37](#)
- generate a list of phones with dummy [3-37](#)
- module in slot [7-4](#)

---

**N**

- NM-1V [7-4](#)
- NM-2V [7-4](#)
- NM-HDV [7-4](#)

---

**O**

## overview

- adding or updating FXS ports for Catalyst 6000 modules [7-19](#)
- adding VG200 gateways and ports [7-2](#)
- BAT [1-1](#)
- Catalyst 6000 FXS ports [7-19](#)
- creating CSV files for FXS ports on Catalyst 6000 modules [7-21](#)
- gateway directory number [7-31](#)
- TAPS [9-1, 9-2](#)
- working with gateways and ports [7-1](#)

---

**P**

## phone

- adding a template [3-3](#)
- adding lines to existing phones [3-31](#)
- adding or updating IP services [3-6](#)
- adding or updating lines [3-5](#)
- adding or updating speed dial settings [3-6](#)
- adding phones-users combination to Cisco CallManager [3-26](#)
- adding to Cisco CallManager [3-24, 3-26](#)
- BAT reaction if line information fails during insert [3-29](#)
- copying a template [3-29](#)
- creating CSV file [3-7](#)
- CSV text file [3-16, 7-12, 7-25](#)
- deleting [3-39](#)

deleting templates [3-41](#)  
 enable authentication proxy rights [3-28](#)  
 enable CTI application use [3-24](#), [3-28](#)  
 exporting records [8-4](#)  
 field descriptions for phone template [3-42](#),  
[3-57](#)  
 generate a list of phones with dummy MAC  
 addresses [3-37](#)  
 updating [3-32](#)  
 updating lines [3-35](#), [5-15](#), [5-16](#)  
 using BAT.xlt to create CSV for phone [3-9](#)  
 using dummy MAC address option [3-15](#), [3-25](#),  
[3-27](#)  
 ports adding VG200 [7-2](#)  
 prerequisites  
     BAT/TAPS [2-3](#)  
     TAPS [2-5](#)

---

## Q

query  
     updating lines [3-35](#), [5-15](#), [5-16](#)  
     updating phones [3-32](#)

---

## R

removing user device profiles [5-17](#)  
 repository manager [2-7](#)  
 reset devices after update [3-34](#)  
 restart devices after update [3-34](#)

---

## S

secure TAPS [9-7](#)  
 securing directory numbers from TAPS [9-7](#)  
 services, adding or updating [3-6](#)  
 specifications [1-2](#)  
 speed dial settings, adding or updating [3-6](#)  
 starting  
     BAT [1-3](#)  
     TAPS [9-6](#)  
 stopping  
     BAT [1-5](#)  
     TAPS [9-7](#)  
 sub-unit [7-4](#)

---

## T

T1-CAS  
     adding VG200 gateways to Cisco  
         CallManager [7-15](#)  
     creating the CSV file for VG200  
         gateways [7-9](#)  
     field descriptions for VG200 [7-39](#)  
 T1-PRI  
     adding VG200 gateways to Cisco  
         CallManager [7-15](#)  
     creating the CSV file for VG200  
         gateways [7-9](#)  
     field descriptions for VG200 [7-44](#)

## TAPS

- auto-registration must be enabled [9-1](#)
  - Cisco CRA required [9-2](#)
  - Cisco IP IVR required [9-2](#)
  - completing installation [2-7](#)
  - completing uninstallation [2-9](#)
  - configuring [9-3](#)
  - halting [9-7](#)
  - installing [2-3, 2-5](#)
  - installing once BAT is already installed [2-5](#)
  - instructions for end-users [9-11](#)
  - overview [9-1, 9-2](#)
  - securing directory numbers [9-7](#)
  - starting [9-6](#)
  - stopping [9-7](#)
  - taps.aef [2-7](#)
  - troubleshooting [10-1, 10-6](#)
  - troubleshooting on the Cisco CRA server [10-6](#)
  - uninstalling [2-8](#)
  - uploading to Cisco CRA Administration server [2-7](#)
  - version [1-5](#)
- taps.aef [2-7](#)
- template
- adding or updating IP services [3-6](#)
  - adding or updating lines [3-5](#)
  - adding or updating speed dial settings [3-6](#)
  - BAT.xlt file location [2-3](#)
  - copying Catalyst 6000 FXS ports [7-28](#)
  - copying gateway directory number [7-33](#)
  - copying phone [3-29](#)
  - copying VG200 [7-16](#)
  - creating Catalyst 6000 FXS ports [7-20](#)
  - creating VG200 [7-3](#)
  - deleting Catalyst 6000 FXS ports [7-34](#)
  - deleting gateway directory number [7-34](#)
  - deleting phone [3-41](#)
  - deleting VG200 [7-34](#)
  - field descriptions for adding or updating lines [3-51](#)
  - field descriptions for adding or updating lines to UDP template [5-18](#)
  - field descriptions for Catalyst 6000 ports [7-57](#)
  - field descriptions for gateway directory number [7-59](#)
  - field descriptions for phone [3-42, 3-57](#)
  - field descriptions for VG200 - E1-PRI or T1-PRI [7-44](#)
  - field descriptions for VG200 - FXO [7-37](#)
  - field descriptions for VG200 - FXS [7-35](#)
  - field descriptions for VG200 - T1-CAS [7-39](#)
  - gateway directory number [7-32](#)
  - gateway directory number is required if you specified directory numbers [7-32](#)
  - migration during upgrade [2-2](#)
  - no backward migration [2-2](#)
  - overview of gateway directory number [7-31](#)
  - phone [3-3](#)
  - user device profiles [5-2](#)

## troubleshooting

- BAT [10-2](#)
- BAT and TAPS [10-1](#)
- couldn't create user object. Check if DC Directory is running [10-6](#)
- data files (CSV) format do not match phone template/sample file [10-3](#)
- errors occur when using the dummy MAC address option [10-4](#)
- Export to BAT Format button does not work in BAT.xlt file [10-3](#)
- MAC address values are not allowed in the file if dummy MAC address values are desired [10-5](#)
- port data in record number n does not match the corresponding sample file/number of lines and speed dials in phone template chosen [10-5](#)
- port identifier contains invalid endpoint prefix [10-4](#)
- port identifier contains invalid port number [10-4](#)
- port number not configured in the template [10-5](#)
- same directory number cannot be assigned twice to a device in the same partition [10-6](#)
- selected template does not contain DN details for directory number [10-4](#)
- TAPS [10-6](#)
- TAPS on the Cisco CRA server [10-6](#)
- the page cannot be displayed [10-3](#)
- when the Cisco CRA server starts, the JTAPI subsystem shows partial service or out of service [10-6](#)

## U

## uninstalling

- BAT/TAPS [2-8](#)
- removing TAPS from Cisco CRA Administration server [2-9](#)

## update users

- creating CSV file [4-12](#)
- creating text-based CSV file [4-15](#)

## updating

- Catalyst 6000 FXS ports [7-19, 7-29](#)
- endpoint identifiers [7-7](#)
- lines [3-35, 5-15, 5-16](#)
- lines for phone template [3-5](#)
- phone configuration using TAPS [9-11](#)
- phones [3-32](#)
- services to phone template [3-6](#)
- speed dial settings to phone template [3-6](#)
- users [4-12](#)
- VGC phones [3-32](#)

upgrading BAT [2-2](#)uploading TAPS to the Cisco CRA Administration server [2-7](#)

## user

- exporting records [8-8](#)
- using BAT.xlt for phone-user combination [3-9](#)

## user device profiles

- adding [5-1, 5-13](#)
- configuring [5-1](#)

- creating a template [5-2](#)
- creating text-based CSV file [5-7](#)
- CSV file [5-4](#)
- deleting [5-17](#)
- exporting records [8-11](#)
- inserting [5-13](#)
- removing [5-17](#)
- users
  - adding [4-1](#)
  - adding to Cisco CallManager [4-8](#)
  - BAT.xlt [4-3](#), [4-13](#)
  - creating CSV file [4-2](#)
  - creating text-based CSV file [4-5](#)
  - deleting [4-20](#)
  - updating [4-12](#)
  - using BAT.xlt for phone-user combination [3-9](#)
- VWIC-2MFT-E1 [7-5](#)
- VWIC-2MFT-T1 [7-4](#)

---

## V

- validate
  - phone records [3-22](#)
  - user device profiles [5-12](#)
- version [1-4](#), [1-5](#)
- VIC-2FXO [7-4](#)
- VIC-2FXS [7-4](#)
- Viewing log files [10-2](#)
- VWIC-1MFT-E1 [7-5](#)
- VWIC-1MFT-T1 [7-4](#)