



A

- activating services
 - BPS [51-1](#)
 - Unified CM Auto-Register Phone Tool [52-6](#)
- adding lines
 - field descriptions for BAT spreadsheet [10-9, 41-3](#)
 - field descriptions for template [3-22](#)
 - to existing phones [10-7, 41-1](#)
 - to existing phones using BAT spreadsheet [10-8, 41-2](#)
 - to existing user device profiles [10-7, 41-1](#)
 - to phone template [3-4](#)
- associating file format for text-based CSV file [4-5, 23-1, 35-1](#)
- auto-registration, enabled for Cisco Unified CallManager
 - enable auto-registration for Unified CM Auto-Register Phone Tool [52-2](#)
- auto-registration options, configuring [52-8](#)

B

- BAT
 - application overview [1-1](#)

- browser requirements [1-11](#)
- configuration process overview [1-3](#)
- data input files [1-2](#)
- error messages [17](#)
- installation [1-2](#)
- log files location [17](#)
- online help [1-11](#)
- scheduling jobs [51-1](#)
- troubleshooting [17](#)
- troubleshooting performance [20](#)
- version [1-11](#)
- BAT.xlt, see BAT spreadsheet
- BAT Performance [47](#)
- BAT spreadsheet
 - adding lines to existing phones [10-8, 41-2](#)
 - Catalyst 6000 FXS ports [44-3](#)
 - field descriptions
 - adding lines [10-9, 41-3](#)
 - updating users [17-2](#)
 - user device profile [32-4](#)
 - IP telephony devices [3-30](#)
 - manager assistant associations [26-9](#)
 - overview [1-8](#)
 - phones [3-30](#)
 - phones with users [22-1](#)

- Unified CM Assistant custom manager assistant for proxy mode [26-11](#)
- Unified CM Assistant default manager assistant [26-9](#)
- user device profile [32-2](#)
- users [14-1](#)
- using for CSV data file [1-8](#)
- VG200 gateway for T1 CAS or T1/E1 PRI [44-1](#)
- VG224 gateway for FXS or VG224 gateway
 - creating CSV data file for FXS
 - creating CSV data file for VG224 gateway [44-4](#)
- browser requirements [1-11](#)
- Bulk Provisioning Service
 - activating BPS [51-1](#)
 - deactivating BPS [51-2](#)

C

Call Pickup Groups

- BAT considerations [49-1](#)
- BAT settings for inserting CSV file (table) [49-5](#)
- creating a CSV file (BAT.xlt) [49-2](#)
- creating custom CSV file (text-based) [44](#)
- CSV file settings (table) [49-4](#)
- inserting CSV file in BAT [49-4](#)
- updating existing CSV file [49-3](#)
- using query to delete call pickup groups [50-1](#)

Catalyst 6000 FXS ports

- creating CSV data file [44-3](#)
- text-based CSV file, creating [40](#)
- text-based CSV file format [41](#)

Cisco CRS

- configuring Unified CM Auto-Register Phone Tool [52-5](#)
- required for Unified CM Auto-Register Phone Tool [52-2](#)
- troubleshooting Unified CM Auto-Register Phone Tool [22](#)

Cisco Customer Response Solutions, see Cisco CRS

Cisco Unified CallManager

- enable auto-registration for Unified CM Auto-Register Phone Tool [52-2](#)

inserting

- CTI ports [6-1, 16-1, 37-1, 44-1](#)
- H.323 clients [6-1, 16-1, 37-1, 44-1](#)
- phones [6-1, 16-1, 37-1, 44-1](#)
- phones with users [25-1](#)
- Unified CM Assistant manager-assistant associations [27-1](#)
- users [16-1](#)
- VG200 gateway (FXS or FXO) [44-6](#)
- VG200 gateway (T1 CAS or T1/E1 PRI) [44-6](#)
- overview of inserting records [1-10](#)

Cisco Unified CallManager Assistant, see Unified CM Assistant

Cisco Unified CM Assistant Configuration Wizard [26-2](#)

Cisco Unified IP-IVR

- required for Unified CM Auto-Register Phone Tool [52-2](#)

Client Matter Codes

- BAT considerations [47-2](#)
- BAT settings for inserting CSV file (table) [47-7](#)
- configuration checklist (table) [47-1](#)
- creating a CSV file (BAT.xlt) [47-3](#)
- creating custom CSV file (text-based) [42](#)
- CSV file settings (table) [47-5](#)
- deleting code settings (BAT) [48-1](#)
- inserting CSV file in BAT [47-6](#)
- updating existing CSV file [47-4](#)

CMC

- text-based CSV file, updating [43](#)

configuring Cisco Unified CallManager records, process [1-3](#)

configuring gateway file format [42](#)

copying

- file format for text-based CSV [34-3](#)
- file format for text-based CSV file [4-3, 43](#)
- phone template [3-8](#)
- template [33-4](#)
- user template [15-3](#)

- CPG
 - text-based CSV file, updating [46](#)
 - CSV, comma separated values text file [1-2, 25](#)
 - CSV, text-based
 - Catalyst 6000 FXS ports, creating [40](#)
 - Catalyst 6000 FXS ports format [41](#)
 - CMC
 - options [47-4](#)
 - updating [43](#)
 - CPG
 - options [49-3](#)
 - updating [46](#)
 - CTI ports format [27](#)
 - CTI ports-users format [27](#)
 - FAC
 - options [47-4](#)
 - updating [44](#)
 - FXO or FXS ports format [38](#)
 - H.323 clients format [27](#)
 - H.323 client-users format [27](#)
 - manager assistant associations
 - creating [36](#)
 - custom format [37](#)
 - manager assistant default formats [36](#)
 - overview [25](#)
 - phones
 - creating [25](#)
 - export file, all details [28](#)
 - options [4-1](#)
 - tips for creating [26](#)
 - with users format [26](#)
 - T1 CAS, T1/E1 PRI format [38](#)
 - user device profile format [33](#)
 - user device profile options [34-1](#)
 - user device profiles
 - creating [33](#)
 - export file [35](#)
 - two lines format [34](#)
 - users
 - creating [30](#)
 - format [31](#)
 - updating [32](#)
 - VG200 gateways, creating [37](#)
 - VG224 gateways, creating [39](#)
 - CSV data file
 - adding new devices [1-5](#)
 - overview [1-5](#)
 - updating existing devices [1-6](#)
 - using BAT spreadsheet (BAT.xlt) [1-8](#)
 - CTI ports
 - deleting [8-1, 13-1, 38-1](#)
 - dummy MAC address, using [6-2, 25-1, 37-2](#)
 - text-based CSV format [27](#)
 - CTI ports-users
 - text-based CSV format [27](#)
 - custom file
 - deleting phones [8-3, 38-2](#)
 - deleting Unified CM Assistant managers [29-2, 30-2](#)
 - deleting users [18-2](#)
 - updating phones [7-2](#)
 - using [1-6](#)
 - using to reset password and PIN [20-3](#)
-
- ## D
- deleting
 - call pickup groups [50-1](#)
 - file format for text-based CSV file [4-5, 34-4, 44](#)
 - manager-assistant associations [28-1](#)
 - phones using custom files [8-3, 38-2](#)
 - phones using query [8-1, 13-1](#)
 - phone template [3-9](#)
 - template [33-5](#)
 - Unified CM Assistant assistants [30-1](#)
 - Unified CM Assistant managers [29-1](#)
 - user device profiles [38-1](#)
 - users [18-1](#)
 - user template [15-3](#)

- VG200 gateway [45-1](#)
- dialed number analyzer
 - trace configuration files [15](#)
- directory number
 - finding secure directory numbers from Unified CM Auto-Register Phone Tool [52-9](#)
 - lifting restrictions [52-10](#)
 - restricting from Unified CM Auto-Register Phone Tool [52-9](#)
 - securing from Unified CM Auto-Register Phone Tool [52-9](#)
- downloading phone configuration using Unified CM Auto-Register Phone Tool [53-2](#)
- dummy MAC address [3-31](#), [6-2](#), [25-1](#), [37-2](#)
 - generate a list [12-5](#)

E

- E1 PRI
 - creating CSV file for VG200 gateway [44-1](#)
 - field descriptions for VG200 gateway template [43-22](#)
 - text-based CSV file format [38](#)
- E1 PRI ports [43-8](#)
- error messages, BAT [17](#)
- exported fields
 - all phone details [9-2](#)
 - all user device profile details [39-1](#)
 - default phone details [9-2](#)
 - default user device profile details [39-2](#)
- exporting
 - fields
 - all phone details [9-2](#)
 - all user device profile details [39-1](#)
 - default phone details [9-2](#)
 - default user device profile details [39-2](#)
 - moving records from one Cisco Unified CallManager to another [9-1](#)
 - phone records options [9-1](#)
 - phones with more than one user [9-5](#)
 - steps for exporting phone records [9-3](#)

- user device profile options [39-3](#)
- user device profile records format [39-1](#)
- user records format [19-1](#)
- user records options [19-1](#)
- using export files [1-6](#)

F

- FAC
 - text-based CSV file, updating [44](#)
- field descriptions
 - adding or updating lines [3-22](#)
- BAT spreadsheet
 - adding lines [10-9](#), [41-3](#)
 - updating users [17-2](#)
 - user device profile [32-4](#)
- phone template [3-9](#)
- updating lines [10-3](#), [40-3](#)
- updating users with BAT spreadsheet [17-2](#)
- user device profile template [33-2](#)
- user template [15-4](#)
- VG200 gateway - T1/E1 PRI template [43-22](#)
- VG200 gateway - T1 CAS template [43-19](#)
- file format for gateway
 - finding [41](#)
- file format for text-based CSV file
 - associating [4-5](#), [23-1](#), [35-1](#)
 - copying [4-3](#), [34-3](#), [43](#)
 - creating phone [4-2](#), [42](#)
 - creating user device profile [34-2](#)
 - deleting [4-5](#), [34-4](#), [44](#)
 - finding [4-2](#), [34-1](#)
 - modifying [4-4](#), [34-4](#), [43](#)
 - overview [1-6](#)
- file format for text-based CSV file gateway
 - associating [45](#)
- finding
 - file [2-1](#)
 - gateway file format [41](#)

- gateway templates [43-3](#)
- gateway file format [41](#)
- jobs [51-3](#)
- phone file format [4-2](#)
- phone template [3-2](#)
- secure directory numbers from Unified CM Auto-Register Phone Tool [52-9](#)
- UDP file format for text-based CSV [34-1](#)
- UDP template [33-1](#)
- user template [15-1](#)

Forced Authorization Codes

- BAT considerations [47-2](#)
- BAT settings for inserting CSV file (table) [47-7](#)
- configuration checklist (table) [47-1](#)
- creating a CSV file (BAT.xlt) [47-3](#)
- creating custom CSV file (text-based) [42](#)
- CSV file settings (table) [47-5](#)
- deleting code settings (BAT) [48-1](#)
- inserting CSV file in BAT [47-6](#)
- updating existing CSV file [47-4](#)

FXO

- inserting VG200 gateway to Cisco Unified CallManager [44-6](#)
- text-based CSV file format for VG200 gateway [38](#)

FXO ports [43-7](#)

FXS

- Catalyst 6000 ports
 - creating CSV data file [44-3](#)
 - text-based CSV format [41](#)
- creating template for Catalyst 6000 ports [43-8](#)
- VG200 gateways
 - inserting to Cisco Unified CallManager [44-6](#)
 - text-based CSV file format [38](#)

G

- gateway
 - associating file format for text-based CSV file [45](#)
- gateway file format

- configuring [42](#)
- finding [41](#)
- gateway template
 - adding or editing [43-4](#)
 - Catalyst 6000 FXS ports
 - creating template [43-8](#)
 - configuration settings [43-11](#)
 - finding [43-3](#)
 - port configuration settings (table) [43-35](#)
 - POTS port configuration settings (table) [43-36](#)
 - VG200 gateway template
 - creating template [43-4, 43-9](#)
 - FXO ports, adding [43-7](#)
 - T1-CAS ports, adding [43-8](#)
 - T1 PRI or E1 PRI ports, adding [43-8](#)

H

- H.323 clients
 - deleting [8-1, 13-1, 38-1](#)
 - text-based CSV format [27](#)
- H.323 client-users
 - text-based CSV format [27](#)
- help, online [1-11](#)

I

- inserting records to Cisco Unified CallManager, overview [1-10](#)
- installing
 - Unified CM Auto-Register Phone Tooloverview [52-4](#)
 - Unified CM Auto-Register Phone Tool prerequisites [52-4](#)
- instructions, Unified CM Auto-Register Phone Tool for end-users [53-2](#)
- IP telephony devices
 - supported with BAT [15-1](#)
- IP telephony devices, see phones

J

jobs

- activating BPS [51-1](#)
- deactivating BPS [51-2](#)
- finding [51-3](#)
- scheduling [51-4](#)
- viewing log files [51-6](#)

Llanguage prompts for Unified CM Auto-Register Phone Tool [52-4](#)

lines

- adding or updating on template [3-4](#)
- field descriptions in template for adding or updating [3-22](#)
- master phone template [1-4](#)
- maximum number [3-5](#)
- updating to user device profiles [40-1](#)

log files

- BAT [17](#)
- file naming convention [17](#)
- report log files [12-6, 21-2, 31-2, 46-2](#)
- viewing job log files [51-6](#)

Mmaster phone template [1-4](#)

MGCP

- T1-CAS ports [43-8](#)
- T1 PRI or E1 PRI ports, adding [43-8](#)

modifying

- file format for text-based CSV [34-4](#)
- file format for text-based CSV file [4-4, 43](#)
- phone template [3-7](#)
- user template [15-3](#)

N

- NM-1V [43-12](#)
- NM-2V [43-12](#)
- NM-HDV [43-12](#)

Ooverriding template values [1-5](#)

overview

- BAT application [1-1](#)
- BAT spreadsheet [1-8](#)
- Cisco Unified CM Assistant [26-1](#)
- CSV data file [1-5](#)
- data input files [1-2](#)
- file formats for text-based CSV files [1-6](#)
- inserting records to Cisco Unified CallManager [1-10](#)
- installation [1-2](#)
- reports [12-1, 21-1, 42-1](#)
- templates [1-4](#)
- text-based CSV files [25](#)
- Unified CM Auto-Register Phone Tool tool [52-1](#)
- user device profiles [32-1](#)
- users [14-1](#)
- validating [1-9](#)

P

passwords

- resetting [20-1](#)

phones

adding

- IP services [3-5](#)
- lines [3-4](#)
- lines to existing [10-7, 41-1](#)
- speed dial settings [3-6, 3-7](#)
- with users [22-1](#)

configuring CAPF [3-43, 15-6](#)creating text-based CSV file [25](#)

- deleting [8-1, 13-1, 38-1](#)
- dummy MAC address, using [3-31, 6-2, 25-1, 37-2](#)
- dummy MAC addresses list [12-5](#)
- export file with all details [28](#)
- exporting records options [9-1](#)
- exporting records steps [9-3](#)
- generating reports [12-1](#)
- insert to Cisco Unified CallManager [6-1, 16-1, 37-1, 44-1](#)
- proxy mode for Unified CM Assistant [26-2](#)
- reloading configurations [52-3](#)
- report options [12-3](#)
- template
 - copying [3-8](#)
 - creating new [3-4](#)
 - deleting [3-9](#)
 - field descriptions [3-9](#)
 - finding template [3-2](#)
 - for IP telephony devices [3-4](#)
 - modifying [3-7](#)
- Unified CM Assistant assistant [26-4](#)
- Unified CM Assistant manager configuration [26-4](#)
- updating [7-1, 17-1, 18-1](#)
- updating with custom file [7-2](#)
- updating with query [7-1](#)
- using Unified CM Auto-Register Phone Tool to configure [52-2](#)
 - enable auto-registration [52-2](#)
- validating records [5-1, 36-1](#)
- phones with users
 - inserting to Cisco Unified CallManager [25-1](#)
 - text-based CSV format [26](#)
 - using BAT spreadsheet [22-1](#)
 - validating records [24-1](#)
- PINs
 - resetting [20-1](#)
- prerequisites
 - Unified CM Auto-Register Phone Tool [52-4](#)

Q

- query
 - customizing a filter [1-6](#)
 - deleting call pickup groups [50-1](#)
 - deleting phones [8-1, 13-1](#)
 - deleting Unified CM Assistant managers [29-1, 30-1](#)
 - deleting users [18-1](#)
 - updating lines [40-1](#)
 - updating phones [7-1](#)
 - using to reset password and PIN [20-1](#)

R

- reports
 - dummy MAC addresses [12-5](#)
 - overview [12-1, 21-1, 42-1](#)
 - phone options [12-3](#)
 - phones [12-1](#)
 - Unified CM Assistant manager assistant [31-1](#)
 - user device profile [42-1](#)
 - users [21-1](#)
 - VG200 gateway [46-1](#)
- resetting password and PIN
 - using custom file [20-3](#)
 - using query [20-1](#)
- resetting phones
 - after update [11-1](#)
 - using custom file [11-2](#)
 - using query [11-1](#)
- restarting phones
 - after update [11-1](#)
 - using custom file [11-2](#)
 - using query [11-1](#)
- retaining user records when updating [17-1](#)

S

securing directory numbers from Unified CM
Auto-Register Phone Tool [52-4, 52-9](#)

services, adding or updating [3-5](#)

speed dial settings, adding or updating [3-6, 3-7](#)

sub-unit [43-5, 43-10](#)

T**T1 CAS**

creating CSV data file for VG200 gateway [44-1](#)

field descriptions for VG200 template [43-19](#)

text-based CSV file format [38](#)

T1-CAS ports, adding [43-8](#)

T1 PRI

creating CSV file for VG200 gateway [44-1](#)

field descriptions for VG200 gateway template [43-22](#)

text-based CSV file format [38](#)

T1 PRI ports [43-8](#)

templates

adding or updating IP services [3-5](#)

adding or updating lines [3-4](#)

adding or updating speed dial settings [3-6, 3-7](#)

BAT template overview [1-4](#)

copying [33-4](#)

copying phone [3-8](#)

copying users [15-3](#)

deleting [33-5](#)

deleting phone [3-9](#)

deleting users [15-3](#)

field descriptions

adding or updating lines [3-22](#)

phone [3-9](#)

user device profiles [33-2](#)

users [15-4](#)

VG200 gateway - T1 CAS gateway [43-19](#)

finding [33-1](#)

master phone [1-4](#)

modifying [33-4](#)

modifying phone [3-7](#)

modifying users [15-3](#)

overriding values [1-5](#)

template type

Catalyst 6000 FXS ports [43-8](#)

IP telephony devices [3-4](#)

phones [3-4](#)

Unified CM Assistant assistant for proxy mode [26-3](#)

Unified CM Assistant manager for proxy mode [26-2](#)

user device profiles [33-2](#)

users [15-2](#)

VG200 gateway template [43-4, 43-9](#)

trace configuration files

viewing [15](#)

troubleshooting

BAT [17](#)

BAT log files [17](#)

BAT performance [20](#)

Unified CM Auto-Register Phone Tool [21](#)

troubleshooting message

BAT.xlt spreadsheet does not work with Excel XP
(Office XP) [20](#)

BAT excel sheet does not respond to actions [18](#)

BAT menu does not display in Cisco Unified
CallManager [17](#)

BAT spreadsheet gives a compilation error while
exporting data [18](#)

cannot access complete BAT functionality [18](#)

CSV data files do not match phone template/sample
file [18](#)

export to BAT does not work in BAT.xlt file [18](#)

job does not display in find and list job window [19](#)

jobs remain in hold state [19](#)

jobs remain in pending state [19](#)

MAC address values are not allowed in CSV file if
dummy MAC address option selected [20](#)

port number not configured in template [20](#)

uploaded csv file does not display [19](#)

when Cisco CRS starts, JTAPI shows partial service or out of service [22](#)

when dialing Unified CM Auto-Register Phone Tool number, caller hears busy [21](#)

U

UDP, see user device profiles

Unified CM Assistant

assistant template for proxy mode [26-3](#)

creating CSV data file [26-9](#)

deleting assistants

described [30-1](#)

using custom file [30-2](#)

deleting manager-assistant associations [28-1](#)

deleting managers

described [29-1](#)

using custom file [29-2](#)

using query [29-1, 30-1](#)

generating reports [31-1](#)

inserting manager-assistant associations [27-1](#)

manager and assistant line configurations, proxy mode [26-3](#)

manager and assistant shared line configurations [26-8](#)

manager template for proxy mode [26-2](#)

overview [26-1](#)

phones

assistant configuration options [26-4](#)

manager configuration options [26-4](#)

proxy line example [26-5](#)

proxy lines on existing [26-6](#)

proxy lines on new [26-6](#)

proxy mode [26-2](#)

shared line example [26-8](#)

shared line mode [26-7](#)

setting up phones and lines [26-1](#)

text-based CSV file, creating [36](#)

text-based CSV file custom format [37](#)

Unified CM Assistant Configuration Wizard [26-2](#)

Unified CM Auto-Register Phone Tool

activating Unified CM Auto-Register Phone Tool service [52-6](#)

Cisco CRS required [52-2](#)

Cisco Unified IP-IVR required [52-2](#)

configuring auto-registration options [52-8](#)

configuring on Cisco CRS server [52-5](#)

finding secure directory numbers [52-9](#)

installation overview [52-4](#)

instructions for end-users [53-2](#)

language prompts [52-4](#)

removing [53-2](#)

lifting restriction on directory numbers [52-10](#)

log files location [21](#)

overview [52-1](#)

reloading configurations [52-3](#)

requirements [52-2](#)

restarting service [52-7](#)

restricting directory numbers [52-9](#)

securing directory numbers [52-4, 52-9](#)

setting options for using [52-7](#)

starting service [52-7](#)

stopping service [52-7](#)

troubleshooting [21](#)

uninstalling [52-6](#)

uninstalling

Unified CM Auto-Register Phone Tool [52-6](#)

updating

lines to user device profiles [40-1](#)

phone configuration using Unified CM Auto-Register Phone Tool [53-2](#)

updating lines

field descriptions [10-3, 40-3](#)

uploading/downloading file

delete [2-3](#)

download [2-2](#)

finding [2-1](#)

upload [2-3](#)

user device profiles

- adding lines to existing [10-7, 41-1](#)
 - BAT spreadsheet
 - field descriptions [32-4](#)
 - using [32-2](#)
 - creating CSV data file [32-2](#)
 - deleting [38-1](#)
 - export file format [39-1](#)
 - export file with all details [35](#)
 - exporting record options [39-3](#)
 - overview [32-1](#)
 - removing [38-1](#)
 - reports, generating [42-1](#)
 - steps for adding [32-1](#)
 - template
 - copying [33-4](#)
 - creating [33-2](#)
 - deleting [33-5](#)
 - finding [33-1](#)
 - modifying [33-4](#)
 - text-based CSV file, creating [33](#)
 - text-based CSV file format [33](#)
 - updating lines [40-1](#)
 - validating records [36-1](#)
 - users
 - adding overview [14-1](#)
 - adding with phones [22-1](#)
 - creating CSV data file [14-1](#)
 - deleting [18-1](#)
 - using custom file [18-2](#)
 - using query [18-1](#)
 - exported records format [19-1](#)
 - exporting records [19-1](#)
 - field descriptions for updating with BAT spreadsheet [17-2](#)
 - generating reports [21-1](#)
 - inserting to Cisco Unified CallManager [16-1](#)
 - resetting passwords and PINs [20-1](#)
 - retaining stored values [17-1](#)
 - template
 - copying [15-3](#)
 - creating new [15-2](#)
 - deleting [15-3](#)
 - field descriptions [15-4](#)
 - finding [15-1](#)
 - for users [15-2](#)
 - modifying [15-3](#)
 - text-based CSV file, creating [30](#)
 - text-based CSV file, updating [32](#)
 - text-based CSV format [31](#)
 - updating [17-1](#)
 - updating users field descriptions [17-2](#)
 - users with phones
 - inserting to Cisco Unified CallManager [25-1](#)
 - using BAT spreadsheet [22-1](#)
 - validating records [24-1](#)
-
- ## V
- validating
 - options [1-9](#)
 - overview [1-9](#)
 - phone and user records [24-1](#)
 - phone records [5-1, 36-1](#)
 - user device profile records [36-1](#)
 - version, finding [1-11](#)
 - VG200 gateway
 - creating CSV data file for T1 CAS or T1/E1 PRI [44-1](#)
 - creating template [43-4, 43-9](#)
 - creating text-based CSV file [37](#)
 - deleting gateway [45-1](#)
 - field descriptions
 - T1/E1 PRI template [43-22](#)
 - T1 CAS template [43-19](#)
 - generating reports [46-1](#)
 - inserting to Cisco Unified CallManager (FXS or FXO) [44-6](#)
 - inserting to Cisco Unified CallManager (T1 CAS or T1/E1 PRI) [44-6](#)

VG200 gateway template

FXO ports, adding [43-7](#)

VG224 gateway

creating text-based CSV file [39](#)

VIC-2FXO [43-5](#)

VIC-2FXS [43-5](#), [43-10](#)

viewing trace configuration files [15](#)

VWIC-1MFT-E1 [43-5](#)

VWIC-1MFT-T1 [43-5](#)

VWIC-2MFT-E1 [43-5](#)

VWIC-2MFT-T1 [43-5](#)

