



Deleting User Device Profiles

Use these procedures to delete a group of user device profiles (UDPs) from the Cisco Unified CallManager database.

You can locate existing phone records by these two methods:

- [Using Query to Delete UDP, page 38-1.](#)
- [Using a Custom File to Delete UDPs, page 38-2](#)

Using Query to Delete UDP

To locate the records that you want to delete, you must define a query filter. To delete UDPs from Cisco Unified CallManager, use the following procedure.

Procedure

- Step 1** Choose **Bulk Administration > User Device Profiles > Delete User Device Profiles > Query**.
The Delete User Device Profiles Configuration window displays.
- Step 2** From the Find drop-down list box, choose one of the following options:
- User
 - Autogenerated
 - All
- Step 3** From the first Device Profiles where drop-down list box, choose one of the following criteria:
- Profile Name
 - Description
 - Device Type
- Step 4** From the second Device Profiles where drop-down list box, choose one of the following criteria:
- begins with
 - contains
 - is exactly
 - ends with

- is empty
- is not empty

Step 5 Specify the appropriate search text, if applicable.



Tip To find all UDPs that are registered in the database, click **Find** without entering any search text.

Step 6 To further define your query and to add multiple filters, check the Search Within Results check box, choose **AND** or **OR** from the drop-down box, and repeat steps 2 and 5.

Step 7 Click **Find**.

A list of discovered templates displays by:

- Device Profile Name
- Description
- Device Type
- Profile Type

Step 8 In the Job Information area, enter the Job description.

Step 9 Click the Run Immediately radio button to delete UDP records immediately or, click Run Later to delete them at a later time.

Step 10 Click **Submit** to create a job for deleting the phone records.

Step 11 Use the Job Scheduler option in the Bulk Administration main menu to schedule and/or activate this job.

For more information on jobs, see the [Chapter 52, “Scheduling Jobs.”](#)

For information on log files, see [“BAT Log Files” section on page 57-17.](#)



Caution

If you do not enter any information in the query text box, the system deletes all UDP records. Because the delete action is final, you cannot retrieve deleted records.

Additional Topics

See the [“Related Topics” section on page 38-3.](#)

Using a Custom File to Delete UDPs

You can create a custom file of UDPs that you want to delete by using a text editor. You can have device profile name, device profile description, and directory number in the same custom file, but you cannot have directory numbers in the same file. You need to create separate files—one file that contains the device names and MAC addresses and another file that contains the directory numbers.



Note

You cannot delete UDPs with shared lines by using a custom file.

Before You Begin

1. Create a text file that lists one of these details for the UDPs that you want to delete:

- Profile names
 - Profile description
 - Directory numbers
2. Put each item on a separate line in the text file.
 3. Upload the custom files to the Cisco Unified CallManager server first node. See [“Uploading a File” section on page 2-3](#).

To delete UDPs that are listed in a custom file, use the following procedure.

Procedure

-
- Step 1** Choose **Bulk Administration > User Device Profiles > Delete User Device Profiles > Custom File**.
The Delete User Device Profiles Configuration window displays.
 - Step 2** In the Delete drop-down list box choose one of the following options:
 - User
 - Autogenerated
 - All
 - Step 3** In the Device Profiles where drop-down list box, choose the type of custom file that you have created from one of the following criteria:
 - Profile Name
 - Profile Description
 - Directory Number
 - Step 4** In the list of custom files, choose the filename of the custom file for this delete.
 - Step 5** Click **Find**.
 - Step 6** A list of UDPs matching your search criteria displays.
 - Step 7** Click **Submit** to create a job to delete the UDPs.
Use the Job Scheduler option in the Bulk Administration main menu to schedule and/or activate this job. For more information on jobs, see the [Chapter 52, “Scheduling Jobs.”](#)
For information on log files, see [“BAT Log Files” section on page 57-17](#).
-

Additional Topics

See the [“Related Topics” section on page 38-3](#).

Related Topics

- [Using Query to Delete UDP, page 38-1](#)
- [Using a Custom File to Delete UDPs, page 38-2](#)
- [Uploading a File, page 2-3](#)
- [Scheduling Jobs, page 52-1](#)
- [Introducing Cisco Unified CM Auto-Register Phone Tool, page 53-2](#)

- [BAT Log Files, page 57-17](#)