



# Cisco Unified CME Commands: X

---

**Revised: December 17, 2007**

This chapter contains commands to configure and maintain Cisco Unified Communications Manager Express (formally known as Cisco Unified CallManager Express). The commands are presented in alphabetical order. Some commands required for configuring Cisco Unified Communications Manager Express (Cisco Unified CME) may be found in other Cisco IOS references. Use the reference master index or search online to find these commands.

# xml user

To define a user who is authorized to use XML applications to execute commands, use the **xml user** command in telephony-service configuration mode. To delete the user, use the **no** form of this command.

**xml user** *user-name* **password** *password* *privilege-level*

**no xml user** *user-name* **password** *password* *privilege-level*

## Syntax Description

<i>user-name</i>	Unique string used by authorized user to access Cisco Unified CME. Maximum length of string: 19 alphanumeric characters.
<b>password</b> <i>password</i>	Alphanumeric string to be used with this user name to provide access to Cisco Unified CME. Maximum length of string: 19 alphanumeric characters.
<i>privilege-level</i>	Level of access to Cisco IOS commands to be granted to this user. Only the commands with the same or a lower level can be executed via XML. Range is 0 to 15.

## Command Default

User name is not defined.

## Command Modes

Telephony-service configuration (config-telephony)

## Command History

Cisco IOS Release	Cisco Product	Modification
12.4(4)XC	Cisco Unified CME 4.0	This command was introduced.
12.4(9)T	Cisco Unified CME 4.0	This command was integrated into Cisco IOS Release 12.4(9)T.

## Usage Guidelines

This command creates a credential be used by an authorized user to access Cisco Unified CME via XML and enable the user to execute all the Cisco IOS commands associated with a particular privilege level.

To change the default privilege level for one or more Cisco IOS commands, use the **privilege** command in global configuration mode.

## Examples

The following example defines user23 as an authorized user at level 15:

```
Router(config)# telephony-service
Router(config-telephony)# xml user user23 password 3Rs92uzQ 15
```

## Related Commands

Command	Description
<b>privilege</b>	Configures a new privilege level for users and associates commands with that privilege level.

# xmlschema

Effective with Cisco Unified CME 4.0, the **xmlschema** command was made obsolete.

For earlier releases, to specify the URL for a Cisco CME eXtensible Markup Language (XML) application program interface (API) schema, use the **xmlschema** command in telephony-service configuration mode. To set the URL for the XML API schema to the default, use the **no** form of this command.

```
xmlschema schema-url
```

```
no xmlschema
```

<b>Syntax Description</b>	<i>schema-url</i>	Local or remote URL as defined in RFC 2396.
---------------------------	-------------------	---

<b>Command Default</b>	Url for Cisco XML API schema is srst-its.xsd.
------------------------	---

<b>Command Modes</b>	Telephony-service configuration (config-telephony)
----------------------	--

Command History	Cisco IOS Release	Cisco Product	Modification
	12.2(15)ZJ	Cisco CME 3.0	This command was introduced.
	12.3(4)T	Cisco CME 3.0	This command was integrated into Cisco IOS Release 12.3(4)T.
	12.4(4)XC	Cisco Unified CME 4.0	This command was made obsolete.
	12.4(9)T	Cisco Unified CME 4.0	This command was made obsolete in Cisco IOS Release 12.4(9)T.

<b>Examples</b>	The following example specifies a URL for an XML API schema:
-----------------	--

```
Router(config)# telephony-service  
Router(config-telephony)# xmlschema http://server2.example.com/schema/schema1.xsd
```

Related Commands	Description
<b>telephony-service</b>	Enters telephony-service configuration mode.

# xmltest

Effective with Cisco Unified CME 4.0, the **xmltest** command was made obsolete.

For earlier releases, to specify that the HTTP payload in eXtensible Markup Language (XML) application program interface (API) queries be interpreted as having form format, use the **xmltest** command in telephony-service configuration mode. To specify that the HTTP payload should be interpreted as plain text (no form) format, use the **no** form of this command.

**xmltest**

**no xmltest**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Default format is plain text (no form) format.

**Command Modes** Telephony-service configuration (config-telephony)

Command History	Cisco IOS Release	Cisco Product	Modification
	12.2(15)ZJ	Cisco CME 3.0	This command was introduced.
	12.3(4)Ts	Cisco CME 3.0	This command was integrated into Cisco IOS Release 12.3(4)T.
	12.4(4)XC	Cisco Unified CME 4.0	This command was made obsolete.
	12.4(9)T	Cisco Unified CME 4.0	This command was made obsolete in Cisco IOS Release 12.4(9)T.

**Examples** The following example specifies that the HTTP payload in XML API queries be interpreted as having form format:

```
Router(config)# telephony-service
Router(config-telephony)# xmltest
```

Related Commands	Description
<b>telephony-service</b>	Enters telephony-service configuration mode.

# xmlthread

Effective with Cisco Unified CME 4.0, the **xmlthread** command was made obsolete.

For earlier releases, to set the maximum number of concurrent Cisco CME eXtensible Markup Language (XML) application program interface (API) queries, use the **xmlthread** command in telephony-service configuration mode. To set the maximum number of queries to the default, use the **no** form of this command.

**xmlthread** *number*

**no xmlthread**

<b>Syntax Description</b>	<i>number</i>	Maximum number of XML API queries. Range is from 1 to 5. Default is 2.
---------------------------	---------------	--

<b>Command Default</b>	The maximum number of queries is 2.
------------------------	-------------------------------------

<b>Command Modes</b>	Telephony-service configuration (config-telephony)
----------------------	--

Command History	Cisco IOS Release	Cisco Product	Modification
	12.2(15)ZJ	Cisco CME 3.0	This command was introduced.
	12.3(4)T	Cisco CME 3.0	This command was integrated into Cisco IOS Release 12.3(4)T.
	12.4(4)XC	Cisco Unified CME 4.0	This command was made obsolete.
	12.4(9)T	Cisco Unified CME 4.0	This command was made obsolete in Cisco IOS Release 12.4(9)T.

**Examples** The following example sets the maximum number of XML API queries to 5:

```
Router(config)# telephony-service
Router(config-telephony)# xmlthread 5
```

Related Commands	Description
<b>telephony-service</b>	Enters telephony-service configuration mode.

