



Release Notes for Cisco Unity-CM TSP Release 8.3(1)

Revised September 16, 2008

These release notes contain requirements, information on new and changed functionality, download and installation instructions, and caveats for Cisco Unity-CM TAPI service provider (TSP) Release 8.3(1).

The Cisco Unity-CM TSP is used only for Cisco Unified Communications Manager SCCP integrations and Cisco Unified Communications Manager Express SCCP integrations.

Cisco Unity-CM TSP version 8.3(1) is automatically installed with Cisco Unity version 7.0(2). To use Cisco Unity-CM TSP 8.3(1) with other supported versions of Cisco Unity and Cisco Unity Connection, download it from the Cisco Unity-CM TSP Software Download page on Cisco.com (see the [“Downloading Cisco Unity-CM TSP Version 8.3\(1\)”](#) section on page 5).

- [Introduction, page 1](#)
- [System Requirements, page 2](#)
- [Related Documentation, page 4](#)
- [New and Changed Requirements and Support—Release 8.3\(1\), page 4](#)
- [New and Changed Functionality—Release 8.3\(1\), page 5](#)
- [Installation and Upgrade Information, page 5](#)
- [Caveats, page 7](#)
- [Troubleshooting, page 8](#)
- [Obtaining Documentation and Submitting a Service Request, page 8](#)

Introduction

The Cisco Unity-CM TSP enables the Skinny Call Control Protocol (SCCP) connection between Cisco Unity and Cisco Unified CM or between Cisco Unity and Cisco Unified CM Express.



System Requirements

See the applicable requirements section, depending on the product:

- [System Requirements—Cisco Unity, page 2](#)
- [System Requirements—Cisco Unity Connection, page 2](#)

The following information is also available in this section:

- [Compatibility Information, page 3](#)
- [Determining the Software Version, page 3](#)

System Requirements—Cisco Unity

- A supported version of Cisco Unity running on the Cisco Unity server:
 - For an integration with Cisco Unified CM, Cisco Unity 4.0(1) through 7.0(2).
 - For an integration with Cisco Unified CM Express, Cisco Unity 4.0(5) through 7.0(2).
- An account with local administrator privileges must be used to upgrade the Cisco Unity-CM TSP. Otherwise, no Cisco Unity ports will be available after the upgrade.
- If you are setting up a Cisco Unified CM integration for the first time, see the applicable version of the Cisco Unified CM integration guide for Cisco Unity, instead of using the instructions in these release notes. Cisco Unified CM integration guides for Cisco Unity are available at http://www.cisco.com/en/US/products/sw/voicesw/ps2237/products_installation_and_configuration_guides_list.html.

System Requirements—Cisco Unity Connection

- A supported version of Cisco Unity Connection 1.x running on the Connection server.



Note Cisco Unity Connection 2.0 or later does not use the Cisco Unity-CM TSP.

- An account with local administrator privileges must be used to upgrade the Cisco Unity-CM TSP. Otherwise, no Cisco Unity Connection ports will be available after the upgrade.
- If you are setting up a Cisco Unified CM integration for the first time, see the applicable version of the Cisco Unified CM integration guide for Cisco Unity Connection, instead of using the instructions in these release notes. Cisco Unified CM integration guides for Cisco Unity Connection are available at http://www.cisco.com/en/US/products/ps6509/products_installation_and_configuration_guides_list.html.

Compatibility Information

For a list of qualified version combinations of the Cisco Unity-CM TSP with Cisco Unified CM, Cisco Unified CM Express, and Cisco Unity or Cisco Unity Connection, see the applicable compatibility matrix:

- For a Cisco Unity system, see *SCCP Compatibility Matrix: Cisco Unity, the Cisco Unity-CM TSP, Cisco Unified Communications Manager, and Cisco Unified Communications Manager Express* at http://www.cisco.com/en/US/products/sw/voicesw/ps2237/products_device_support_tables_list.html.
- For a Cisco Unity Connection system, see *SCCP Compatibility Matrix: Cisco Unity Connection, the Cisco Unity-CM TSP, Cisco Unified Communications Manager, and Cisco Unified Communications Manager Express* at http://www.cisco.com/en/US/products/ps6509/products_device_support_tables_list.html.

Determining the Software Version

This section contains procedures for determining the version in use for the following software:

- [Cisco Unity-CM TSP, page 3](#)
- [Cisco Unity, page 4](#)
- [Cisco Unity Connection \(1.x Only\), page 4](#)

Cisco Unity-CM TSP

To Determine the Cisco Unity-CM TSP Version

- Step 1** Browse to the applicable directory, depending on the Windows version:

Windows 2003	Windows\System32 directory
Other versions	WinNT\System32

- Step 2** Right-click **AvSkinny.tsp**, and click **Properties**.

In the Properties window, click the **Version** tab.

- Step 3** In the Item Name list, click **Product Version**. The Cisco Unity-CM TSP version is displayed in the Value window.

Cisco Unity

To Determine the Cisco Unity Version

-
- Step 1** In the Cisco Unity Administrator, go to the **System > Configuration > Software Versions** page. The Cisco Unity version is displayed in the Cisco Unity Build Number field.
-

Cisco Unity Connection (1.x Only)



Note

This section applies only to Cisco Unity Connection 1.x.

To Determine the Cisco Unity Connection Version by Using Cisco Unity Connection Administration

-
- Step 1** In Cisco Unity Connection Administration, scroll to the bottom of the navigation bar.
- Step 2** Click **About**. The Connection version is displayed below “Cisco Unity Connection.”
-

You can also use the Cisco Unity Connection Server Status utility to determine the version. This is useful when Connection is not running.

To Determine the Cisco Unity Connection Version by Using the Cisco Unity Connection Server Status Utility

-
- Step 1** In the Cisco Unity Connection Server Status utility, click the **Server Status** tab. The Connection version is displayed in the Version field.
-

Related Documentation

For descriptions and URLs of Cisco Unity documentation on Cisco.com, see the *Cisco Unity Documentation Guide*. The document is shipped with Cisco Unity and is available at http://www.cisco.com/en/US/products/sw/voicesw/ps2237/products_documentation_roadmaps_list.html.

For descriptions and URLs of Cisco Unity Connection documentation on Cisco.com, see the *Cisco Unity Connection Documentation Guide*. The document is shipped with Cisco Unity Connection and is available at http://www.cisco.com/en/US/products/ps6509/products_documentation_roadmaps_list.html.

New and Changed Requirements and Support—Release 8.3(1)

There are no new or changed requirements with Cisco Unity-CM TSP Release 8.3(1).

See the applicable release notes for information on new and changed requirements and support in earlier versions of the Cisco Unity-CM TSP. Release notes for all versions of the Cisco Unity-CM TSP are available at http://www.cisco.com/en/US/products/sw/voicesw/ps2237/prod_release_notes_list.html.

New and Changed Functionality—Release 8.3(1)

This section contains information about new and changed functionality for Cisco Unity-CM TSP Release 8.3(1) only. See the applicable release notes for information on new and changed functionality in earlier versions of the Cisco Unity-CM TSP. Release notes for all versions of the Cisco Unity-CM TSP are available at http://www.cisco.com/en/US/products/sw/voicesw/ps2237/prod_release_notes_list.html.

Improved Use of Caller Information

For Skinny Client Control Protocol (SCCP) integrations, caller information is identified, parsed, and provided to Cisco Unity components. This information is used for customized subject lines and can be displayed by the applicable phones and by Cisco Unified Personal Communicator.

Installation and Upgrade Information

- [Downloading Cisco Unity-CM TSP Version 8.3\(1\), page 5](#)
- [Installing the Cisco Unity-CM TSP, page 6](#)
- [Uninstalling the Cisco Unity-CM TSP, page 7](#)

Downloading Cisco Unity-CM TSP Version 8.3(1)

Version 8.3(1) is automatically installed with Cisco Unity 7.0(2). Do the procedure in this section only if you are installing Cisco Unity-CM TSP 8.3(1) for use with a system running another supported version of Cisco Unity or Cisco Unity Connection.

To Download the Cisco Unity-CM TSP

-
- Step 1** Confirm that the Cisco Unity server or the Cisco Unity Connection server has at least 6 MB of hard-disk space available for the download file and the extracted files.
- Step 2** Log on to a computer with a high-speed Internet connection, and go to the Voice and Unified Communications Downloads page at <http://tools.cisco.com/support/downloads/pub/Redirect.x?mdfid=278875240>.



Note To access the Download page, you must be logged on to Cisco.com as a registered user.

- Step 3** In the tree control on the Downloads page, expand **Unified Communications Applications > Voice Mail and Unified Messaging > Cisco Unity**, and click **Cisco Unity-CM TSP Version 8.3**.
- Step 4** On the Select Software page, click **8.3(1)**.

- Step 5** In the right pane, click the link for the Cisco Unity-CM TSP 8.3(1).
- Step 6** On the Download Image page, click **Download**.
- Step 7** On the Supporting Documents page, click **Agree**.
- Step 8** Follow the prompts to save the file to the default directory or to the directory of your choice.
- Step 9** Unzip the file **CiscoUnityCMTSP8.3.1.exe** to the default directory or to the directory of your choice.
- Step 10** Delete the file **CiscoUnityCMTSP8.3.1.exe** to free hard disk space.
-

Installing the Cisco Unity-CM TSP

See the applicable section, depending on the product and version:

- [Installing the Cisco Unity-CM TSP on a Cisco Unity System, page 6](#)
- [Installing the Cisco Unity-CM TSP on a Cisco Unity Connection 1.x System, page 6](#)

(Note that version Cisco Unity-CM TSP 8.3(1) is automatically installed with Cisco Unity 7.0(2).)

Installing the Cisco Unity-CM TSP on a Cisco Unity System

Do the procedure in this section only if you are installing Cisco Unity-CM TSP 8.3(1) on a Cisco Unity system.

To Install the Cisco Unity-CM TSP on a Cisco Unity System

- Step 1** Stop Cisco Unity (right-click the Cisco Unity icon in the system tray, then click **Stop Cisco Unity**).
- Step 2** Browse to the directory in which you saved the extracted Cisco Unity-CM TSP files in the “[Downloading Cisco Unity-CM TSP Version 8.3\(1\)](#)” section on page 5, and double-click **SkinnySetup.exe**.
- Step 3** Follow the on-screen prompts.
- Step 4** Restart the Cisco Unity server.
-

Installing the Cisco Unity-CM TSP on a Cisco Unity Connection 1.x System

Do the procedure in this section only if you are installing Cisco Unity-CM TSP 8.3(1) on a Cisco Unity Connection 1.x system.

To Install the Cisco Unity-CM TSP on a Cisco Unity Connection 1.x System

- Step 1** Stop Cisco Unity Connection (right-click the **Cisco Unity Connection** icon in the system tray, then click **Stop > Cisco Unity Connection**).
- Step 2** Browse to the directory in which you saved the extracted Cisco Unity-CM TSP files in the “[Downloading Cisco Unity-CM TSP Version 8.3\(1\)](#)” section on page 5, and double-click **SkinnySetup.exe**.
- Step 3** Follow the on-screen prompts.

Step 4 Restart the Cisco Unity Connection server.

Uninstalling the Cisco Unity-CM TSP

It is not necessary to uninstall an earlier version of the Cisco Unity-CM TSP before installing version 8.3(1). The installation process automatically removes the older Cisco Unity-CM TSP.

Caveats

This section lists only Severity 1, 2, and 3 caveats.

You can find the latest caveat information for Cisco Unity-CM TSP version 8.3(1)—in addition to caveats of any severity for any release—by using Bug Toolkit, an online tool available for customers to query defects according to their own needs. Bug Toolkit is available at http://www.cisco.com/pcgi-bin/Support/Bugtool/launch_bugtool.pl.



Note

To access Bug Toolkit, you must be logged on to Cisco.com as a registered user.

Note that this section contains caveat information for Cisco Unity-CM TSP Release 8.3(1) only. For caveat information for earlier versions of the Cisco Unity-CM TSP, see the applicable release notes. Release notes for all versions of the Cisco Unity-CM TSP are available at http://www.cisco.com/en/US/products/sw/voicesw/ps2237/prod_release_notes_list.html.

Open Caveats—Release 8.3(1)

There are no severity 1, 2, or 3 open caveats for the Cisco Unity and Cisco Unity Connection products.

Resolved Caveats—Release 8.3(1)

Revised September 16, 2008



Note

[Table 1](#) lists caveats for the Cisco Unity and Cisco Unity Connection products.

Click a link in the Caveat Number column to view the latest information on the caveat in Bug Toolkit. (Caveats are listed in order by severity, then by component, then by caveat number.)

Table 1 Cisco Unity-CM TSP Release 8.3(1) Resolved Caveats

Caveat Number	Component	Severity	Description
CSCsk30869	telephony	2	SCCP constant re-registration causes network connectivity issues
CSCsk33686	telephony	2	RFC2833 digits from secure SIP phones not working on Unity
CSCsk73751	telephony	2	Unity should be able to record mismatch packetization size
CSCsi65508	telephony	3	Unity TSP port failback detection fails

Table 1 Cisco Unity-CM TSP Release 8.3(1) Resolved Caveats (continued)

Caveat Number	Component	Severity	Description
CSCsj13401	telephony	3	Unity Failover results from OpenSSL errors
CSCsj29059	diallogic	3	PIMG: Clipping at beginning of prompt playback after DTMF
CSCs123106	telephony	3	blind transfer to RNA fails with latest CCME build

Troubleshooting

For information on troubleshooting the Cisco Unity-CM TSP and the phone system integration, see the applicable documentation:

- *Troubleshooting Guide for Cisco Unity* at http://www.cisco.com/en/US/products/sw/voicesw/ps2237/prod_troubleshooting_guides_list.html.
- *Cisco Unity Connection Troubleshooting Guide* at http://www.cisco.com/en/US/products/ps6509/prod_troubleshooting_guides_list.html.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.

CCDE, CCENT, Cisco Eos, Cisco Lumin, Cisco Nexus, Cisco StadiumVision, Cisco TelePresence, Cisco WebEx, the Cisco logo, DCE, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn and Cisco Store are service marks; and Access Registrar, Aironet, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, EtherFast, EtherSwitch, Event Center, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, iQuick Study, IronPort, the IronPort logo, LightStream, Linksys, MediaTone, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, Network Registrar, PCNow, PIX, PowerPanels, ProConnect, ScriptShare, SenderBase, SMARTnet, Spectrum Expert, StackWise, The Fastest Way to Increase Your Internet Quotient, TransPath, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0809R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2008 Cisco Systems, Inc. All rights reserved.