



Preface

This document describes the requirements and tasks to install and upgrade the software for Cisco StadiumVision Director Remote Release 3.1. It also includes documentation for hardware installation and configuration on the Cisco UCS C22 server, if using that hardware for your Cisco StadiumVision Director Remote server platform.

The content is intended for Cisco StadiumVision system administrators and technical field engineers who are responsible for designing and deploying Cisco StadiumVision solutions. It is expected that readers of this document are familiar with basic IP networking, Linux, and VMware virtualization.

Document Revision History

[Table 1](#) lists the technical changes made to this document since it was first published.

Table 1 Document Revision History

Date	Change Summary
January 14, 2014	Corrected references to the tested versions of VMware vSphere ESXi with Cisco StadiumVision Director Remote from 4.1 and 5.0 to 4.1 and 5.1.
April 4, 2013	<p>The following changes were made:</p> <ul style="list-style-type: none"> Added information about contacting Cisco Technical Support to obtain the Cisco StadiumVision Director Remote OVA file in the “Installing Cisco StadiumVision Director Remote Software on a Server for the First Time” on page 5. Revised the cable to be used in the Cisco UCS C22 server single-CPU configuration to the UCSC-CABLE-A5 in the “Appendix A: Cisco UCS C22 Hardware Installation Guidelines” on page 21.
March 19, 2013	First release of this document for Cisco StadiumVision Director Remote Release 3.1.0-205.

Document Organization

Chapter	Description
“Getting Started Installing or Upgrading a Cisco StadiumVision Director Remote Server”	Provides information that you should read before you perform an initial installation or upgrade of the Cisco StadiumVision Director Remote Release 3.1 software.
“Installing Cisco StadiumVision Director Remote Software on a Server for the First Time”	Describes how to install the Cisco StadiumVision Director Remote Release 3.1 software from Cisco.com. The process applies to a brand new server that has never been installed with any version of Cisco StadiumVision Director Remote software.
“Upgrading Cisco StadiumVision Director Remote Software”	Describes how to upgrade an existing server already running Cisco StadiumVision Director Remote software. This procedure is also referred to generally as an <i>ISO upgrade</i> and is similar to the ISO upgrade on Cisco StadiumVision Director using the Text Utility Interface (TUI).
“Appendix A: Cisco UCS C22 Hardware Installation Guidelines”	Provides the prerequisites and installation guidelines when installing the Cisco UCS C22 Server as your platform for the Cisco StadiumVision Director Remote software.

Related Documentation

See the *Cisco StadiumVision Director Server Administration Guide, Release 3.1* for information about setting up and managing your Cisco StadiumVision Director servers.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What’s New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What’s New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.