



A

- AC electrical specifications [A-1](#)
- AC power [2-8](#)
 - connecting [3-12](#)
 - cord, connecting [3-12](#)
 - line conditioners [5-5](#)
 - power source interruptions [5-4](#)
 - protection devices [5-5](#)
 - receptacle [1-4](#)
 - site installation preparation [2-8](#)
 - uninterruptible power supplies [5-5](#)
- altitude, guidelines [5-2](#)
- audience [vii](#)

B

- booting the system [3-12](#)

C

- cable pinouts
 - RJ-45 to DB-25 [1-6](#)
 - RJ-45 to DB-9 [1-6](#)
- cabling
 - cables, connecting [3-10](#)
 - Category 5e cable [1-5, 3-11](#)
 - general precautions [2-4](#)
 - rear panel functions [1-4](#)
 - requirements [1-5, 3-11](#)
 - site preparation guidelines [2-8](#)
 - troubleshooting connections [4-2](#)
- cautions, description of [ix](#)

- cleaning operating environment, guidelines [5-3](#)

CLI

- saving connection session [3-13](#)
- serial console connection, establishing [3-13](#)

connections

- cables [3-10](#)
- console port to modem [B-1](#)
- power [3-12](#)
- troubleshooting [4-2](#)

console port

- connections [3-11](#)
- description [1-5](#)
- establishing connection [3-13](#)
- location [1-4](#)
- modem, connecting [B-1](#)
- operating settings [1-6](#)
- pinouts [1-6](#)

- corrosion, preventing damage [5-3](#)

D

- damage to product, reporting [3-2](#)
- documentation
 - conventions [ix](#)
 - related [viii](#)
 - set [viii](#)
- dust, preventing damage [5-3](#)

E

- electrical specifications [A-1](#)
- electricity, safety precautions [2-4](#)
- electromagnetic interference

See EMI

electrostatic discharge, protecting against [2-5, 5-3](#)

EMI, preventing effects of [5-3](#)

environment, maintaining [5-1](#)

environmental

- site requirements [2-7](#)
- specifications [A-1](#)

ESD, preventing damage [5-3](#)

Ethernet interfaces

- cabling requirements [1-5, 3-11](#)
- Category 5 UTP cable [3-11](#)
- connector pinout [1-5](#)
- description [1-5](#)
- Ethernet 0 connector [1-4](#)
- Ethernet 1 connector [1-4](#)
- Ethernet controller [1-5](#)
- specifications [A-2](#)

F

four-post rack mount kit

- installation instructions [3-2](#)

front panel

- features [1-2](#)
- illustration [1-2](#)

H

hard drive

- magnetism effects [5-4](#)

hardware

- features [1-2](#)
- troubleshooting [4-1](#)

humidity guidelines [5-2](#)

HyperTerminal

- launching [3-13](#)
- saving session [3-13](#)

ID button [1-3](#)

installation

- choosing a site [2-7](#)
- creating a safe environment [2-8](#)
- general precautions [2-4](#)
- network, setting up [2-10](#)
- precautions for rack-mounting [2-9](#)
- preparation for [2-1](#)
- preparing for
 - LAN options, precautions for [2-10](#)
 - modems, precautions for [2-10](#)
 - telecommunications, precautions for [2-10](#)
- required tools and equipment [2-10](#)
- site preparation [2-6](#)
- site requirements [2-6](#)
- tools and equipment required [2-10](#)
- unpacking and inspecting [3-2](#)

L

LAN

- options, precautions for [2-10](#)
- precautions [2-10](#)

LED indicators

- monitoring operating status [3-14](#)

line conditioners, using [5-5](#)

M

magnetism, preventing effects of [5-4](#)

maintenance [5-1](#)

modem

- connecting to console port [B-1](#)
- precautions [2-10](#)

N

network, physically removing an appliance [3-14](#)

O

operating status, monitoring [3-14](#)

P

physically removing an appliance from a network [3-14](#)

physical specifications [A-2](#)

port connectors [1-4](#)

port specifications [A-2](#)

power

AC power receptacle [1-4](#)

connecting to system [3-12](#)

power source interruptions, preventing damage [5-4](#)

power button [1-3](#)

power protection devices [5-5](#)

power source interruptions [5-4](#)

power supplies, using uninterruptible [5-5](#)

power supply guidelines [2-8](#)

R

rack mounting

four-post rack [3-2](#)

identifying unit by System ID button [1-4](#)

identifying unit by system ID button [1-3](#)

installation considerations [3-3](#)

precautions [2-9](#)

radio frequency interference. See RFI

rear panel

connections [1-4](#)

features [1-4](#)

removing or replacing the appliance [3-14](#)

RFI, preventing effects of [5-3](#)

RJ-45 to DB2-5 cable pinouts [1-6](#)

RJ-45 to DB-9 cable pinouts [1-6](#)

S

safety

creating a safe environment [2-8](#)

electrostatic discharge [2-5](#)

general precautions [2-4](#)

important safety instructions [2-2](#)

installation [2-1](#)

precautions with electricity [2-4](#)

preventing EMI [2-6](#)

safe environment, creating [2-8](#)

warnings and cautions [2-1](#)

with electricity [2-4](#)

sensors

power supply guidelines [2-8](#)

serial port

connection [3-13](#)

description [1-5](#)

location [1-4](#)

pinouts [1-6](#)

site

environment, maintenance factors [5-1](#)

preparation [2-6](#)

requirements [2-6](#)

specifications [A-1](#)

electrical [A-1](#)

environmental [A-1](#)

physical [A-2](#)

port [A-2](#)

starting the system [3-12](#)

surge protectors, using [5-5](#)

System ID button [1-4](#)

system ID button [1-3](#)

T

- technical specifications [A-1](#)
- telecommunications, precautions [2-10](#)
- temperature guidelines [5-2](#)
- troubleshooting [4-1](#)
 - basic checks [4-1](#)
 - connections [4-2](#)
 - switches [4-2](#)
- troubleshooting system hardware [4-1](#)

U

- uninterruptible power supplies, using [5-5](#)

W

- warnings
 - regarding
 - batteries and explosion danger [2-3](#)
 - chassis, opening [2-2](#)
 - chassis, working on [2-2](#)
 - disposal of unit [2-3](#)
 - explosion [2-3](#)
 - faceplates and cover panels, removing [2-3](#)
 - failure to ground equipment [2-3](#)
 - ground conductor, defeating [2-2, 2-7](#)
 - installation area [2-7](#)
 - instructions, reading [2-3](#)
 - jewelry [2-3](#)
 - lightning activity [2-3, 3-10](#)
 - On/Off switch [2-3](#)
 - power cords, more than one [2-2](#)
 - safety cover [2-2](#)
 - short circuits [2-2, 2-8](#)
 - translations of [2-2](#)