

DOCSIS 3.1 Path Selection

This document describes how to configure the path selecion on the Cisco cBR Series Converged Broadband Router.

- Information about Path Selection, on page 1
- How to Configure Path Selection, on page 1
- Additional References, on page 5
- Feature Information for DOCSIS 3.1 Path Selection, on page 5

Information about Path Selection

DOCSIS 3.1 Path Selection feature is enhanced to support OFDM downstream channels and OFDMA upstream channels. The RCC selection process is enhanced to include OFDM channels. The TCC selection process is enhanced to include OFDMA channels.

How to Configure Path Selection

Configuring Downstream Bonding Group with OFDM Channel

To configure the downstream bonding group with OFDM channel, follow the steps below:

enable
configure terminal
interface wideband-cable slot/subslot/bay:wideband-channel
description text
cable bundle id

 $\textbf{cable rf-channels channel-list} \ \textit{grouplist bandwidth-percent} \ \textit{percentage-bandwidth}$



Note

Channel 158 to 162 are specified as OFDM channel.

Verifying Downstream Bonding Group with OFDM Channel Configuration

To display the details of the downstream bonding group with OFDM channel, use the **show running-config interface** command as shown in the example below:

```
Router# show running-config interface wideband-cable 3/0/0:13
Building configuration...

Current configuration: 212 bytes!
interface Wideband-Cable3/0/0:13
description D31-DSBG: 1 SC-QAM plus 1 OFDM
cable bundle 1
cable rf-channels channel-list 8 bandwidth-percent 30
cable rf-channels channel-list 158 bandwidth-percent 25
end
```

Configuring Upstream Bonding Group with OFDMA Channel

To configure the upstream bonding group with OFDMA channel, follow the steps below:

```
enable
configure terminal
interface cable slot/subslot/bay
cable upstream bonding-group id
upstream id
```

Verifying Upstream Bonding Group with OFDMA Channel Configuration

To display the details of the upstream bonding group with OFDMA channel, use the **show running-config interface** command as shown in the example below:

```
Router# show running-config interface cable 6/0/3
Building configuration...
Current configuration: 212 bytes
interface Cable6/0/3
load-interval 30
downstream Integrated-Cable 6/0/1 rf-channel 158
upstream 0 Upstream-Cable 1/0/0 us-channel 0
upstream 1 Upstream-Cable 1/0/0 us-channel 1
upstream 2 Upstream-Cable 1/0/0 us-channel 2
upstream 3 Upstream-Cable 1/0/0 us-channel 3
 upstream 6 Upstream-Cable 1/0/0 us-channel 12
 cable upstream balance-scheduling
 cable upstream bonding-group 2
 upstream 0
  upstream 1
 upstream 2
 upstream 3
 upstream 6
 attributes 80000000
cable bundle 1
cable privacy accept-self-signed-certificate
```

Verifying the Path Selection Status

To display the path selection status of a cable modem, use the **show cable modem path-sel** command as shown in the example below:

```
router#show cable modem 38c8.5cfe.efa6 path-sel
CM 38c8.5cfe.efa6 Path-Sel Info: 07:20
RCS Filter Result: Succeed
Candidate RCS List: 2
                  Preliminary RCP TLV-56 LBG
Pass Pass -- Pass
 RCC-Id Owner-Id
                                                        SF-Attr
         1 :12289 Pass
 1
                                               Pass
                                                        Pass
                                                                 Pass
                              Pass --
        1 :12290 Pass
                                              Pass
                                                        Pass
                                                                 Pass
TCS Filter Result: Succeed
TCS Info:
                     : 0x7
                                  UCID: 1 2 3
 TCS in CGD
 TCS in Freq Range : 0x7
TCS Impaired : 0x0
                                  UCID: 1 2 3
TCS Passed filters:
                    : 0x7
 Preliminary
                                 UCID: 1 2 3
 LB Group
                     : 0x7
                                  UCID: 1 2 3
                    : 0x7
 .... Mask
CM Attr Mask
                                 UCID: 1 2 3
                    : 0x7
                                 UCID: 1 2 3
Candidate US-BG List: 4
 UBG-Id Chan-Mask Preliminary TLV-56 LBG
                                                 SF-Attr CM-Attr
              Pass
         0x7
                     Pass
                                         Pass
                                                 Pass
                                                          Pass
 65537
         0 \times 2
                                        Pass
                                                          Pass
                                                 Pass
 65538 0x4
                                 --
                   Pass
                                       Pass
                                                Pass
                                                          Pass
 65536 0x1
                    Pass
                                       Pass
                                                Pass
                                                          Pass
Primary DS Chan Result: Skipped
Candidate Primary DS Chan List: 0
Primary US Chan Result: Skipped
Candidate Primary US Chan List: 0
```

Clearing the Path Selection Status

To clear the path selection status for all CMs, use the **clear cable modem all path-sel** command as shown in the example below:

```
Router# clear cable modem all path-sel

Router# show cable modem c8fb.26a6.c46a path-sel

CM c8fb.26a6.c46a Path-Sel Info: N/A

Path-Sel status has been cleared after register online.
```

Verifying the RCC Configuration

To verify the runtime RCCs on a cable interface, use the **show cable mac-domain rcc** command as shown in the example below:

Router# show cable mac-domain cable 7/0/0 rcc

RCC-ID	RCP	RCs MD-DS-SG CMs	WB/RCC-TMPL	D3.0 D3.1
4	00 00 00 00 00	16 0 1	WB (Wi7/0/0:0)	Y Y
5	00 00 00 00 00	25 0 2	WB (Wi7/0/0:1)	N Y
6	00 10 00 00 08	8 0 0	RCC-TMPL(3:1)	Y N
7	00 00 00 00 00	4 0 0	WB (Wi7/0/0:4)	Y Y

To display the detailed information for only DOCSIS 3.1 capable RCC, use the **show cable mac-domain rcc simplified** command as shown in the example below:

router#show cable mac-domain cable 7/0/0 rcc 5 simplified

RCC ID Created Via CM attribute			Wi	deband 800000	- Wi7/0/0:1	
Primary Rece	ive Channel	Li	st	:		
Chan Idx	RF Chan			DCID	Freq	
1	In7/0/0:0			1	453000000	
Non-Primary H	Receive Chan	ne	el :	List:		
Chan Idx	RF Chan			DCID	Freq	
2	In7/0/0:1			2	459000000	
3	In7/0/0:2			3	465000000	
4	In7/0/0:3			4	471000000	
5	In7/0/0:4			5	477000000	
6	In7/0/0:5			6	483000000	
7	In7/0/0:6			7	489000000	
8	In7/0/0:7			8	495000000	
9	In7/0/0:8			9	501000000	
10	In7/0/0:9			10	507000000	
11	In7/0/0:10			11	513000000	
12	In7/0/0:11			12	519000000	
13	In7/0/0:12			13	525000000	
14	In7/0/0:13			14	531000000	
15	In7/0/0:14			15	537000000	
16	In7/0/0:15			16	54300000	
17	In7/0/0:16			17	549000000	
18	In7/0/0:17			18	555000000	
19	In7/0/0:18			19	561000000	
20	In7/0/0:19			20	567000000	
21	In7/0/0:20			21	573000000	
22	In7/0/0:21			22	579000000	
23	In7/0/0:22			23	585000000	
24	In7/0/0:23			24	591000000	
25	In7/0/0:158			159	663000000	
OFDM Receive	Channel Lis	t:				
Chan Idx	RF Chan			DCID	PLC-Freq	Profiles
25	In7/0/0:158			159	663000000	0 1 2

Additional References

Related Document

Document Title	Link
Cisco cBR Converged Broadband Routers Layer 2 and DOCSIS 3.0 Configuration	
Guide	

MIBs

MIBs	MIBs Link
• DOCSIF31-MIB	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:
	http://www.cisco.com/go/mibs

Technical Assistance

Description	Link
The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.	http://www.cisco.com/support
To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.	
Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.	

Feature Information for DOCSIS 3.1 Path Selection

Use Cisco Feature Navigator to find information about the platform support and software image support. Cisco Feature Navigator enables you to determine which software images support a specific software release, feature set, or platform. To access Cisco Feature Navigator, go to the www.cisco.com/go/cfn link. An account on the Cisco.com page is not required.



Note

The following table lists the software release in which a given feature is introduced. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Table 1: Feature Information for DOCSIS 3.1 Path Selection

Feature Name	Releases	Feature Information
DOCSIS 3.1 Path Selection	Cisco IOS XE Fuji 16.7.1	This feature was integrated on the Cisco cBR Series Converged Broadband Routers.
DOCSIS 3.1 Upstream Path Selection	Cisco IOS XE Fuji 16.7.1	This feature was integrated on the Cisco cBR Series Converged Broadband Routers.