



Cisco Network Insights for Resources Application for Cisco Data Center Network Manager Release Notes, Release 2.0.1

Cisco Network Insights for Resources (NIR) application consist of a pair of monitoring utilities that can be added to the Cisco Data Center Network Manager (DCNM).

This document describes the features, issues, and limitations for Cisco NIR on the Cisco DCNM.

For more information, see [Related Content](#).

Date	Description
Apr 8, 2020	Compatibility information for Software Telemetry.
Mar 27, 2020	Compatibility information for Cisco NIR.
July 15, 2019	Software Telemetry Resources support DOM levels.
July 15, 2019	This release supports software streaming telemetry only.
July 8, 2019	Added link to Cisco Network Insights Resources Application for DCNM User Guide.
June 6, 2019	Release became available.

Contents

- [New Software Features](#)
- [Open Issues](#)
- [Resolved Issues](#)
- [Downloading and Installing NIR Application in DCNM](#)
- [Cisco Network Insights for Resources](#)
- [Hardware Requirements](#)
- [Compatibility Information](#)
- [Verified Scalability Limits](#)
- [Usage Guidelines and Limitations](#)
- [Related Content](#)
- [Documentation Feedback](#)
- [Legal Information](#)

New Software Features

Feature	Description
---------	-------------

Software Streaming Telemetry

Environmental – Cisco NIR collects the following environmental data:

- CPU (System & Pre-Process)
- Memory (System & Pre-Process)
- Fan Utilization
- Power
- Temperature
- Storage
- DOM levels

Interface – Cisco NIR collects the following interface data:

- Rx/Tx Rate
- CRC errors

Hardware Resource Utilization – Cisco NIR collects the following hardware resource utilization data:

- Ports Utilization
- Ports in admin UP state
- Bandwidth Utilization
- Control Plane Policers
- LPM
- QoS TCAM
- VLAN, Port, Routed ACLs
- MAC Address Table

Network State – Cisco NIR collects the following network state data:

- MAC addresses
- IPv4 and IPv6 learned routes
- IPv4 and IPv6 host routes
- Multicast routes
- VLANs
- VRFs
- VNIs/VTEPs

Protocol Statistics – Cisco NIR collects the following protocol statistics:

- 3LLDP, LACP

Open Issues

Bug ID	Description	Exists In
CSCvn42171	After deleting an app in APIC GUI, installing a new version and enabling it, the About window continues to show the older version of the app, even if browser window is refreshed. The correct version is displayed upon clearing the browser cache (or using a different browser).	2.0.1

Resolved Issues

None in this release.

Downloading and Installing NIR Application in DCNM

See the [Cisco Network Insights – Resources Application for DCNM User Guide](#) for information and procedures on downloading and installing the NIR application.

Cisco Network Insights for Resources

The Network Insights for Resources (NIR) application provides a way to gather resource information through data collection to get an overview of available resources and their active processes and configurations across the entire Cisco DCNM.

The Cisco NIR application consists of the following components:

- **Data Collection**—The streaming of telemetry data is done by using software or hardware agents in the fabric devices. As each data source is different and the format in which data is streamed is different, there are corresponding "collectors" running Analytics that translate the telemetry events from the devices into data records to be stored in the data lake. The data stored in the data lake is a format that the analytics pipeline can understand and work upon. The 2.0.1 release supports only software streaming telemetry.
- **Resource and Environmental Utilization**—Resource analytics supports configuration, operational and hardware resources. Environmental covers CPU, memory, temperature, and fan speed, storage, power, and DOM levels related to the leaf switches. System analytics also covers, Anomalies, and trending information of each resource and graphing of parameters which help Network operators to debug over periods of time.
- **Predictive Analytics and Correlation**—The value-add of this platform is predicting failures in the fabric and correlating internal fabric failures to the user-visible/interested failures.

Hardware Requirements

This section describes the Cisco DCNM LAN deployment requirements for Cisco NIR software telemetry. A DCNM-native HA deployment is recommended.

Hardware Requirements for Deployments up to 80 Switches

Node	Deployment Mode	CPU	Memory	Storage	Network

Compatibility Information

Node	Deployment Mode	CPU	Memory	Storage	Network
DCNM	OVA/ISO	16 vCPUs	32G	500G HDD	3xNIC
Computes (x3)	OVA/ISO	16 vCPUs	64G	500G HDD	3xNIC

Hardware Requirements for Deployments from 81 to 250 Switches

Node	Deployment Mode	CPU	Memory	Storage	Network
DCNM	OVA/ISO	16 vCPUs	32G	500G HDD	3xNIC
Computes (x3)	ISO	32 vCPUs	256G	2.4TB HDD	3xNIC*

* Network card: Quad-port 10/25G

Compatibility Information

For Cisco NIR on Cisco DCNM compatibility with Day-2 Operations apps, see the [Cisco Day-2 Operations Apps Support Matrix](#).

Software/Hardware	Release
Minimum Cisco NXOS version required for Software Telemetry	7.0(3)I7(6)
Cisco Device supported for Software Telemetry	Cisco Cloud Scale ASIC devices

Verified Scalability Limits

Software/Hardware	Number
Number of nodes supported for Software and Hardware Telemetry	250

Usage Guidelines and Limitations

This section lists the usage guidelines and limitations for Cisco NIR:

- Telemetry for hardware TCAM utilization, such as forwarding TCAM and ACL TCAM are not supported on Cisco Nexus C9504, C9508, and C9516 Series platforms.

Related Content

The Cisco NIR documentation can be accessed from the following website:

<https://www.cisco.com/c/en/us/support/data-center-analytics/network-insights-resources/model.html>

The documentation includes installation, upgrade, configuration, programming, and troubleshooting guides, technical references, and release notes, as well as other documentation.

Document	Description
Cisco NIR Application for the Cisco DCNM Release Notes	This document.
Cisco NIR Application for the Cisco DCNM User Guide	Describes how to download, install, and set up Cisco NIR in Cisco DCNM.

Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, send your comments to cisconetworkinsights-docfeedback@cisco.com.

Legal Information

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2019-2020 Cisco Systems, Inc. All rights reserved.