

Performing NX-OS CLI Tasks

- Cisco ACI Virtual Machine Networking, on page 1
- Cisco ACI with VMware VDS Integration, on page 3
- Custom EPG Names and Cisco ACI, on page 11
- Microsegmentation with Cisco ACI, on page 13
- Intra-EPG Isolation Enforcement and Cisco ACI, on page 15
- Cisco ACI with Cisco UCSM Integration, on page 17
- Cisco ACI with Microsoft SCVMM, on page 18

Cisco ACI Virtual Machine Networking

Configuring a NetFlow Exporter Policy for Virtual Machine Networking Using the NX-OS-Style CLI

The following example procedure uses the NX-OS-style CLI to configure a NetFlow exporter policy for virtual machine networking.

Procedure

Step 1 Enter the configuration mode.

Example:

apic1# config

Step 2 Configure the exporter policy.

```
apic1(config)# flow vm-exporter vmExporter1 destination address 2.2.2.2 transport udp 1234
apic1(config-flow-vm-exporter)# source address 4.4.4.4
apic1(config-flow-vm-exporter)# exit
apic1(config)# exit
```

Consuming a NetFlow Exporter Policy Under a VMM Domain Using the NX-OS-Style CLI for VMware VDS

The following procedure uses the NX-OS-style CLI to consume a NetFlow exporter policy under a VMM domain.

Procedure

```
Step 1
          Enter the configuration mode.
          Example:
          apic1# config
Step 2
          Consume the NetFlow exporter policy.
          Example:
          apic1(config) # vmware-domain mininet
          apic1(config-vmware)# configure-dvs
          apic1(config-vmware-dvs)# flow exporter vmExporter1
          apic1(config-vmware-dvs-flow-exporter)# active-flow-timeout 62
          apic1(config-vmware-dvs-flow-exporter)# idle-flow-timeout 16
          apic1(config-vmware-dvs-flow-exporter)# sampling-rate 1
          apic1(config-vmware-dvs-flow-exporter)# exit
          apic1(config-vmware-dvs)# exit
          apic1(config-vmware) # exit
          apic1(config)# exit
```

Enabling or Disabling NetFlow on an Endpoint Group Using the NX-OS-Style CLI for VMware VDS

The following procedure enables or disables NetFlow on an endpoint group using the NX-OS-style CLI.

Procedure

```
Step 1 Enable NetFlow:
```

```
apic1# config
apic1(config) # tenant tn1
apic1(config-tenant) # application app1
apic1(config-tenant-app) # epg epg1
apic1(config-tenant-app-epg) # vmware-domain member mininet
apic1(config-tenant-app-epg-domain) # flow monitor enable
apic1(config-tenant-app-epg-domain) # exit
apic1(config-tenant-app-epg) # exit
apic1(config-tenant-app) # exit
apic1(config-tenant-app) # exit
apic1(config-tenant) # exit
apic1(config-tenant) # exit
```

Step 2 (Optional) If you no longer want to use NetFlow, disable the feature: Example: apic1(config-tenant-app-epg-domain)# no flow monitor enable

Cisco ACI with VMware VDS Integration

Creating a VMware VDS Domain Profile

Creating a vCenter Domain Profile Using the NX-OS Style CLI

Before you begin

This section describes how to create a vCenter domain profile using the NX-OS style CLI:

Procedure

Step 1 In the CLI, enter configuration mode:

Example:

apic1# configure
apic1(config)#

Step 2 Configure a VLAN domain:

Example:

```
apic1(config)# vlan-domain dom1 dynamic
apic1(config-vlan)# vlan 150-200 dynamic
apic1(config-vlan)# exit
apic1(config)#
```

Step 3 Add interfaces to this VLAN domain. These are the interfaces to be connected to VMware hypervisor uplink ports:

Example:

```
apic1(config)# leaf 101-102
apic1(config-leaf)# interface ethernet 1/2-3
apic1(config-leaf-if)# vlan-domain member dom1
apic1(config-leaf-if)# exit
apic1(config-leaf)# exit
```

Step 4 Create a VMware domain and add VLAN domain membership:

```
apic1(config)# vmware-domain vmmdom1
apic1(config-vmware)# vlan-domain member dom1
```

apic1(config-vmware)#

Create the domain with a specific delimiter:

Example:

apic1(config) # vmware-domain vmmdom1 delimiter @

Step 5 Configure the domain type to DVS:

Example:

```
apic1(config-vmware)# configure-dvs
apic1(config-vmware-dvs)# exit
apic1(config-vmware)#
```

Step 6 (Optional) Configure a retention time for detached endpoints:

You can choose a delay of between 0 and 600 seconds. The default is 0.

Example:

apic1(config) # vmware-domain <domainName>

apic1(config-vmware)# ep-retention-time <value>

Step 7 Configure a controller in the domain:

Example:

```
apic1(config-vmware)# vcenter 192.168.66.2 datacenter prodDC
apic1(config-vmware-vc)# username administrator
Password:
Retype password:
apic1(config-vmware-vc)# exit
apic1(config-vmware)# exit
apic1(config)# exit
```

Note When configuring the password, you must precede special characters such as '\$' or '!' with a backslash ('\\$') to avoid misinterpretation by the Bash shell. The escape backslash is necessary only when configuring the password; the backslash does not appear in the actual password.

Step 8 Verify configuration:

```
apic1# show running-config vmware-domain vmmdom1
# Command: show running-config vmware-domain vmmdom1
# Time: Wed Sep 2 22:14:33 2015
vmware-domain vmmdom1
vlan-domain member dom1
vcenter 192.168.66.2 datacenter prodDC
username administrator password *****
configure-dvs
exit
exit
```

Creating a Read-Only VMM Domain Using the NX-OS Style CLI

You can use the NX-OS style CLI to create a read-only VMM domain.

Before you begin

- Fulfill the prerequisites in the section Prerequisites for Creating a VMM Domain Profile.
- In the VMware vCenter, ensure that under the **Networking** tab, the VDS is contained by a folder.

Also ensure that the folder and the VDS have the exact same name of the read-only VMM domain that you plan to create.

Procedure

Step 1 In the CLI, enter configuration mode:

Example:

```
apic1# configure
apic1(config)#
```

Step 2 Configure a controller in the domain:

Example:

Note The name of the read-only domain (labVDS) must be the same as the name of the VDS and the folder that contains in the VMware vCenter.

```
apic1(config) # vmware-domain labVDS access-mode readonly
apic1(config-vmware) # vcenter 10.1.1.1 datacenter prodDC
apic1(config-vmware-vc) # username administrator@vpshere.local
Password:
Retype password:
apic1(config-vmware-vc) # exit
apic1(config-vmware) # configure-dvs
apic1(config-vmware-dvs) # exit
apic1(config-vmware) # end
```

- **Note** When configuring the password, you must precede special characters such as '\$' or '!' with a backslash ('\\$') to avoid misinterpretation by the Bash shell. The escape backslash is necessary only when configuring the password; the backslash does not appear in the actual password.
- **Step 3** Verify the configuration:

```
apic1# show running-config vmware-domain prodVDS
# Command: show running-config vmware-domain prodVDS
# Time: Wed Sep 2 22:14:33 2015
vmware-domain prodVDS access-mode readonly
vcenter 10.1.1.1 datacenter prodDC
username administrator@vsphere.local password *****
configure-dvs
exit
exit
```

What to do next

You can attach an EPG to the read-only VMM domain and configure policies for it. However, those policies are not pushed to the VDS in the VMware vCenter.

Promoting a Read-Only VMM Domain Using the NX-OS Style CLI

You can use the NX-OS style CLI to promote a read-only VMM domain.

Before you begin

Instructions for promoting a read-only VMM domain to a managed domain assume you have completed the following prerequisites:

- Fulfill the prerequisites in the section Prerequisites for Creating a VMM Domain Profile.
- Configure a read-only domain as described in Creating a Read-Only VMM Domain.
- In the VMware vCenter, under the **Networking** tab, ensure that the VDS is contained by a network folder of the exact same name of the read-only VMM domain that you plan to promote.

Procedure

Step 1 In the CLI, enter configuration mode.

Example:

apic1# configure
apic1(config)#

Step 2 Change the VMM domain's access mode to managed.

In the following example, replace *vmmDom1* with the VMM domain you have previously configured as read-only.

Example:

```
apic1(config)# vmware-domain vmmDom1 access-mode readwrite
apic1(config-vmware)# exit
apic1(config)# exit
```

Step 3 Create a new Link Aggregation Group (LAG) policy.

If you are using vCenter version 5.5 or later, you must create a LAG policy for the domain to use Enhanced LACP feature, as described in Create LAGs for DVS Uplink Port Groups Using the NX-OS Style CLI, on page 7.

Otherwise, you can skip this step.

Step 4 Associate the LAG policy with appropriate EPGs.

If you are using vCenter version 5.5 or later, you must associate the LAG policy with the EPGs to use Enhanced LACP feature, as described in Associate Application EPGs to VMware vCenter Domains with Enhanced LACP Policies Using the NX-OS Style CLI, on page 7.

Otherwise, you can skip this step.

What to do next

Any EPGs you attach to the VMM domain and any policies you configure will now be pushed to the VDS in the VMware vCenter.

Enhanced LACP Policy Support

Create LAGs for DVS Uplink Port Groups Using the NX-OS Style CLI

Improve distributed virtual switch (DVS) uplink port group load balancing by putting the port groups into link aggregation groups (LAGs) and associating them with specific load-balancing algorithms. You can perform this task using the NX-OS style CLI.

Before you begin

You must have created a VMware vCenter virtual machine manager (VMM) domain for VMware VDS or Cisco Application Centric Infrastructure (ACI) Virtual Edge.

Procedure

Create or delete an enhanced LACP policy.

Example:

```
apic1(config-vmware)# enhancedlacp LAG name
apic1(config-vmware-enhancedlacp)# lbmode loadbalancing mode
apic1(config-vmware-enhancedlacp)# mode mode
apic1(config-vmware-enhancedlacp)# numlinks max number of uplinks
apic1(config-vmware)# no enhancedlacp LAG name to delete
```

What to do next

If you are using VMware VDS, associate endpoint groups (EPGs) to the domain with the enhanced LACP policy. If you are using Cisco Application Centric Infrastructure (ACI) Virtual Edge, associate internally created inside and outside port groups with the enhanced LACP policy, then associate EPGs to the domain with the policy.

Associate Application EPGs to VMware vCenter Domains with Enhanced LACP Policies Using the NX-OS Style CLI

Associate application endpoint groups (EPGs) with the VMware vCenter domain with LAGs and a load-balancing algorithm. You can perform this task using NX-OS style CLI. You can also deassociate application EPGs from the domain.

Before you begin

You must have created link aggregation groups (LAGs) for distributed virtual switch (DVS) uplink port groups and associated a load-balancing algorithm to the LAGs.

Procedure

Step 1 Associate an application EPG with the domain or deassociate it from the domain.

Example:

```
apic1(config-tenant-app-epg-domain) # lag-policy name of the LAG policy to associate apic1(config-tenant-app-epg-domain) # no lag-policy name of the LAG policy to deassociate
```

Step 2 Repeat Step 1 for other application EPGs in the tenant as desired.

Endpoint Retention Configuration

Configure Endpoint Retention Using the NX-OS Style CLI

Before you begin

You must have created a vCenter domain.

Procedure



Creating a Trunk Port Group

Creating a Trunk Port Group Using the NX-OS Style CLI

This section describes how to create a trunk port group using the NX-OS Style CLI.

Before you begin

• Trunk port groups must be tenant independent.

Procedure

Vlan Domain

Step 1	Go to the vmware-domain context, enter the following command:			
	Example:			
	apic1(config-vmware)# vmware-domain <i>ifav2-vcenter1</i>			
Step 2	Create a trunk port group, enter the following command:			
	Example:			
	<pre>apic1(config-vmware)# trunk-portgroup trunkpg1</pre>			
Step 3	Enter the VLAN range:			
	Example:			
	apic1(c	onfig-vmware-trunk)# vlan-range 2800-2820, 2830-2850		
	Note	If you do not specify a VLAN range, the VLAN list will be taken from the domain's VLAN namespace.		
Step 4	The mac changes is accept by default. If you choose to not to accept the mac changes, enter the following command:			
	Example:			
	apic1(config-vmware-trunk)# no mac-changes accept			
Step 5	The forged transmit is accept by default. If you choose to not to accept the forged transmit, enter the following command:			
	Example	Example:		
	apic1(config-vmware-trunk)# no forged-transmit accept			
Step 6	The promiscuous mode is disable by default. If you choose to enable promiscuous mode on the trunk port group:			
	Example:			
	apic1(config-vmware-trunk)# allow-promiscuous enable			
Step 7	The trunk port group immediacy is set to on-demand by default. If you want to enable immediate immediacy, enter the following command:			
	Example:			
	<pre>apic1(config-vmware-trunk)# immediacy-immediate enable</pre>			
Step 8	Show the VMware domain:			
	Example:			
	apicl(co Domain l Virtual Switchin	onfig-vmware) # show vmware domain name mininet Name : mininet Switch Mode : VMware Distributed Switch ng Encap Mode : vlan		

: mininet (2800-2850, 2860-2900)

Physical Interfaces : : 2 Number of EPGs Faults by Severity : 0, 2, 4, 0 LLDP override : no CDP override : no Channel Mode override : no vCenters: Faults: Grouped by severity (Critical, Major, Minor, Warning) vCenter Type Datacenter Status ESXs VMs Faults 172.22.136.195 vCenter mininet online 2 57 0,0,4,0 Trunk Portgroups: VLANs Name _____ 280-285 epgtr1 280-285 epgtr2 epgtr3 2800-2850

apic1(config-vmware) # show vmware domain name mininet trunk-portgroup

Name	Aggregated EPG
epgtr1 epgtr2	test www.testcom3 test830
epgtr3	test wwwtestcom3 test830
	test wwwtestcom3 test833

apic1(config-vmware)#)	# show vmware domain nar	ne ifav2-vcenter1	trunk-portgroup	name	trunkpg1
Name	Aggregated E	PG	Encap		

Traine -	11991094004 210	Encap
trunkpg1	LoadBalance ap1 epg1	vlan-318
	LoadBalance ap1 epg2	vlan-317
	LoadBalance ap1 failover-epg	vlan-362
	SH:13I:common:ASAv-HA:test-	vlan-711
	rhi rhiExt rhiExtInstP	
	SH:13I:common:ASAv-HA:test-	vlan-712
	rhi rhiInt rhiIntInstP	
	test-dyn-ep ASA_FWctxctx1bd-	vlan-366
	inside int	
	test-dyn-ep ASA_FWctxctx1bd-	vlan-888
	inside1 int	
	test-dyn-ep ASA_FWctxctx1bd-	vlan-365
	outside ext	
	test-dyn-ep ASA_FWctxctx1bd-	vlan-887
	outsidel ext	
	test-inb FW-Inbctxtrans-	vlan-886
	vrfinside-bd int	
	test-inb FW-Inbctxtrans-	vlan-882
	vrfoutside-bd ext	
	test-inb inb-ap inb-epg	vlan-883
	test-pbr pbr-ap pbr-cons-epg	vlan-451
	test-pbr pbr-ap pbr-prov-epg	vlan-452
	test1 ap1 epg1	vlan-453

```
test1|ap1|epg2
                                                                  vlan-485
                                 test1|ap1|epg3
                                                                  vlan-454
                                 test2-scale|ASA-
                                                                  vlan-496
                                 Trunkctxctx1bd-inside1|int
                                                                  vlan-811
                                 test2-scale|ASA-
                                 Trunkctxctx1bd-inside10|int
apic1(config-vmware)# show running-config vmware-domain mininet
# Command: show running-config vmware-domain mininet
# Time: Wed May 25 21:09:13 2016
  vmware-domain mininet
   vlan-domain member mininet type vmware
    vcenter 172.22.136.195 datacenter mininet
     exit
    configure-dvs
     exit
    trunk-portgroup epgtr1 vlan 280-285
    trunk-portgroup epgtr2 vlan 280-285
    trunk-portgroup epgtr3 vlan 2800-2850
    exit
```

Custom EPG Names and Cisco ACI

Configure or Change a Custom EPG Name Using the NX-OS Style CLI

You can use the NX-OS Style CLI to configure or change a custom endpoint group (EPG) name. Execute the following command in configuration mode for the application EPG domain.



Note

You can use the NX-OS Style CLI to configure or change a custom EPG name only for VMware vCenter-based domains. If you use Microsoft System Center Virtual Machine Manager, you can use the Cisco Application Policy Infrastructure Controller (APIC) GUI or the REST API to configure or change a custom EPG name.



Note Make sure to attach the EPG to the Virtual Machine Manager (VMM) using a single CLI under the following circumstances:

- You attach the EPG and specify a custom EPG name.
- You intend that the attachment takes over an existing EPG in VMware vCenter with the same name as the custom EPG name.

If you fail to attach the EPG and specify a custom EPG name in a single CLI line, you may create duplicate EPGs.

Before you begin

You must have performed the tasks in the section Prerequisites for Configuring a Custom EPG Name in this chapter.

Procedure

Add or modify the custom EPG name for port-groups in VMM domain;

Example:

```
apicl(config-tenant-app-epg-domain)# custom-epg-name My\|Port-group_Name\!XYZ
apicl(config-tenant-app-epg-domain)# show running-config
# Command: show running-config tenant Tenant1 application App1 epg Epg1 vmware-domain member
dvs1
# Time: Tue Nov 12 07:33:00 2019
tenant Tenant1
    application App1
    epg Epg1
    vmware-domain member dvs1
    custom-epg-name My|Port-group_Name!XYZ
    exit
    exit
    exit
    exit
    exit
    exit
    exit
```

What to do next

Verify the port group name, using Verify the Port Group Name in VMware vCenter in this chapter.

Delete a Custom EPG Name Using the NX-OS Style CLI

You can delete a custom endpoint group (EPG) name using the NX-OS Style CLI. Doing so renames the port group in the Virtual Machine Manager domain to the default format: tenant|application|epg.



```
Note
```

You can use the NX-OS Style CLI to delete a custom EPG name only for VMware vCenter-based domains. If you use Microsoft System Center Virtual Machine Manager, you can use the Cisco Application Policy Infrastructure Controller (APIC) GUI or the REST API to delete a custom EPG name.

Procedure

Remove the custom EPG name, applying the default name format to the port group in the VMM domain.

```
apic1(config-tenant-app-epg-domain)# no custom-epg-name
apic1(config-tenant-app-epg-domain)# show running-config
# Command: show running-config tenant Tenant1 application App1 epg Epg1 vmware-domain member
dvs1
# Time: Tue Nov 12 07:51:38 2019
tenant Tenant1
```

```
application App1
epg Epg1
vmware-domain member dvs1
exit
exit
exit
exit
```

What to do next

Verify the change, using Verify the Port Group Name in VMware vCenter in this chapter.

Microsegmentation with Cisco ACI

Configuring Microsegmentation with Cisco ACI Using the NX-OS-Style CLI

This section describes how to configure Microsegmentation with Cisco ACI for Cisco ACI Virtual Edge, VMware VDS, or Microsoft Hyper-V Virtual Switch using VM-based attributes within an application EPG.

Procedure

Step 1 In the CLI, enter configuration mode:

Example:

apic1# configure
apic1(config)#

Step 2 Create the uSeg EPG:

Example:

This example is for an application EPG.

Note The command to allow microsegmentation in the following example is required for VMware VDS only.

```
apic1(config)# tenant cli-ten1
apic1(config-tenant)# application cli-a1
apic1(config-tenant-app)# epg cli-baseEPG1
apic1(config-tenant-app-epg)# bridge-domain member cli-bd1
apic1(config-tenant-app-epg)# vmware-domain member cli-vmm1 allow-micro-segmentation
```

Example:

(Optional) This example sets match EPG precedence for the uSeg EPG:

```
apicl(config)# tenant Coke
apicl(config-tenant)# application cli-al
apicl(config-tenant-app)# epg cli-uepg1 type micro-segmented
apicl(config-tenant-app-uepg)# bridge-domain member cli-bd1
apicl(config-tenant-app-uepg)# match-precedence 10
```

Example:

This example uses a filter based on the attribute VM Name.

```
apic1(config)# tenant cli-ten1
apic1(config-tenant)# application cli-a1
apic1(config-tenant-app)# epg cli-uepg1 type micro-segmented
apic1(config-tenant-app-uepg)# bridge-domain member cli-bd1
apic1(config-tenant-app-uepg)# attribute-logical-expression `vm-name contains <cos1>'
```

Example:

This example uses a filter based on an IP address.

Example:

This example uses a filter based on a MAC address.

Example:

This example uses the operator AND to match all attributes and the operator OR to match any attribute.

```
apic1(config)# tenant cli-ten1
apic1(config-tenant)# application cli-a1
apic1(config-tenant-app)# epg cli-uepg1 type micro-segmented
apic1(config-tenant-app-uepg)# attribute-logical-expression 'hv equals host-123 OR (guest-os
equals "Ubuntu Linux (64-bit)" AND domain contains fex)'
```

Example:

This example uses a filter based on the attribute VM-Custom Attribute.

```
apic1(config)# tenant cli-ten1
apic1(config-tenant)# application cli-a1
apic1(config-tenant-app)# epg cli-uepg1 type micro-segmented
apic1(config-tenant-app-uepg)# bridge-domain member cli-bd1
apic1(config-tenant-app-uepg)# attribute-logical-expression 'custom <Custom Attribute Name>
equals <Custom Attribute value>'
```

Step 3 (Cisco ACI Virtual Edge only): Attach the uSeg EPG to a Cisco ACI Virtual Edge VMM domain, specifying the switching and encapsulation modes:

Example:

```
vmware-domain member AVE-CISCO
switching-mode AVE
encap-mode vxlan
exit
```

Step 4 Verify the uSeg EPG creation:

Example:

The following example is for a uSeg EPG with a VM name attribute filter

```
apicl(config-tenant-app-uepg)# show running-config
# Command: show running-config tenant cli-ten1 application cli-al epg cli-uepg1 type
micro-segmented # Time: Thu Oct 8 11:54:32 2015
tenant cli-ten1
    application cli-a1
    epg cli-uepg1 type micro-segmented
```

```
bridge-domain cli-bd1
   attribute-logical-expression `vm-name contains cos1 force'
   {vmware-domain | microsoft-domain} member cli-vmm1
   exit
   exit
exit
```

Intra-EPG Isolation Enforcement and Cisco ACI

Configuring Intra-EPG Isolation for VMware VDS or Microsoft Hyper-V Virtual Switch using the NX-OS Style CLI

Procedure

Step 1 In the CLI, create an intra-EPG isolation EPG:

Example:

The following example is for VMware VDS:

```
apic1(config) # tenant Test Isolation
apic1(config-tenant) # application PVLAN
apic1(config-tenant-app) # epg EPG1
apic1(config-tenant-app-epg)# show running-config
# Command: show running-config tenant Tenant VMM application Web epg intraEPGDeny
  tenant Tenant VMM
    application Web
      epg intraEPGDeny
        bridge-domain member VMM BD
        vmware-domain member PVLAN encap vlan-2001 primary-encap vlan-2002 push on-demand
        vmware-domain member mininet
         exit
        isolation enforce
        exit
      exit
    exit
apic1(config-tenant-app-epg)#
```

Example:

The following example is for Microsoft Hyper-V Virtual Switch:

```
apicl(config) # tenant Test_Isolation
apicl(config-tenant) # application PVLAN
apicl(config-tenant-app) # epg EPG1
apicl(config-tenant-app-epg) # show running-config
# Command: show running-config tenant Tenant_VMM application Web epg intraEPGDeny
tenant Tenant_VMM
    application Web
    epg intraEPGDeny
        bridge-domain member VMM_BD
        microsoft-domain member domain1 encap vlan-2003 primary-encap vlan-2004
        microsoft-domain member domain2
        exit
        isolation enforce
```

exit
exit
exit
apic1(config-tenant-app-epg)#

Step 2 Verify the configuration:

```
Example:
```

```
show epg StaticEPG detail
Application EPg Data:
        : Test_Isolation
: PVLAN
Tenant
Application
AEPg
           : StaticEPG
      : VMM_BD
: no
BD
uSeg EPG
Intra EPG Isolation : enforced
Vlan Domains : VMM
Consumed Contracts : VMware vDS-Ext
Provided Contracts : default, Isolate EPG
Denied Contracts :
Qos Class : unspecified
Tag List
           :
VMM Domains:
Domain Type Deployment Immediacy Resolution Immediacy State
Encap
     -----
DVS1
             VMware On Demand
                                 immediate
                                               formed
  auto
        auto
Static Leaves:
Node Encap
                  Deployment Immediacy Mode
                                            Modification Time
_____
Static Paths:
                                     Modification Time
Node Interface
                           Encap
_____
1018
      eth101/1/1
                          vlan-100
                                     2016-02-11T18:39:02.337-08:00
                                     2016-02-11T18:39:02.337-08:00
1019
      eth1/16
                          vlan-101
Static Endpoints:
Node
     Interface
                  Encap
                             End Point MAC End Point IP Address
     Modification Time
_____ _____
_____
Dynamic Endpoints:
Encap: (P):Primary VLAN, (S):Secondary VLAN
       Interface
                              End Point MAC
                                          End Point TP Address
Node
                 Encap
    Modification Time
----- ----- ------
     _____
1017 eth1/3
                   vlan-943(P) 00:50:56:B3:64:C4 ---
   2016-02-17T18:35:32.224-08:00
                   vlan-944(S)
```

Cisco ACI with Cisco UCSM Integration

Integrating Cisco UCSM Using the NX-OS Style CLI

You can use the NX-OS style CLI to integrate Cisco UCS Manager (UCSM) into the Cisco Application Centric Infrastructure (ACI) fabric.

Before you begin

You must have fulfilled the prerequisites in the section Cisco UCSM Integration Prerequisites in this guide.

Procedure

Create the integration group, the integration for the integration group, and choose the Leaf Enforced or the Preprovision policy.

If you choose the default **Pre-provision** policy, Cisco Application Policy Infrastructure Controller (APIC) detects which virtual machine manager (VMM) domain that you use. Cisco APIC then pushes all VLANs associated with that domain to the target Cisco UCSM.

If you choose the **Leaf Enforced** policy, Cisco APIC detects only the VLANS that are deployed to the top-of-rack leaf nodes. Cisco APIC then filters out any undeployed VLANs, resulting in fewer VLANs pushed to the Cisco UCSM.

Note The following example includes an example of specifying the uplink port channel, which your deployment might require. For example, Layer 2 disjoint networks require that you make that specification.

```
APIC-1# config terminal
APIC-1(config) # integrations-group GROUP-123
APIC-1(config-integrations-group) # integrations-mgr UCSM 001 Cisco/UCSM
APIC-1 (config-integrations-mgr) #
APIC-1(config-integrations-mgr) # device-address 1.1.1.2
APIC-1(config-integrations-mgr) # user admin
Password:
Retype password:
APIC-1 (config-integrations-mgr) #
APIC-1(config-integrations-mgr)# encap-sync preprovision
APIC-1(config-integrations-mgr) # nicprof-vlan-preserve ?
overwrite overwrite
preserve preserve
APIC-1 (config-integrations-mgr) # nicprof-vlan-preserve preserve
APIC-1(config-integrations-mgr)#
  exit
```

Cisco ACI with Microsoft SCVMM

Creating a Static IP Address Pool Using the NX-OS Style CLI

Procedure

Step 1 In the CLI, enter configuration mode:

Example:

apic1# config

Step 2 Create the Static IP Address Pool:

Example:

```
apic1(config) # tenant t0
apic1(config-tenant) # application a0
apic1(config-tenant-app)# epg e0
apic1(config-tenant-app-epg) # mic
microsoft microsoft-domain
apic1(config-tenant-app-epg)# microsoft static-ip-pool test_pool gateway 1.2.3.4/5
apic1(config-tenant-app-epg-ms-ip-pool)# iprange 1.2.3.4 2.3.4.5
apic1(config-tenant-app-epg-ms-ip-pool)# dns
dnssearchsuffix dnsservers dnssuffix
apic1(config-tenant-app-epg-ms-ip-pool)# dnssuffix testsuffix
apic1(config-tenant-app-epg-ms-ip-pool)# exit
apic1(config-tenant-app-epg) # no mi
microsoft microsoft-domain
apic1(config-tenant-app-epg) # no microsoft static-ip-pool ?
test pool
apic1(config-tenant-app-epg) # no microsoft static-ip-pool test_pool gateway ?
gwAddress gwAddress
apic1(config-tenant-app-epg) # no microsoft static-ip-pool test pool gateway 1.2.3.4/5
apic1(config-tenant-app-epg)#
```

Step 3 Verify the Static IP Address Pool:

```
apic1(config-tenant-app-epg-ms-ip-pool) # show running-config
# Command: show running-config tenant t0 application a0 epg e0 microsoft static-ip-pool
test_pool gateway 1.2.3.4/5
# Time: Thu Feb 11 23:08:04 2016
  tenant t0
    application a0
      epg e0
        microsoft static-ip-pool test pool gateway 1.2.3.4/5
          iprange 1.2.3.4 2.3.4.5
          dnsservers
          dnssuffix testsuffix
          dnssearchsuffix
          winservers
          exit.
        exit
      exit
```

L

Creating a SCVMM Domain Profile Using the NX-OS Style CLI

This section describes how to create a SCVMM domain profile using the command-line interface (CLI).

Procedure

Step 1 In the NX-OS Style CLI, configure a vlan-domain and add the VLAN ranges:

Example:

```
apic1# configure
apic1(config)# vlan-domain vmm_test_1 dynamic
apic1(config-vlan)# vlan 150-200 dynamic
apic1(config-vlan)# exit
```

Step 2 Add interfaces to the vlan-domain:

Example:

```
apic1(config) # leaf 101
apic1(config-leaf) # interface ethernet 1/2
apic1(config-leaf-if) # vlan-domain member vmm_test_1
apic1(config-leaf-if) # exit
apic1(config-leaf) # exit
```

Step 3 Create the Microsoft SCVMM domain and associate it with the previously created vlan-domain. Create the SCVMM controller under this domain:

```
apic1(config)# microsoft-domain mstest
apic1(config-microsoft)# vlan-domain member vmm_test_1
apic1(config-microsoft)# scvmm 134.5.6.7 cloud test
apic1#
```