

Cisco MDS 9000 Series EPLD Release Notes

Release 9.4(1a)



Contents

Introduction 3

EPLD Bundle Support Matrix 3

EPLD Versions in Cisco MDS 9000 EPLD Bundle..... 5

Resolved Issues 7

Guidelines and Limitations 7

Determining EPLD Versions..... 8

Installing EPLD Updates 11

Legal Information 15

Introduction

Switches and directors in the Cisco MDS 9000 Series contain several electrical programmable logical devices (EPLDs) that provide hardware functionalities in all the modules. EPLD upgrades are periodically provided to include enhanced hardware functionality or to resolve known issues.

EPLD bundles are released as part of a Cisco MDS NX-OS release. Therefore, the EPLD bundles have a version number that matches the Cisco MDS NX-OS release they are part of.

An EPLD bundle is a package containing updates for multiple EPLDs. Each EPLD update has its own version number, which is independent of the Cisco MDS NX-OS release. As EPLD changes are infrequent, an EPLD bundle may contain new updates for only some EPLDs. The remaining EPLD updates will be the same version as the previous EPLD bundle.

You need not update switch EPLDs unless otherwise advised by TAC. For detailed functional image upgrade instructions, refer to the [Cisco MDS 9000 NX-OS Fundamentals Configuration Guide, Release 9.x](#). To download EPLD bundles, go to the URL: <https://software.cisco.com/download/navigator.html>.

Date	Description
January 13, 2024	Initial Release

EPLD Bundle Support Matrix

The version of the EPLD bundle must match the version of the Cisco MDS NX-OS release that is running when the EPLD upgrades are installed. This requirement only applies during EPLD code upgrades or downgrades. Cisco MDS NX-OS can be subsequently upgraded or downgraded without changing the EPLD versions.

The following table shows the EPLD bundles that are compatible with specific NX-OS releases.

Table 1. Release Compatibility Matrix

NX-OS Releases	EPLD Bundle
NX-OS 9.4(1a)	m9000-pkg1-9.4.1a.epld
	m9000-pkg2-9.4.1a.epld
	m9000-pkg3-9.4.1a.epld

The following table lists the Cisco MDS 9000 components and the EPLD bundle versions that are supported for the components.

Table 2. EPLD Support Matrix

EPLD Bundle	Cisco MDS 9000 Components	Product Identifier (PID)
m9000-pkg1.9.4.1a.epld	MDS 9148S 48-Port 16-Gbps Fabric Switch	DS-C9148S-K9-SUP
	MDS 9250i 40-Port 16-Gbps Fabric Switch	DS-C9250I-K9-SUP

EPLD Bundle	Cisco MDS 9000 Components	Product Identifier (PID)
m9000-pkg2.9.4.1a.epld ¹	MDS 9396S 16-Gbps Multilayer Fabric Switch	DS-C9396S-K9-SUP
	MDS 9700 Supervisor Module 1	DS-X97-SF1-K9
	MDS 9700 Supervisor Module 1	DS-X97-SF1E-K9
	MDS 9700 Supervisor Module 4	DS-X97-SF4-K9
	48-Port 16-Gbps Advanced Fibre Channel Module	DS-X9448-768K9
	48-Port 32-Gbps Advanced Fibre Channel Module	DS-X9648-1536K9
	48-Port 64-Gbps Advanced Fibre Channel Module	DS-X9748-3072K9
	24-Port 40-Gbps FCoE Module	DS-X9824-960K9
	48-Port 10-Gbps FCoE Module	DS-X9848-480K9
	MDS 9706 Fabric Module 1	DS-X9706-FAB1
	MDS 9706 Fabric Module 3	DS-X9706-FAB3
	MDS 9710 Fabric Module 1	DS-X9710-FAB1
	MDS 9718 Fabric Module 1	DS-X9718-FAB1
	MDS 9710 Fabric Module 3	DS-X9710-FAB3
	MDS 9718 Fabric Module 3	DS-X9718-FAB3
	MDS 9706 Fan Module	DS-C9706-FAN
	MDS 9710 Fan Module	DS-C9710-FAN
	MDS 9718 Fan Module	DS-C9718-FAN
m9000-pkg3.9.4.1a.epld	MDS 9132T Fibre Channel Switch	DS-C9132T-K9-SUP
	MDS 9124V Fibre Channel Switch	DS-C9124V-K9-SUP
	MDS 9148T Fibre Channel Switch	DS-C9148T-K9-SUP
	MDS 9148V Fibre Channel Switch	DS-C9148V-K9-SUP
	MDS 9220i Fibre Channel Switch	DS-C9220I-K9
	MDS 9396T Fibre Channel Switch	DS-C9396T-K9-SUP
	MDS 9396V Fibre Channel Switch	DS-C9396V-K9

¹ Although the **show version epld** command displays Cisco MDS 9132T, MDS 9148T, and MDS 9396T platforms as supported in this bundle, they are not supported. Instead, they are supported in the m9000-pk3 bundle as indicated in this table.

EPLD Versions in Cisco MDS 9000 EPLD Bundle

Each EPLD bundle that you can download from <http://www.cisco.com> is a bundle of EPLD upgrades. The following table lists the EPLD versions for Cisco MDS 9000 series platforms for Cisco MDS NX-OS Release 9.4(1a).

Model Number/Application Models	Module Type	EPLD Device	Version
MDS 9124V Fibre Channel Fabric Switch			
DS-C9124V-K9-SUP	24-Port 8/16/32/64-Gbps 1-RU Fabric Switch	MI IO SPI	0.012
		IO SPI 2	0.014
MDS 9132T Fibre Channel Fabric Switch			
DS-C9132T	32-Port 4/8/16/32-Gbps 1-RU Fabric Switch	IO SPI 2	0.024
		MI IO SPI	0.017
		LEM IO SPI	0.016
MDS 9148S Fibre Channel Fabric Switch			
DS-C9148S-K9	48-Port 2/4/8/16-Gbps Fabric Switch	Power Manager	0x1f
MDS 9148T Fibre Channel Fabric Switch			
DS-C9148T-K9	48-Port 4/8/16/32-Gbps 1-RU Fabric Switch	SFP SPI	0.01
		IO SPI 2	0.01
		MI IO SPI	0.01
MDS 9148V Fibre Channel Fabric Switch			
DS-C9148V-K9-SUP	48-Port 8/16/32/64-Gbps 1-RU Fabric Switch	MI IO SPI	0.012
		IO SPI 2	0.014
MDS 9220i Multiservice Fabric Switch			
DS-C9220I-K9	4/8/16/32-Gbps 1-RU Fabric Switch	IO SPI 2	0.024
		MI IO SPI	0.027
		AKFPGA SPI	1
MDS 9250i Multiservice Fabric Switch			
DS-C9250I-K9	40-Port 2/4/8/16-Gbps Fabric Switch	Power Manager	0x1a
		DB Power Manager	0x0b

Model Number/Application Models	Module Type	EPLD Device	Version
MDS 9396S Fibre Channel Fabric Switch			
DS-C9396S-K9	96-Port 2/4/8/16-Gbps Fabric Switch	IO SPI 2	1.00
		IO SPI	1.00
MDS 9396T Fibre Channel Fabric Switch			
DS-C9396T-K9	96-Port 4/8/16/32-Gbps 2-RU Fabric Switch	SFP SPI	0.007
		IO SPI 2	0.013
		MI IO SPI	0.006
		LEM-1 SPI	0.016
		LEM-2 SPI	0.016
		LEM-3 SPI	0.016
MDS 9700 Series Common Modules			
DS-X97-SF1-K9	Supervisor Module 3	Power Manager SPI	22.00
DS-X97-SF1E-K9	Supervisor Module 3	Power Manager SPI	22.00
DS-X97-SF4-K9	Supervisor Module 4	Power Manager SPI	23.00
DS-X9448-768K9	48-Port 16-Gbps Advanced Fibre Channel Module	Power Manager	10.00
		IO	15.00
DS-X9648-1536K9	48-Port 32-Gbps Fibre Channel Switching Module	Power Manager SPI	0.002
		SFP SPI	0.005
		IO SPI	2.00
DS-X9748-3072K9	48-Port 64-Gbps Fibre Channel Switching Module	SFP SPI	0.008
		IO SPI	0.029
DS-X9824-960K9	40-Gbps FCoE Module	Power Manager SPI	1.01
		IO SPI 2	0.03
		IO SPI	0.03
DS-X9848-480K9	10-Gbps FCoE Module	Power Manager SPI	0.01
		IO	0.01
DS-X9334-K9	24/10-Port SAN Extension	Power Manager SPI	1.001

Model Number/Application Models	Module Type	EPLD Device	Version
	Module	IO SPI	2.00
MDS 9706 Series Specific Modules			
DS-C9706-FAN	Fan	Fan Controller (1)	0.01
		Fan Controller (2)	0.01
DS-X9706-FAB-1	Fabric Module 1	Power Manager	1.00
DS-X9706-FAB-3	Fabric Module 3	Power Manager	0.01
MDS 9710 Series Specific Modules			
DS-C9710-FAN	Fan	Fan Controller (1)	0.01
		Fan Controller (2)	0.01
DS-X9710-FAB-1	Fabric Module 1	Power Manager	1.00
DS-X9710-FAB-3	Fabric Module 3	Power Manager	0.01
MDS 9718 Series Specific Modules			
DS-C9718-FAN	Fan	Fan Controller (1)	0.01
		Fan Controller (2)	0.01
DS-X9718-FAB-1	Fabric Module 1	Power Manager	1.00
DS-X9718-FAB-3	Fabric Module 3	Power Manager	0.01

Resolved Issues

This EPLD release contains minor hardware-related changes that do not change the product specification. For example, handling new versions of hardware electrical components on a new revision of a module. These changes are backward compatible with older hardware, but unnecessary unless specifically documented below.

There are no resolved issues in this release.

Guidelines and Limitations

When you upgrade or downgrade the EPLDs, observe the following guidelines and limitations:

- You can upgrade each module only when it is online. The EPLD upgrade is only disruptive to the module being upgraded.
- If you interrupt an EPLD upgrade or downgrade, the module must be upgraded again.
- In Cisco MDS 9000 Director Switches, EPLD upgrade or downgrade can only be executed from the active supervisor module. To upgrade the supervisor EPLDs nondisruptively, upgrade the

standby supervisor and then switchover. After the new standby supervisor is online, its EPLDs can be upgraded.

- In Cisco MDS 9000 Series Fabric Switches, be sure to specify 1 as the module number. The switch must be power cycled for the EPLDs to start running the new code.

Determining EPLD Versions

This includes the following sections.

Module EPLD Versions

Use the **show version module *slot* epld** command to view all current EPLD versions on a specific module.

Displaying Current EPLD Versions for a Module

```
switch# show version module 1 epld
EPLD Device Version
-----
Power Manager SPI 0.002
IO SPI 0.038
SFP SPI 0.005
```

Fan Module EPLD Versions

Use **show version fan *slot* epld** command to view all current EPLD versions on a specific fan module. The following command output shows the currently installed EPLD versions on a fan module.

Displaying Current EPLD Versions for a Fan Module

```
switch# show version fan 1 epld
EPLD Device Version
-----
Fan Controller (1) 0.006
Fan Controller (2) 0.006
```

Fabric Module EPLD Versions

Use the **show version xbar *slot* epld** command to view all current EPLD versions on a specific fabric module. The following command output shows the currently installed EPLD versions on a fabric module.

Displaying Current EPLD Versions for a Fabric Module

```
switch# show version xbar 2 epld
EPLD Device Version
-----
Power Manager 0.008
```

Displaying EPLD Versions in an EPLD Bundle

Use the **show version epld *uri*** command to view all the updates contained in an EPLD package. The following example shows the EPLD versions contained in an EPLD bundle.

Displaying EPLD Versions in an EPLD Bundle

```
switch# show version epld m9000-pkg3.9.4.1a.epld
```

Retrieving EPLD versions... Please wait.

EPLD image file 9.4.1a built on Mon Jan 4 22:59:21 2024

Module Type	Model	EPLD Device	Version

Supervisor Module-3	DS-X97-SF1-K9	Power Manager SPI	22.000
Supervisor Module-3	DS-X97-SF1E-K9	Power Manager SPI	22.000
Supervisor Module-4	DS-X97-SF4-K9	Power Manager SPI	23.000
Fabric Module 1	DS-X9718-FAB1	Power Manager	1.002
Fabric Module 1	DS-X9710-FAB1	Power Manager	1.003
Fabric Module 1	DS-X9706-FAB1	Power Manager	1.002
Fabric Module 3	DS-X9706-FAB-3	Power Manager	0.010
Fabric Module 3	DS-X9710-FAB-3	Power Manager	0.008
Fabric Module 3	DS-X9718-FAB-3	Power Manager	0.007
16 Gbps Advanced FC Module	DS-X9448-768K9	Power Manager	10.000
16 Gbps Advanced FC Module	DS-X9448-768K9	IO	15.000
10 Gbps FCoE Module	DS-X9848-480K9	Power Manager	0.006
10 Gbps FCoE Module	DS-X9848-480K9	IO	0.005
40 Gbps FCoE Module	DS-X9824-960K9	Power Manager SPI	1.005
40 Gbps FCoE Module	DS-X9824-960K9	IO SPI 2	0.028
40 Gbps FCoE Module	DS-X9824-960K9	IO SPI	0.031
Fan	DS-C9718-FAN	Fan Controller (1)	0.006
Fan	DS-C9718-FAN	Fan Controller (2)	0.006
Fan	DS-C9710-FAN	Fan Controller (1)	0.006
Fan	DS-C9710-FAN	Fan Controller (2)	0.006
Fan	DS-C9706-FAN	Fan Controller (1)	0.006
Fan	DS-C9706-FAN	Fan Controller (2)	0.006
2/4/8/16G Fabric Switch	DS-C9396S-K9	IO SPI 2	1.002
2/4/8/16G Fabric Switch	DS-C9396S-K9	IO SPI	1.003
32 Gbps Advanced FC Module	DS-X9648-1536K9	Power Manager SPI	0.002
32 Gbps Advanced FC Module	DS-X9648-1536K9	SFP SPI	0.005
32 Gbps Advanced FC Module	DS-X9648-1536K9	IO SPI	2.000

1/10/40G IPS, 2/4/8/10/16G FC Modul	DS-X9334-K9	Power Manager SPI	1.001
1/10/40G IPS, 2/4/8/10/16G FC Modul	DS-X9334-K9	IO SPI	2.000
4/8/16/32G 1 RU Fabric Switch	DS-C9132T	IO SPI 2	0.024
4/8/16/32G 1 RU Fabric Switch	DS-C9132T	MI IO SPI	0.017
4/8/16/32G 1 RU Fabric Switch	DS-C9132T	LEM IO SPI	0.016
4/8/16/32G 2 RU Fabric Switch	DS-C9396T-K9	SFP SPI	0.007
4/8/16/32G 2 RU Fabric Switch	DS-C9396T-K9	IO SPI 2	0.013
4/8/16/32G 2 RU Fabric Switch	DS-C9396T-K9	MI IO SPI	0.006
4/8/16/32G 2 RU Fabric Switch	DS-C9396T-K9	LEM-1 SPI	0.016
4/8/16/32G 2 RU Fabric Switch	DS-C9396T-K9	LEM-2 SPI	0.016
4/8/16/32G 2 RU Fabric Switch	DS-C9396T-K9	LEM-3 SPI	0.016
4/8/16/32G 1 RU Fabric Switch	DS-C9148T-K9	SFP SPI	0.007
4/8/16/32G 1 RU Fabric Switch	DS-C9148T-K9	IO SPI 2	0.013
4/8/16/32G 1 RU Fabric Switch	DS-C9148T-K9	MI IO SPI	0.006
1/10/25/40G IPS, 4/8/16/32G FC Swi	DS-C9220I-K9	IO SPI 2	0.024
1/10/25/40G IPS, 4/8/16/32G FC Swi	DS-C9220I-K9	MI IO SPI	0.027
1/10/25/40G IPS, 4/8/16/32G FC Swi	DS-C9220I-K9	AKFPGA SPI	1.000
8/16/32/64 Gbps Advanced FC Module	DS-X9748-3072K9	SFP SPI	0.008
8/16/32/64 Gbps Advanced FC Module	DS-X9748-3072K9	IO SPI	0.029
8/16/32/64G 1 RU Fabric Switch	DS-C9148V-K9	IO SPI 2	0.014
8/16/32/64G 1 RU Fabric Switch	DS-C9148V-K9	MI IO SPI	0.015
8/16/32/64G 1 RU Fabric Switch	DS-C9124V-K9	IO SPI 2	0.014
8/16/32/64G 1 RU Fabric Switch	DS-C9124V-K9	MI IO SPI	0.015
8/16/32/64G 2 RU Fabric Switch	DS-C9396V-K9	SFP SPI	0.006
8/16/32/64G 2 RU Fabric Switch	DS-C9396V-K9	IO SPI 2	0.015
8/16/32/64G 2 RU Fabric Switch	DS-C9396V-K9	MI IO SPI	0.0114

switch # **show version module 1 epld**

EPLD Device Version

MI IO SPI 0.012

IO SPI 2 0.014

Installing EPLD Updates

Supervisors, switching, fabric, and fan modules may be upgraded in a switch. For Director switches, modules can be upgraded together or individually. For Fabric switches, modules are upgraded individually. Fabric switches do not require fabric and fan modules to be upgraded.

The modules to be upgraded are specified by the user. If the module number that is specified in the command is not present, the update is aborted. Otherwise, a warning and a prompt to continue is printed. If the user proceeds, the status of each specified module is printed followed by a table of installed and new EPLD versions. If no modules require upgrading, the command exits. If any module EPLD version is different and requires upgrading, the user is prompted to continue. All EPLDs are updated on the first specified module. The update process may take several minutes. After the update, the module is power cycled. For switching modules, this power cycle disrupts traffic on all ports of the module. If the new EPLD version is the same as the installed version or the module is present but not online, no action is taken for that module. If more than one module is specified, the download and power cycle process is repeated for the next module.

This section includes the following topics:

Installing EPLD Updates on All Modules in a Director Switch

To update all EPLDs sequentially with a single command, use the **install all epld** command with the **module all fan-module all xbar all** options. After each module is upgraded, it is power cycled to load the EPLD update. Switching module power cycles are disruptive to the traffic passing through them. If the active supervisor requires upgrading, it will be updated last and a supervisor switchover executed. Fan modules do not require to be power cycled.

Installing a Director Switch Supervisor Module EPLD Update

To update the EPLDs on supervisor modules of Director Switches in a nondisruptive manner, follow these steps:

- Step 1.** Update the EPLD on the standby supervisor module. On the active supervisor module, enter the **install all epld** command, specifying the current standby supervisor module number.

After the EPLD update is complete, the standby supervisor module will be power cycled.
- Step 2.** After the standby supervisor module reaches the 'ha-standby' state, perform a switchover and wait until the new standby supervisor module reaches the 'ha-standby' state.
- Step 3.** From the active supervisor module, repeat the above steps.

For information about how to update the EPLDs on supervisor modules of the Fabric switches, see [Installing a Switching Module EPLD Update](#).

Updating the Standby Supervisor Module EPLDs on a Cisco MDS 9700 Series Switch

```
switch# install all epld bootflash:m9000-pkg2-9.4.1a.epld parallel module 6
Copy complete, now saving to disk (please wait)...
EPLD image signature verification passed
Compatibility check:
Module Type Upgradable Impact      Reason
-----
6 SUP  Yes  disruptive Module      Upgradable
Retrieving EPLD versions... Please wait.
```

Images will be upgraded according to following table:

Module	Type	EPLD	Running-Version	New-Version	Upg-Required
6	SUP	Power Manager SPI	18.000	19.000	Yes

The above modules require upgrade.

Do you want to continue (y/n) ? [n] y

Starting Module 6 EPLD Upgrade

Module 6 : Power Manager SPI [Upgrade Started]

Module 6 : Power Manager SPI [Erasing] : 100.00%

Module 6 : Power Manager SPI [Programming] : 100.00% (6020818 of 6020818 total bytes)

Module 6 Upgrade Done.

Waiting for Module 6 to come online.

Module 6 EPLD upgrade is successful.

EPLD Upgrade Completed.

Module Type Upgrade-Result

6	SUP	Success
---	-----	---------

Installing a Switching Module EPLD Update

For Director Switches, use the `install all epld uri parallel module slot` command to update the EPLDs on an individual module. Use the `module all` option to update the EPLDs of both supervisors and all switching modules.

Updating Module EPLDs on a Director Switch

```
switch# install all epld bootflash:m9000-pkg2.9.4.1a.epld parallel module 1
```

WARNING!!!: Executing the "install all epld" command

may result in multiple modules going offline and affect redundant links.

For EPLD upgrade best practices, please refer below link:

http://www.cisco.com/c/en/us/td/docs/switches/datacenter/mds9000/sw/7_3/upgrade/upgrade.html

Do you want to continue (y/n) ? [n] **y**

Copy complete, now saving to disk (please wait)...

EPLD image signature verification passed

Compatibility check:

Module	Type	Upgradable	Impact	Reason
--------	------	------------	--------	--------

1	LC	Yes	disruptive	Module Upgradable
---	----	-----	------------	-------------------

Retrieving EPLD versions... Please wait.

Images will be upgraded according to following table:

Module	Type	EPLD	Running-Version	New-Version	Upg-Required
1	LC	Power Manager	10.000	10.000	No
1	LC	IO	15.000	15.000	No

All Modules are up to date.

Installing a Fabric Switch Supervisor EPLD Update

Note: An EPLD update of the supervisor module of Fabric Switches (Cisco MDS 9100, Cisco MDS 9200, and Cisco MDS 9300 Series switches) is disruptive since there is no redundant supervisor to take over while the update is in progress. All traffic through the system is stopped while updating and the switch is power cycled after the upgrade has been completed. The update may take up to 30 minutes to complete.

The following message is displayed:

```
Data traffic on the switch will be affected!!
The switch will reload after the upgrade process.
Do you want to continue (y/n) ?
```

For more information about upgrading supervisor modules in Director Switches, see [Installing a Director Switch Supervisor Module EPLD Update](#).

Updating Supervisor EPLDs on a Fabric Switch

```
switch# install module 1 epld bootflash:m9000-pkg2-9.4.1a.epld
Retrieving EPLD versions... Please wait.
Images will be upgraded according to following table:
Module Type EPLD Running-Version New-Version Upg-Required
-----
1      SUP  IO SPI      0.034      1.003      Yes
1      SUP  IO SPI 2    0.005      1.002      Yes
Data traffic on the switch will be affected!!
The switch will reload after the upgrade process.
Do you want to continue (y/n) ? [n] y
Module 1 : IO SPI [Programming] : 100.00% ( 12970 of 12970 total bytes)
Module 1 : IO SPI 2 [Programming] : 100.00% ( 3137 of 3137 total bytes)
Waiting for Module to come online.
Module 1 EPLD upgrade is successful.
Reconfiguring Active Supervisor EPLDs.
The Supervisor will reset.
Module 1 : IO SPI 2 [Programming] : 0.70% ( 22 of 3137 total bytes)
Module 1 EPLD upgrade is successful.
```

Installing a Fan Module EPLD Update

Use the `install all epld uri parallel fan-module slot` command to upgrade the EPLDs on the fan modules. The EPLD update for a fan module is nondisruptive and a power cycle is not required after the update.

Upgrading Fan Module EPLDs on a Cisco MDS 9700 Series Switch

```
switch# install all epld bootflash:m9000-pkg2.9.4.1a.epld parallel fan-module 1
WARNING!!!: Executing the "install all epld" command
may result in multiple modules going offline and affect redundant links.
It is strongly recommended to use one of the following
```

when EPLD upgrade is attempted on a system carrying production traffic.or Module EPLDs".

1) "install module <mod#> epld"

2) "install all epld <uri> parallel module <mod#>"

where <mod#> is on a single module

For EPLD upgrade best practices, please refer to the link-

http://www.cisco.com/en/US/docs/switches/datacenter/sw/best_practices/cli_mgmt_guide/epld_upgrade.html

Do you want to continue (y/n) ? [n] y

Copy complete, now saving to disk (please wait)...

EPLD image signature verification passed

Retrieving EPLD versions... Please wait.

Images will be upgraded according to following table:

Module	Type	EPLD	Running-Version	New-Version	Upg-Required
-----	----	-----	-----	-----	-----
1	FAN	Fan Controller (1)	0.002	0.006	Yes
1	FAN	Fan Controller (2)	0.002	0.006	Yes

Programming Fan Module 1

Do you want to continue (y/n) ? [n] **y**

Fan 1 (1 of 2) : Fan Controller [Verifying] : 100.00% (135658 of 135658 total bytes)

Fan 1 (2 of 2) : Fan Controller [Verifying] : 100.00% (135658 of 135658 total bytes)

Waiting for Module to come online.

Fan Module 1 EPLD upgrade is successful.

Installing a Fabric Module EPLD Update

The Cisco MDS 9700 Series switches have dedicated fabric modules. These modules contain EPLDs, which can be upgraded as described in this section. All other Cisco MDS switches do not have these modules, so this process is not applicable to them.

For Cisco MDS 9700 Series switches, use the **install all epld uri parallel xbar-module slot** command to update the EPLDs on the fabric modules. This process power cycles the updated module. To ensure that the data traffic performance is not affected while the module is power cycled, check the fabric bandwidth utilization by using the show hardware fabric-utilization detail command. If there is adequate reserve fabric bandwidth available before the update starts, then the update will be nondisruptive.

Upgrading Fabric Module EPLDs for a Cisco MDS 9700 Series Switch

```
switch# install all epld bootflash:m9000-pkg2.9.4.1a.epld parallel xbar-module 1
```

WARNING!!!: Executing the "install all epld" command

may result in multiple modules going offline and affect redundant links.

It is strongly recommended to use one of the following

when EPLD upgrade is attempted on a system carrying production traffic.

1) "install module <mod#> epld"

2) "install all epld <uri> parallel module <mod#>"

where <mod#> is on a single module

For EPLD upgrade best practices, please refer to the link-
[http://www.cisco.com/en/US/docs/switches/datacenter/
sw/best_practices/cli_mgmt_guide/epld_upgrade.html](http://www.cisco.com/en/US/docs/switches/datacenter/sw/best_practices/cli_mgmt_guide/epld_upgrade.html)

Do you want to continue (y/n) ? [n] **y**

Copy complete, now saving to disk (please wait)...

EPLD image signature verification passed

Compatibility check:

Module	Type	Upgradable	Impact	Reason
--------	------	------------	--------	--------

1	Xbar	Yes	disruptive	Module Upgradable
---	------	-----	------------	-------------------

Retrieving EPLD versions... Please wait.

Images will be upgraded according to following table:

Module	Type	EPLD Running-Version	New-Version	Upg-Required
--------	------	----------------------	-------------	--------------

1	Xbar	Power Manager	1.003	1.004	Yes
---	------	---------------	-------	-------	-----

The above modules require upgrade.

Do you want to continue (y/n) ? [n] **y**

Starting Xbar Module 1 EPLD Upgrade

Xbar Module 1 EPLD upgrade is successful.

EPLD Upgrade Completed.

Module	Type	Upgrade-Result
--------	------	----------------

1	Xbar	Success
---	------	---------

Legal Information

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2024 Cisco Systems, Inc. All rights reserved.