



Migrating From DCNM to ND

- [Migrating from DCNM to ND, on page 1](#)

Migrating from DCNM to ND

You cannot upgrade directly from DCNM 11.5(4) to Nexus Dashboard 4.3.1. Use this workflow instead to upgrade from DCNM 11.5(4) to Nexus Dashboard 4.3.1:

1. First upgrade from DCNM 11.5(4) to Nexus Dashboard 4.1.1 using the procedures provided in the "Migrating From DCNM to ND" section in [Cisco Nexus Dashboard Deployment and Upgrade Guide, Release 4.1.x](#).
2. Then upgrade from Nexus Dashboard 4.1.1 to Nexus Dashboard 4.3.1 using the procedures provided in [Upgrading a Nexus Dashboard 4.1.1 Cluster to This Release](#).



Note

There is a known issue where the Nexus Dashboard Orchestrator (NDO) app is disabled after upgrading from DCNM 11.5 to Nexus Dashboard 4.1.1. You will have to manually re-enable the NDO (Orchestrator) app before upgrading from Nexus Dashboard 4.1.1 to Nexus Dashboard 4.3.1; otherwise, you will see an upgrade pre-check failure.

1. Enable the **Display advanced settings and options for TAC support** feature (**Admin > System Settings > General > Advanced Settings > Display advanced settings and options for TAC support**).

You have to enable the **Display advanced settings and options for TAC support** feature in order to see the **Features** tab in the next step.

2. Manually re-enable the NDO (Orchestrator) app (**Admin > System Status > Features**).

You can then disable the **Display advanced settings and options for TAC support** feature again, if necessary.

