



# Deploying Cisco Nexus Data Broker Software in Centralized Standalone Mode

---

This chapter contains details of procedures for installing and upgrading NDB in centralized mode.

Before you proceed with the upgrade/ install procedures in this chapter, compare the **md5sum** between the NDB CCO image and image file copied to linux. Use the following command to check (linux):

```
cisco@NDB-virtual-machine:~/3.10/$ md5sum ndb1000-sw-app-k9-3.10.0.zip
Displayed output: 518db25b4a89c996340c0316f72a6287 ndb1000-sw-app-k9-3.10.0.zip
```

- [Installing or Upgrading the Cisco Nexus Data Broker Software in Centralized Mode, on page 1](#)
- [Starting the Application , on page 6](#)
- [Verifying The Application Status, on page 6](#)

## Installing or Upgrading the Cisco Nexus Data Broker Software in Centralized Mode

Before proceeding with the installation, check the System Requirements section in the [Overview](#) chapter of this guide.

In Cisco NDB Release 3.10, JRE is unbundled from the NDB package. You need to install Java on the NDB server before starting NDB 3.10.0.



---

**Note** Only Oracle Java is supported.

---

1. Install Java version greater than 1.8.0\_45
2. Set JAVA\_HOME environment variable; command to be used- export JAVA\_HOME=(jre\_path)

## Installing the Cisco Nexus Data Broker Software in Centralized Mode

Complete these steps to install Cisco Nexus Data Broker software in Centralized mode:

**Step 1** In a web browser, navigate to **www.cisco.com**.

**Step 2** Under **Support**, click **All Downloads**.

**Step 3** In the center pane, click **Cloud and Systems Management**.

**Step 4** If prompted, enter your Cisco.com **username** and **password** to log in.

**Step 5** In the right pane, click **Network Controllers and Applications**, and then click **Cisco Nexus Data Broker**.

The file information for Release 3.10 is displayed: Cisco Nexus Data Broker Software Application:  
ndb1000-sw-app-k9-3.10.0.zip

**Step 6** Download the Cisco Nexus Data Broker application bundle.

**Step 7** Create a directory in your Linux machine where you plan to install Cisco Nexus Data Broker.

For example, in your Home directory, create `CiscoNDB`.

**Step 8** Copy the Cisco Nexus Data Broker zip file into the directory that you created.

**Step 9** Unzip the Cisco Nexus Data Broker zip file.

The Cisco Nexus Data Broker software is installed in a directory called `ndb`. The directory contains the following:

- `runndb.sh` file—The file that you use to launch Cisco Nexus Data Broker.
- `version.properties` file—The Cisco Nexus Data Broker build version.
- `configuration` directory—The directory that contains the Cisco Nexus Data Broker initialization files.  
This directory also contains the `startup` subdirectory where configurations are saved.
- `bin` directory—The directory that contains the following script:
  - `ndb` file—This script contains the Cisco Nexus Data Broker common CLI.
- `etc` directory—The directory that contains profile information.
- `lib` directory—The directory that contains the Cisco Nexus Data Broker Java libraries.
- `logs` directory—The directory that contains the Cisco Nexus Data Broker logs.

**Note** The `logs` directory is created after the Cisco Nexus Data Broker application is started.

- `plugins` directory—The directory that contains the OSGi plugins.
- `work` directory—The webserver working directory.

**Note** The `work` directory is created after the Cisco Nexus Data Broker application is started.

**Step 10** Start the NDB application using `runndb.sh -start .`

## Upgrading the Application Software in Centralized Mode Using CLI

Use the **upgrade** command to upgrade to Cisco NDB Release 3.10.0.

**Note**

- When you upgrade the software to Cisco Nexus Data Broker Release 3.2 or later release, the hostname should not be changed during the upgrade process. If the hostname is changed during the upgrade process, the upgrade might fail. If you are upgrading from release 2.x, 3.0 and 3.1, the domain name configuration in the switch should be removed before upgrading the software.

In case, the upgrade was not successful because of the mismatch of the host name, use RMA to correct the configuration of the device. See the *RMA* section in the *Cisco Nexus Data Broker Configuration Guide*.

- When you run the **upgrade** command, the installation and the configuration are upgraded. However, any changes you made to the shell scripts or configuration files, for example, `config.ini`, are overwritten. After you complete the upgrade process, you must manually reapply your changes to those files.
- The latest NDB zip file must be extracted in an empty directory.

**Hitless Upgrade**

For hitless upgrade, configuration backup for releases prior to NDB Release 3.8, will always be the standard upgrade by re-configuring the devices during the upgrade.

Configuration backup taken for releases NDB 3.8 and after, will always be a Hitless upgrade using CLI.

**Before you begin**

- Backup up the NDB configuration. See the *Backup/Restore* section in the *Cisco Nexus Data Broker Configuration Guide*.
- Back up your `config.ini` file.

**Important**

You should manually backup your `config.ini` file before upgrading, because the backup process does not back them up for you. If you do not backup your files before upgrading, any changes you made will be lost.

**Note**

When you run `runndb.sh` script, there is a thread in the script that monitors the log and the Cisco Nexus Data Broker JAVA process to monitor the health of the Cisco Nexus Data Broker. The default value for this option is 30 Seconds.

- Step 1** Backup your Cisco Nexus Data Broker release installation using your standard backup procedures.
- Step 2** In a web browser, navigate to [Cisco.com](https://www.cisco.com).
- Step 3** Under **Support**, click **All Downloads**.
- Step 4** In the center pane, click **Cloud and Systems Management**.
- Step 5** In the right pane, click **Network Controllers and Applications**, and then click **Cisco Nexus Data Broker**.
- Step 6** Download the Cisco NDB Release 3.10 applicable bundle: Cisco Nexus Data Broker Software Application—`ndb1000-sw-app-k9-3.10.0.zip`

- Step 7** Create a temporary directory in your Linux machine where you plan to upgrade to Cisco NDB.
- Step 8** Unzip the Cisco NDB Release 3.10 zip file into the temporary directory that you created.
- Step 9** Navigate to the `ndb` directory that was created when you installed the Cisco Nexus Data Broker release (created in the previous step).
- Step 10** Stop the running Cisco Nexus Data Broker instance.
- Step 11** Navigate to the `ndb/bin` directory in the temporary directory that you created for Cisco NDB Release 3.10 upgrade software.
- Step 12** Upgrade the application by entering the `./ndb upgrade --perform --target-home {ndb_directory_to_be_upgraded} [--verbose] [--backupfile {ndb_backup_location_and_zip_filename}]` command.

You can use one of the following options:

Option	Description
<code>--perform --target-home {ndb_directory_to_be_upgraded}</code>	Upgrades the Cisco ndb Monitor Manager installation to Cisco NDB.
<code>--perform --target-home {ndb_directory_to_be_upgraded} --backupfile {ndb_backup_location_and_zip_filename}</code>	Upgrades the Cisco ndb Monitor Manager installation to Cisco NDB and creates a backup.zip file in the directory path that you set.  <b>Note</b> <ul style="list-style-type: none"> <li>You must provide the name of the backup file and the .zip extension.</li> <li>The backup file should not be saved in the ndb directory with current NDB installation or its subdirectory.</li> </ul>
<code>--verbose</code>	Displays detailed information to the console. This option can be used with any other option and is disabled by default.
<code>--validate --target-home {ndb_directory_to_be_upgraded}</code>	Validates the installation.
<code>./ndb help upgrade</code>	Displays the options for the <b>upgrade</b> command.

- Step 13** Navigate to the older folder (**xnc** in releases prior to Release 3.10) where you originally installed Cisco NDB. Rename the folder from **xnc** to **ndb**.
- Step 14** Start the application processes using `runndb.sh -start`.

## Upgrading the Application Software in Centralized Mode Using GUI



**Note** The latest NDB zip file must be extracted in an empty directory.

### Hitless Upgrade

For hitless upgrade, configuration backup for releases prior to NDB Release 3.8, will always be the standard upgrade by re-configuring the devices during the upgrade.

Configuration backup taken for releases NDB 3.8 and after, will always be a Hitless upgrade using CLI.

Complete the following steps to upgrade the application software in the Centralized mode using GUI:

- 
- Step 1** Login to the NDB GUI.
- Step 2** Navigate to **Administration > Backup/Restore** to download the configuration in zip file format.  
The default name of the zip file is **configuration\_startup.zip**.
- Step 3** Stop the current NDB instance using the **runxnc.sh -stop** command.  
**Example:**  

```
./runxnc.sh -stop
```
- Step 4** If TLS certification is enabled between NDB server and NXOS switch, copy the `tlsTrustStore` and `tlsKeyStore` files to `/ndb/configuration` from the old ndb backup.
- Step 5** In a web browser, navigate to [Cisco.com](https://www.cisco.com).
- Step 6** Under **Support**, click **All Downloads**.
- Step 7** In the center pane, click **Cloud and Systems Management**.
- Step 8** In the right pane, click **Network Controllers and Applications**, and then click **Cisco Nexus Data Broker**.
- Step 9** Download the Cisco NDB Release 3.10 applicable bundle: Cisco Nexus Data Broker Software Application—ndb1000-sw-app-k9-3.10.0.zip
- Step 10** Create a directory in your Linux machine where you plan to upgrade to Cisco NDB.
- Step 11** Unzip the Cisco NDB Release 3.10 zip file into the directory that you created.
- Step 12** Navigate to the `ndb` directory that was created when you installed the Cisco Nexus Data Broker release (created in the previous step).
- Step 13** Start the new NDB installation using the **runndb.sh -start** command.  
**Example:**  

```
./runndb.sh -start
```
- Step 14** Navigate to **Administration > Backup/Restore**.
- Step 15** To reconfigure the device during the upgrade, select the **Restore** option (by checking the check-box) during configuration upload.
- Step 16** Restart the new NDB instance using the **runndb.sh -restart** command.  
**Example:**  

```
./runndb.sh -restart
```
-

## Starting the Application

**Note** When you are running NDB for the first time, the URL that you need to connect to and the port that it is listening on are displayed on the screen. For example, when you run the `./runndb.sh` script, the following message is displayed on the screen: Web GUI can be accessed using below URL: [`https://<IP_address>:8443`].

Java 8 is required for NDB. Setup `JAVA_HOME` before NDB is started.

You can use one of the following options:

Option	Description
no option	
<b>-jmxport</b> <i>port_number</i>	Enables JMX remote access on the specified JVM port.
<b>-debugport</b> <i>port_number</i>	Enables debugging on the specified JVM port.
<b>-start</b>	
<b>-start</b> <i>port_number</i>	
<b>-stop</b>	
<b>-restart</b>	
<b>-status</b>	
<b>-console</b>	
<b>-help</b>	Displays the options for the <code>./runndb.sh</code> command.
<b>-tls</b>	To enable TLS, start the controller by entering the <code>./runndb.sh -tls -tlskeystore keystore_file_location -tlstruststore truststore_file_location</code> command.

## Verifying The Application Status

**Step 1** Navigate to the `ndb` directory that was created when you installed the software.

**Step 2** Verify that the application is running by entering the `./runndb.sh -status` command.

The controller outputs the following, which indicates that the controller is running the Java process with PID 21680:

```
Controller with PID:21680 -- Running!
```

**What to do next**

Connect the switches to the controller. For more information, see the configuration guide for your switches.

