Configuring System Message Logging

This chapter describes how to configure system message logging on Cisco NX-OS devices.

This chapter contains the following sections:

- About System Message Logging, on page 1
- Guidelines and Limitations for System Message Logging, on page 2
- Default Settings for System Message Logging, on page 3
- Configuring System Message Logging, on page 4
- Verifying the System Message Logging Configuration, on page 18
- Repeated System Logging Messages, on page 19
- Configuration Example for System Message Logging, on page 19
- Additional References, on page 19

About System Message Logging

You can use system message logging to control the destination and to filter the severity level of messages that system processes generate. You can configure logging to terminal sessions, a log file, and syslog servers on remote systems.

For more information about the system message format and the messages that the device generates, see the Cisco NX-OS System Messages Reference.

By default, the device outputs messages to terminal sessions and logs system messages to a log file.

The following table describes the severity levels used in system messages. When you configure the severity level, the system outputs messages at that level and lower.

Table 1: System Message Severity Levels

Level	Description
0 – emergency	System unusable
1 – alert	Immediate action needed
2 – critical	Critical condition
3 – error	Error condition

Level	Description
4 – warning	Warning condition
5 – notification	Normal but significant condition
6 – informational	Informational message only
7 – debugging	Appears during debugging only

The device logs the most recent 100 messages of severity 0, 1, or 2 to the NVRAM log. You cannot configure logging to the NVRAM.

You can configure which system messages should be logged based on the facility that generated the message and its severity level.

Syslog Servers

The syslog servers run on remote systems that log system messages based on the syslog protocol. You can configure up to eight IPv4 or IPv6 syslog servers.

To support the same configuration of syslog servers on all switches in a fabric, you can use Cisco Fabric Services (CFS) to distribute the syslog server configuration.

Note When the device first initializes, messages are sent to syslog servers only after the network is initialized.

Secure Syslog Servers

Beginning with Cisco NX-OS Release 9.2(1), you can configure the syslog server with support for a secure TLS transport connectivity to remote logging servers. Additionally, you can enforce the NX-OS switches (client) identity via the mutual authentication configuration. For NX-OS switches, this feature supports TLSv1.1 and TLSv1.2.

The Secure syslog server feature uses the TCP/TLS transport and security protocols to provide device authentication and encryption. This feature enables a Cisco NX-OS device (acting as a client) to make a secure, encrypted outbound connection to remote syslog servers (acting as a server) supporting secure connectivity for logging. With authentication and encryption, this feature allows for a secure communication over an insecure network.

Guidelines and Limitations for System Message Logging

System message logging has the following configuration guidelines and limitations:

- System messages are logged to the console and the log file by default.
- Any system messages that are printed before the syslog server is reachable (such as supervisor active or online messages) cannot be sent to the syslog server.

- Cisco recommends maintaining the logging levels for all processes at default. Increasing the levels to higher values can result in seeing syslog messages that are not intended for customers, can generate false alarms, and are generally supposed to be used for short-term troubleshooting purposes by TAC. Cisco does not provide support for syslog messages at levels above default.
- Beginning with Cisco NX-OS Release 9.2(1), you can configure the syslog server with support for a secure TLS transport connectivity to remote logging servers. This feature supports TLS v1.1 and TLS v1.2.
- For the secure syslog server(s) to be reachable over an in-band (nonmanagement) interface, the CoPP profile may need tweaks. Especially when multiple logging servers are configured and when many syslogs are generated in a short time (such as, boot up and config application).
- This guideline applies to the user-defined persistent logging file:

  The syslog command, **logging logfile**, allows the configuration of the logfile both in persistent (/logflash/log) and non-persistent locations (/log).

  The default logfile is named "messages" and this file, along with backup files (if present) messages.1, messages.2, messages.3, messages.4 cannot be deleted, even by the **delete /log/** or **delete logflash:/log/** commands.

  There is a provision to configure custom-named logfiles (**logging logfile** *file-name severity*), however this custom-named file can be deleted by the delete operation. If this occurs, syslog logging does not function.

  For example, the custom-named logfile is configured and the same file gets deleted via delete operation. Because this is an intentional delete operation, in order to log the syslog messages on the custom logfiles, you must reconfigure the custom logfile using command **logging logfile** *file-name severity*. Until this configuration is performed, the syslog logging cannot occur.
- Generally, the syslogs display the local time zone. However, few components such as NGINX display the logs in UTC time zone.

Default Settings for System Message Logging

The following table lists the default settings for the system message logging parameters.

Table 2: Default System Message Logging Parameters

Parameters	Default
Console logging	Enabled at severity level 2
Monitor logging	Enabled at severity level 5
Log file logging	Enabled to log messages at severity level 5
Module logging	Enabled at severity level 5
Facility logging	Enabled
Time-stamp units	Seconds

Parameters	Default
Syslog server logging	Disabled
Syslog server configuration distribution	Disabled

Configuring System Message Logging

Note Be aware that the Cisco NX-OS commands for this feature might differ from those commands used in Cisco IOS.

Configuring System Message Logging to Terminal Sessions

You can configure the device to log messages by their severity level to console, Telnet, and SSH sessions.

By default, logging is enabled for terminal sessions.

Note The current critical (default) logging level is maintained if the console baud speed is 9600 baud (default). All attempts to change the console logging level will generate an error message. To increase the logging level (above critical), you must change the console baud speed to 38400 baud.

Procedure

	Command or Action	Purpose
Step 1	**terminal monitor** **Example:** `switch# terminal monitor`	Enables the device to log messages to the console.

Step 2	**configure terminal**
	Example:
	`switch# configure terminal`
	`switch(config)#`
		Enters global configuration mode.

Step 3	[**no**] **logging console** [*severity-level*] **Example:** `switch(config)# logging console 3`	Configures the device to log messages to the console session based on a specified severity level or higher. A lower number indicates a higher severity level. Severity levels range from 0 to 7: • 0 – emergency • 1 – alert

	Command or Action	Purpose
		• 2 – critical • 3 – error • 4 – warning • 5 – notification • 6 – informational • 7 – debugging If the severity level is not specified, the default of 2 is used. The **no** option disables the device's ability to log messages to the console.
Step 4	(Optional) **show logging console** **Example:** `switch(config)# show logging console`	Displays the console logging configuration.
Step 5	[**no**] **logging monitor** [*severity-level*] **Example:** `switch(config)# logging monitor 3`	Enables the device to log messages to the monitor based on a specified severity level or higher. A lower number indicates a higher severity level. Severity levels range from 0 to 7: • 0 – emergency • 1 – alert • 2 – critical • 3 – error • 4 – warning • 5 – notification • 6 – informational • 7 – debugging The configuration applies to Telnet and SSH sessions. If the severity level is not specified, the default of 2 is used. The **no** option disables the device's ability to log messages to the Telnet and SSH sessions.
Step 6	(Optional) **show logging monitor** **Example:** `switch(config)# show logging monitor`	Displays the monitor logging configuration.

	Command or Action	Purpose
Step 7	[**no**] **logging message interface type ethernet description** **Example:** `switch(config)# logging message interface type ethernet description`	Enables you to add the description for physical Ethernet interfaces and subinterfaces in the system message log. The description is the same description that was configured on the interface. The **no** option disables the printing of the interface description in the system message log for physical Ethernet interfaces.
Step 8	(Optional) **copy running-config startup-config** **Example:** `switch(config)# copy running-config startup-config`	Copies the running configuration to the startup configuration.

Configuring the Origin ID for Syslog Messages

You can configure Cisco NX-OS to append the hostname, an IP address, or a text string to syslog messages that are sent to remote syslog servers.

Procedure

	Command or Action	Purpose

Step 1	**configure terminal**
	Example:
	`switch# configure terminal`
	`switch(config)#`
		Enters global configuration mode.

Step 2	Required: **logging origin-id** {**hostname** | **ip** *ip-address* | **string** *text-string*} **Example:** `switch(config)# logging origin-id string n9k-switch-abc`	Specifies the hostname, IP address, or text string to be appended to syslog messages that are sent to remote syslog servers.

Step 3	(Optional) **show logging origin-id**
	Example:
	`switch(config)# show logging origin-id`
	`Logging origin_id : enabled (string: n9k-switch-abc)`
		Displays the configured hostname, IP address, or text string that is appended to syslog messages that are sent to remote syslog servers.

Step 4	(Optional) **copy running-config startup-config** **Example:** `switch(config)# copy running-config startup-config`	Copies the running configuration to the startup configuration.

Logging System Messages to a File

You can configure the device to log system messages to a file. By default, system messages are logged to the file /logflash/log/*logfilename*.

Procedure

	Command or Action	Purpose

Step 1	**configure terminal**
	Example:
	`switch# configure terminal`
	`switch(config)#`
		Enters global configuration mode.

Step 2	[**no**] **logging logfile** *logfile-name severity-level* [**persistent threshold** *percent* | **size** *bytes*]
	Example:
	`switch(config)# logging logfile my_log 6`
	`switch(config)# logging logfile my_log 6 persistent threshold 90`
		Configures the nonpersistent or persistent log file parameters.
		logfile-name: Configures the name of the log file that is used to store system messages. Default filename is "message".
		severity-level: Configures the minimum severity level to log. A lower number indicates a higher severity level. Default is 5. Range is from 0 through 7:
		• 0 – emergency
		• 1 – alert
		• 2 – critical
		• 3 – error
		• 4 – warning
		• 5 – notification
		• 6 – informational
		• 7 – debugging
		persistent threshold *percent*: Optionally configure the threshold percentage for the persistent log file. Range is from 0 through 99.
		Note
		Setting **persistent threshold** to 0 (zero) disables the persistent threshold feature and generates no threshold syslogs.
		percent configures the percent threshold size of the persistent file. Once the threshold size is reached, an alert notification message is logged. On reaching 100% utilization of the persistent

	Command or Action	Purpose

		log file, the system sends another syslog message notification. The system then creates a backup file of the existing log file and starts writing into a new log file with the configured threshold percentage applied. In total, the last five backup files are present at most. After five files, the system deletes files based on the oldest modified.
		Note
		Persistent logging is a system-enabled feature. Log files are located here: /logflash/log/[filename].
		
		Outputs of the following show commands support the persistent log file feature:
		• **show logging info**
		• **show logging**
		
		The outputs include the following persistent logging information:
		`Logging logflash: enabled (Severity: notifications)(threshold percentage: 99)`
		`Logging logfile: enabled`
		`Name - messages: Severity - notifications Size - 4194304`
		size *bytes*: Optionally specify maximum file size. Range is from 4096 through 4194304 bytes.

Step 3	**logging event** {**link-status** | **trunk-status**} {**enable** | **default**} **Example:** `switch(config)# logging event link-status default`	Logs interface events. • **link-status**—Logs all UP/DOWN and CHANGE messages. • **trunk-status**—Logs all TRUNK status messages. • **enable**—Specifies to enable logging to override the port level configuration. • **default**—Specifies that the default logging configuration is used by interfaces that are not explicitly configured.
Step 4	(Optional) **show logging info** **Example:** `switch(config)# show logging info`	Displays the logging configuration.

	Command or Action	Purpose
Step 5	(Optional) **copy running-config startup-config** **Example:** `switch(config)# copy running-config startup-config`	Copies the running configuration to the startup configuration.

Configuring Module and Facility Messages Logging

You can configure the severity level and time-stamp units of messages logged by modules and facilities.

Procedure

	Command or Action	Purpose

Step 1	**configure terminal**
	Example:
	`switch# configure terminal`
	`switch(config)#`
		Enters global configuration mode.

Step 2	[**no**] **logging module** [*severity-level*] **Example:** `switch(config)# logging module 3`	Enables module log messages that have the specified severity level or higher. Severity levels range from 0 to 7: • 0 – emergency • 1 – alert • 2 – critical • 3 – error • 4 – warning • 5 – notification • 6 – informational • 7 – debugging If the severity level is not specified, the default of 5 is used. The **no** option disables module log messages.
Step 3	(Optional) **show logging module** **Example:** `switch(config)# show logging module`	Displays the module logging configuration.
Step 4	[**no**] **logging level** *facility severity-level* **Example:** `switch(config)# logging level aaa 2`	Enables logging messages from the specified facility that have the specified severity level or higher. Severity levels range from 0 to 7: • 0 – emergency

	Command or Action	Purpose
		• 1 – alert • 2 – critical • 3 – error • 4 – warning • 5 – notification • 6 – informational • 7 – debugging To apply the same severity level to all facilities, use the **all** facility. For defaults, see the **show logging level** command. The **no** option resets the logging severity level for the specified facility to its default level. If you do not specify a facility and severity level, the device resets all facilities to their default levels.
Step 5	(Optional) **show logging level** [*facility*] **Example:** `switch(config)# show logging level aaa`	Displays the logging level configuration and the system default level by facility. If you do not specify a facility, the device displays levels for all facilities.
Step 6	(Optional) [**no**] **logging level** *ethpm* **Example:** **switch(config)# logging level ethpm ?** <0-7> 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug link-down Configure logging level for link down syslog messages link-up Configure logging level for link up syslog messages **switch(config)#logging level ethpm link-down ?** error ERRORS notif NOTICE **(config)# logging level ethpm link-down error ?** <CR> **(config)# logging level ethpm link-down notif ?** <CR>	Enables logging of the Ethernet Port Manager link-up/link-down syslog messages at level 3. Use the **no** option to use the default logging level for Ethernet Port Manager syslog messages.

	Command or Action	Purpose
	switch(config)#logging level ethpm link-up ? error ERRORS notif NOTICE **(config)# logging level ethpm link-up error ?** <CR> **(config)# logging level ethpm link-up notif ?** <CR>	
Step 7	[**no**] **logging timestamp** {**microseconds** | **milliseconds** | **seconds**} **Example:** `switch(config)# logging timestamp milliseconds`	Sets the logging time-stamp units. By default, the units are seconds. **Note** This command applies to logs that are kept in the switch. It does not apply to the external logging server.
Step 8	(Optional) **show logging timestamp** **Example:** `switch(config)# show logging timestamp`	Displays the logging time-stamp units configured.
Step 9	(Optional) **copy running-config startup-config** **Example:** `switch(config)# copy running-config startup-config`	Copies the running configuration to the startup configuration.

Configuring Logging Syslogs Compliant to RFC 5424

The command can be modified in the following ways :

- [*no*] **logging rfc-strict 5424**
- **show logging rfc-strict 5424**

Procedure

	Command or Action	Purpose
Step 1	`switch(config)#`[*no*] logging rfc-strict 5424	(optional) Negate a command or set its defaults
Step 2	`switch(config)#` **logging rfc-strict 5424**	Modify message logging facilities and set RFC to which messages should be compliant.
Step 3	`switch(config)#`show logging rfc-strict 5424	Displays the syslogs which will be compliant to RFC 5424

Configuring Syslog Servers

Note Cisco recommends that you configure the syslog server to use the management virtual routing and forwarding (VRF) instance. For more information on VRFs, see Cisco Nexus 9000 Series NX-OS Unicast Routing Configuration Guide.

You can configure up to eight syslog servers that reference remote systems where you want to log system messages.

Procedure

	Command or Action	Purpose

Step 1	**configure terminal**
	Example:
	`switch# configure terminal`
	`switch(config)#`
		Enters global configuration mode.

Step 2	[**no**] **logging server** *host* [*severity-level* [**use-vrf** *vrf-name*]]
	Example:
	`switch(config)# logging server 192.0.2.253`
	Example:
	`switch(config)# logging server 2001::35 use-vrf red`
		Configures a syslog server at the specified hostname, IPv4, or IPv6 address. You can specify logging of messages to a particular syslog server in a VRF by using the **use-vrf** keyword. The **use-vrf** *vrf-name* keyword identifies the default or management values for the VRF name. The default VRF is the management VRF, by default. However, the **show-running** command will not list the default VRF. Severity levels range from 0 to 7:
		• 0 – emergency
		• 1 – alert
		• 2 – critical
		• 3 – error
		• 4 – warning
		• 5 – notification
		• 6 – informational
		• 7 – debugging
		The default outgoing facility is local7.
		The **no** option removes the logging server for the specified host.
		The first example forwards all messages on facility local 7. The second example forwards

	Command or Action	Purpose
		messages with severity level 5 or lower to the specified IPv6 address in VRF red.
Step 3	Required: **logging source-interface loopback** *virtual-interface* **Example:** `switch(config)# logging source-interface loopback 5`	Enables a source interface for the remote syslog server. The range for the *virtual-interface* argument is from 0 to 1023.
Step 4	(Optional) **show logging server** **Example:** `switch(config)# show logging server`	Displays the syslog server configuration.
Step 5	(Optional) **copy running-config startup-config** **Example:** `switch(config)# copy running-config startup-config`	Copies the running configuration to the startup configuration.

Configuring Secure Syslog Servers

Procedure

	Command or Action	Purpose

Step 1	**configure terminal**
	Example:
	`switch# configure terminal`
	`switch(config)#`
		Enters global configuration mode.

Step 2	[**no**] **logging server** *host* [*severity-level* [**port** *port-number*][**secure**[**trustpoint client-identity** *trustpoint-name*]][**use-vrf** *vrf-name*]]
	Example:
	`switch(config)# logging server 192.0.2.253 secure`
	Example:
	`switch(config)# logging server 2001::35 secure trustpoint client-identity myCA use-vrf red`
		Configures a syslog server at the specified hostname or IPv4 or IPv6 address. Optionally, you can enforce a mutual authentication by installing the client identity certificate that is signed by any CA and using the trustpoint client-identity option.
		The default destination port for a secure TLS connection is 6514.

Step 3	(Optional) **logging source-interface** *interface name* **Example:** `switch(config)# logging source-interface lo0`	Enables a source interface for the remote syslog server.

	Command or Action	Purpose
Step 4	(Optional) **show logging server** **Example:** `switch(config)# show logging server`	Displays the syslog server configuration. If the secure option is configured, the output will have an entry with the transport information. By default, the transport is UDP if the secure option is not configured.
Step 5	(Optional) **copy running-config startup-config** **Example:** `switch(config)# copy running-config startup-config`	Copies the running configuration to the startup configuration.

Configuring the CA Certificate

For the secure syslog feature support, the remote servers must be authenticated via a trustpoint configuration.

Procedure

	Command or Action	Purpose

Step 1	**configure terminal**
	Example:
	`switch# configure terminal`
	`switch(config)#`
		Enters global configuration mode.

Step 2	[**no**] **crypto ca trustpoint** *trustpoint-name*
	Example:
	`switch(config)# crypto ca trustpoint winca`
	`switch(config-trustpoint)#`
		Configures a trustpoint.
		Note
		You must configure the ip domain-name before the trustpoint configuration.

Step 3	Required: **crypto ca authenticate** *trustpoint-name* **Example:** `switch(config-trustpoint)# crypto ca authenticate winca`	Configures a CA certificate for the trustpoint.
Step 4	(Optional) **show crypto ca certificate** **Example:** `switch(config)# show crypto ca certificates`	Displays the configured certificate/chain and the associated trustpoint.
Step 5	(Optional) **copy running-config startup-config** **Example:** `switch(config)# copy running-config startup-config`	Copies the running configuration to the startup configuration so that the trustpoint is persistent across the reload of the device.

Enrolling the CA Certificate

For mutual authentication, where the remote server wants the NX-OS switch (the client) to identify, that the peer authentication is mandatory, this is an additional configuration to enroll the certificate on the switch.

Procedure

	Command or Action	Purpose

Step 1	**configure terminal**
	Example:
	`switch# configure terminal`
	`switch(config)#`
		Enters global configuration mode.

Step 2	Required: **crypto key generate rsa label** *key name* **exportable modules 2048** **Example:** `switch(config-trustpoint)# crypto key generate rsa label myKey exportable modulus 2048`	Configure an RSA key pair. By default, the Cisco NX-OS software generates an RSA key using 1024 bits.

Step 3	[**no**] **crypto ca trustpoint** *trustpoint-name*
	Example:
	`switch(config)# crypto ca trustpoint myCA`
	`switch(config-trustpoint)#`
		Configures a trustpoint.
		Note
		You must configure the ip domain-name before the trustpoint configuration.

Step 4	Required: **rsakeypair** *key-name* **Example:** `switch(config-trustpoint)# rsakeypair myKey`	Associates the keypair generated to the trustpoint CA.
Step 5	**crypto ca trustpoint** *trustpoint-name* **Example:** `switch(config)# crypto ca authenticate myCA`	Configures a CA certificate for the trustpoint.
Step 6	[**no**] **crypto ca enroll** *trustpoint-name* **Example:** `switch(config)# crypto ca enroll myCA`	Generate an identity certificate of the switch to enroll it to a CA.
Step 7	**crypto ca import** *trustpoint-name* **certificate** **Example:** `switch(config-trustpoint)# crypto ca import myCA certificate`	Imports the identity certificate signed by the CA to the switch.
Step 8	(Optional) **show crypto ca certificates** **Example:** `switch# show crypto ca certificates`	Displays the configured certificate or chain and the associated trustpoint.

	Command or Action	Purpose
Step 9	Required: **copy running-config startup-config** **Example:** `switch# copy running-config startup-config`	Copies the running configuration to the startup configuration.

Configuring Syslog Servers on a UNIX or Linux System

You can configure a syslog server on a UNIX or Linux system by adding the following line to the /etc/syslog.conf file:

facility.level <five tab characters> *action*

The following table describes the syslog fields that you can configure.

Table 3: Syslog fields in syslog.conf

Field	Description
Facility	Creator of the message, which can be auth, authpriv, cron, daemon, kern, lpr, mail, mark, news, syslog, user, local0 through local7, or an asterisk (*) for all. These facility designators allow you to control the destination of messages based on their origin. **Note** Check your configuration before using a local facility.
Level	Minimum severity level at which messages are logged, which can be debug, info, notice, warning, err, crit, alert, emerg, or an asterisk (*) for all. You can use none to disable a facility.
Action	Destination for messages, which can be a filename, a hostname preceded by the at sign (@), a comma-separated list of users, or an asterisk (*) for all logged-in users.

Procedure

Step 1 Log debug messages with the local7 facility in the file /var/log/myfile.log by adding the following line to the /etc/syslog.conf file:

Example:

```
debug.local7 var/log/myfile.log
```

Step 2 Create the log file by entering these commands at the shell prompt:

Example:

```
$ touch /var/log/myfile.log
$ chmod 666 /var/log/myfile.log
```

Step 3 Make sure the system message logging daemon reads the new changes by checking myfile.log after entering this command:

Example:

```
$ kill -HUP ~cat /etc/syslog.pid~
```

Displaying and Clearing Log Files

You can display or clear messages in the log file and the NVRAM.

Procedure

	Command or Action	Purpose
Step 1	Required: **show logging last** *number-lines* **Example:** `switch# show logging last 40`	Displays the last number of lines in the logging file. You can specify from 1 to 9999 for the last number of lines.
Step 2	**show logging logfile duration** *hh:mm:ss* **Example:** `switch# show logging logfile duration 15:10:0`	Displays the messages in the log file that have occurred within the duration entered.
Step 3	**show logging logfile last-index** **Example:** `switch# show logging logfile last-index`	Displays the sequence number of the last message in the log file.
Step 4	**show logging logfile** [**start-time** *yyyy mmm dd hh:mm:ss*] [**end-time** *yyyy mmm dd hh:mm:ss*] **Example:** `switch# show logging logfile start-time 2013 oct 1 15:10:0`	Displays the messages in the log file that have a timestamp within the span entered. If you do not enter an end time, the current time is used. You enter three characters for the month time field and digits for the year and day time fields.
Step 5	**show logging logfile** [**start-seqn** *number*] [**end-seqn** *number*] **Example:** `switch# show logging logfile start-seqn 100 end-seqn 400`	Displays messages occurring within a range of sequence numbers. If you do not include an end sequence number, the system displays messages from the start number to the last message in the log file.
Step 6	**show logging nvram** [**last** *number-lines*] **Example:**	Displays the messages in the NVRAM. To limit the number of lines displayed, you can enter the

	Command or Action	Purpose
	`switch# show logging nvram last 10`	last number of lines to display. You can specify from 1 to 100 for the last number of lines.
Step 7	**clear logging logfile** [**persistent**] **Example:** `switch# clear logging logfile`	Clears the contents of the log file. **persistent**: Clears the contents of the log file from the persistent location.
Step 8	**clear logging nvram** **Example:** `switch# clear logging nvram`	Clears the logged messages in NVRAM.

Verifying the System Message Logging Configuration

To display system message logging configuration information, perform one of the following tasks:

Command	Purpose
show logging console	Displays the console logging configuration.
show logging info	Displays the logging configuration.
show logging last *number-lines*	Displays the last number of lines of the log file.
show logging level [*facility*]	Displays the facility logging severity level configuration.
show logging logfile duration *hh:mm:ss*	Displays the messages in the log file that have occurred within the duration entered.
show logging logfile last-index	Displays the sequence number of the last message in the log file.
show logging logfile [**start-time** *yyyy mmm dd hh:mm:ss*] [**end-time** *yyyy mmm dd hh:mm:ss*]	Displays the messages in the log file based on a start and end date/time.
show logging logfile [**start-seqn** *number*] [**end-seqn** *number*]	Displays messages occurring within a range of sequence numbers. If you do not include an end sequence number, the system displays messages from the start number to the last message in the log file.
show logging module	Displays the module logging configuration.
show logging monitor	Displays the monitor logging configuration.
show logging nvram [**last** *number-lines*]	Displays the messages in the NVRAM log.
show logging server	Displays the syslog server configuration.
show logging timestamp	Displays the logging time-stamp units configuration.

Repeated System Logging Messages

System processes generate logging messages. Depending on the filters used to control which severity levels are generated, a large number of messages can be produced with many of them being repeated.

To make it easier to develop scripts to manage the volume of logging messages, and to eliminate repeated messages from "flooding" the output of the **show logging log** command, the following method of logging repeated messages is used.

In the old method, when the same message was repeated, the default was to state the number of times it reoccurred in the message:

```
2019 Mar 11 13:42:44 Cisco-customer %PTP-2-PTP_INCORRECT_PACKET_ON_SLAVE:
Incorrect delay response packet received on slave interface Eth1/48 by
2c:5a:0f:ff:fe:51:e9:9f. Source Port Identity is 08:00:11:ff:fe:22:3e:4e. Requesting Port
Identity is 00:1c:73:ff:ff:ee:f6:e5
2019 Mar 11 13:43:15 Cisco-customer last message repeated 242 times
```

The new method simply appends the repeat count to the end of the repeated message:

```
2019 Mar 11 13:42:44 Cisco-customer %PTP-2-PTP_INCORRECT_PACKET_ON_SLAVE:
Incorrect delay response packet received on slave interface Eth1/48 by
2c:5a:0f:ff:fe:51:e9:9f. Source Port Identity is 08:00:11:ff:fe:22:3e:4e. Requesting Port
Identity is 00:1c:73:ff:ff:ee:f6:e5

2019 Mar 11 13:43:15 Cisco-customer %PTP-2-PTP_INCORRECT_PACKET_ON_SLAVE:
Incorrect delay response packet received on slave interface Eth1/48 by
2c:5a:0f:ff:fe:51:e9:9f. Source Port Identity is 08:00:11:ff:fe:22:3e:4e. Requesting Port
Identity is 00:1c:73:ff:ff:ee:f6:e5 (message repeated 242 times)
```

Configuration Example for System Message Logging

This example shows how to configure system message logging:

```
configure terminal
 logging console 3
 logging monitor 3
 logging logfile my_log 6
 logging module 3
 logging level aaa 2
 logging timestamp milliseconds
 logging server 172.28.254.253
 logging server 172.28.254.254 5 facility local3
 copy running-config startup-config
```

Additional References

Related Documents

Related Topic	Document Title
System messages	*Cisco NX-OS System Messages Reference*