



F Show Commands

- [show fabric-binding database, on page 6](#)
- [show fabric-binding efmd statistics, on page 7](#)
- [show fabric-binding fip, on page 8](#)
- [show fabric-binding statistics, on page 9](#)
- [show fabric-binding status, on page 10](#)
- [show fabric-binding violations, on page 11](#)
- [show fabric database dci, on page 12](#)
- [show fabric database host, on page 14](#)
- [show fabric database host statistics, on page 18](#)
- [show fabric database host summary, on page 21](#)
- [show fabric database profile-map, on page 22](#)
- [show fabric database static-host, on page 23](#)
- [show fabric database statistics, on page 24](#)
- [show fabric forwarding host-db, on page 26](#)
- [show fabric forwarding ip local, on page 28](#)
- [show fabric forwarding ipv6 local, on page 29](#)
- [show fabric multicast globals, on page 30](#)
- [show fabric multicast ipv4 l2 vni, on page 32](#)
- [show fabric multicast statistics, on page 33](#)
- [show fabric multicast vrf, on page 35](#)
- [show fabric switch information, on page 36](#)
- [show fc2 bind, on page 37](#)
- [show fc2 classf, on page 38](#)
- [show fc2 exchange, on page 40](#)
- [show fc2 exchresp, on page 42](#)
- [show fc2 flogi, on page 44](#)
- [show fc2 nport, on page 45](#)
- [show fc2 plogi, on page 47](#)
- [show fc2 plogi_pwwn, on page 49](#)
- [show fc2 port brief, on page 50](#)
- [show fc2 port drops, on page 53](#)
- [show fc2 port state, on page 56](#)
- [show fc2 socket, on page 58](#)

- [show fc2 sockexch](#), on page 59
- [show fc2 socknotify](#), on page 60
- [show fc2 socknport](#), on page 61
- [show fc2 vsan](#), on page 62
- [show fcalias](#), on page 63
- [show fcdomain](#), on page 64
- [show fcdomain address-allocation](#), on page 65
- [show fcdomain allowed](#), on page 66
- [show fcdomain domain-list](#), on page 67
- [show fcdomain fcid persistent](#), on page 68
- [show fcdomain pending-diff](#), on page 69
- [show fcdomain pending](#), on page 70
- [show fcdomain session-status](#), on page 71
- [show fcdomain statistics](#), on page 72
- [show fcdomain status](#), on page 73
- [show fcdomain vsan](#), on page 74
- [show fdroplatency](#), on page 75
- [show fcid-allocation area](#), on page 76
- [show fcid-allocation company-id-from-wwn](#), on page 77
- [show fcns database](#), on page 78
- [show fcns statistics](#), on page 80
- [show fcoe-npv issu-impact](#), on page 81
- [show fcoe](#), on page 82
- [show fcoe database](#), on page 83
- [show fcs database](#), on page 84
- [show fcs ie](#), on page 85
- [show fcs platform](#), on page 86
- [show fcs port](#), on page 87
- [show fcs statistics](#), on page 88
- [show fcs vsan](#), on page 89
- [show fctimer](#), on page 90
- [show fctimer D_S_TOV](#), on page 91
- [show fctimer E_D_TOV](#), on page 92
- [show fctimer F_S_TOV](#), on page 93
- [show fctimer R_A_TOV](#), on page 94
- [show fctimer last action status](#), on page 95
- [show fctimer pending-diff](#), on page 96
- [show fctimer pending](#), on page 97
- [show fctimer session status](#), on page 98
- [show fctimer status](#), on page 99
- [show fctimer vsan](#), on page 100
- [show fdmi database](#), on page 101
- [show fdmi database detail](#), on page 102
- [show fdmi database detail hba-id vsan](#), on page 103
- [show fdmi database detail vsan](#), on page 104
- [show fdmi database vsan](#), on page 105

- show fdmi suppress-updates, on page 106
- show feature-set, on page 107
- show feature-set services, on page 108
- show feature, on page 109
- show fex interface priority-flow-control, on page 110
- show fhrp, on page 111
- show fhrp verbose, on page 112
- show file, on page 114
- show fips status, on page 115
- show flogi auto-area-list, on page 116
- show flogi database, on page 117
- show flow cache, on page 118
- show flow cache, on page 120
- show flow event, on page 122
- show flow exporter, on page 124
- show flow filter, on page 126
- show flow interface, on page 127
- show flow monitor, on page 128
- show flow profile, on page 129
- show flow record, on page 131
- show flow rtp, on page 134
- show flow rtp timeout, on page 136
- show flow system, on page 137
- show flow timeout, on page 139
- show flow tracer, on page 140
- show flow vrf, on page 141
- show forwarding, on page 142
- show forwarding adjacency, on page 143
- show forwarding consistency-fretta l2, on page 146
- show forwarding distribution clients, on page 147
- show forwarding distribution evpn storm-control, on page 148
- show forwarding distribution fib-state, on page 149
- show forwarding distribution ip igmp snooping, on page 150
- show forwarding distribution ipv6 multicast route, on page 151
- show forwarding distribution l2 multicast, on page 153
- show forwarding distribution lisp counters, on page 156
- show forwarding distribution lisp vrf enabled, on page 157
- show forwarding distribution multicast, on page 158
- show forwarding distribution multicast client-ack-db, on page 159
- show forwarding distribution multicast client, on page 160
- show forwarding distribution multicast download, on page 161
- show forwarding distribution multicast mfib, on page 162
- show forwarding distribution multicast outgoing-interface-list L2_PRIME, on page 163
- show forwarding distribution multicast resp-ack-timer-msgs, on page 164
- show forwarding distribution multicast route, on page 165
- show forwarding distribution multicast route sr um-nat, on page 168

- [show forwarding distribution multicast sr hash-db](#), on page 169
- [show forwarding distribution multicast vxlan dsg-db](#), on page 170
- [show forwarding distribution multicast vxlan vlan-db](#), on page 171
- [show forwarding distribution nve overlay-vlan](#), on page 172
- [show forwarding distribution peer-id](#), on page 173
- [show forwarding distribution srv6 local-sid bd-mapping](#), on page 174
- [show forwarding distribution trace](#), on page 175
- [show forwarding ecmp](#), on page 176
- [show forwarding ecmp recursive](#), on page 178
- [show forwarding inconsistency](#), on page 183
- [show forwarding interfaces](#), on page 185
- [show forwarding ipv6](#), on page 186
- [show forwarding ipv6 adjacency](#), on page 189
- [show forwarding ipv6 inconsistency](#), on page 191
- [show forwarding ipv6 multicast route](#), on page 193
- [show forwarding kvfib cache on](#), on page 196
- [show forwarding l2 multicast](#), on page 197
- [show forwarding l2vpn label vpls](#), on page 199
- [show forwarding l2vpn label xconnect](#), on page 200
- [show forwarding l2vpn vlan](#), on page 201
- [show forwarding mpls](#), on page 202
- [show forwarding mpls drop-stats](#), on page 204
- [show forwarding mpls ecmp](#), on page 205
- [show forwarding mpls eompls](#), on page 207
- [show forwarding mpls eompls ir](#), on page 208
- [show forwarding mpls option_b](#), on page 210
- [show forwarding mpls srte module](#), on page 211
- [show forwarding mpls summary](#), on page 212
- [show forwarding multicast-sr loopback interface](#), on page 213
- [show forwarding multicast-sr mac-trap-db](#), on page 214
- [show forwarding multicast outgoing-interface-list](#), on page 215
- [show forwarding multicast pvlan replicated-routes](#), on page 217
- [show forwarding multicast route](#), on page 218
- [show forwarding nve l2 ingress-replication-peers](#), on page 221
- [show forwarding nve l3 adjacency tunnel](#), on page 224
- [show forwarding nve l3 adjacency v6-tunnel](#), on page 226
- [show forwarding nve l3 ecmp](#), on page 228
- [show forwarding nve l3 peers](#), on page 229
- [show forwarding nve underlay-interfaces](#), on page 230
- [show forwarding otv](#), on page 231
- [show forwarding otv ipv6 multicast route](#), on page 232
- [show forwarding otv multicast outgoing-interface-list](#), on page 235
- [show forwarding otv multicast route](#), on page 236
- [show forwarding otv vlan](#), on page 237
- [show forwarding proactive-cc inconsistencies](#), on page 238
- [show forwarding security group-tag](#), on page 240

- show forwarding security mac, on page 242
- show forwarding srv6 adjacency decap, on page 244
- show forwarding srv6 adjacency encap, on page 245
- show forwarding srv6 bsid-peer, on page 246
- show forwarding srv6 bsid, on page 247
- show forwarding srv6 ecmp, on page 248
- show forwarding srv6 local-sid, on page 249
- show forwarding srv6 peers, on page 250
- show forwarding trace, on page 251
- show forwarding trace profile, on page 252
- show forwarding trace profile funcstats, on page 253
- show frequency synchronization clock-interface brief, on page 254
- show frequency synchronization clock-interface detail, on page 256
- show frequency synchronization configuration errors, on page 259
- show frequency synchronization interface, on page 261
- show frequency synchronization interface brief, on page 264
- show frequency synchronization selection, on page 266
- show fspf, on page 268
- show fspf database, on page 269
- show fspf interface, on page 270
- show fspf vsan, on page 271
- show fspf vsan interface, on page 272
- show fte event, on page 273
- show fte exporter, on page 274
- show fte monitor, on page 275
- show fte record, on page 276

show fabric-binding database

show fabric-binding database

show fabric-binding database [{ active [vsan <i0>] | vsan1 <i1> }]

Syntax Description

show	Show running system information
fabric-binding	Show Fabric Binding
database	Show Fabric Binding Configured database
active	(Optional) Activated Fabric Bindings
vsan	(Optional) VSAN id
<i>i0</i>	(Optional) VSAN range
vsan1	(Optional) VSAN id
<i>i1</i>	(Optional) VSAN range

Command Mode

- /exec

show fabric-binding efmd statistics

show fabric-binding efmd statistics [vsan <i0>]

Syntax Description

show	Show running system information
fabric-binding	Show Fabric Binding
efmd	Exchange Fabric Membership Data
statistics	EFMD protocol statistics
vsan	(Optional) VSAN id
<i>i0</i>	(Optional) VSAN range

Command Mode

- /exec

show fabric-binding fip

show fabric-binding fip

show fabric-binding fip

Syntax Description

show	Show running system information
fabric-binding	Fabric Binding configuration
fip	Display the enabled FIP

Command Mode

- /exec

show fabric-binding statistics

show fabric-binding statistics [vsan <i0>]

Syntax Description

show	Show running system information
fabric-binding	Show Fabric Binding
statistics	Statistics of Fabric Binding
vsan	(Optional) VSAN Id
<i>i0</i>	(Optional) VSAN range

Command Mode

- /exec

show fabric-binding status

show fabric-binding status

show fabric-binding status [vsan <i0>]

Syntax Description

show	Show running system information
fabric-binding	Show Fabric Binding
status	Fabric binding Status
vsan	(Optional) VSAN Id
<i>i0</i>	(Optional) VSAN range

Command Mode

- /exec

show fabric-binding violations

show fabric-binding violations [last <i0>]

Syntax Description

show	Show running system information
fabric-binding	Show Fabric Binding
violations	Violations of Fabric Binding policies
last	(Optional) Latest n violations
<i>i0</i>	(Optional) Violation number

Command Mode

- /exec

show fabric database dci

show fabric database dci

```
show fabric database dci [ { vrf { <vrf-name> | <vrf-known-name> } [ peer-id <peer-ip-address> ] [ detail ] } ] [ __readonly__ [ TABLE_database_dci <vrf_name><state><flags><profile><instance> ] [ TABLE_database_dci_detail <packet_arrival_time><sent_to_database_manager_at><received_parameters_from_database_manager_at><sent_apply_to_configuration_manager_at><completed_executing_all_commands_at><sent_un_apply_to_configuration_manager_at><completed_unapplying_all_commands_at> ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Fabric Database
dci	DCI Profile Database
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
peer-id	(Optional) management ip address of peer
<i>peer-ip-address</i>	(Optional) IP address in CIDR format
detail	(Optional) Show detailed information
<u>__readonly__</u>	(Optional) Read Only
TABLE_database_dci	(Optional) table show fabric database dci
<i>vrf_name</i>	(Optional)
<i>state</i>	(Optional)
<i>flags</i>	(Optional)
<i>profile</i>	(Optional)
<i>instance</i>	(Optional)
TABLE_database_dci_detail	(Optional) detail for table show fabric database dci
<i>packet_arrival_time</i>	(Optional) Profile request time
<i>sent_to_database_manager_at</i>	(Optional) Profile request sent to DCNM
<i>received_parameters_from_database_manager_at</i>	(Optional) Profile downloaded from DCNM
<i>sent_apply_to_configuration_manager_at</i>	(Optional) Profile sent to PPM to apply

<i>completed_executing_all_commands_at</i>	(Optional) Profile applied by PPM
<i>sent_un_apply_to_configuration_manager_at</i>	(Optional) Profile un-apply sent to PPM
<i>completed_unapplying_all_commands_at</i>	(Optional) Profile un-applied by PPM

Command Mode

- /exec

show fabric database host

show fabric database host

```
show fabric database host [ detail ] [ { vni <vni-id> } | { dot1q <vlan-id> } ] [ __readonly__ [
    TABLE_database_host [ <trigger_source> ] [ <client_type> ] [ <got_trigger_at> ] [ <number_of_client_hosts>
    ] [ <number_of_associated_interfaces> ] [ <profile_be_un_applied_in_seconds> ] [
        <new_vdp_requests_be_accepted_in_seconds> ] [ <recovered_profile_be_checked_for_validity_in_seconds>
        ] [ <mac_aging_checked_in_seconds> ] [ <sent_to_database_manager_at> ] [
            <received_parameters_from_database_manager_at> ] [ <displaying_parameters_for_profile> ] [
                <displaying_parameters_for_instance> ] [ <no_parameters_for_the_profile> ] [
                    <displaying_re_written_parameters_for_vpc_role> ] [ TABLE_parameter [ <parameter_index> ] [ <parameter>
                    ] ] [ TABLE_static_profile <profile><instance><no_parameters_for_the_profile> ] [ TABLE_migrated_profile
                    <profile><instance_index><previous_profile><previous_instance_index> ] [ TABLE_rollback_profile
                    <profile><instance_index> ] [ <got_vlan_allocated_from_vlan_manager_at> ] [
                        <sent_apply_to_configuration_manager_at> ] [ <completed_executing_all_commands_at> ] [
                            <sent_to_vpc_peer_at> ] [ <completed_executing_all_commands_on_vpc_peer_at> ] [
                                <sent_un_apply_to_configuration_manager_at> ] [ <completed_unapplying_all_commands_at> ] [
                                    TABLE_database_host_vni { [ <vni_id> ] [ <vlan_id> ] [ <state> <flag> <profile_name> <instance_name>
                                    ] [ <packet_arrival_time> <request_profile_time> <got_profile_time> <sent_to_PPM_time>
                                    <profile_apply_time> <del_to_PPM_time> ] [ { TABLE_database_host_detail <interface> <encap> <flags>
                                    <state> [ <vsi_id> ] [ <client> ] [ <host> ] } ] } [ TABLE_database_host_vlan { [ <vlan_id> ] [ <vni_id> ]
                                    ] [ <state> <flag> <profile_name> <instance_name> ] [ <packet_arrival_time> <request_profile_time>
                                    <got_profile_time> <sent_to_PPM_time> <profile_apply_time> <del_to_PPM_time> ] [ {
                                        TABLE_database_host_detail <interface> <encap> <flags> <state> [ <vsi_id> ] } ] } [
                                        TABLE_extranet_vrf_entries { <vrf> <l3_vni> <state> <profile> <instance> } ] ]]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Fabric Database
host	Host to profile mapping
detail	(Optional) Show hosts and interfaces
vni	(Optional) Virtual Network Identifier
<i>vni-id</i>	(Optional)
dot1q	(Optional) Dot1Q Encapsulation
<i>vlan-id</i>	(Optional)
__readonly__	(Optional) Read Only
TABLE_database_host	(Optional) table show fabric database host {dot1q vni}
<i>trigger_source</i>	(Optional) TODO
<i>client_type</i>	(Optional) TODO

<i>got_trigger_at</i>	(Optional) TODO
<i>number_of_client_hosts</i>	(Optional) TODO
<i>number_of_associated_interfaces</i>	(Optional) TODO
<i>profile_be_un_applied_in_seconds</i>	(Optional) TODO
<i>new_vdp_requests_be_accepted_in_seconds</i>	(Optional) TODO
<i>recovered_profile_be_checked_for_validity_in_seconds</i>	(Optional) TODO
<i>mac_agging_checked_in_seconds</i>	(Optional) TODO
<i>sent_to_database_manager_at</i>	(Optional) TODO
<i>received_parameters_from_database_manager_at</i>	(Optional) TODO
<i>displaying_parameters_for_profile</i>	(Optional) TODO
<i>displaying_parameters_for_instance</i>	(Optional) TODO
<i>no_parameters_for_the_profile</i>	(Optional) TODO
<i>displaying_re_written_parameters_for_ypc_role</i>	(Optional) TODO
<i>TABLE_parameter</i>	(Optional) table show the parameters
<i>parameter_index</i>	(Optional) TODO
<i>parameter</i>	(Optional) TODO
<i>TABLE_static_profile</i>	(Optional) show static profile
<i>profile</i>	(Optional) TODO
<i>instance</i>	(Optional) TODO
<i>no_parameters_for_the_profile</i>	(Optional) TODO
<i>TABLE_migrated_profile</i>	(Optional) show migrated profile
<i>profile</i>	(Optional) TODO
<i>instance_index</i>	(Optional) TODO
<i>previous_profile</i>	(Optional) TODO
<i>previous_instance_index</i>	(Optional) TODO
<i>TABLE_rollback_profile</i>	(Optional) show rollback profile
<i>profile</i>	(Optional) TODO
<i>instance_index</i>	(Optional) TODO
<i>got_vlan_allocated_from_vlan_manager_at</i>	(Optional) TODO

show fabric database host

<i>sent_apply_to_configuration_manager_at</i>	(Optional) TODO
<i>completed_executing_all_commands_at</i>	(Optional) TODO
<i>sent_to_vpc_peer_at</i>	(Optional) TODO
<i>completed_executing_all_commands_on_vpc_peer_at</i>	(Optional) TODO
<i>sent_unapply_to_configuration_manager_at</i>	(Optional) TODO
<i>completed_unapplying_all_commands_at</i>	(Optional) TODO
TABLE_database_host_vni	(Optional) table show fabric database host vni based
<i>vni_id</i>	(Optional) TODO Add comment
<i>vlan_id</i>	(Optional) TODO Add comment
<i>state</i>	(Optional) TODO Add comment
<i>flag</i>	(Optional) TODO
<i>profile_name</i>	(Optional) TODO
<i>instance_name</i>	(Optional) TODO
<i>packet_arrival_time</i>	(Optional) TODO
<i>request_profile_time</i>	(Optional) TODO
<i>got_profile_time</i>	(Optional) TODO
<i>sent_to_PPM_time</i>	(Optional) TODO
<i>profile_apply_time</i>	(Optional) TODO
<i>del_to_PPM_time</i>	(Optional) TODO
TABLE_database_host_detail	(Optional) table show fabric database host detail
<i>interface</i>	(Optional) TODO
<i>encap</i>	(Optional) TODO
<i>flags</i>	(Optional) TODO
<i>state</i>	(Optional) TODO
<i>vsi_id</i>	(Optional) TODO
<i>client</i>	(Optional) TODO
<i>host</i>	(Optional) TODO
TABLE_database_host_vlan	(Optional) table show fabric database host vlan based
<i>vlan_id</i>	(Optional) TODO Add comment

<i>vni_id</i>	(Optional) TODO Add comment
<i>state</i>	(Optional) TODO Add comment
<i>flag</i>	(Optional) TODO
<i>profile_name</i>	(Optional) TODO
<i>instance_name</i>	(Optional) TODO
<i>packet_arrival_time</i>	(Optional) TODO
<i>request_profile_time</i>	(Optional) TODO
<i>got_profile_time</i>	(Optional) TODO
<i>sent_to_PPM_time</i>	(Optional) TODO
<i>profile_apply_time</i>	(Optional) TODO
<i>del_to_PPM_time</i>	(Optional) TODO
TABLE_database_host_detail	(Optional) table show fabric database host detail
<i>interface</i>	(Optional) TODO
<i>encap</i>	(Optional) TODO
<i>flags</i>	(Optional) TODO
<i>state</i>	(Optional) TODO
<i>vsi_id</i>	(Optional) TODO
TABLE_extranet_vrf_entries	(Optional) table extranet VRF entries
<i>vrf</i>	(Optional) TODO
<i>l3_vni</i>	(Optional) TODO
<i>state</i>	(Optional) TODO
<i>profile</i>	(Optional) TODO
<i>instance</i>	(Optional) TODO

Command Mode

- /exec

show fabric database host statistics

show fabric database host statistics

```
show fabric database host statistics [ __readonly__ [ TABLE_database_host_statistics { [ <data_snoop_triggers>
] [ <data_snoop_deletes> ] [ <data_snoop_responses> ] [ <vdp_association_requests> ] [
<vdp_deassociation_requests> ] [ <vdp_association_responses> ] [ <vdp_error_responses> ] [
<unsupported_interfaces> ] [ <no_profile_map_errors> ] [ <outstanding_delete_retry_add> ] [
<duplicate_add_existing_host> ] [ <hmm_api_error_cannot_add_host> ] [ <existing_profile_new_host> ] [
<profile_apply_from_vpc_peer> ] [ <profile_un_apply_from_vpc_peer> ] [ <host_apply_from_vpc_peer> ] [
<host_un_apply_from_vpc_peer> ] [ <early_delete_cancel_add> ] [ <dhcp_requests> ] [ <dhcp_responses> ] [
<dhcp_error_responses> ] [ <adbm_requests> ] [ <adbm_responses> ] [ <adbm_error_responses> ] [
<adbm_error_requests> ] [ <adbm_db_notifications> ] [ <vnseg_no_bridge_domain> ] [
<vnseg_encap_responses> ] [ <vnseg_vni_responses> ] [ <vnseg_unknown_responses> ] [
<vnseg_bd_down_notif> ] [ <bd_mgr_requests> ] [ <bd_mgr_success_responses> ] [
<bd_mgr_failure_responses> ] [ <bd_mgr_unreserve> ] [ <bd_mgr_inconsistencies> ] [ <no_mac_on_bd_notif> ] [
<refresh_failures> ] [ <profile_apply_received> ] [ <profile_vpc_queued> ] [ <profile_local_apply_queued> ] [
<profile_local_unapply_queued> ] [ <profile_apply_sent> ] [ <profile_apply_responses> ] [
<profile_apply_success> ] [ <profile_unapply_success> ] [ <profile_apply_failure> ] [ <profile_commands> ] [
<profile_error_incomplete_configs> ] [ <profile_api_error> ] [ <profile_unapply_sent> ] [
<profile_top_queue_adds> ] [ <profile_high_queue_adds> ] [ <profile_low_queue_adds> ] [
<profile_unapply_failure> ] [ <outstanding_vlan_requests> ] [ <outstanding_adbm_requests> ] [
<outstanding_profile_applies> ] [ <outstanding_vpc_profile_applies> ] [ <node_recon_pending> ] [
<node_recon_attempts> ] [ <node_recon_failures> ] } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Fabric Database
host	Auto-configured Hosts
statistics	Statistics - Mostly shows non-zero values
<u>__readonly__</u>	(Optional) Read Only
TABLE_database_host_statistics	(Optional) table show fabric database host statistics
<i>data_snoop_triggers</i>	(Optional) TODO
<i>data_snoop_deletes</i>	(Optional) TODO
<i>data_snoop_responses</i>	(Optional) TODO
<i>vdp_association_requests</i>	(Optional) TODO
<i>vdp_deassociation_requests</i>	(Optional) TODO
<i>vdp_association_responses</i>	(Optional) TODO
<i>vdp_error_responses</i>	(Optional) TODO

<i>unsupported_interfaces</i>	(Optional) TODO
<i>no_profile_map_errors</i>	(Optional) TODO
<i>outstanding_delete_retry_add</i>	(Optional) TODO
<i>duplicate_add_existing_host</i>	(Optional) TODO
<i>hmm_api_error_cannot_add_host</i>	(Optional) TODO
<i>existing_profile_new_host</i>	(Optional) TODO
<i>profile_apply_from_vpc_peer</i>	(Optional) TODO
<i>profile_un_apply_from_vpc_peer</i>	(Optional) TODO
<i>host_apply_from_vpc_peer</i>	(Optional) TODO
<i>host_un_apply_from_vpc_peer</i>	(Optional) TODO
<i>early_delete_cancel_add</i>	(Optional) TODO
<i>dhcp_requests</i>	(Optional) TODO
<i>dhcp_responses</i>	(Optional) TODO
<i>dhcp_error_responses</i>	(Optional) TODO
<i>adbm_requests</i>	(Optional) TODO
<i>adbm_responses</i>	(Optional) TODO
<i>adbm_error_responses</i>	(Optional) TODO
<i>adbm_error_requests</i>	(Optional) TODO
<i>adbm_db_notifications</i>	(Optional) TODO
<i>vnseg_no_bridge_domain</i>	(Optional) TODO
<i>vnseg_encap_responses</i>	(Optional) TODO
<i>vnseg_vni_responses</i>	(Optional) TODO
<i>vnseg_unknown_responses</i>	(Optional) TODO
<i>vnseg_bd_down_notif</i>	(Optional) TODO
<i>bd_mgr_requests</i>	(Optional) TODO
<i>bd_mgr_success_responses</i>	(Optional) TODO
<i>bd_mgr_failure_responses</i>	(Optional) TODO
<i>bd_mgr_unreserve</i>	(Optional) TODO
<i>bd_mgr_inconsistencies</i>	(Optional) TODO

show fabric database host statistics

<i>no_mac_on_bd_notif</i>	(Optional) TODO
<i>refresh_failures</i>	(Optional) TODO
<i>profile_apply_received</i>	(Optional) TODO
<i>profile_vpc_queued</i>	(Optional) TODO
<i>profile_local_apply_queued</i>	(Optional) TODO
<i>profile_local_unapply_queued</i>	(Optional) TODO
<i>profile_apply_sent</i>	(Optional) TODO
<i>profile_apply_responses</i>	(Optional) TODO
<i>profile_apply_success</i>	(Optional) TODO
<i>profile_unapply_success</i>	(Optional) TODO
<i>profile_apply_failure</i>	(Optional) TODO
<i>profile_commands</i>	(Optional) TODO
<i>profile_error_incomplete_configs</i>	(Optional) TODO
<i>profile_api_error</i>	(Optional) TODO
<i>profile_unapply_sent</i>	(Optional) TODO
<i>profile_top_queue_adds</i>	(Optional) TODO
<i>profile_high_queue_adds</i>	(Optional) TODO
<i>profile_low_queue_adds</i>	(Optional) TODO
<i>profile_unapply_failure</i>	(Optional) TODO
<i>outstanding_vlan_requests</i>	(Optional) TODO
<i>outstanding_adbm_requests</i>	(Optional) TODO
<i>outstanding_profile_applies</i>	(Optional) TODO
<i>outstanding_vpc_profile_applies</i>	(Optional) TODO
<i>node_recon_pending</i>	(Optional) TODO
<i>node_recon_attempts</i>	(Optional) TODO
<i>node_recon_failures</i>	(Optional) TODO

Command Mode

- /exec

show fabric database host summary

```
show fabric database host summary [ __readonly__ [ TABLE_database_host_summary {  
<number_of_instances_applied> <number_of_client_hosts> <recovery_timeout_minute>  
<cleanup_timeout_minute> <client_add_suppression_timeout_minute> <mac_aging_timeout_minute>  
<autoid_support> } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Fabric Database
host	Auto-configured Hosts
summary	Summary
<u>__readonly__</u>	(Optional) Read Only
TABLE_database_host_summary	(Optional) table show fabric database host summary
<i>number_of_instances_applied</i>	(Optional) TODO
<i>number_of_client_hosts</i>	(Optional) TODO
<i>recovery_timeout_minute</i>	(Optional) TODO
<i>cleanup_timeout_minute</i>	(Optional) TODO
<i>client_add_suppression_timeout_minute</i>	(Optional) TODO
<i>mac_aging_timeout_minute</i>	(Optional) TODO
<i>autoid_support</i>	(Optional) List of supported auto-generate ids

Command Mode

- /exec

show fabric database profile-map

show fabric database profile-map

```
show fabric database profile-map { global | [ <id> | interface <interface-id> ] } [ __readonly__ [ TABLE_database_profile_map { <map> <proto> <vni> <dot1q> <flags> <profile_name> } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Fabric Database
profile-map	Profile Map
global	Global profile (apply to all interfaces)
<i>id</i>	(Optional) Profile Map ID
interface	(Optional) Specified interface to display
<i>interface-id</i>	(Optional) Name of interface
<u>__readonly__</u>	(Optional) Read Only
TABLE_database_profile_map	(Optional) table show fabric database profile-map
<i>map</i>	(Optional) TODO
<i>proto</i>	(Optional) TODO
<i>vni</i>	(Optional) TODO
<i>dot1q</i>	(Optional) TODO
<i>flags</i>	(Optional) TODO
<i>profile_name</i>	(Optional) TODO

Command Mode

- /exec

show fabric database static-host

```
show fabric database static-host [ __readonly__ { TABLE_database_static_host <host_key> <interface> <state> <retry_delay> <retry_attempts> } ]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Fabric Database
static-host	Configured Static Hosts
__readonly__	(Optional) Read Only
TABLE_database_static_host	(Optional) table show fabric database static-host
host_key	(Optional) static-host key
interface	(Optional) interface name
state	(Optional) static-host state
retry_delay	(Optional) seconds until next retry
retry_attempts	(Optional) cumulative retry attempts

Command Mode

- /exec

show fabric database statistics

show fabric database statistics

```
show fabric database statistics [ type { network | profile | cabling | partition | bl-dci | host } ] [ __readonly__ { TABLE_types <dbtype> <requests> <dispatched> <not_dispatched> <re_dispatched> } [ { TABLE_dbs <is_active> <type> <prot> <serverdb> [ <reqs> <ok> <nores> <err> <tmout> <pend> ] } ] { LastPollTime <poll_time> } { LastUpdateTime <update_time> } [ { TABLE_updates <update_type> <update_status> } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
database	Show Fabric Database
statistics	Show database statistics
type	(Optional) Enter database type
network	(Optional) Network Database
profile	(Optional) Port or Switch Profile Database
cabling	(Optional) Cable Management Database
partition	(Optional) Partition Database
bl-dci	(Optional) Border Leaf - DCI
host	(Optional) Host
__readonly__	(Optional)
TABLE_types	(Optional) totals by type
dbtype	(Optional) type of database
requests	(Optional) number of requests
dispatched	(Optional) number dispatched
not_dispatched	(Optional) number not dispatched
re_dispatched	(Optional) number re-dispatched
TABLE_dbs	(Optional) per-database stats
is_active	(Optional) active/inactive
type	(Optional) database type
prot	(Optional) database protocol
serverdb	(Optional) server database

<i>reqs</i>	(Optional) requests
<i>ok</i>	(Optional) OK
<i>nores</i>	(Optional) nores
<i>err</i>	(Optional) err
<i>tmout</i>	(Optional) tmout
<i>pend</i>	(Optional) pend
LastPollTime	(Optional) last poll time
<i>poll_time</i>	(Optional) poll time
LastUpdateTime	(Optional) last update time for db status change
<i>update_time</i>	(Optional) update time
TABLE_updates	(Optional) totals ty type
<i>update_type</i>	(Optional) db type
<i>update_status</i>	(Optional) db status

Command Mode

- /exec

show fabric forwarding host-db

show fabric forwarding host-db

```
show fabric forwarding host-db [ { vrf { <vrf-name> | <vrf-known-name> | all } } ] [ __readonly__ [
TABLE_forwarding_host_db_vrf { <vrf> <vrf_id> <vrf_state> <vrf_reason> <vnii_id> <refcount>
<conversational_learning> [ TABLE_limit_type <limit_type> <enable> <threshold> <action> ] [ TABLE_ipv4
<address_family> <vrf> <table_id> <table_state> <refcount> <local_hosts> <remote_hosts> <aggregates>
[ TABLE_aggregate_list <aggregate_subnet_prefix_list> <aggregate_subnet_prefix_state> ] ] [ TABLE_ipv6
<address_family> <vrf> <table_id> <table_state> <refcount> <local_hosts> <remote_hosts> <aggregates>
[ TABLE_aggregate_list <aggregate_subnet_prefix_list> <aggregate_subnet_prefix_state> ] ] } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
forwarding	Fabric Forwarding Protocol: Host Mobility Manager (HMM)
host-db	Host Database info
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<u>__readonly__</u>	(Optional) Read Only
TABLE_forwarding_host_db_vrf	(Optional) table show fabric forwarding host-db vrf
<i>vrf</i>	(Optional) TODO
<i>vrf_id</i>	(Optional) TODO
<i>vrf_state</i>	(Optional) TODO
<i>vrf_reason</i>	(Optional) TODO
<i>vni_id</i>	(Optional) TODO
<i>refcount</i>	(Optional) TODO
<i>conversational_learning</i>	(Optional) TODO
TABLE_limit_type	(Optional) table for limit type
<i>limit_type</i>	(Optional) TODO
<i>enable</i>	(Optional) TODO
<i>threshold</i>	(Optional) TODO
<i>action</i>	(Optional) TODO

TABLE_ipv4	(Optional) Information for address family IPv4
<i>address_family</i>	(Optional) TODO
<i>vrf</i>	(Optional) TODO
<i>table_id</i>	(Optional) TODO
<i>table_state</i>	(Optional) TODO
<i>refcount</i>	(Optional) TODO
<i>local_hosts</i>	(Optional) TODO
<i>remote_hosts</i>	(Optional) TODO
<i>aggregates</i>	(Optional) TODO
TABLE_aggregate_list	(Optional) table for aggregate subnet prefix list
<i>aggregate_subnet_prefix_list</i>	(Optional) TODO
TABLE_ipv6	(Optional) Information for address family IPv6
<i>address_family</i>	(Optional) TODO
<i>vrf</i>	(Optional) TODO
<i>table_id</i>	(Optional) TODO
<i>table_state</i>	(Optional) TODO
<i>refcount</i>	(Optional) TODO
<i>local_hosts</i>	(Optional) TODO
<i>remote_hosts</i>	(Optional) TODO
<i>aggregates</i>	(Optional) TODO
TABLE_aggregate_list	(Optional) table for aggregate subnet prefix list
<i>aggregate_subnet_prefix_list</i>	(Optional) TODO
<i>aggregate_subnet_prefix_state</i>	(Optional) TODO

Command Mode

- /exec

show fabric forwarding ip local

show fabric forwarding ip local

```
show fabric forwarding ip { local-host-db [ { vrf { <vrf-name> | <vrf-known-name> | all } } ] [ <ip-prefix> ] } [ __readonly__ [ TABLE_forwarding_ip_local_host_db_vrf { <hmm_host> <vrf> <status_in> { TABLE_hosts <host> <mac_address> <svi> <flags_0x> <physical_interface> <status> } } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
forwarding	Fabric Forwarding Protocol: Host Mobility Manager (HMM)
ip	Display IP information
local-host-db	HMM Local Host Database
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<i>ip-prefix</i>	(Optional) IP prefix in CIDR format
<u>__readonly__</u>	(Optional) Read Only
TABLE_forwarding_ip_local_host_db_vrf	(Optional) table show fabric forwarding ip local-host-db vrf
<i>hmm_host</i>	(Optional) TODO
<i>vrf</i>	(Optional) TODO
<i>status_in</i>	(Optional) TODO
TABLE_hosts	(Optional) table show information for each hosts
<i>host</i>	(Optional) TODO
<i>mac_address</i>	(Optional) TODO
<i>svi</i>	(Optional) TODO
<i>flags_0x</i>	(Optional) TODO
<i>physical_interface</i>	(Optional) TODO
<i>status</i>	(Optional) *-valid, x-deleted, a-aged out, c-cleaned

Command Mode

- /exec

show fabric forwarding ipv6 local

```
show fabric forwarding ipv6 { local-host-db [ { vrf { <vrf-name> | <vrf-known-name> | all } } ] [ <ipv6-prefix> ] } [ __readonly__ [ TABLE_forwarding_ipv6_local_host_db_vrf { <hmm_host> <vrf> <status_in> { TABLE_hosts <host> <mac_address> <svi> <flags_0x> <physical_interface> <status> } } ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
forwarding	Fabric Forwarding Protocol: Host Mobility Manager (HMM)
ipv6	Display IPv6 information
local-host-db	HMM Local Host Database
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
<u>__readonly__</u>	(Optional) Read Only
TABLE_forwarding_ipv6_local_host_db_vrf	(Optional) table show fabric forwarding ipv6 local-host-db vrf
<i>hmm_host</i>	(Optional) TODO
<i>vrf</i>	(Optional) TODO
<i>status_in</i>	(Optional) TODO
TABLE_hosts	(Optional) table show information for each hosts
<i>host</i>	(Optional) TODO
<i>mac_address</i>	(Optional) TODO
<i>svi</i>	(Optional) TODO
<i>flags_0x</i>	(Optional) TODO
<i>physical_interface</i>	(Optional) TODO
<i>status</i>	(Optional) *-valid, x-deleted, a-aged out, c-cleaned

Command Mode

- /exec

show fabric multicast globals

show fabric multicast globals

```
show fabric multicast globals [ __readonly__ [ <pruning> ] [ <switch_role> ] [ <fabric_control_seg> ] [ <peer_fabric_ctrl_addr> ] [ <advertise_vpc_rpf_routes> ] [ <created_vni_list> ] [ <fwd_encap> ] [ <mrib_sync_delay> ] [ <bgp_eor_rcvd> ] [ <bgp_eor_rcvd_ts> ] [ <cli_done_rcvd> ] [ <cli_done_rcvd_ts> ] [ <local_nlri_req> ] [ <dist_dr> ] [ <dist_pending> ] [ <spt_only> ] [ <pim_trm_bl> ] [ <pim6_trm_bl> ] [ <l2_trm_evpn> ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
multicast	Multicast information
globals	show the global settings
<i>__readonly__</i>	(Optional)
<i>pruning</i>	(Optional)
<i>switch_role</i>	(Optional)
<i>fabric_control_seg</i>	(Optional)
<i>peer_fabric_ctrl_addr</i>	(Optional)
<i>advertise_vpc_rpf_routes</i>	(Optional)
<i>created_vni_list</i>	(Optional)
<i>fwd_encap</i>	(Optional)
<i>mrib_sync_delay</i>	(Optional)
<i>bgp_eor_rcvd</i>	(Optional)
<i>bgp_eor_rcvd_ts</i>	(Optional)
<i>cli_done_rcvd</i>	(Optional)
<i>cli_done_rcvd_ts</i>	(Optional)
<i>local_nlri_req</i>	(Optional)
<i>dist_dr</i>	(Optional)
<i>dist_pending</i>	(Optional)
<i>spt_only</i>	(Optional)
<i>pim_trm_bl</i>	(Optional)
<i>pim6_trm_bl</i>	(Optional)

<i>l2_trm_evpn</i>	(Optional)
--------------------	------------

Command Mode

- /exec

show fabric multicast ipv4 l2 vni

show fabric multicast ipv4 l2 vni

```
show fabric multicast { ipv4 | ipv6 } { l2-mroute } vni { <vni-id> | all } [ __readonly__ TABLE_vni <vnid> [ TABLE_mroute <mroute_desc> [ TABLE_fabric <fabric_node_addr> ] ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
multicast	Multicast information
ipv4	Display IP information
ipv6	Display IPv6 information
l2-mroute	display l2-mroute status
vni	Virtual Network Identifier
<i>vni-id</i>	VNI number
all	Display all L2 VNI NGMVPN is aware of
__readonly__	(Optional)
TABLE_vni	(Optional)
<i>vnid</i>	(Optional)
TABLE_mroute	(Optional)
<i>mroute_desc</i>	(Optional)
TABLE_fabric	(Optional)
<i>fabric_node_addr</i>	(Optional)

Command Mode

- /exec

show fabric multicast statistics

```
show fabric multicast statistics [ __readonly__ [ <remote_nlri_msgs_rx> ] [ <remote_nlri_msgs_rx_fail> ] [ <local_nlri_msgs_tx> ] [ <local_nlri_msgs_tx_fail> ] [ <import_rt_msgs_tx> ] [ <import_rt_msgs_tx_fail> ] [ <m2rib_msgs_tx> ] [ <m2rib_msgs_tx_fail> ] [ <mrib_msgs_tx> ] [ <mrib_msgs_tx_fail> ] [ <m6rib_msgs_tx> ] [ <m6rib_msgs_tx_fail> ] [ <pim_msgs_tx> ] [ <pim_msgs_tx_fail> ] [ <pim_msgs_rx> ] [ <pim_all_remote_ssm_rp_req_rx> ] [ <pim6_msgs_tx> ] [ <pim6_msgs_tx_fail> ] [ <pim6_msgs_rx> ] [ <pim6_all_remote_ssm_rp_req_rx> ] [ <remote_nlri_ack_tx> ] [ <remote_nlri_ack_tx_fail> ] [ <all_local_nlri_req_rx> ] [ <local_nlri_ack_rx> ] [ <remote_route_req_tx> ] [ <remote_route_req_tx_fail> ] [ <pim6_all_local_ssm_rp_req_tx> ] [ <pim6_all_local_ssm_rp_req_tx_fail> ] [ <igmp_local_route_rx> ] [ <igmp_local_route_ack_rx> ] [ <igmp_msgs_tx> ] [ <igmp_msgs_tx_fail> ] [ <igmp_l2_vni_up_down_rx> ] [ <mts_q_high_warning_rx> ] [ <mts_q_full_warning_rx> ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
multicast	Multicast information
statistics	Show statistics
<u>__readonly__</u>	(Optional)
<i>remote_nlri_msgs_rx</i>	(Optional)
<i>remote_nlri_msgs_rx_fail</i>	(Optional)
<i>local_nlri_msgs_tx</i>	(Optional)
<i>local_nlri_msgs_tx_fail</i>	(Optional)
<i>import_rt_msgs_tx</i>	(Optional)
<i>import_rt_msgs_tx_fail</i>	(Optional)
<i>m2rib_msgs_tx</i>	(Optional)
<i>m2rib_msgs_tx_fail</i>	(Optional)
<i>mrib_msgs_tx</i>	(Optional)
<i>mrib_msgs_tx_fail</i>	(Optional)
<i>m6rib_msgs_tx</i>	(Optional)
<i>m6rib_msgs_tx_fail</i>	(Optional)
<i>pim_msgs_tx</i>	(Optional)
<i>pim_msgs_tx_fail</i>	(Optional)
<i>pim_msgs_rx</i>	(Optional)

show fabric multicast statistics

<i>pim_all_remote_ssm_rp_req_rx</i>	(Optional)
<i>pim6_msgs_tx</i>	(Optional)
<i>pim6_msgs_tx_fail</i>	(Optional)
<i>pim6_msgs_rx</i>	(Optional)
<i>pim6_all_remote_ssm_rp_req_rx</i>	(Optional)
<i>remote_nlri_ack_tx</i>	(Optional)
<i>remote_nlri_ack_tx_fail</i>	(Optional)
<i>all_local_nlri_req_rx</i>	(Optional)
<i>local_nlri_ack_rx</i>	(Optional)
<i>remote_route_req_tx</i>	(Optional)
<i>remote_route_req_tx_fail</i>	(Optional)
<i>pim6_all_local_ssm_rp_req_tx</i>	(Optional)
<i>pim6_all_local_ssm_rp_req_tx_fail</i>	(Optional)
<i>igmp_local_route_rx</i>	(Optional)
<i>igmp_local_route_ack_rx</i>	(Optional)
<i>igmp_msgs_tx</i>	(Optional)
<i>igmp_msgs_tx_fail</i>	(Optional)
<i>igmp_l2_vni_up_down_rx</i>	(Optional)
<i>mts_q_high_warning_rx</i>	(Optional)
<i>mts_q_full_warning_rx</i>	(Optional)

Command Mode

- /exec

show fabric multicast vrf

```
show fabric multicast vrf [ { <vrf-name> | <vrf-known-name> | all } ] [ __readonly__ TABLE_vrf
<context_name> [ <context_id> ] [ <vprime_iod> ] [ <vnid> ] [ <l3trm> ] [ <iropt> ] ]
```

Syntax Description

show	Show running system information
fabric	Fabric
multicast	Multicast information
vrf	Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display all VRFs NGMVPN is aware of
__readonly__	(Optional)
TABLE_vrf	(Optional)
<i>context_name</i>	(Optional)
<i>context_id</i>	(Optional)
<i>vprime_iod</i>	(Optional)
<i>vnid</i>	(Optional)
<i>l3trm</i>	(Optional)
<i>iropt</i>	(Optional)

Command Mode

- /exec

show fabric switch information

show fabric switch information

show fabric switch information [vsan <i0>]

Syntax Description

show	Show running system information
fabric	Show Fabric Information
switch	Show switch details.
information	Show switch model, version and other details
vsan	(Optional) VSAN id
<i>i0</i>	(Optional) VSAN range

Command Mode

- /exec

show fc2 bind

```
show fc2 bind [ __readonly__ { TABLE_fc2bind <SOCKET><FLAGS><NLEVEL><RULE><SINDEX>
<VSAN><D_ID><MASK><TYPE><SUBTYPE><M_VALUES> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
bind	show fc2 socket bindings
__readonly__	(Optional) Read only
TABLE_fc2bind	(Optional) show fc2 bind
SOCKET	(Optional) socket
FLAGS	(Optional) flags
NLEVEL	(Optional) nlevel
RULE	(Optional) rule
SINDEX	(Optional) sidnex
VSAN	(Optional) vsan
D_ID	(Optional) d_id
MASK	(Optional) mask
TYPE	(Optional) type
SUBTYPE	(Optional) subtype
M_VALUES	(Optional) m_values

Command Mode

- /exec

show fc2 classf

show fc2 classf

```
show fc2 classf[ __readonly__ { TABLE_fc2classf <HIX><VSAN><S_ID><D_ID><IFIDX><R_A_TOV>
<E_D_TOV><F-SO><RC><RS><CS><EE><2-SO><RS><3-SO><RS><EECNT><TCCNT><FCNT>
<REFCNT> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
classf	show fc2 classf sessions
<u>__readonly__</u>	(Optional) Read only
TABLE_fc2classf	(Optional) show fc2 classf
<i>HIX</i>	(Optional) hix
<i>VSAN</i>	(Optional) vsan
<i>S_ID</i>	(Optional) sid
<i>D_ID</i>	(Optional) did
<i>IFIDX</i>	(Optional) ifidx
<i>R_A_TOV</i>	(Optional) r_a_tov
<i>E_D_TOV</i>	(Optional) e_d_tov
<i>F-SO</i>	(Optional) f-so
<i>RC</i>	(Optional) rc
<i>RS</i>	(Optional) rs
<i>CS</i>	(Optional) cs
<i>EE</i>	(Optional) ee
<i>2-SO</i>	(Optional) 2-so
<i>RS</i>	(Optional) rs
<i>3-SO</i>	(Optional) 3-so
<i>RS</i>	(Optional) rs
<i>EECNT</i>	(Optional) eecnt
<i>TCCNT</i>	(Optional) tccnt
<i>FCNT</i>	(Optional) fcnt

<i>REFCNT</i>	(Optional) refcnt
---------------	-------------------

Command Mode

- /exec

show fc2 exchange

show fc2 exchange

```
show fc2 exchange [ __readonly__ { TABLE_ExchngInfo [ <ECB_INUSE> ] [ <ECB_DROPPED> ] [ <ECB_TOTAL> ] [ <ECB_MAX> ] } [ TABLE_fc2exchange <HIX> <VSAN> <X_ID> <OX_ID> <RX_ID> <O_ID> <R_ID> <ESTAT> <STATE> <SOCKET> <DIFINDEX> <CS> <TYPE> <SEQID> <TCNT> <RCNT> <LO> <HI> <SSTAT> <LOGIN> ] ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
exchange	show fc2 active exchanges
<u>__readonly__</u>	(Optional) Read only
TABLE_ExchngInfo	(Optional) ecb info
ECB_INUSE	(Optional) ecb in use
ECB_DROPPED	(Optional) ecb dropped
ECB_TOTAL	(Optional) ecb total
ECB_MAX	(Optional) ecb threshold
TABLE_fc2exchange	(Optional) show fc2 exchange
HIX	(Optional) hix
VSAN	(Optional) vsan
X_ID	(Optional) xid
OX_ID	(Optional) oxid
RX_ID	(Optional) rxid
O_ID	(Optional) o_id
R_ID	(Optional) r_id
ESTAT	(Optional) estat
STATE	(Optional) state
SOCKET	(Optional) socket
DIFINDEX	(Optional) dIFINDEX
CS	(Optional) cs
TYPE	(Optional) type

<i>SEQID</i>	(Optional) seqid
<i>TCNT</i>	(Optional) tcnt
<i>RCNT</i>	(Optional) rcnt
<i>LO</i>	(Optional) lo
<i>HI</i>	(Optional) hi
<i>SSTAT</i>	(Optional) sstat
<i>LOGIN</i>	(Optional) login

Command Mode

- /exec

show fc2 exchresp

show fc2 exchresp

```
show fc2 exchresp [ __readonly__ { TABLE_fc2exchresp <HIX> <VSAN> <OX_ID> <S_ID> <CS>
<SIFINDEX> <OX_ID2> <RX_ID2> <O_ID> <R_ID> <ESTAT> <STATE> <SOCKET> <TYPE> <SEQID>
<TCNT> <RCNT> <LO> <HI> <SSTAT> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
exchresp	show fc2 active responder exchanges
<u>__readonly__</u>	(Optional) Read only
TABLE_fc2exchresp	(Optional) show fc2 exchresp
<i>HIX</i>	(Optional) hix
<i>VSAN</i>	(Optional) vsan
<i>OX_ID</i>	(Optional) oxid
<i>S_ID</i>	(Optional) sid
<i>CS</i>	(Optional) cs
<i>SIFINDEX</i>	(Optional) sifindex
<i>OX_ID2</i>	(Optional) oxid
<i>RX_ID2</i>	(Optional) rxid
<i>O_ID</i>	(Optional) oid
<i>R_ID</i>	(Optional) rid
<i>ESTAT</i>	(Optional) estat
<i>STATE</i>	(Optional) state
<i>SOCKET</i>	(Optional) socket
<i>TYPE</i>	(Optional) type
<i>SEQID</i>	(Optional) seqid
<i>TCNT</i>	(Optional) tcnt
<i>RCNT</i>	(Optional) rcnt
<i>LO</i>	(Optional) lo
<i>HI</i>	(Optional) hi

<i>SSTAT</i>	(Optional) sstat
--------------	------------------

Command Mode

- /exec

show fc2 flogi

show fc2 flogi

```
show fc2 flogi [ __readonly__ { TABLE_fc2flogi <HIX><VSAN><S_ID><FLOGI><IFINDEX><TYPE>
} ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
flogi	show fc2 flogi table
__readonly__	(Optional) Read only
TABLE_fc2flogi	(Optional) show fc2 flogi
HIX	(Optional) hix
VSAN	(Optional) vsan
S_ID	(Optional) sid
FLOGI	(Optional) flogi
IFINDEX	(Optional) ifindex
TYPE	(Optional) type

Command Mode

- /exec

show fc2 nport

```
show fc2 nport [ __readonly__ { TABLE_fc2nport <REF> <VSAN> <D_ID> <MASK> <FL> <ST>
<IFINDEX><CF><TC><2-SO><IC><RC><RS><CS><EE><3-SO><3-SO-IC><3-SO-RC><3-SO-RS>
<3-SO-CS><3-SO-EE> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
nport	show fc2 local nports
__readonly__	(Optional) Read only
TABLE_fc2nport	(Optional) show fc2 nport
REF	(Optional) ref
VSAN	(Optional) vsan
D_ID	(Optional) did
MASK	(Optional) mask
FL	(Optional) fl
ST	(Optional) st
IFINDEX	(Optional) ifindex
CF	(Optional) cf
TC	(Optional) tc
2-SO	(Optional) 2so
IC	(Optional) ic
RC	(Optional) rc
RS	(Optional) rs
CS	(Optional) cs
EE	(Optional) ee
3-SO	(Optional) 3so
3-SO-IC	(Optional) 3so-ic
3-SO-RC	(Optional) 3so-rc
3-SO-RS	(Optional) 3so-rs

show fc2 nport

<i>3-SO-CS</i>	(Optional) 3so-cs
<i>3-SO-EE</i>	(Optional) 3so-ee

Command Mode

- /exec

show fc2 plogi

```
show fc2 plogi [ __readonly__ { TABLE_fc2plogi <HIX> <ADDRESS> <VSAN> <S_ID> <D_ID>
<IF_INDEX> <FL> <STATE> <CF> <TC> <2-SO> <IC> <RC> <RS> <CS> <EE> <3-SO> <3SO_IC>
<3SO_RC> <3SO_RS> <3SO_CS> <3SO_EE> <EECNT> <TCCNT> <2CNT> <3CNT> <REFCNT> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
plogi	show fc2 plogi sessions
__readonly__	(Optional) Read only
TABLE_fc2plogi	(Optional) show fc2 plogi
HIX	(Optional) hix
ADDRESS	(Optional) address
VSAN	(Optional) vsan
S_ID	(Optional) sid
D_ID	(Optional) did
IF_INDEX	(Optional) ifindex
FL	(Optional) fl
STATE	(Optional) state
CF	(Optional) cf
TC	(Optional) tc
2-SO	(Optional) 2so
IC	(Optional) ic
RC	(Optional) rc
RS	(Optional) rs
CS	(Optional) cs
EE	(Optional) ee
3-SO	(Optional) 3so
3SO_IC	(Optional) ic
3SO_RC	(Optional) rc

show fc2 plogi

<i>3SO_RS</i>	(Optional) rs
<i>3SO_CS</i>	(Optional) cs
<i>3SO_EE</i>	(Optional) ee
<i>EECNT</i>	(Optional) eecnt
<i>TCCNT</i>	(Optional) TCCNT
<i>2CNT</i>	(Optional) 2cnt
<i>3CNT</i>	(Optional) 3cnt
<i>REFCNT</i>	(Optional) refcnt

Command Mode

- /exec

show fc2 plogi_pwwn

```
show fc2 plogi_pwwn [ __readonly__ { TABLE_fc2plogi_pwwn <HIX> <ADDRESS> <VSAN> <S_ID>
<D_ID> <IFINDEX> <FL> <STATE> <PWWN> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
plogi_pwwn	show fc2 plogi pwwn entries
__readonly__	(Optional) Read only
TABLE_fc2plogi_pwwn	(Optional) show fc2 plogi_pwwn
HIX	(Optional) hix
ADDRESS	(Optional) address
VSAN	(Optional) vsan
S_ID	(Optional) s_id
D_ID	(Optional) d_id
IFINDEX	(Optional) ifindex
FL	(Optional) fl
STATE	(Optional) state
PWWN	(Optional) pwwn

Command Mode

- /exec

show fc2 port brief

show fc2 port brief

```
show fc2 port brief [ __readonly__ { TABLE_fc2portbrief <BAD_FRAME_RX> } [ TABLE_FCSTAT <IX>
<ST><MOD><EMUL><TXPKTS><TXDROP><TXERR><RXPKTS><RXDROP> ] [ TABLE_LBSTAT
<IX><ST><MOD><EMUL><TXLBPKTS><TXLBDROP><RXLBPKTS><RXLBDROP> ] [
TABLE_VFCSTAT <IX><ST><MOD><EMUL><TXPKTS><TXDROP><TXERR><RXPKTS>
<RXDROP> ] [ TABLE_VFCPOSTAT <IX><ST><MOD><EMUL><TXPKTS><TXDROP><TXERR>
<RXPKTS><RXDROP> ] [ TABLE_VFCSLOTSTAT <IX><ST><MOD><EMUL><TXPKTS>
<TXDROP><TXERR><RXPKTS><RXDROP> ] ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
port	show fc2 physical port table
brief	display only active port counters
<u>__readonly__</u>	(Optional) Read only
TABLE_fc2portbrief	(Optional) bad frames received
BAD_FRAME_RX	(Optional) fc2 bad frames rx
TABLE_FCSTAT	(Optional) FC Stat table
IX	(Optional) index
ST	(Optional) status
MOD	(Optional) mode
EMUL	(Optional) TEemul
TXPKTS	(Optional) txpackets
TXDROP	(Optional) txdrops
TXERR	(Optional) txerrorcnt
RXPKTS	(Optional) rx packets
RXDROP	(Optional) rx drop
TABLE_LBSTAT	(Optional) LB Stat table
IX	(Optional) index
ST	(Optional) status
MOD	(Optional) mode
EMUL	(Optional) TEemul

<i>TXLBPKTS</i>	(Optional) tx lb packets
<i>TXLBDROP</i>	(Optional) tx lb drops
<i>RXLBPKTS</i>	(Optional) rx lb packets
<i>RXLBDROP</i>	(Optional) rx lb drop
<i>TABLE_VFCSTAT</i>	(Optional) VFC Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul
<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops
<i>TXERR</i>	(Optional) txerrorcnt
<i>RXPKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop
<i>TABLE_VFCPOSTAT</i>	(Optional) VFC po Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul
<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops
<i>TXERR</i>	(Optional) txerrorcnt
<i>RXPKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop
<i>TABLE_VFC SLOTSTAT</i>	(Optional) VFC slot Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul

```
show fc2 port brief
```

<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops
<i>TXERR</i>	(Optional) txerrorcnt
<i>RXPKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop

Command Mode

- /exec

show fc2 port drops

```
show fc2 port drops [ __readonly__ [ TABLE_FCSTAT <IX> <ST> <MOD> <EMUL> <TXPKTS>
<TXDROP> <TXERR> <RXPKTS> <RXDROP> ] [ TABLE_LBSTAT <IX> <ST> <MOD> <EMUL>
<TXLBPKTS> <TXLBDROP> <RXLBPKTS> <RXLBDROP> ] [ TABLE_VFCSTAT <IX> <ST> <MOD>
<EMUL> <TXPKTS> <TXDROP> <TXERR> <RXPKTS> <RXDROP> ] [ TABLE_VFCPOSTAT <IX>
<ST> <MOD> <EMUL> <TXPKTS> <TXDROP> <TXERR> <RXPKTS> <RXDROP> ] [
TABLE_VFCSLOTSTAT <IX> <ST> <MOD> <EMUL> <TXPKTS> <TXDROP> <TXERR> <RXPKTS>
<RXDROP> ] ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
port	show fc2 physical port table
drops	display active port drop counters
__readonly__	(Optional) Read only
TABLE_FCSTAT	(Optional) FC Stat table
IX	(Optional) index
ST	(Optional) status
MOD	(Optional) mode
EMUL	(Optional) TEemul
TXPKTS	(Optional) txpackets
TXDROP	(Optional) txdrops
TXERR	(Optional) txerrorcnt
RXPKTS	(Optional) rx packets
RXDROP	(Optional) rx drop
TABLE_LBSTAT	(Optional) LB Stat table
IX	(Optional) index
ST	(Optional) status
MOD	(Optional) mode
EMUL	(Optional) TEemul
TXLBPKTS	(Optional) tx lb packets
TXLBDROP	(Optional) tx lb drops

show fc2 port drops

<i>RXLBPKTS</i>	(Optional) rx lb packets
<i>RXLBDROP</i>	(Optional) rx lb drop
<i>TABLE_VFCSTAT</i>	(Optional) VFC Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul
<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops
<i>TXERR</i>	(Optional) txerrorcnt
<i>RXPKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop
<i>TABLE_VFCPOSTAT</i>	(Optional) VFC po Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul
<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops
<i>TXERR</i>	(Optional) txerrorcnt
<i>RXPKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop
<i>TABLE_VFC SLOTSTAT</i>	(Optional) VFC slot Stat table
<i>IX</i>	(Optional) index
<i>ST</i>	(Optional) status
<i>MOD</i>	(Optional) mode
<i>EMUL</i>	(Optional) TEemul
<i>TXPKTS</i>	(Optional) txpackets
<i>TXDROP</i>	(Optional) txdrops

<i>TXERR</i>	(Optional) txerrorcnt
<i>RXPKTS</i>	(Optional) rx packets
<i>RXDROP</i>	(Optional) rx drop

Command Mode

- /exec

show fc2 port state

show fc2 port state

```
show fc2 port state [ __readonly__ [ TABLE_FCPORTSTATE [ <PORT_STRING> ] [ <PORT_NO> ] [ <UP_DOWN_CNTR> ] [ [ <UP_STRING> ] + [ <UP_TIME> ] + [ <UP_REFETIME> ] + [ <DOWN_STRING> ] + [ <DOWN_TIME> ] + [ <DOWN_REFETIME> ] + ] + ] [ TABLE_VFCPORTSTATE [ <PORT_STRING> ] [ <PORT_NO> ] [ <UP_DOWN_CNTR> ] [ [ <UP_STRING> ] + [ <UP_TIME> ] + [ <UP_REFETIME> ] + [ <DOWN_STRING> ] + [ <DOWN_TIME> ] + [ <DOWN_REFETIME> ] + ] + ] [ TABLE_VFCPOPORTSTATE [ <PORT_STRING> ] [ <PORT_NO> ] [ <UP_DOWN_CNTR> ] [ [ <UP_STRING> ] + [ <UP_TIME> ] + [ <UP_REFETIME> ] + [ <DOWN_STRING> ] + [ <DOWN_TIME> ] + [ <DOWN_REFETIME> ] + ] + ] [ TABLE_VFCPORTSLOTSTATE [ <PORT_STRING> ] [ <PORT_NO> ] [ <UP_DOWN_CNTR> ] [ [ <UP_STRING> ] + [ <UP_TIME> ] + [ <UP_REFETIME> ] + [ <DOWN_STRING> ] + [ <DOWN_TIME> ] + [ <DOWN_REFETIME> ] + ] + ] ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
port	show fc2 physical port table
state	display port state history
<u>__readonly__</u>	(Optional) Read only
TABLE_FCPORTSTATE	(Optional) fc port state change history
<i>PORT_STRING</i>	(Optional) port name
<i>PORT_NO</i>	(Optional) port number
<i>UP_DOWN_CNTR</i>	(Optional) up-down counter
<i>UP_STRING</i>	(Optional) up
<i>UP_TIME</i>	(Optional) up time
<i>UP_REFETIME</i>	(Optional) up from
<i>DOWN_STRING</i>	(Optional) down string
<i>DOWN_TIME</i>	(Optional) down time
<i>DOWN_REFETIME</i>	(Optional) down from
TABLE_VFCPORTSTATE	(Optional) vfc port state change history
<i>PORT_STRING</i>	(Optional) port name
<i>PORT_NO</i>	(Optional) port number
<i>UP_DOWN_CNTR</i>	(Optional) up-down counter
<i>UP_STRING</i>	(Optional) up

<i>UP_TIME</i>	(Optional) up time
<i>UP_REFTIME</i>	(Optional) up from
<i>DOWN_STRING</i>	(Optional) down string
<i>DOWN_TIME</i>	(Optional) down time
<i>DOWN_REFTIME</i>	(Optional) down from
TABLE_VFCPOPORTSTATE	(Optional) vfc po port state change history
<i>PORT_STRING</i>	(Optional) port name
<i>PORT_NO</i>	(Optional) port number
<i>UP_DOWN_CNTR</i>	(Optional) up-down counter
<i>UP_STRING</i>	(Optional) up
<i>UP_TIME</i>	(Optional) up time
<i>UP_REFTIME</i>	(Optional) up from
<i>DOWN_STRING</i>	(Optional) down string
<i>DOWN_TIME</i>	(Optional) down time
<i>DOWN_REFTIME</i>	(Optional) down from
TABLE_VFCPORTSLOTSTATE	(Optional) vfc port slot state change history
<i>PORT_STRING</i>	(Optional) port name
<i>PORT_NO</i>	(Optional) port number
<i>UP_DOWN_CNTR</i>	(Optional) up-down counter
<i>UP_STRING</i>	(Optional) up
<i>UP_TIME</i>	(Optional) up time
<i>UP_REFTIME</i>	(Optional) up from
<i>DOWN_STRING</i>	(Optional) down string
<i>DOWN_TIME</i>	(Optional) down time
<i>DOWN_REFTIME</i>	(Optional) down from

Command Mode

- /exec

show fc2 socket

show fc2 socket

```
show fc2 socket [ __readonly__ { TABLE_fc2socket <SOCKET> <REFCNT> <PROTOCOL> <FLAGS>
<PID> <RCVBUF> <RMEM_USED> <QLEN> <NOTSK> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
socket	show fc2 active sockets
<u>__readonly__</u>	(Optional) Read only
TABLE_fc2socket	(Optional) show fc2 socket
<i>SOCKET</i>	(Optional) socket
<i>REFCNT</i>	(Optional) refcnt
<i>PROTOCOL</i>	(Optional) protocol
<i>FLAGS</i>	(Optional) flags
<i>PID</i>	(Optional) pid
<i>RCVBUF</i>	(Optional) rcvbuf
<i>RMEM_USED</i>	(Optional) rmem_used
<i>QLEN</i>	(Optional) qlen
<i>NOTSK</i>	(Optional) not_sk

Command Mode

- /exec

show fc2 sockexch

```
show fc2 sockexch [ __readonly__ { TABLE_fc2sockexch <SOCKET> <VSAN> <X_ID> <OX_ID>
<RX_ID> <O_ID> <R_ID> <ESTAT> <STATE> <CS> <TYPE> <SK> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
sockexch	show fc2 active exchanges for each socket
__readonly__	(Optional) Read only
TABLE_fc2sockexch	(Optional) show fc2 sockexch
SOCKET	(Optional) socket
VSAN	(Optional) vsan
X_ID	(Optional) x_id
OX_ID	(Optional) oxid
RX_ID	(Optional) rxid
O_ID	(Optional) o_id
R_ID	(Optional) r_id
ESTAT	(Optional) estat
STATE	(Optional) state
CS	(Optional) cs
TYPE	(Optional) type
SK	(Optional) sk

Command Mode

- /exec

show fc2 socknotify

show fc2 socknotify

```
show fc2 socknotify [ __readonly__ { TABLE_fc2socknotify <SOCKET> <ADDRESS> <REF> <VSAN>
<D_ID> <MASK> <FL> <ST> <IFINDEX> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
socknotify	show fc2 local nport plogi/logo notifications per each socket
__readonly__	(Optional) Read only
TABLE_fc2socknotify	(Optional) show fc2 socknotify
SOCKET	(Optional) socket
ADDRESS	(Optional) address
REF	(Optional) ref
VSAN	(Optional) vsan
D_ID	(Optional) d_id
MASK	(Optional) mask
FL	(Optional) fl
ST	(Optional) st
IFINDEX	(Optional) ifindex

Command Mode

- /exec

show fc2 socknport

```
show fc2 socknport [ __readonly__ { TABLE_fc2socknport <SOCKET> <ADDRESS> <REF> <VSAN>
<D_ID> <MASK> <FL> <ST> <IFINDEX> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
socknport	show fc2 local nports per each socket
<u>__readonly__</u>	(Optional) Read only
TABLE_fc2socknport	(Optional) show fc2 socknport
<i>SOCKET</i>	(Optional) socket
<i>ADDRESS</i>	(Optional) address
<i>REF</i>	(Optional) ref
<i>VSAN</i>	(Optional) vsan
<i>D_ID</i>	(Optional) d_id
<i>MASK</i>	(Optional) mask
<i>FL</i>	(Optional) fl
<i>ST</i>	(Optional) st
<i>IFINDEX</i>	(Optional) ifindex

Command Mode

- /exec

show fc2 vsan

```
show fc2 vsan [ __readonly__ { TABLE_fc2vsan <VSAN> <X_ID> <E_D_TOV> <R_A_TOV> <WWN>
<IOP_MODE> } ]
```

Syntax Description

show	Show running system information
fc2	show fc2 tables and statistics
vsan	show fc2 vsan table
<u>__readonly__</u>	(Optional) Read only
TABLE_fc2vsan	(Optional) show fc2 vsan
VSAN	(Optional) vsan
X_ID	(Optional) xid
E_D_TOV	(Optional) e_d_tov
R_A_TOV	(Optional) r_a_tov
WWN	(Optional) wwn
IOP_MODE	(Optional) iop_mode

Command Mode

- /exec

show fcalias

```
show fcalias [ [ name <s0> ] [ [ pending ] [ vsan <i0> ] ] ]
```

Syntax Description

show	Show running system information
fcalias	Fcalias show commands
name	(Optional) Show members of a specified fcalias
s0	(Optional) Enter the name of fcalias
pending	(Optional) Show members of a specified fcalias in session
vsan	(Optional) Show aliases belonging to the specified VSAN
i0	(Optional) VSAN id range

Command Mode

- /exec

show fcdomain

show fcdomain

show fcdomain

Syntax Description

show	Show running system information
fcdomain	Show fcdomain information

Command Mode

- /exec

show fcdomain address-allocation

show fcdomain address-allocation [{ cache | vsan <i0> }]

Syntax Description

show	Show running system information
fcdomain	Show fcdomain information
address-allocation	Show statistics for the fcid allocation
cache	(Optional) Show cache content for the fcid allocation
vsan	(Optional) Specify the vsan id
<i>i0</i>	(Optional) VSAN id

Command Mode

- /exec

show fcdomain allowed

show fcdomain allowed

show fcdomain allowed [vsan <i0>]

Syntax Description

show	Show running system information
fcdomain	Show fcdomain information
allowed	Show list of allowed domain IDs
vsan	(Optional) Specify the vsan id
<i>i0</i>	(Optional) VSAN id

Command Mode

- /exec

show fcdomain domain-list

show fcdomain domain-list [vsan <i0>]

Syntax Description

show	Show running system information
fcdomain	Show fcdomain information
domain-list	Show list of domain IDs granted by the principal sw
vsan	(Optional) Specify the vsan id
<i>i0</i>	(Optional) VSAN id

Command Mode

- /exec

show fcdomain fcid persistent

show fcdomain fcid persistent

show fcdomain fcid persistent [{ unused [vsan <i0>] | vsan1 <i1> }]

Syntax Description

show	Show running system information
fcdomain	Show fcdomain information
fcid	Show persistent FCIDs (across reboot)
persistent	Show persistent FCIDs (across reboot)
unused	(Optional) Show unused persistent FCIDs (across reboot)
vsan	(Optional) Specify the vsan id
<i>i0</i>	(Optional) VSAN id
vsan1	(Optional) Specify the vsan id
<i>i1</i>	(Optional) VSAN id

Command Mode

- /exec

show fcdomain pending-diff

show fcdomain pending-diff [vsan <i0>]

Syntax Description

show	Show running system information
fcdomain	Show fcdomain information
pending-diff	Show the difference between running and pending configuration
vsan	(Optional) Specify the vsan id
<i>i0</i>	(Optional) VSAN id

Command Mode

- /exec

show fcdomain pending

show fcdomain pending

show fcdomain pending [vsan <i0>]

Syntax Description

show	Show running system information
fcdomain	Show fcdomain information
pending	Show the pending configuration
vsan	(Optional) Specify the vsan id
<i>i0</i>	(Optional) VSAN id

Command Mode

- /exec

show fcdomain session-status

show fcdomain session-status [vsan <i0>]

Syntax Description

show	Show running system information
fcdomain	Show fcdomain information
session-status	Show the last action performed by fcdomain
vsan	(Optional) Specify the vsan id
<i>i0</i>	(Optional) VSAN id

Command Mode

- /exec

show fcdomain statistics

show fcdomain statistics

show fcdomain statistics [{ interface <if0> [vsan <i0>] | vsan1 <i1> }]

Syntax Description

show	Show running system information
fcdomain	Show fcdomain information
statistics	Show the statistics of fcdomain
interface	(Optional) Specify the fibre channel interface
<i>if0</i>	(Optional)
vsan	(Optional) Specify the vsan id
<i>i0</i>	(Optional) VSAN id
vsan1	(Optional) Specify the vsan id
<i>i1</i>	(Optional) VSAN id

Command Mode

- /exec

show fcdomain status

show fcdomain status

Syntax Description

show	Show running system information
fcdomain	Show fcdomain information
status	Show all vsan-independent information in fcdomain

Command Mode

- /exec

show fcdomain vsan

show fcdomain vsan <i0>

Syntax Description

show	Show running system information
fcdomain	Show fcdomain information
vsan	Specify the vsan id
<i>i0</i>	VSAN id

Command Mode

- /exec

show fcdroplatency

```
show fcdroplatency [ { network | switch } ] [ __readonly__ [ <switch_latency> ] [ <global_network_latency> ] [ TABLE_vsan_network_latency { <vsan-no> <network-latency> } ] ]
```

Syntax Description

show	Show running system information
fcdroplatency	show switch or network latency
network	(Optional) network latency in milliseconds
switch	(Optional) switch latency in milliseconds
__readonly__	(Optional)
switch_latency	(Optional) Switch latency value
global_network_latency	(Optional) global network latency value
TABLE_vsan_network_latency	(Optional) VSAN specific network latency settings
vsan-no	(Optional) vsan number
network-latency	(Optional) VSAN specific network latency

Command Mode

- /exec

show fcid-allocation area

show fcid-allocation area

show fcid-allocation area

Syntax Description

show	Show running system information
fcid-allocation	Show information about fcid-allocation list
area	Show information about fcid-allocation list

Command Mode

- /exec

show fcid-allocation company-id-from-wwn

show fcid-allocation company-id-from-wwn <wwn0>

Syntax Description

show	Show running system information
fcid-allocation	Show information about fcid-allocation list
company-id-from-wwn	Company id (or OUI).
<i>wwn0</i>	Enter WWN to extract company_id/oui

Command Mode

- /exec

show fcns database

show fcns database

```
show fcns database [ { detail [ vsan <i0> ] | domain <i1>[ { detail [ vsan1 <i2> ] | vsan2 <i3> } ] | fcid <fcid4>
{ detail2 vsan3 <i5> | vsan4 <i6> } | local [ { detail1 [ vsan5 <i7> ] | vsan6 <i8> } ] | npv [ { detail1 [ vsan7
<i9> ] | node_wwn <wwn10> [ vsan8 <i11> ] | vsan9 <i12> } ] | proxy-host { detail4 vsan10 <i13> | vsan11
<i14> } | vsan12 <i15> } ]
```

Syntax Description

show	Show running system information
fcns	show name server tables
database	show name server database
detail	(Optional) show all objects in each entry
vsan	(Optional) show local entries for the given vsan(s)
<i>i0</i>	(Optional) VSAN id range
domain	(Optional) show entries in a domain
<i>i1</i>	(Optional) domain-id
detail	(Optional) show all objects in each entry
vsan1	(Optional) show entries for a domain for the given vsan(s)
<i>i2</i>	(Optional) VSAN id range
vsan2	(Optional) show entries for a domain for the given vsan(s)
<i>i3</i>	(Optional) VSAN id range
fcid	(Optional) show entry for the given port
<i>fcid4</i>	(Optional) enter FCID
detail2	(Optional) show all objects in the entry
vsan3	(Optional) show port entry for the given vsan
<i>i5</i>	(Optional) VSAN id
vsan4	(Optional) show port entry for the given vsan
<i>i6</i>	(Optional) VSAN id
local	(Optional) show local entries
detail1	(Optional) show all objects in each entry
vsan5	(Optional) show local entries for the given vsan(s)

<i>i7</i>	(Optional) VSAN id range
<i>vsan6</i>	(Optional) show local entries for the given vsan(s)
<i>i8</i>	(Optional) VSAN id range
<i>npv</i>	(Optional) show n-port virtualization (npv) entries
<i>detail1</i>	(Optional) show all objects in each entry
<i>vsan7</i>	(Optional) show npv entries for the given vsan(s)
<i>i9</i>	(Optional) VSAN id range
<i>node_wwn</i>	(Optional) show end-devices logged in via an npv node
<i>wwn10</i>	(Optional) Node WWN of NPV
<i>vsan8</i>	(Optional) show npv entries for the given vsan(s)
<i>i11</i>	(Optional) VSAN id range
<i>vsan9</i>	(Optional) show npv entries for the given vsan(s)
<i>i12</i>	(Optional) VSAN id range
<i>proxy-host</i>	(Optional) show entry for the proxy-host
<i>detail4</i>	(Optional) show all objects in the entry
<i>vsan10</i>	(Optional) show port entry for the given vsan
<i>i13</i>	(Optional) VSAN id
<i>vsan11</i>	(Optional) show port entry for the given vsan
<i>i14</i>	(Optional) VSAN id
<i>vsan12</i>	(Optional) show entries for the given vsan(s)
<i>i15</i>	(Optional) VSAN id range

Command Mode

- /exec

show fcns statistics

show fcns statistics

show fcns statistics [{ detail [vsan <i0>] | vsan1 <i1> }]

Syntax Description

show	Show running system information
fcns	show name server tables
statistics	show name server statistics
detail	(Optional) show detailed statistics
vsan	(Optional) show detailed statistics for the vsan(s)
<i>i0</i>	(Optional) VSAN id range
vsan1	(Optional) show statistics for the vsan(s)
<i>i1</i>	(Optional) VSAN id range

Command Mode

- /exec

show fcoe-npv issu-impact

```
show fcoe-npv issu-impact [ __readonly__ { <is_impact> } [ TABLE_interface <vfc_intf> <fc_id> ] ]
```

Syntax Description

show	Show running system informationrunning system information
fcoe-npv	feature fcoe-npv
issu-impact	Show feature fcoe-npv config issues if attempting to do non-disruptive ISSU
<u>__readonly__</u>	(Optional) Read Only
<i>is_impact</i>	(Optional) show issu impact
TABLE_interface	(Optional) show fcoe database
<i>vfc_intf</i>	(Optional) vfc port Interface index
<i>fc_id</i>	(Optional) vfc port FCID

Command Mode

- /exec

show fcoe

show fcoe

```
show fcoe [ __readonly__ { TABLE_fcf <fcf_if_index> <fcf_mac> <fc_map> <fcf_priority>
<fka_Advertisement> } [ TABLE_vfc <vfc_name> <vfefc_mac> ] ]
```

Syntax Description

show	Show running system information
fcoe	Show FCOE paramters
<u>__readonly__</u>	(Optional) Read Only
TABLE_fcf	(Optional) fcf table
fcf_if_index	(Optional) fcf if index
fcf_mac	(Optional) fcf mac
fc_map	(Optional) fc map
fcf_priority	(Optional) fcf priority
fka_Advertisement	(Optional) fka Advertisement
TABLE_vfc	(Optional) vfc details table for sup
vfc_name	(Optional) vfc name
vfefc_mac	(Optional) vfefc mac

Command Mode

- /exec

show fcoe database

```
show fcoe database [ __readonly__ { TABLE_interface <interface> [ <fcid> ] [ <port_name> ] <mac_address> } <flogi_count> [ TABLE_veport <interface> <mac_address> <vsan> ] ]
```

Syntax Description

show	Show running system information
fcoe	Show FCOE paramters
database	Show FCOE database
<u>__readonly__</u>	(Optional) Read Only
<i>interface</i>	(Optional) Interface index
TABLE_interface	(Optional) show fcoe database
<i>fcid</i>	(Optional) fcid
<i>port_name</i>	(Optional) port name
<i>mac_address</i>	(Optional) mac address
<i>interface</i>	(Optional) ve port Interface index
TABLE_veport	(Optional) ve port details
<i>mac_address</i>	(Optional) ve port mac address
<i>flogi_count</i>	(Optional) flogi_count
<i>vsan</i>	(Optional) ve port VSAN trunking

Command Mode

- /exec

show fcs database

show fcs database

show fcs database [vsan <i0>]

Syntax Description

show	Show running system information
database	Show local database of FCS
vsan	(Optional) Show local database for a VSAN
<i>i0</i>	(Optional) VSAN range

Command Mode

- /exec

show fcs ie

```
show fcs ie [ { nwwn <wwn0> vsan <i1> | vsan1 <i2> } ]
```

Syntax Description

show	Show running system information
ie	Show Interconnect Element Objects Information
nwwn	(Optional) IE WWN
<i>wwn0</i>	(Optional) IE WWN
vsan	(Optional) VSAN id of IE
<i>i1</i>	(Optional) VSAN id
vsan1	(Optional) VSAN id of IE
<i>i2</i>	(Optional) VSAN range

Command Mode

- /exec

show fcs platform

show fcs platform

show fcs platform { name <s0> vsan <i0> | vsan1 <i1> }

Syntax Description

show	Show running system information
platform	Show Platform Objects Information
name	Platform Name
<i>s0</i>	Platform name string
vsan	VSAN id of the platform
<i>i0</i>	VSAN id
vsan1	VSAN id of the platform
<i>i1</i>	VSAN range

Command Mode

- /exec

show fcs port

```
show fcs port { pwwn <wwn0> vsan <i1> | vsan1 <i2> }
```

Syntax Description

show	Show running system information
port	Show Port Objects Information
pwwn	Port WWN
<i>wwn0</i>	Port WWN
vsan	VSAN id of the port
<i>i1</i>	VSAN id
vsan1	VSAN id of the port
<i>i2</i>	VSAN range

Command Mode

- /exec

show fcs statistics

show fcs statistics

show fcs statistics [vsan <i0>]

Syntax Description

show	Show running system information
statistics	Show statistics for FCS packets.
vsan	(Optional) Show statistics for a VSAN
<i>i0</i>	(Optional) VSAN range

Command Mode

- /exec

show fcs vsan

show fcs vsan

Syntax Description

show	Show running system information
vsan	Show list of all the VSANs and plat-check-mode for each

Command Mode

- /exec

show fctimer

show fctimer

show fctimer [__readonly__ { <F_S_TOV><D_S_TOV><E_D_TOV><R_A_TOV> }]

Syntax Description

show	show running system information
fctimer	show Fibre Channel timers
__readonly__	(Optional) Read only
<i>F_S_TOV</i>	(Optional) F_S_TOV
<i>D_S_TOV</i>	(Optional) D_S_TOV
<i>E_D_TOV</i>	(Optional) E_D_TOV
<i>R_A_TOV</i>	(Optional) R_A_TOV

Command Mode

- /exec

show fctimer D_S_TOV

```
show fctimer D_S_TOV [ vsan <i0> ] [ __readonly__ [ TABLE_D_S_TOV [ <vsan-no> ] <D_S_TOV> ] [ <non-exist-vsang> ] ]
```

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
D_S_TOV	D_S_TOV in milliseconds
vsan	(Optional) Specify VSAN id
<i>i0</i>	(Optional) VSAN id range
<u>__readonly__</u>	(Optional)
TABLE_D_S_TOV	(Optional) table D_S_TOV
<i>vsan-no</i>	(Optional) vsan number
<i>D_S_TOV</i>	(Optional) D_S_TOV
<i>non-exist-vsang</i>	(Optional) non configured vsans

Command Mode

- /exec

show fctimer E_D_TOV

show fctimer E_D_TOV

show fctimer E_D_TOV [vsan <i0>] [__readonly__ [TABLE_E_D_TOV [<vsan-no>] <E_D_TOV>] [<non-exist-vsang>]]

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
E_D_TOV	E_D_TOV in milliseconds
vsan	(Optional) Specify VSAN id
<i>i0</i>	(Optional) VSAN id range
<u>__readonly__</u>	(Optional)
TABLE_E_D_TOV	(Optional) table
<i>vsan-no</i>	(Optional) vsan number
<i>E_D_TOV</i>	(Optional) E_D_TOV
<i>non-exist-vsang</i>	(Optional) not exist vsans

Command Mode

- /exec

show fctimer F_S_TOV

show fctimer F_S_TOV [vsan <i0>] [__readonly__ [TABLE_F_S_TOV [<vsan-no>] <F_S_TOV>] [<non-exist-vsang>]]

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
F_S_TOV	F_S_TOV in milliseconds
vsan	(Optional) Specify VSAN id
<i>i0</i>	(Optional) VSAN id range
__readonly__	(Optional)
TABLE_F_S_TOV	(Optional) table
<i>vsan-no</i>	(Optional) vsan number
<i>F_S_TOV</i>	(Optional) F_S_TOV
<i>non-exist-vsang</i>	(Optional) not exist vsans

Command Mode

- /exec

show fctimer R_A_TOV

show fctimer R_A_TOV

show fctimer R_A_TOV [vsan <i0>] [__readonly__ [TABLE_R_A_TOV [<vsan-no>] <R_A_TOV>] [<non-exist-vsang>]]

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
R_A_TOV	R_A_TOV in milliseconds
vsan	(Optional) Specify VSAN id
<i>i0</i>	(Optional) VSAN id range
<u>__readonly__</u>	(Optional)
TABLE_R_A_TOV	(Optional) table
<i>vsan-no</i>	(Optional) vsan number
<i>R_A_TOV</i>	(Optional) R_A_TOV
<i>non-exist-vsang</i>	(Optional) non exist vsans

Command Mode

- /exec

show fctimer last action status

```
show fctimer last action status [ __readonly__ [ <vsan> ] <last_action_timestamp> <last_action>
<last_action_result> <last_action_failure_reason> ]
```

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
last	Show the status of the last cfs commit/abort operation
action	Show the status of the last cfs commit/abort operation
status	Show the status of the last cfs commit/abort operation
<u>__readonly__</u>	(Optional) Readonly
<i>vsan</i>	(Optional) Vsan
<i>last_action_timestamp</i>	(Optional) Last action timestamp
<i>last_action</i>	(Optional) Last action
<i>last_action_result</i>	(Optional) Last action result
<i>last_action_failure_reason</i>	(Optional) Last action failure reason

Command Mode

- /exec

show fctimer pending-diff

show fctimer pending-diff

show fctimer pending-diff [__readonly__ <status_fctimer>]

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
pending-diff	Show the difference between pending database and running config
__readonly__	(Optional)
<i>status_fctimer</i>	(Optional) Show the difference between pending database and running config

Command Mode

- /exec

show fctimer pending

show fctimer pending [__readonly__ <status_fctimer>]

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
pending	Show the status of pending fctimer commands
__readonly__	(Optional)
<i>status_fctimer</i>	(Optional) Show the status of pending fctimer commands

Command Mode

- /exec

show fctimer session status

show fctimer session status

show fctimer session status [__readonly__ [<vsan>] <last_action_timestamp> <last_action> <last_action_result> <last_action_failure_reason>]

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
session	Show the state of fctimer cfs session
status	Show the status of the last cfs commit/abort operation
__readonly__	(Optional) Readonly
<i>vsan</i>	(Optional) Vsan
<i>last_action_timestamp</i>	(Optional) Last action timestamp
<i>last_action</i>	(Optional) Last action
<i>last_action_result</i>	(Optional) Last action result
<i>last_action_failure_reason</i>	(Optional) Last action failure reason

Command Mode

- /exec

show fctimer status

show fctimer status [__readonly__ <Distribution>]

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
status	cfs distribution is enabled or disabled
__readonly__	(Optional) read only
<i>Distribution</i>	(Optional) distribution

Command Mode

- /exec

show fctimer vsan

```
show fctimer vsan <i0> [ __readonly__ { TABLE_fctimer <vsan-no> <F_S_TOV> <D_S_TOV> <E_D_TOV>
<R_A_TOV> } [ <non-exist-vsang> ] ]
```

Syntax Description

show	Show running system information
fctimer	show Fibre Channel timers
vsan	Specify VSAN id
<i>i0</i>	VSAN id range
<u>__readonly__</u>	(Optional) Read only
TABLE_fctimer	(Optional) table
<i>vsan-no</i>	(Optional) vsan number
<i>F_S_TOV</i>	(Optional) F_S_TOV
<i>D_S_TOV</i>	(Optional) D_S_TOV
<i>E_D_TOV</i>	(Optional) E_D_TOV
<i>R_A_TOV</i>	(Optional) R_A_TOV
<i>non-exist-vsang</i>	(Optional) non exist vsans

Command Mode

- /exec

show fdmi database

show fdmi database

Syntax Description

show	Show running system information
fdmi	Show fdmi information
database	show fdmi database

Command Mode

- /exec

show fdmi database detail

show fdmi database detail

show fdmi database detail

Syntax Description

show	Show running system information
fdmi	Show fdmi information
database	show fdmi database
detail	show all objects in each entry

Command Mode

- /exec

show fdmi database detail hba-id vsan

show fdmi database detail hba-id <wwn0> vsan <i1>

Syntax Description

show	Show running system information
fdmi	Show fdmi information
database	show fdmi database
detail	show all objects in each entry
hba-id	show entries for the given HBA id
wwn0	HBA id
vsan	show HBA id the given vsan
i1	VSAN id

Command Mode

- /exec

```
show fdmi database detail vsan
```

show fdmi database detail vsan

show fdmi database detail vsan <i0>

Syntax Description

show	Show running system information
fdmi	Show fdmi information
database	show fdmi database
detail	show all objects in each entry
vsan	show entries for the given vsan(s)
i0	VSAN id range

Command Mode

- /exec

show fdmi database vsan

show fdmi database vsan <i0>

Syntax Description

show	Show running system information
fdmi	Show fdmi information
database	show fdmi database
vsan	show entries for the given vsan(s)
<i>i0</i>	VSAN id range

Command Mode

- /exec

show fdmi suppress-updates

show fdmi suppress-updates

show fdmi suppress-updates

Syntax Description

show	Show running system information
fdmi	Show fdmi information
suppress-updates	Show vsans on which updates are suppressed

Command Mode

- /exec

show feature-set

```
show feature-set [ <name> ] [ <id> ] [ __readonly__ TABLE_cfcFeatureSetTable <cfcFeatureSetIndex>
<cfcFeatureSetName><cfcFeatureSetAction><cfcFeatureSetLastAction><cfcFeatureSetLastActionResult>
<cfcFeatureSetLastFailureReason> <cfcFeatureSetOpStatus> <cfcFeatureSetOpStatusReason> ]
```

Syntax Description

show	Show running system information
feature-set	Show feature set status
<i>name</i>	(Optional) feature-set name
<i>id</i>	(Optional) feature-set id
<u>__readonly__</u>	(Optional)
TABLE_cfcFeatureSetTable	(Optional) feature-set table
<i>cfcFeatureSetIndex</i>	(Optional) feature-set table index
<i>cfcFeatureSetName</i>	(Optional) feature-set name
<i>cfcFeatureSetAction</i>	(Optional) action
<i>cfcFeatureSetLastAction</i>	(Optional) last action
<i>cfcFeatureSetLastActionResult</i>	(Optional) last action result
<i>cfcFeatureSetLastFailureReason</i>	(Optional) last failure reason
<i>cfcFeatureSetOpStatus</i>	(Optional) operation status
<i>cfcFeatureSetOpStatusReason</i>	(Optional) operation status

Command Mode

- /exec

show feature-set services

show feature-set services

```
show feature-set services <s0> [ __readonly__ [ { TABLE_services <service_name> } ] { <count> <feature_set> } ]
```

Syntax Description

show	Show running system information
feature-set	Show feature set status
services	Show services in feature set
__readonly__	(Optional)
TABLE_services	(Optional) all service names in feature set
service_name	(Optional) name of the service
count	(Optional) number of services in the feature set
feature_set	(Optional) feature set name
s0	Name of feature set

Command Mode

- /exec

show feature

```
show feature [ __readonly__ [ { TABLE_cfcFeatureCtrlTable <cfcFeatureCtrlIndex2>
<cfcFeatureCtrlInstanceNum2><cfcFeatureCtrlName2><cfcFeatureCtrlAction2><cfcFeatureCtrlLastAction2>
<cfcFeatureCtrlLastActionResult2> <cfcFeatureCtrlLastFailureReason2> <cfcFeatureCtrlOpStatus2>
<cfcFeatureCtrlOpStatusReason2> <cfcFeatureCtrlTag2> } ] ]
```

Syntax Description

show	Show running system information
feature	Show feature status
__readonly__	(Optional)
TABLE_cfcFeatureCtrlTable	(Optional) feature table
cfcFeatureCtrlIndex2	(Optional) feature table index
cfcFeatureCtrlInstanceNum2	(Optional) instance number
cfcFeatureCtrlName2	(Optional) feature name
cfcFeatureCtrlAction2	(Optional) Action to be triggered for the feature
cfcFeatureCtrlLastAction2	(Optional) Last action triggered for the feature
cfcFeatureCtrlLastActionResult2	(Optional) The result of execution of the last action
cfcFeatureCtrlLastFailureReason2	(Optional) Failure Reason
cfcFeatureCtrlOpStatus2	(Optional) operation status
cfcFeatureCtrlOpStatusReason2	(Optional) Reason for current operation status
cfcFeatureCtrlTag2	(Optional) Name of the instance in string format in case of multinstance feature

Command Mode

- /exec

show fex interface priority-flow-control

show fex interface priority-flow-control

```
show fex { <fexnum> interface | interface [ <if_list> ] } priority-flow-control [ detail ] [ __readonly__ [ TABLE_pfc_interface<if_name_str><admin><oper>[ <oper_vl_bmap> ] [ <cos-list> ] <rx-stats><tx-stats> [ <rx_ppp_cos_0> ] [ <rx_ppp_cos_1> ] [ <rx_ppp_cos_2> ] [ <rx_ppp_cos_3> ] [ <rx_ppp_cos_4> ] [ <rx_ppp_cos_5> ] [ <rx_ppp_cos_6> ] [ <rx_ppp_cos_7> ] [ <tx_ppp_cos_0> ] [ <tx_ppp_cos_1> ] [ <tx_ppp_cos_2> ] [ <tx_ppp_cos_3> ] [ <tx_ppp_cos_4> ] [ <tx_ppp_cos_5> ] [ <tx_ppp_cos_6> ] [ <tx_ppp_cos_7> ] ] ]
```

Syntax Description

show	commands to display
fex	Show FEX information
<i>fexnum</i>	FEX number
interface	Interface for displaying PFC information
<i>if_list</i>	(Optional) List of interfaces
priority-flow-control	Show interface PFC information
detail	(Optional) Show detailed per priority Tx/Rx PFC statistics
__readonly__	(Optional)
<i>if_name_str</i>	(Optional) interface name
TABLE_pfc_interface	(Optional) PFC information of an interface
<i>admin</i>	(Optional) PFC admin
<i>oper</i>	(Optional) PFC oper
<i>oper_vl_bmap</i>	(Optional) VL bitmap value
<i>cos-list</i>	(Optional) List of class-of-service values

Command Mode

- /exec

show fhrp

show fhrp [<intf>] [__readonly__ { TABLE_brief <intf_name> <intf_state> <ipv4_state> <ipv6_state> <hardware_status> <refcount> }]

Syntax Description

fhrp	FHRP Show commands
show	Show running system information
<i>intf</i>	(Optional) Specify a single interface
<u>__readonly__</u>	(Optional)
TABLE_brief	(Optional) Show brief FHRP interface information
<i>intf_name</i>	(Optional) Interface name
<i>intf_state</i>	(Optional) Interface state
<i>ipv4_state</i>	(Optional) Interface IPv4 state
<i>ipv6_state</i>	(Optional) Interface IPv6 state
<i>hardware_status</i>	(Optional) Interface hardware status
<i>refcount</i>	(Optional) Interface refcount

Command Mode

- /exec

show fhrp verbose

show fhrp verbose

```
show fhrp [ <intf> ] verbose [ __readonly__ { TABLE_det <intf_name> <handle> <refcount> { TABLE_clients <client_id> <client_name> } <running> <expired> <v_retries> <v_time> <r_delay> <min_delay> <remaining_delay> <i_state> <ipv4_state> <ipv6_state> <h_state> <int_l2> } ]
```

Syntax Description

fhrp	FHRP Show commands
show	Show running system information
<i>intf</i>	(Optional) Specify a single interface
verbose	Display detailed information
<u>__readonly__</u>	(Optional)
TABLE_det	(Optional) Detailed FHRP interface information
<i>intf_name</i>	(Optional) Interface name
<i>handle</i>	(Optional) Interface handle
<i>refcount</i>	(Optional) Reference count
TABLE_clients	(Optional) FHRP clients present on interface
<i>client_id</i>	(Optional) FHRP client id
<i>client_name</i>	(Optional) FHRP client name
<i>running</i>	(Optional) Time verify up timer running
<i>expired</i>	(Optional) Verify up timer has expired
<i>v_retries</i>	(Optional) Verify retries
<i>v_time</i>	(Optional) Verify remaining time
<i>r_delay</i>	(Optional) Reload delay
<i>min_delay</i>	(Optional) Min delay
<i>remaining_delay</i>	(Optional) Remaining delay
<i>i_state</i>	(Optional) Interface state
<i>ipv4_state</i>	(Optional) Interface IPv4 state
<i>ipv6_state</i>	(Optional) Interface IPv6 state
<i>h_state</i>	(Optional) Interface hardware state
<i>int_l2</i>	(Optional) Interface is L2-only

Command Mode

- /exec

show file

show file

```
show file <uri0> [ cksum | md5sum | sha256sum | sha512sum ] [ __readonly__ { [ <file_content> ] + [ <file_content_cksum> ] [ <file_content_md5sum> ] [ <file_content_sha256sum> ] [ <file_content_sha512sum> ] } ]
```

Syntax Description

show	Show running system information
file	Displays content of files
<i>uri0</i>	Filename to be displayed
cksum	(Optional) Displays CRC checksum for a file
md5sum	(Optional) Displays MD5 checksum for a file
sha256sum	(Optional) Displays SHA256 checksum for a file
sha512sum	(Optional) Displays SHA512 checksum for a file
<u>__readonly__</u>	(Optional) Read only
<i>file_content</i>	(Optional) uri file content buffer string
<i>file_content_cksum</i>	(Optional) uri file content checksum
<i>file_content_md5sum</i>	(Optional) uri file content md5sum
<i>file_content_sha256sum</i>	(Optional) uri file content sha256sum
<i>file_content_sha512sum</i>	(Optional) uri file content sha512sum

Command Mode

- /exec

show fips status

show fips status [__readonly__ { operation_status<o_status>} { mode_state<m_state>} [TABLE_sessions <lc_num> <lc_status>]]

Syntax Description

show	Show running system information
fips	Show if FIPS mode is enabled or disabled
status	Whether FIPS mode is enabled or disabled
__readonly__	(Optional)
operation_status	(Optional) run-time information about fips
<i>o_status</i>	(Optional) operational status of fips
mode_state	(Optional) mode state
<i>m_state</i>	(Optional) fips or non-fips state
TABLE_sessions	(Optional) all lc status
<i>lc_num</i>	(Optional) the lc number
<i>lc_status</i>	(Optional) the lc status

Command Mode

- /exec

show flogi auto-area-list

show flogi auto-area-list

show flogi auto-area-list

Syntax Description

show	Show running system information
flogi	Show information about FLOGI
auto-area-list	Show list of ouis that are allocated area.

Command Mode

- /exec

show flogi database

```
show flogi database [ { details | [ fcid <fcid0> ] [ details ] | [ interface <if0> ] [ details ] | [ vsan <i1> ] [ details ] } ]
```

Syntax Description

show	Show running system information
flogi	Show information about FLOGI
database	Show information about FLOGI sessions
details	(Optional) details: shows fcid allocation details
fcid	(Optional) fcid: enter the fcid to be matched
<i>fcid0</i>	(Optional) Enter fcid
details	(Optional) details: shows fcid allocation details
interface	(Optional) interface id: enter the interface id of the port
<i>if0</i>	(Optional) Enter interface id
details	(Optional) details: shows fcid allocation details
vsan	(Optional) vsan id:Enter the vsan number
<i>i1</i>	(Optional) Enter vsan
details	(Optional) details: shows fcid allocation details

Command Mode

- /exec

show flow cache

show flow cache

```
show flow cache [ ipv4 | ipv6 | ce ] [ __readonly__ TABLE_flow_cache <flow-type> <source-ip>
<destination-ip> <bridge-domain-id> <source-port> <destination-port> <protocol> <ipv6-flowlabel>
<byte-count> <packet-count> <tcp-flags> <tos> <if-id> <flow-start> <flow-end> <source-mac>
<destination-mac> <ether-type> ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
cache	Show NetFlow Exporter Cache
ipv4	(Optional) Show ipv4 cache entries
ipv6	(Optional) Show ipv6 cache entries
ce	(Optional) Show ce cache entries
<u>__readonly__</u>	(Optional)
TABLE_flow_cache	(Optional) The XML flow cache table
<i>flow-type</i>	(Optional) Flow type - v4,v6 or MAC
<i>source-ip</i>	(Optional) Source IP
<i>destination-ip</i>	(Optional) Destination IP
<i>bridge-domain-id</i>	(Optional) Bridge Domain ID
<i>source-port</i>	(Optional) Source Port
<i>destination-port</i>	(Optional) Destination Port
<i>protocol</i>	(Optional) Protocol
<i>ipv6-flowlabel</i>	(Optional) Ipv6 flowlabel
<i>byte-count</i>	(Optional) Byte Count
<i>packet-count</i>	(Optional) Packet Count
<i>tcp-flags</i>	(Optional) TCP Flags
<i>tos</i>	(Optional) TOS
<i>if-id</i>	(Optional) IF ID
<i>flow-start</i>	(Optional) Flow Start Time
<i>flow-end</i>	(Optional) Flow End Time

<i>source-mac</i>	(Optional) Source MAC
<i>destination-mac</i>	(Optional) Destination MAC
<i>ether-type</i>	(Optional) Ether Type

Command Mode

- /exec

show flow cache

show flow cache

```
show flow cache [ ipv4 | ipv6 | ce ] [ __readonly__ [ { TABLE_flow_cache <flow-cache-index> [ <flow-type> ]
] [ <source-ip> ] [ <destination-ip> ] [ <source-mac> ] [ <destination-mac> ] [ <bridge-domain-id> ] [
<ether-type> ] [ <source-port> ] [ <destination-port> ] [ <protocol> ] [ <ipv6-flowlabel> ] [ <byte-count> ]
[ <packet-count> ] [ <tcp-flags> ] [ <tos> ] [ <if-id> ] [ <output-if-id> ] [ <flow-start> ] [ <flow-end> ] [
<profile> ] } ] ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
cache	Show NetFlow Exporter Cache
ipv4	(Optional) Show ipv4 cache entries
ipv6	(Optional) Show ipv6 cache entries
ce	(Optional) Show ce cache entries
__readonly__	(Optional)
TABLE_flow_cache	(Optional) The XML flow cache table
<i>flow-cache-index</i>	(Optional) Flow Index
<i>flow-type</i>	(Optional) Flow type - v4,v6 or MAC
<i>source-ip</i>	(Optional) Source IP
<i>destination-ip</i>	(Optional) Destination IP
<i>source-mac</i>	(Optional) Source MAC
<i>destination-mac</i>	(Optional) Destination MAC
<i>bridge-domain-id</i>	(Optional) Bridge Domain ID
<i>ether-type</i>	(Optional) Ether Type
<i>source-port</i>	(Optional) Source Port
<i>destination-port</i>	(Optional) Destination Port
<i>protocol</i>	(Optional) Protocol
<i>ipv6-flowlabel</i>	(Optional) Ipv6 flowlabel
<i>byte-count</i>	(Optional) Byte Count
<i>packet-count</i>	(Optional) Packet Count
<i>tcp-flags</i>	(Optional) TCP Flags

<i>tos</i>	(Optional) TOS
<i>if-id</i>	(Optional) IF ID
<i>output-if-id</i>	(Optional) OUTPUT IF ID
<i>flow-start</i>	(Optional) Flow Start Time
<i>flow-end</i>	(Optional) Flow End Time
<i>profile</i>	(Optional) Profile

Command Mode

- /exec

show flow event

show flow event

```
show flow event [ name ] [ { <eventname> } ] [ __readonly__ [ { TABLE_nfm_event <event> [ <description> ] <use_count> [ { TABLE_nfm_group <events> [ <buffer_drops> ] [ <fwd_drops> ] [ <acl_drops> ] [ <flow_count> ] [ <latency_threshold> ] [ <latency_unit> ] [ <latency_flow_count> ] [ <recv_window_zero> ] [ <ip_df> ] [ <tos_value> ] [ <ttl_value> ] [ <max_burst_value> ] } } ] ] ]
```

Syntax Description

show	Show running system information
flow	Show Analytics information
event	Show Event Configuration
name	(Optional) Show the configuration for a specific Event
<i>eventname</i>	(Optional) Specify a event
<u>__readonly__</u>	(Optional)
TABLE_nfm_event	(Optional) Event Table
<i>event</i>	(Optional) Analytics event
<i>description</i>	(Optional) Description of Analytics event
<i>use_count</i>	(Optional) Use count of Analytics event
TABLE_nfm_group	(Optional)
<i>events</i>	(Optional) Drop or Latency type of events
<i>buffer_drops</i>	(Optional) Capture buffer-drops
<i>fwd_drops</i>	(Optional) Capture fwd-drops
<i>acl_drops</i>	(Optional) Capture acl-drops
<i>flow_count</i>	(Optional) Drop type flow count
<i>latency_threshold</i>	(Optional) Latency threshold value
<i>latency_unit</i>	(Optional) Unit for latency threshold measurement
<i>latency_flow_count</i>	(Optional) Latency type flow count
<i>recv_window_zero</i>	(Optional) Capture Receive Window Zero events
<i>ip_df</i>	(Optional) Capture IpDf events
<i>tos_value</i>	(Optional) Type of Service value
<i>ttl_value</i>	(Optional) Time To Live value

<i>max_burst_value</i>	(Optional) Max Burst value
------------------------	----------------------------

Command Mode

- /exec

show flow exporter

show flow exporter

```
show flow exporter [ name ] [ <exporter> ] [ __readonly__ { TABLE_flow_exporter <exporter> [ <description> ] [ <dest_intf> ] [ <dest> ] [ <vrf> ] [ <vrf_id> ] [ <vrf_resolved> ] [ <dest_udp> ] [ <events_dest_udp> ] [ <source_intf> ] [ <source_ip> ] [ <dscp> ] [ <exp_vers> ] [ <seqnum> ] [ <samp_table_to> ] [ <if_table_to> ] [ <stats_to> ] [ <temp_to> ] [ <rec_sent> ] [ <temp_sent> ] [ <pkts_sent> ] [ <bytes_sent> ] [ <dest_unreach> ] [ <buff_events> ] [ <pkts_drop_no_route> ] [ <pkts_drop_other> ] [ <pkts_drop_lc_rp> ] [ <pkts_drop_op_drops> ] [ <time_last_cleared> ] } ] }
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
exporter	Show NetFlow Exporter Configuration and Statistics
name	(Optional) Show a specific Flow Exporter
<i>exporter</i>	(Optional) Specify an exporter
<u>__readonly__</u>	(Optional)
TABLE_flow_exporter	(Optional)
<i>exporter</i>	(Optional)
<i>description</i>	(Optional)
<i>dest_intf</i>	(Optional)
<i>dest</i>	(Optional)
<i>vrf</i>	(Optional)
<i>vrf_id</i>	(Optional)
<i>vrf_resolved</i>	(Optional)
<i>dest_udp</i>	(Optional)
<i>events_dest_udp</i>	(Optional)
<i>source_intf</i>	(Optional)
<i>source_ip</i>	(Optional)
<i>dscp</i>	(Optional)
<i>seqnum</i>	(Optional)
<i>exp_vers</i>	(Optional)
<i>samp_table_to</i>	(Optional)

<i>if_table_to</i>	(Optional)
<i>stats_to</i>	(Optional)
<i>temp_to</i>	(Optional)
<i>rec_sent</i>	(Optional)
<i>temp_sent</i>	(Optional)
<i>pkts_sent</i>	(Optional)
<i>bytes_sent</i>	(Optional)
<i>dest_unreach</i>	(Optional)
<i>buff_events</i>	(Optional)
<i>pkts_drop_no_route</i>	(Optional)
<i>pkts_drop_other</i>	(Optional)
<i>pkts_drop_lc_rp</i>	(Optional)
<i>pkts_drop_op_drops</i>	(Optional)
<i>time_last_cleared</i>	(Optional)

Command Mode

- /exec

show flow filter

show flow filter

show flow filter [__readonly__ [{ TABLE_flow_filter <name> <ipv4acl> <ipv6acl> }]]

Syntax Description

show	Show running system information
flow	Show Analytics information
filter	Show filter Configuration
__readonly__	(Optional)
TABLE_flow_filter	(Optional) flow filter data
<i>name</i>	(Optional) Filter Name
<i>ipv4acl</i>	(Optional) IPv4 ACL
<i>ipv6acl</i>	(Optional) IPv6 ACL

Command Mode

- /exec

show flow interface

```
show flow { interface [ <intf> ] | vlan [ <vlan> ] } [ __readonly__ [ { TABLE_flow_interface [ <intf_name> ] [ <vlan_id> ] [ <filter> ] [ <v4in_mon_name> ] [ <v4in_direction> ] [ <v4in_profile_id> ] [ <v6in_mon_name> ] [ <v6in_direction> ] [ <v6in_profile_id> ] [ <l2in_mon_name> ] [ <l2in_direction> ] [ <l2in_profile_id> ] } ] ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
interface	Flow interface information
<i>intf</i>	(Optional) Interface
vlan	Flow vlan information
<i>vlan</i>	(Optional) Vlan number
__readonly__	(Optional)
TABLE_flow_interface	(Optional) flow interface data
<i>intf_name</i>	(Optional) Interface
<i>vlan_id</i>	(Optional) VLAN ID
<i>filter</i>	(Optional) Filter name
<i>v4in_mon_name</i>	(Optional) IPv4 Input monitor name
<i>v4in_direction</i>	(Optional) IPv4 Input direction
<i>v4in_profile_id</i>	(Optional) IPv4 Input profile id
<i>v6in_mon_name</i>	(Optional) IPv6 Input monitor name
<i>v6in_direction</i>	(Optional) IPv6 Input direction
<i>v6in_profile_id</i>	(Optional) IPv6 Input profile id
<i>l2in_mon_name</i>	(Optional) l2 Input monitor name
<i>l2in_direction</i>	(Optional) l2 Input direction
<i>l2in_profile_id</i>	(Optional) l2 Input profile id

Command Mode

- /exec

show flow monitor

show flow monitor

```
show flow monitor [ name ] [ <monitor> [ cache [ detailed ] ] ] [ __readonly__ [ { TABLE_flow_monitor
<monitor> [ <description> ] <use_count> [ <record> ] [ <bucket_id> ] [ <exporter1> ] [ <exporter2> ] [
<src_addr> ] [ <dest_addr> ] [ <direction> ] [ <pkt_count> ] [ <byte_count> ] } ] ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
monitor	Show Monitor Configuration
name	(Optional) Show a specific Flow Monitor
<i>monitor</i>	(Optional) Specify a monitor
cache	(Optional) Flow monitor cache contents
detailed	(Optional) Show the entire cache contents
<u>readonly</u>	(Optional)
TABLE_flow_monitor	(Optional)
<i>monitor</i>	(Optional)
<i>use_count</i>	(Optional)
<i>description</i>	(Optional)
<i>record</i>	(Optional)
<i>exporter1</i>	(Optional)
<i>exporter2</i>	(Optional)
<i>bucket_id</i>	(Optional)
<i>src_addr</i>	(Optional)
<i>dest_addr</i>	(Optional)
<i>direction</i>	(Optional)
<i>pkt_count</i>	(Optional)
<i>byte_count</i>	(Optional)

Command Mode

- /exec

show flow profile

```
show flow profile [<profile>] [ __readonly__ [ { TABLE_flow_profile <name> [ <desc> ] <number-of-users>
<export-intvl> <source-port> <packet-id-shift> <burst-intvl-shift> <mtu> [ <guess-threshold-lo> ] [
<guess-threshold-hi> ] [ { TABLE_payload_bin <payload-bin-num> <payload-bin-lo> <payload-bin-hi> } ]
[ { TABLE_tcpopthdr_bin <tcpopthdr-bin-num> <tcpopthdr-bin-lo> <tcpopthdr-bin-hi> } ] [ {
TABLE_rcvwinsize_bin <rcvwinsize-bin-num> <rcvwinsize-bin-lo> <rcvwinsize-bin-hi> } ] } ] ]
```

Syntax Description

show	Show running system information
flow	Show Analytics information
profile	Show profile Configuration
<i>profile</i>	(Optional) Specify a profile
<i>__readonly__</i>	(Optional)
TABLE_flow_profile	(Optional) HW flow profile
<i>name</i>	(Optional) HW profile name
<i>desc</i>	(Optional) Description of HW profile
<i>number-of-users</i>	(Optional) No. of users
<i>export-intvl</i>	(Optional) Export Interval
<i>source-port</i>	(Optional) Source Port
<i>packet-id-shift</i>	(Optional) IP Packet ID Shift
<i>burst-intvl-shift</i>	(Optional) Burst Interval Shift
<i>mtu</i>	(Optional) MTU
<i>guess-threshold-lo</i>	(Optional) Sequence Number Guess Threshold Lo
<i>guess-threshold-hi</i>	(Optional) Sequence Number Guess Threshold Hi
TABLE_payload_bin	(Optional) Payload Bin
<i>payload-bin-num</i>	(Optional) Bin Number
<i>payload-bin-lo</i>	(Optional) Bin Lo
<i>payload-bin-hi</i>	(Optional) Bin Hi
TABLE_tcpopthdr_bin	(Optional) TCP Opt Hdr Bin
<i>tcpopthdr-bin-num</i>	(Optional) Bin Number
<i>tcpopthdr-bin-lo</i>	(Optional) Bin Lo

show flow profile

<i>tcpophdr-bin-hi</i>	(Optional) Bin Hi
TABLE_rcvwinSize_bin	(Optional) Receive Windows Size Bin
<i>rcvwinSize-bin-num</i>	(Optional) Bin Number
<i>rcvwinSize-bin-lo</i>	(Optional) Bin Lo
<i>rcvwinSize-bin-hi</i>	(Optional) Bin Hi

Command Mode

- /exec

show flow record

```
show flow record [ name ] [ { <record> } | { netflow-original } | { netflow { protocol-port | layer2-switched
{ input } | { ipv4 | ipv6 | l2 } { original-input } } } ] [ __readonly__ [ { TABLE_flow_record <record>
[ <description> ] <use_count> <template> [ <match_ip_src> ] [ <match_ip_dst> ] [ <match_proto> ] [
<match_tos> ] [ <match_l4_src> ] [ <match_l4_dst> ] [ <match_ingress> ] [ <match_egress> ] [
<match_src_as_peer> ] [ <match_dst_as_peer> ] [ <match_ipv6_src> ] [ <match_ipv6_dst> ] [
<match_ipv6_flow> ] [ <match_ipv6_option> ] [ <match_ipv6_traffic> ] [ <match_l2_src> ] [ <match_l2_dst>
] [ <match_l2_src_vlan> ] [ <match_l2_dst_vlan> ] [ <match_l2_1q> ] [ <match_l2_cos> ] [ <match_l2_etype>
] [ <match_flow_dir_match> ] [ <match_ipv4v6_src> ] [ <match_ipv4v6_dst> ] [ <collect_src_as> ] [
<collect_dst_as> ] [ <collect_src_as_peer> ] [ <collect_dst_as_peer> ] [ <collect_fwd_status> ] [
<collect_ipv4_next_hop> ] [ <collect_ipv4_bgp_next> ] [ <collect_ipv6_next_hop> ] [
<collect_ipv6_bgp_next> ] [ <collect_tcp_flags> ] [ <collect_flow_dir> ] [ <collect_bytes> ] [
<collect_bytes_long> ] [ <collect_packets> ] [ <collect_packets_long> ] [ <collect_time_first> ] [
<collect_time_last> ] [ <collect_ingress_coll> ] [ <collect_egress_coll> ] [ <collect_sampler_id> ] [
<collect_ip_ver> ] [ <collect_packet_disp> ] } ] ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
record	Show Record Configuration
name	(Optional) Show the configuration for a specific Flow Record
<i>record</i>	(Optional) Specify a record
netflow-original	(Optional) Traditional IPv4 input NetFlow with origin ASs
netflow	(Optional) Traditional NetFlow collection schemes
ipv4	(Optional) IPv4 collection schemes
ipv6	(Optional) IPv6 collection schemes
l2	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
layer2-switched	(Optional) Layer2-Switched collection schemes
original-input	(Optional) Input NetFlow
input	(Optional) Input NetFlow
protocol-port	(Optional) Protocol and Ports aggregation scheme
__readonly__	(Optional)
TABLE_flow_record	(Optional) flow record data
<i>record</i>	(Optional)
<i>description</i>	(Optional)

show flow record

<i>use_count</i>	(Optional)
<i>template</i>	(Optional)
<i>match_ip_src</i>	(Optional)
<i>match_ip_dst</i>	(Optional)
<i>match_proto</i>	(Optional)
<i>match_tos</i>	(Optional)
<i>match_l4_src</i>	(Optional)
<i>match_l4_dst</i>	(Optional)
<i>match_ingress</i>	(Optional)
<i>match_egress</i>	(Optional)
<i>match_src_as_peer</i>	(Optional)
<i>match_dst_as_peer</i>	(Optional)
<i>match_ipv6_src</i>	(Optional)
<i>match_ipv6_dst</i>	(Optional)
<i>match_ipv6_flow</i>	(Optional)
<i>match_ipv6_option</i>	(Optional)
<i>match_ipv6_traffic</i>	(Optional)
<i>match_l2_src</i>	(Optional)
<i>match_l2_dst</i>	(Optional)
<i>match_l2_src_vlan</i>	(Optional)
<i>match_l2_dst_vlan</i>	(Optional)
<i>match_l2_lq</i>	(Optional)
<i>match_l2_cos</i>	(Optional)
<i>match_l2_etype</i>	(Optional)
<i>match_flow_dir_match</i>	(Optional)
<i>match_ipv4v6_src</i>	(Optional)
<i>match_ipv4v6_dst</i>	(Optional)
<i>collect_src_as</i>	(Optional)
<i>collect_dst_as</i>	(Optional)

<i>collect_src_as_peer</i>	(Optional)
<i>collect_dst_as_peer</i>	(Optional)
<i>collect_fwd_status</i>	(Optional)
<i>collect_ipv4_next_hop</i>	(Optional)
<i>collect_ipv4_bgp_next</i>	(Optional)
<i>collect_ipv6_next_hop</i>	(Optional)
<i>collect_ipv6_bgp_next</i>	(Optional)
<i>collect_tcp_flags</i>	(Optional)
<i>collect_flow_dir</i>	(Optional)
<i>collect_bytes</i>	(Optional)
<i>collect_bytes_long</i>	(Optional)
<i>collect_packets</i>	(Optional)
<i>collect_packets_long</i>	(Optional)
<i>collect_time_first</i>	(Optional)
<i>collect_time_last</i>	(Optional)
<i>collect_ingress_coll</i>	(Optional)
<i>collect_egress_coll</i>	(Optional)
<i>collect_sampler_id</i>	(Optional)
<i>collect_ip_ver</i>	(Optional)
<i>collect_packet_disp</i>	(Optional)

Command Mode

- /exec

show flow rtp

show flow rtp

```
show flow rtp { errors { active | history } | details } [ ipv4 | ipv6 ] [ __readonly__ [ <flow-timeout> ] [ {
    TABLE_flow_rtp <flow-rtp-index> [ <flow-type> ] [ <source-ip> ] [ <destination-ip> ] [ <bridge-domain-id>
    ] [ <source-port> ] [ <destination-port> ] [ <protocol> ] [ <packet-count> ] [ <bytes-per-sec> ] [ <bits-per-sec>
    ] [ <start-time> ] [ <if-name> ] [ <vrf-name> ] [ { TABLE_flow_rtp_errors <loss-start> [ <loss-end> ] [
        <packet-loss> ] } ] } ] ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
rtp	Real-time Transport Protocol
errors	Show NetFlow RTP flows error information
active	Show RTP flows with active losses
history	Show RTP flows with loss history
details	Show NetFlow RTP detailed information
ipv4	(Optional) Show ipv4 RTP entries
ipv6	(Optional) Show ipv6 RTP entries
__readonly__	(Optional)
TABLE_flow_rtp	(Optional) The XML flow rtp table
flow-timeout	(Optional) Flow Timeout
flow-rtp-index	(Optional) Flow RTP Index
flow-type	(Optional) Flow type - v4,v6
source-ip	(Optional) Source IP
destination-ip	(Optional) Destination IP
bridge-domain-id	(Optional) Bridge Domain ID
source-port	(Optional) Source Port
destination-port	(Optional) Destination Port
protocol	(Optional) Protocol
packet-count	(Optional) Packet Count
bytes-per-sec	(Optional) Bytes Per Second
bits-per-sec	(Optional) Bits Per Second

<i>start-time</i>	(Optional) Flow Start Time
<i>if-name</i>	(Optional) IF/Vlan
<i>vrf-name</i>	(Optional) VRF
TABLE_flow_rtp_errors	(Optional) The XML flow rtp errors table
<i>loss-start</i>	(Optional) Loss Start Time
<i>loss-end</i>	(Optional) Loss End Time
<i>packet-loss</i>	(Optional) Packet loss

Command Mode

- /exec

show flow rtp timeout

show flow rtp timeout

show flow rtp timeout [__readonly__ { <flush_cache_to> }]

Syntax Description

show	Show running system information
flow	Show NetFlow information
rtp	Real-time Transport Protocol
timeout	Show NetFlow RTP flow error monitoring timeout values
<u>__readonly__</u>	(Optional)
<i>flush_cache_to</i>	(Optional)

Command Mode

- /exec

show flow system

```
show flow system [ __readonly__ <system_exporter_id> [ <switch_latency> ] [ { TABLE_flow_interface [ <intf_name> ] [ <exporter_id> ] [ <profile_name> ] [ <v4in_mon_name> ] [ <v4in_direction> ] [ <v6in_mon_name> ] [ <v6in_direction> ] [ <filter_name> ] [ <event_name> ] [ <ipv4_hit> ] [ <ipv4_create> ] [ <ipv6_hit> ] [ <ipv6_create> ] [ <ce_hit> ] [ <ce_create> ] [ <packets_seen> ] [ <skip_collect> ] [ <export_count> ] } ] ]
```

Syntax Description

show	Show running system information
flow	Show Analytics information
system	Show system Configuration
<u>__readonly__</u>	(Optional)
<i>system_exporter_id</i>	(Optional) System Exporter ID
<i>switch_latency</i>	(Optional) System Switch Latency Enabled
TABLE_flow_interface	(Optional) flow interface data
<i>intf_name</i>	(Optional) Interface
<i>exporter_id</i>	(Optional) Exporter ID
<i>profile_name</i>	(Optional) HW Profile Name
<i>v4in_mon_name</i>	(Optional) IPv4 Input monitor name
<i>v4in_direction</i>	(Optional) IPv4 Input direction
<i>v6in_mon_name</i>	(Optional) IPv6 Input monitor name
<i>v6in_direction</i>	(Optional) IPv6 Input direction
<i>filter_name</i>	(Optional) User Filter Name
<i>event_name</i>	(Optional) User Event name
<i>ipv4_hit</i>	(Optional) Number of packets that hit an Ipv4 hash entry
<i>ipv4_create</i>	(Optional) Number of packets that created a new Ipv4 hash entry
<i>ipv6_hit</i>	(Optional) Number of packets that hit an Ipv6 hash entry
<i>ipv6_create</i>	(Optional) Number of packets that created a new Ipv6 hash entry
<i>ce_hit</i>	(Optional) Number of packets that hit an ce hash entry
<i>ce_create</i>	(Optional) Number of packets that created a new ce hash entry
<i>packets_seen</i>	(Optional) Number of packets seen

show flow system

<i>skip_collect</i>	(Optional) Number of packets that skipped the analytics collect
<i>export_count</i>	(Optional) Number of Analytics packets exported

Command Mode

- /exec

show flow timeout

```
show flow timeout [ __readonly__ [ <active_to> ] [ <inactive_to> ] [ <fast_to> ] [ <th_pkts> ] [ <agg_age_to> ] <flush_cache_to> ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
timeout	Show NetFlow flow cache timeout values
<u>__readonly__</u>	(Optional)
<i>active_to</i>	(Optional)
<i>inactive_to</i>	(Optional)
<i>fast_to</i>	(Optional)
<i>th_pkts</i>	(Optional)
<i>agg_age_to</i>	(Optional)
<i>flush_cache_to</i>	(Optional)

Command Mode

- /exec

show flow tracer

show flow tracer

```
show flow tracer [ __readonly__ [ { TABLE_flow_tracer <flow-tracer-index> [ <source-ip> ] [ <destination-ip> ]
] [ <bridge-domain-id> ] [ <source-port> ] [ <destination-port> ] [ <protocol> ] [ <packet-count> ] [ <if-name>
] [ <fwd-drop> ] [ <rpf-fail> ] [ <policing-drop> ] [ <ids-drop> ] [ <policy-drop> ] [ <buffer-drop> ] } ] ]
```

Syntax Description

show	Show running system information
flow	Show NetFlow information
tracer	Show packet tracer information
<u>__readonly__</u>	(Optional)
TABLE_flow_tracer	(Optional)
<i>flow-tracer-index</i>	(Optional) Flow Index
<i>source-ip</i>	(Optional) Source IP
<i>destination-ip</i>	(Optional) Destination IP
<i>bridge-domain-id</i>	(Optional) Bridge Domain ID
<i>source-port</i>	(Optional) Source Port
<i>destination-port</i>	(Optional) Destination Port
<i>protocol</i>	(Optional) Protocol
<i>packet-count</i>	(Optional) Packet Count
<i>if-name</i>	(Optional) Ingress Interface
<i>fwd-drop</i>	(Optional) Fowarding Drops
<i>rpf-fail</i>	(Optional) RPF Port Sec Failures
<i>policing-drop</i>	(Optional) Policing Drops
<i>ids-drop</i>	(Optional) Ids Drops
<i>policy-drop</i>	(Optional) ACL Drops
<i>buffer-drop</i>	(Optional) Buffer Drops

Command Mode

- /exec

show flow vrf

```
show flow vrf [ <vrf_name> ] [ __readonly__ [ { TABLE_flow_vrf [ <vrf_name> ] [ <v4in_mon_name> ] [ <v4in_direction> ] [ <v6in_mon_name> ] [ <v6in_direction> ] [ <filter_name> ] } ] ]
```

Syntax Description

show	Show running system information
flow	Show Analytics information
vrf	Show VRF Configuration
<i>vrf_name</i>	(Optional) Specify a vrf
<u>__readonly__</u>	(Optional)
TABLE_flow_vrf	(Optional) flow vrf data
<i>vrf_name</i>	(Optional) VRF name
<i>v4in_mon_name</i>	(Optional) IPv4 Input monitor name
<i>v4in_direction</i>	(Optional) IPv4 Input direction
<i>v6in_mon_name</i>	(Optional) IPv6 Input monitor name
<i>v6in_direction</i>	(Optional) IPv6 Input direction
<i>filter_name</i>	(Optional) User Filter Name

Command Mode

- /exec

show forwarding

show forwarding

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | table <table_id> ] [ ipv4 ] [ route | rnadb ] [ recursive ] [ summary | [ [ detail | platform | partial | ipsg ] [ max-display-count <display_count> ] ] | [ <prefix> [ longer-prefixes ] [ detail | platform ] | <address> [ detail | platform ] ] |
```

Syntax Description

show	
forwarding	display fib information
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
table	(Optional) display info per vpn-id
<i>table_id</i>	(Optional) table id in hex
ipv4	(Optional) ipv4
route	(Optional) display IP routing table
ipsg	(Optional) display IPv4 IPSG routes
rnadb	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
recursive	(Optional) display routes with recursive next hops
partial	(Optional) display routes with partial ECMPs
summary	(Optional) display route counts
<i>prefix</i>	(Optional) display single exact match route
longer-prefixes	(Optional) display longer prefixes
<i>address</i>	(Optional) display single longest match route
detail	(Optional) show detailed information about the routes
platform	(Optional) one command to show pi and pd info together
max-display-count	(Optional) displays max # of routes
<i>display_count</i>	(Optional) count

Command Mode

- /exec

show forwarding adjacency

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] [ ipv4 ] adjacency [ mpls ] [ lisp ] [ nve ] [ <aif> ] [ <anh> ] [ detail | stats | platform ] [ module <module> ] [ __readonly__ [ <adj-count> ] [ TABLE_adj { [ <fec> ] [ <nexthop> ] [ <intf> ] [ <rewinfo> ] [ <interface> ] [ <bgp_rnh> ] [ <bgp_orig_as> ] [ <bgp_peer_as> ] [ <pkts> ] [ <bytes> ] [ <exp> ] [ <src_addr> ] [ <dest_addr> ] [ <lisp_flags> ] [ <lisp_inst_id> ] [ <pltfm_key> ] [ <hh> ] [ <refcount> ] } ] [ TABLE_ip_adjacency { [ <nh> ] [ <rwinfo> ] [ <intf> ] [ <intf_idx> ] [ <hhandle> ] [ <refcnt> ] [ <flags> ] [ <holder> ] [ <pbr_cnt> ] [ <wccp_cnt> ] [ <rewrite-p> ] [ TABLE_index { [ <hw_adj> ] [ <cmn-idx> ] [ <lif> ] [ <buf-idx> ] } ] } ] ]
```

Syntax Description

show	
forwarding	display fib information
ipv4	(Optional) ipv4
adjacency	display adjacency information
platform	(Optional) one command to show pi and pd info together
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
mpls	(Optional) mpls adjacency information
lisp	(Optional) LISP adjacency information
nve	(Optional) VxLAN tunnel adjacency information
<i>aif</i>	(Optional) adjacency output interface
<i>anh</i>	(Optional) adjacency next hop
detail	(Optional) detail
stats	(Optional) adjacency statistics
module	(Optional) slot
<i>module</i>	(Optional) slot number
__readonly__	(Optional)
<i>adj-count</i>	(Optional) total adj count
TABLE_adj	(Optional) Table Adjacency
<i>fec</i>	(Optional) FEC info

show forwarding adjacency

<i>nexthop</i>	(Optional) next hop address
<i>intf</i>	(Optional) output interface
<i>rewinfo</i>	(Optional) rewrite information
<i>interface</i>	(Optional) output interface
<i>bgp_rnh</i>	(Optional) next hop address
<i>bgp_orig_as</i>	(Optional) bgp orig as
<i>bgp_peer_as</i>	(Optional) bgp peer as
<i>exp</i>	(Optional) exp mapping
<i>pkts</i>	(Optional) packet stats
<i>bytes</i>	(Optional) bytes stats
<i>src_addr</i>	(Optional) src address
<i>dest_addr</i>	(Optional) dest address
<i>lisp_flags</i>	(Optional) lisp flags
<i>lisp_inst_id</i>	(Optional) lisp instance id
<i>pltfm_key</i>	(Optional) platform key
<i>hh</i>	(Optional) Hardware Handle
<i>refcount</i>	(Optional) reference count
TABLE_ip_adjacency	(Optional) Table ip adjacency
<i>nh</i>	(Optional) next hop address
<i>rwinfo</i>	(Optional) rewrite information
<i>intf</i>	(Optional) output interface
<i>intf_idx</i>	(Optional) Interface index
<i>hhandle</i>	(Optional) Hw Handle
<i>refcnt</i>	(Optional) reference count
<i>flags</i>	(Optional) Adjacency flags
<i>holder</i>	(Optional) Holder bitmap
<i>pbr_cnt</i>	(Optional) PBR count
<i>wccp_cnt</i>	(Optional) WCCP count
<i>rewrite-p</i>	(Optional) Rewrite pointer

TABLE_index	(Optional) HW index table
<i>hw-adj</i>	(Optional) v4 adj hw index
<i>cmn-idx</i>	(Optional) CMN Index
<i>lif</i>	(Optional) LIF
<i>buf-idx</i>	(Optional) Buffer index

Command Mode

- /exec

show forwarding consistency-fretta l2

show forwarding consistency-fretta l2

show forwarding consistency-fretta l2 <module>

Syntax Description

show	Show running system information
forwarding	Forwarding information
consistency-fretta	consistency
l2	Verify l2 mac programming in the hardware
<i>module</i>	Enter module number

Command Mode

- /exec

show forwarding distribution clients

show forwarding distribution clients [__readonly__ <id><pid><name><shms><shme><shmn>]

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	fib distribution info
clients	unicast client information
__readonly__	(Optional)

Command Mode

- /exec

show forwarding distribution evpn storm-control

show forwarding distribution evpn storm-control

```
show forwarding distribution evpn storm-control [ __readonly__ <header> [ TABLE_storm_control_level
<type> <status> <level> ] [ TABLE_interface_bandwidth <interface> <type> <bandwidth> ] [
TABLE_total_bandwidth <type> <bandwidth> ] ]
```

Syntax Description

show	Show running system information
forwarding	forwarding information
distribution	fib distribution info
evpn	evpn distribution info
storm-control	storm-control information
<u>__readonly__</u>	(Optional)
<i>header</i>	(Optional) Header
TABLE_storm_control_level	(Optional) Table storm control level
<i>type</i>	(Optional) Traffic type
<i>status</i>	(Optional) Status
<i>level</i>	(Optional) Level
TABLE_interface_bandwidth	(Optional) Table interface bandwidth
<i>interface</i>	(Optional) Interface
<i>type</i>	(Optional) Type
<i>bandwidth</i>	(Optional) Bandwidth
TABLE_total_bandwidth	(Optional) Table total bandwidth
<i>type</i>	(Optional) Type
<i>bandwidth</i>	(Optional) Bandwidth

Command Mode

- /exec

show forwarding distribution fib-state

```
show forwarding distribution fib-state [ __readonly__ <slot> <state><ttc><tprc><tv4ac><tv6ac> {  
    TABLE_fib_state <tid><tafi><prc><pc><tname> } ]
```

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	fib distribution info
fib-state	unicast fib state info
__readonly__	(Optional)
<i>slot</i>	(Optional) slot number
TABLE_fib_state	(Optional) fib-state table

Command Mode

- /exec

show forwarding distribution ip igmp snooping

show forwarding distribution ip igmp snooping

show forwarding distribution ip igmp snooping [vlan <vlan-id> [group [<grpaddr> | <mac-grpaddr>] [source <srcaddr>]] [detail] [__readonly__ <refcount> <oiflist_id> <last_oiflist_id> <ftag-id>]]

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
ip	IPV4 information
igmp	MFDM IGMP information
snooping	L2 mcast snooping related information
vlan	(Optional) Info specific to a vlan
<i>vlan-id</i>	(Optional) Vlan id value
group	(Optional) Group specific information
<i>grpaddr</i>	(Optional) Group address
<i>mac-grpaddr</i>	(Optional) Group MAC address
source	(Optional) (G,S) specific information
<i>srcaddr</i>	(Optional) Source address
detail	(Optional) Detailed display
<u>__readonly__</u>	(Optional)
<i>refcount</i>	(Optional) Reference Count
<i>oiflist_id</i>	(Optional) OIF list Identifier
<i>last_oiflist_id</i>	(Optional) Last OIF list Identifier
<i>ftag-id</i>	(Optional) ftag Id

Command Mode

- /exec

show forwarding distribution ipv6 multicast route

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	display fib distribution information
ipv6	IPV6 related information
multicast	display IPv6 multicast information
route	display routing table
vrf	(Optional) display routes for a specific VRF
<i>vrf-name</i>	(Optional) VRF name
all	(Optional) Display information for all VRFs
table	(Optional) table
<i>table_id</i>	(Optional) table number
group	(Optional) Multicast IPv6 Group Address
source	(Optional) Multicast IPv6 Source Address
summary	(Optional) display route counts
<u>__readonly__</u>	(Optional)
TABLE_vrf	(Optional)
<i>vrf-name</i>	(Optional)
<i>table-name</i>	(Optional)
<i>table-id</i>	(Optional)
<i>total-num-groups</i>	(Optional)
TABLE_route_summary	(Optional)
<i>total-num-routes</i>	(Optional)

show forwarding distribution ipv6 multicast route

<i>num-star-g-route</i>	(Optional)
<i>num-sg-route</i>	(Optional)
<i>num-star-g-prfx</i>	(Optional)
<i>num-group-count</i>	(Optional)
TABLE_one_route	(Optional)
<i>source-addrs</i>	(Optional)
<i>source-len</i>	(Optional)
<i>group-addrs</i>	(Optional)
<i>group-len</i>	(Optional)
<i>df-ordinal</i>	(Optional)
<i>rpf-intf</i>	(Optional)
<i>flags</i>	(Optional)
<i>stats-pkts</i>	(Optional)
<i>stats-bytes</i>	(Optional)
<i>oif-count</i>	(Optional)
<i>oiflist-index</i>	(Optional)
TABLE_oif	(Optional)
<i>oif-name</i>	(Optional)
<i>mti-src-intf</i>	(Optional)
<i>mti-grp-ip</i>	(Optional)
<i>mti-src-ip</i>	(Optional)

Command Mode

- /exec

show forwarding distribution l2 multicast

```
show forwarding distribution l2 multicast [ ip-based | mac-based ] [ [ vni <vni-id> ] | [ vlan <vlan-id> [ { group { <grpaddr> | <v6grpaddr> } [ source { <srcaddr> | <v6srcaddr> } ] } | destination-mac <dmac> ] ] [ summary ] [ __readonly__ [ TABLE_sum [ <mode> ] [ <num_vlan> ] [ <num_starg> ] [ <num_sg> ] [ <num_aggstarg> ] [ TABLE_sum_info [ <ftag_id> ] [ <vlan_id> ] [ <routeable_flag> ] [ <v6_routable_flag> ] [ <num_starg> ] [ <num_sg> ] [ <num_aggstarg> ] [ <total_route> ] ] ] [ TABLE_route [ <vlan> ] [ <grp_str> ] [ <v6grp_str> ] [ <src_str> ] [ <v6src_str> ] [ <grp_mac> ] [ <src_mac> ] [ TABLE_oif [ <oiflist_id> ] [ <refcount> ] [ <l3_usage> ] [ <plt_index> ] [ <num_oif> ] [ <oif_name> ] [ <flags> ] [ <dvif> ] ] ] ] ]
```

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
l2	L2 information
multicast	L2 multicast information
ip-based	(Optional) IPv4 based
mac-based	(Optional) MAC based
vlan	(Optional) Info specific to a vlan
vlan-id	(Optional) Vlan id value
vni	(Optional) Info specific to a vni
vni-id	(Optional) Vni id value
group	(Optional) Group specific information
grpaddr	(Optional) Group address
source	(Optional) (G,S) specific information
srcaddr	(Optional) Source address
destination-mac	(Optional) Destination MAC specific information
dmac	(Optional) Destination MAC address
summary	(Optional) display route counts
__readonly__	(Optional)
TABLE_sum	(Optional)
mode	(Optional) Mode
num_vlan	(Optional) Num of VLAN

show forwarding distribution l2 multicast

<i>num_starg</i>	(Optional) Num of Starg routes
<i>num_sg</i>	(Optional) Num of SG routes
<i>num_aggstarg</i>	(Optional) Num of Aggregated Starg routes
TABLE_sum_info	(Optional)
<i>vlan_id</i>	(Optional) vlan id
<i>ftag_id</i>	(Optional) ftag id
<i>routable_flag</i>	(Optional) Routable flag
<i>v6_routable_flag</i>	(Optional) Routable flag
<i>num_starg</i>	(Optional) Num of starg routes
<i>num_sg</i>	(Optional) Num of sg routes
<i>num_aggstarg</i>	(Optional) Num of Aggregated Starg routes
<i>total_route</i>	(Optional) Total Routes
TABLE_route	(Optional)
<i>vlan</i>	(Optional) vlan
<i>grp_str</i>	(Optional) Group Address
<i>v6grp_str</i>	(Optional) v6 Group address
<i>src_str</i>	(Optional) Source Address
<i>v6src_str</i>	(Optional) v6 Group address
<i>grp_mac</i>	(Optional) Group Mac
<i>src_mac</i>	(Optional) Source Mac
TABLE_oif	(Optional)
<i>oiflist_id</i>	(Optional) oiflist index
<i>refcount</i>	(Optional) reference count
<i>l3_usage</i>	(Optional) l3 usage
<i>plt_index</i>	(Optional) platform index
<i>num_oif</i>	(Optional) Num of outgoing interface
<i>oif_name</i>	(Optional) Oif details
<i>flags</i>	(Optional)
<i>dvif</i>	(Optional)

Command Mode

- /exec

show forwarding distribution lisp counters

show forwarding distribution lisp counters

show forwarding distribution lisp counters [__readonly__ <count>]

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	fib distribution information
lisp	for lisp application
counters	counters
__readonly__	(Optional)
<i>count</i>	(Optional) count

Command Mode

- /exec

show forwarding distribution lisp vrf enabled

show forwarding distribution lisp vrf enabled [__readonly__ { TABLE_lisp_vrf_enabled <vrf> <lisp_enabled> <req_id> <operation> }]

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	fib distribution information
lisp	for lisp application
vrf	vrf
enabled	enabled
__readonly__	(Optional)
TABLE_lisp_vrf_enabled	(Optional)
vrf	(Optional) vrf key
<i>lisp_enabled</i>	(Optional) lisp enabled status
<i>req_id</i>	(Optional) req id
<i>operation</i>	(Optional) operation

Command Mode

- /exec

show forwarding distribution multicast

show forwarding distribution multicast

show forwarding distribution multicast [messages] [__readonly__ <num_accepting_routes> <slot> <fibstate>]

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast FIB distribution information
messages	(Optional) Outstanding Message Information
__readonly__	(Optional)
<i>num_accepting_routes</i>	(Optional) Number of fibs accepting routes
<i>slot</i>	(Optional) Slot
<i>fibstate</i>	(Optional) IP Multicast FIB process state

Command Mode

- /exec

show forwarding distribution multicast client-ack-db

show forwarding distribution multicast client-ack-db [__readonly__ <xid> <num_recipients> <num_responses>]

Syntax Description

show	show
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast
client-ack-db	Displays the client ack db
__readonly__	(Optional)
xid	(Optional) XID
num_recipients	(Optional) Number of recipients
num_responses	(Optional) Number of responses

Command Mode

- /exec

show forwarding distribution multicast client

show forwarding distribution multicast client

show forwarding distribution multicast client [__readonly__ <num-clients> <client-name> <client-id> <shmem-name>]

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast information
client	Show multicast distribution client information
__readonly__	(Optional)
<i>num-clients</i>	(Optional) Number of Clients registered
<i>client-name</i>	(Optional) Client Name
<i>client-id</i>	(Optional) Client-id
<i>shmem-name</i>	(Optional) Shared Memory Segment Name

Command Mode

- /exec

show forwarding distribution multicast download

show forwarding distribution multicast download [__readonly__ [TABLE_MFDM_DOWNLOAD_INFO <db_type> [TABLE_MFDM_PENDING_INFO [<table_id>]]]]

Syntax Description

show	
forwarding	forwarding information
distribution	FIB distribution information
multicast	Multicast FIB distribution information
download	show download queues
__readonly__	(Optional)
TABLE_MFDM_DOWNLOAD_INFO	(Optional) MFDM download info
<i>db_type</i>	(Optional) Database type
TABLE_MFDM_PENDING_INFO	(Optional) Routes Pending info
<i>table_id</i>	(Optional) Table ID

Command Mode

- /exec

show forwarding distribution multicast mfib

show forwarding distribution multicast mfib

show forwarding distribution multicast { mfib-txlist [vrf <vrf-name>] | mfib-buffers } [__readonly__ <no-free-buffers> <no-used-buffers>]

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast information
mfib-txlist	Show MFIB transmission-list information
vrf	(Optional) Specify VRF
<i>vrf-name</i>	(Optional) Specify VRF name
mfib-buffers	Show MFIB route buffer information
__readonly__	(Optional)
<i>no-free-buffers</i>	(Optional) Number of Free txlist MFIB buffers
<i>no-used-buffers</i>	(Optional) Number of Used txlist MFIB buffers

Command Mode

- /exec

show forwarding distribution multicast outgoing-interface-list L2_PRIME

show forwarding distribution multicast outgoing-interface-list L2_PRIME [__readonly__ <index> <dvif> <platform_index> <ref_count> <l2-oifs> <port_set>]

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast FIB distribution information
outgoing-interface-list	Outgoing interface list
L2_PRIME	Layer 2 oiflist
<i>index</i>	(Optional) Outgoing Interface List index
<i>__readonly__</i>	(Optional)
<i>dvif</i>	(Optional) Destination VIF
<i>platform_index</i>	(Optional) Platform index
<i>ref_count</i>	(Optional) Reference count
<i>l2-oifs</i>	(Optional) L2 oifs
<i>port_set</i>	(Optional) Port set

Command Mode

- /exec

show forwarding distribution multicast resp-ack-timer-msgs

show forwarding distribution multicast resp-ack-timer-msgs

show forwarding distribution multicast resp-ack-timer-msgs

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast information
resp-ack-timer-msgs	show response ack timers for MFDM

Command Mode

- /exec

show forwarding distribution multicast route

```
show forwarding distribution [ ip ] multicast route [ table <id> | vrf { <vrf_name> | <vrf-known-name> | all } ] [ [ group { <gaddr> [ <mask> ] | <gprefix> } [ source { <saddr> [ <smask> ] | <sprefix> } ] ] | summary ] [ __readonly__ TABLE_vrf [ <vrf-name> ] [ <table-name> ] [ <table-id> ] [ <table-wildcard> ] [ <total-num-groups> ] [ TABLE_route_summary [ <vrf-name> ] [ <total-num-routes> ] [ <num-star-g-route> ] [ <num-sg-route> ] [ <num-star-g-prfx> ] [ <num-group-count> ] ] [ TABLE_one_route [ <source-addrs> ] [ <source-len> ] [ <group-addrs> ] [ <group-len> ] [ <df-ordinal> ] [ <rpf-intf> ] [ <flags> ] [ <upstream-addrs> ] [ <stats-state> ] [ <stats-pkts> ] [ <stats-bytes> ] [ <oif-count> ] [ <oiflist-index> ] [ TABLE_oif [ <oif-name> ] [ <mti-src-intf> ] [ <mti-grp-ip> ] [ <mti-src-ip> ] [ <next-hop> ] ] ] ] ]
```

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
ip	(Optional) IPV4 information
multicast	Multicast information
route	Multicast route related information
vrf	(Optional) Specify VRF
<i>vrf_name</i>	(Optional) Specify VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
table	(Optional) Specify Multicast Routing Table
<i>id</i>	(Optional) Multicast Routing Table Identifier
group	(Optional) IPv4 Multicast Group specific
<i>gaddr</i>	(Optional) IPv4 Multicast Group Address
<i>mask</i>	(Optional) mask for group ip address
<i>gprefix</i>	(Optional) IPv4 Multicast Group Prefix
source	(Optional) IPv4 Multicast Source specific
<i>saddr</i>	(Optional) IPv4 Source Address
<i>smask</i>	(Optional) mask for group ip address
<i>sprefix</i>	(Optional) IPv4 Multicast Source Prefix
summary	(Optional) display route counts

show forwarding distribution multicast route

<code>__readonly__</code>	(Optional)
<code>TABLE_vrf</code>	(Optional)
<code>vrf-name</code>	(Optional)
<code>table-name</code>	(Optional)
<code>table-id</code>	(Optional)
<code>table-wildcard</code>	(Optional)
<code>total-num-groups</code>	(Optional)
<code>TABLE_route_summary</code>	(Optional)
<code>total-num-routes</code>	(Optional)
<code>num-star-g-route</code>	(Optional)
<code>num-sg-route</code>	(Optional)
<code>num-star-g-prfx</code>	(Optional)
<code>num-group-count</code>	(Optional)
<code>TABLE_one_route</code>	(Optional)
<code>source-addrs</code>	(Optional)
<code>source-len</code>	(Optional)
<code>group-addrs</code>	(Optional)
<code>group-len</code>	(Optional)
<code>df-ordinal</code>	(Optional)
<code>rpf-intf</code>	(Optional)
<code>upstream-addrs</code>	(Optional)
<code>flags</code>	(Optional)
<code>stats-state</code>	(Optional)
<code>stats-pkts</code>	(Optional)
<code>stats-bytes</code>	(Optional)
<code>oif-count</code>	(Optional)
<code>oiflist-index</code>	(Optional)
<code>TABLE_oif</code>	(Optional)
<code>oif-name</code>	(Optional)

<i>mti-src-intf</i>	(Optional)
<i>mti-grp-ip</i>	(Optional)
<i>mti-src-ip</i>	(Optional)
<i>next-hop</i>	(Optional)

Command Mode

- /exec

show forwarding distribution multicast route sr um-nat

show forwarding distribution multicast route sr um-nat

```
show forwarding distribution multicast route sr um-nat [ __readonly__ TABLE_one_route
<pre-translated-source-addrs><pre-translated-dest-addrs>
<post-translated-source-addrs><post-translated-dest-addrs>
<post-translated-source-udp-port><post-translated-dest-udp-port> <mti-src-intf><vrf-name> ]
```

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast information
route	Multicast route related information
sr	sr related information
um-nat	UM NAT route translation information
__readonly__	(Optional)
TABLE_one_route	(Optional)

Command Mode

- /exec

show forwarding distribution multicast sr hash-db

show forwarding distribution multicast sr hash-db

Syntax Description

show	show
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast
sr	Service reflect rules
hash-db	Hash database

Command Mode

- /exec

show forwarding distribution multicast vxlan dsg-db

show forwarding distribution multicast vxlan dsg-db

show forwarding distribution multicast vxlan dsg-db

Syntax Description

show	show
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast
vxlan	vxlan
dsg-db	delivery group/source db

Command Mode

- /exec

show forwarding distribution multicast vxlan vlan-db

show forwarding distribution multicast vxlan vlan-db

Syntax Description

show	show
forwarding	Display Forwarding Information
distribution	FIB distribution information
multicast	Multicast
vxlan	vxlan
vlan-db	Vlan database

Command Mode

- /exec

show forwarding distribution nve overlay-vlan

show forwarding distribution nve overlay-vlan

show forwarding distribution nve overlay-vlan [__readonly__ TABLE_overlay_vlan_peer_id <Vlan> <SVP> <install> <Origin> <VFP-region> <peercount> <peer_id> +]

Syntax Description

show	Show running system information
forwarding	forwarding information
distribution	fib distribution info
nve	nve distribution info
overlay-vlan	overlay-vlan adjacency info
<u>__readonly__</u>	(Optional)
TABLE_overlay_vlan_peer_id	(Optional) overlay vlan peer id table
<i>Vlan</i>	(Optional) VLAN
<i>SVP</i>	(Optional) SVP
<i>install</i>	(Optional) install
<i>Origin</i>	(Optional) Origin
<i>VFP-region</i>	(Optional) VFP-region
<i>peercount</i>	(Optional) Total count of Peers
<i>peer_id</i>	(Optional) Peer-ID

Command Mode

- /exec

show forwarding distribution peer-id

show forwarding distribution peer-id [vpls | otv] [__readonly__ <header> TABLE_peer_id <app> <vlan> <id> <peer_id>]

Syntax Description

show	Show running system information
forwarding	forwarding information
distribution	fib distribution info
peer-id	HW Peer-id allocation info
vpls	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
otv	(Optional) OTV
__readonly__	(Optional)
header	(Optional) Header
TABLE_peer_id	(Optional) Peer ID table
app	(Optional) OTV/VPLS
vlan	(Optional) VLAN
id	(Optional) ID
peer_id	(Optional) Peer-ID

Command Mode

- /exec

show forwarding distribution srv6 local-sid bd-mapping

show forwarding distribution srv6 local-sid bd-mapping

show forwarding distribution srv6 local-sid bd-mapping [__readonly__ { local_sid_bd_map <sid_bd_map> } [{ TABLE_local_sid <local_sid> <Table_id> <func_type> <bd> <locator> <function> <args> }]]

Syntax Description

show	Show running system information
forwarding	forwarding information
distribution	fib distribution info
srv6	Srv6 related
local-sid	Local SID
bd-mapping	Local Sid to BD mappings
__readonly__	(Optional)
local_sid_bd_map	(Optional) Local-sid to BD mapping
sid_bd_map	(Optional) Local-sid to BD mappingi number
TABLE_local_sid	(Optional) Table with local SID's
local_sid	(Optional) V6 prefix associated with local-sid
Table_id	(Optional) Table ID
func_type	(Optional) Function behavior type
bd	(Optional) Bridge domain
locator	(Optional) Locator V6 address
function	(Optional) function
args	(Optional) args

Command Mode

- /exec

show forwarding distribution trace

show forwarding distribution trace

Syntax Description

show	
forwarding	Display Forwarding Information
distribution	fib distribution info
trace	unicast trace information

Command Mode

- /exec

show forwarding ecmp

show forwarding ecmp

```
show forwarding ecmp [ { [ vrf { <vrf-name> | <vrf-known-name> } ] lisp } ] [ platform ] [ module <module> ] [ partial ] [ __readonly__ [ <header> <ecmp_hash> <intf> <nh> <v6nh> <hw_index> <num_mpls> <holder> <refcount> <num_paths> <sw_ptr> <ecmp_partial> ] [ TABLE_ecmp { [ <hash> ] [ <num_paths> ] [ <hwindex> ] [ <ecmppartial> ] [ TABLE_index { [ <ecmp_idx> ] [ <cmn_idx> ] } ] [ <refcnt> ] [ <ecmp_holder> ] } [ TABLE_adjacency { [ <intf> ] [ <nh> ] [ <v6nh> ] [ <hw_adj_idx> ] [ <hw_cmn_idx> ] [ <lif> ] [ <hw_nve_adj_idx> ] [ <hw_nve_cmn_idx> ] [ <nve_lif> ] } ] [ <vobj_count> ] [ <vxlan_vobj_count> ] [ <vxlan> ] [ <vobj_list_header> ] [ <vobj_id> ] ] ]
```

Syntax Description

show	
forwarding	Display fib information
ecmp	Show information about ECMPs
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
lisp	(Optional) Show information about LISP ECMPs
platform	(Optional) one command to show pi and pd info together
module	(Optional) slot
<i>module</i>	(Optional) slot number
partial	(Optional) Show partially installed ECMPs
__readonly__	(Optional)
<i>header</i>	(Optional) o/p header
<i>ecmp_hash</i>	(Optional) ecmp hash
<i>intf</i>	(Optional) interface
<i>nh</i>	(Optional) next hop
<i>v6nh</i>	(Optional) V6 next hop
<i>hw_index</i>	(Optional) Hw index
<i>num_mpls</i>	(Optional) No of MPLS ecmp
<i>holder</i>	(Optional) holder bitmap
<i>refcount</i>	(Optional) refcount
<i>sw_ptr</i>	(Optional) Software pointer

<i>num_paths</i>	(Optional) No of paths
<i>ecmp_partial</i>	(Optional) partial ecmp
<i>TABLE_ecmp</i>	(Optional) ecmp table
<i>hash</i>	(Optional) ecmp hash
<i>num_paths</i>	(Optional) No of paths
<i>hwindex</i>	(Optional) Hw index
<i>ecmppartial</i>	(Optional) partial ecmp
<i>TABLE_index</i>	(Optional) index table
<i>ecmp_idx</i>	(Optional) hw ecmp index
<i>cnn_idx</i>	(Optional) cnn index
<i>refcnt</i>	(Optional) refcount
<i>ecmp_holder</i>	(Optional) holder bitmap
<i>TABLE_adjacency</i>	(Optional) adjacency table
<i>intf</i>	(Optional) interface
<i>nh</i>	(Optional) next hop
<i>v6nh</i>	(Optional) v6 next hop
<i>hw_adj_idx</i>	(Optional) hw adj index
<i>hw_cnn_idx</i>	(Optional) hw cnn index
<i>lif</i>	(Optional) lif
<i>hw_nve_adj_idx</i>	(Optional) nve adj index
<i>hw_nve_cnn_idx</i>	(Optional) nve cnn index
<i>nve_lif</i>	(Optional) nve lif
<i>vobj_count</i>	(Optional) vobj count
<i>vxlan_vobj_count</i>	(Optional) vxlan vobj count
<i>vxlan</i>	(Optional) vxlan
<i>vobj_list_header</i>	(Optional) vobj list header
<i>vobj-id</i>	(Optional) vobj id

Command Mode

- /exec

show forwarding ecmp recursive

show forwarding ecmp recursive

```
show forwarding ecmp recursive [ platform ] [ srv6 ] [ max-display-count <display_count> ] [ module <module>
] [ partial ] [ __readonly__ [ TABLE_vobj { [ <header_vobj> ] [ <header_ecmp> ] } [ TABLE_vobj_idx { [
<hw_vobj_index> ] [ <cmn_index> ] } ] [ <num_pfxs> ] [ <ecmp_partial> ] [ <activepath_hdr> ] [
<ecmp_hw_prog_fail> ] [ TABLE_active { [ TABLE_activepath { [ <ap_nh> ] [ <ap_v6nh> ] [ <ap_rnh_len>
] [ <ap_nh_vpn_label> ] [ <ap_rnh_table_id> ] [ <ap_nh_weight> ] } } ] [ <backuppPath_hdr> ] [
TABLE_backuppPath { [ <bp_nh> ] [ <bp_v6nh> ] [ <bp_nh_vpn_label> ] [ <bp_rnh_table_id> ] [
<bp_nh_weight> ] } ] [ <cnh_hdr> ] [ TABLE_cnh { [ <nh> ] [ <v6nh> ] [ <intf> ] [ TABLE_cnh_adj { [
<hw_adj> ] [ <hw_cmn_index> ] [ <lif> ] } } ] [ <hw_inst_n> ] [ <ls_count_n> ] [ <hw_inst_o> ] [
<ls_count_o> ] [ <fec_type> ] [ <header_fec_ecmp> ] [ <hw_vobj_fec_idx> ] [ <cmn_idx> ] [
<vobj_hw_inst_n> ] [ <vobj_ls_count_n> ] [ <vobj_hw_inst_o> ] [ <vobj_ls_count_o> ] [ <vobj_refcount>
] [ <vobj_function> ] [ TABLE_vobj_ecmp { [ <ec_hash> ] [ <ec_num_paths> ] [ <ec_hwindex> ] [
<ec_ecmppartial> ] [ <ec_refcnt> ] [ <ec_ecmp_holder> ] } [ TABLE_adjacency_ec { [ <ec_intf> ] [ <ec_nh>
] [ <ec_v6nh> ] [ <ec_hw_adj_idx> ] [ <ec_hw_cmn_idx> ] [ <ec_lif> ] [ <ec_hw_nve_adj_idx> ] [
<ec_hw_nve_cmn_idx> ] [ <ec_nve_lif> ] } ] [ <ec_vobj_count> ] [ <ec_vxlan_vobj_count> ] [ <ec_vxlan>
] [ <ec_vobj_list_header> ] ] [ <header> <num_pfxs> <rnh_table_id> <nh> <rnh_len> <v6nh> <hw_instance>
<nh_vpn_label> <nh_weight> <cnh_intf> <ecmp_partial> ] [ TABLE_ecmp { [ <hash> ] [ <num_paths> ]
[ <hwindex> ] [ <ecmppartial> ] [ TABLE_index { [ <ecmp_idx> ] [ <cmn_idx> ] } ] [ <refcnt> ] [
<ecmp_holder> ] } [ TABLE_adjacency { [ <intf> ] [ <nh> ] [ <v6nh> ] [ <hw_adj_idx> ] [ <hw_cmn_idx>
] [ <lif> ] [ <hw_nve_adj_idx> ] [ <hw_nve_cmn_idx> ] [ <nve_lif> ] } ] [ <vobj_count> ] [
<vxlan_vobj_count> ] [ <vxlan> ] [ <vobj_list_header> ] [ TABLE_vobj_id { [ <vobj_id> ] } ] [
<vobj_function> ] ] ]
```

Syntax Description

show	
forwarding	Display fib information
ecmp	Show information about ECMPs
recursive	Show information about recursive ECMPs
platform	(Optional) one command to show pi and pd info together
srv6	(Optional) Show information about SRV6 encapsulation
module	(Optional) slot
partial	(Optional) Show partially installed ECMPs
<i>module</i>	(Optional) slot number
max-display-count	(Optional) displays max # of routes
<i>display_count</i>	(Optional) count
__readonly__	(Optional)
TABLE_vobj	(Optional) Table vobj
<i>header_vobj</i>	(Optional) vobj o/p header

<i>header_ecmp</i>	(Optional) ecmp o/p header
<i>TABLE_vobj_idx</i>	(Optional) Table vobj index
<i>hw_vobj_index</i>	(Optional) HW VOBJ Index
<i>cmn_index</i>	(Optional) cmn index
<i>num_pfxs</i>	(Optional) Number of prefixes using this virtual object
<i>ecmp_partial</i>	(Optional) partial ecmp
<i>ecmp_hw_prog_fail</i>	(Optional) Ecmp Hardware Program failure
<i>activepath_hdr</i>	(Optional) o/p header
<i>TABLE_active</i>	(Optional) table active
<i>TABLE_activepath</i>	(Optional) table active path
<i>ap_nh</i>	(Optional) Next hop info
<i>ap_v6nh</i>	(Optional) v6 Next hop info
<i>ap_rnh_len</i>	(Optional) Next hop mask length
<i>ap_nh_vpn_label</i>	(Optional) NH VPN label
<i>ap_rnh_table_id</i>	(Optional) The table id where the RNHs are present
<i>ap_nh_weight</i>	(Optional) weighted ecmp info
<i>backuppath_hdr</i>	(Optional) o/p header
<i>TABLE_backuppath</i>	(Optional) backup path table
<i>bp_nh</i>	(Optional) Next hop info
<i>bp_v6nh</i>	(Optional) v6 Next hop info
<i>bp_nh_vpn_label</i>	(Optional) NH VPN label
<i>bp_rnh_table_id</i>	(Optional) The table id where the RNHs are present
<i>bp_nh_weight</i>	(Optional) weighted ecmp info
<i>cnh_hdr</i>	(Optional) o/p header
<i>TABLE_cnh</i>	(Optional) cnh table
<i>nh</i>	(Optional) Next hop info
<i>v6nh</i>	(Optional) v6 Next hop info
<i>intf</i>	(Optional) cnh output interface
<i>TABLE_cnh_adj</i>	(Optional) Table cnh adjacency

show forwarding ecmp recursive

<i>hw_adj</i>	(Optional) cnh hw adjacency
<i>hw_cmn_index</i>	(Optional) cnh hw cmn idx
<i>lif</i>	(Optional) lif
<i>hw_inst_n</i>	(Optional) Hardware instance info new
<i>ls_count_n</i>	(Optional) ls count new
<i>hw_inst_o</i>	(Optional) Hardware instance info old
<i>ls_count_o</i>	(Optional) ls count old
<i>fec_type</i>	(Optional) fec type
<i>header_fec_ecmp</i>	(Optional) o/p header
<i>hw_vobj_fec_idx</i>	(Optional) hw fec idx
<i>cmn_idx</i>	(Optional) cmn idx
<i>vobj_hw_inst_n</i>	(Optional) vobj hw instance
<i>vobj_ls_count_n</i>	(Optional) ls count new
<i>vobj_hw_inst_o</i>	(Optional) hw instnace info old
<i>vobj_ls_count_o</i>	(Optional) ls count old
<i>vobj_refcount</i>	(Optional) vobj refcount
<i>vobj_function</i>	(Optional) vobj function
TABLE_vobj_ecmp	(Optional) ecmp table
<i>ec_hash</i>	(Optional) ecmp hash
<i>ec_num_paths</i>	(Optional) No of paths
<i>ec_hwindex</i>	(Optional) Hw index
<i>ec_ecmppartial</i>	(Optional) partial ecmp
<i>ec_refcnt</i>	(Optional) refcount
<i>ec_ecmp_holder</i>	(Optional) holder bitmap
TABLE_adjacency_ec	(Optional) adjacency table
<i>ec_intf</i>	(Optional) interface
<i>ec_nh</i>	(Optional) next hop
<i>ec_v6nh</i>	(Optional) v6 next hop
<i>ec_hw_adj_idx</i>	(Optional) hw adj index

<i>ec_hw_cmn_idx</i>	(Optional) hw cmn index
<i>ec_lif</i>	(Optional) lif
<i>ec_hw_nve_adj_idx</i>	(Optional) nve adj index
<i>ec_hw_nve_cmn_idx</i>	(Optional) nve cmn index
<i>ec_nve_lif</i>	(Optional) nve lif
<i>ec_vobj_count</i>	(Optional) vobj count
<i>ec_vxlan_vobj_count</i>	(Optional) vxlan vobj count
<i>ec_vxlan</i>	(Optional) vxlan
<i>ec_vobj_list_header</i>	(Optional) vobj list header
<i>vobj_function</i>	(Optional) vobj function
<i>header</i>	(Optional) o/p header
<i>num_pfxs</i>	(Optional) Number of prefixes using this virtual object
<i>rnh_table_id</i>	(Optional) The table id where the RNHs are present
<i>nh</i>	(Optional) Next hop info
<i>rnh_len</i>	(Optional) Next hop mask length
<i>v6nh</i>	(Optional) V6 Next hop info
<i>hw_instance</i>	(Optional) Hardware instance info
<i>nh_vpn_label</i>	(Optional) NH VPN label
<i>nh_weight</i>	(Optional) weighted ecmp info
<i>cnh_intf</i>	(Optional) cnh output interface
<i>ecmp_partial</i>	(Optional) partial ecmp
<i>TABLE_ecmp</i>	(Optional) ecmp table
<i>hash</i>	(Optional) ecmp hash
<i>num_paths</i>	(Optional) No of paths
<i>hwindex</i>	(Optional) Hw index
<i>ecmppartial</i>	(Optional) partial ecmp
<i>TABLE_index</i>	(Optional) index table
<i>ecmp_idx</i>	(Optional) hw ecmp index
<i>cmn_idx</i>	(Optional) cmn index

show forwarding ecmp recursive

<i>refcnt</i>	(Optional) refcount
<i>ecmp_holder</i>	(Optional) holder bitmap
TABLE_adjacency	(Optional) adjacency table
<i>intf</i>	(Optional) interface
<i>nh</i>	(Optional) next hop
<i>v6nh</i>	(Optional) v6 next hop
<i>hw_adj_idx</i>	(Optional) hw adj index
<i>hw_cmn_idx</i>	(Optional) hw cmn index
<i>lif</i>	(Optional) lif
<i>hw_nve_adj_idx</i>	(Optional) nve adj index
<i>hw_nve_cmn_idx</i>	(Optional) nve cmn index
<i>nve_lif</i>	(Optional) nve lif
<i>vobj_count</i>	(Optional) vobj count
<i>vxlan_vobj_count</i>	(Optional) vxlan vobj count
<i>vxlan</i>	(Optional) vxlan
<i>vobj_list_header</i>	(Optional) vobj list header
TABLE_vobj_id	(Optional) vobj_id table
<i>vobj-id</i>	(Optional) vobj id

Command Mode

- /exec

show forwarding inconsistency

```
show forwarding [ ip | ipv4 ] [ unicast ] inconsistency [ suppress-transient ] [ vrf { <vrf-name> | all_vrfs } ]
[ module { <module> | all_modules } ] [ __readonly__ [ <err_str> ] [ <cc_header> ] [ <table_id> ] [ <slot_id>
] [ <exec_time> ] [ <elapsed_time> ] [ <inconsis_adjs> ] [ TABLE_inconsistency_adjs { <id> <slot> [ <unit>
] <vrf> [ <ipaddr> ] [ <ipprefix> ] [ <interface> ] <reason> } ] [ <inconsis_routes> ] [
TABLE_inconsistency_routes { <id> <slot> [ <unit> ] <vrf> [ <ipaddr> ] [ <ipprefix> ] [ <interface>
<reason> } ] [ <run_status> ] ]
```

Syntax Description

show	show
forwarding	Display Forwarding Information
ip	(Optional) ipv4
ipv4	(Optional) ipv4
unicast	(Optional) unicast
inconsistency	route inconsistency check
suppress-transient	(Optional) Supress Transient state
vrf	(Optional) check routes for a specific VRF
<i>vrf-name</i>	(Optional) VRF name
module	(Optional) check routes for a specific module
<i>module</i>	(Optional) module number
all_modules	(Optional) all module's
all_vrfs	(Optional) all vrf's
__readonly__	(Optional)
<i>err_str</i>	(Optional)
<i>cc_header</i>	(Optional)
<i>table_id</i>	(Optional)
<i>slot_id</i>	(Optional)
<i>exec_time</i>	(Optional)
<i>elapsed_time</i>	(Optional)
<i>inconsis_adjs</i>	(Optional)
TABLE_inconsistency_adjs	(Optional)

show forwarding inconsistency

<i>id</i>	(Optional)
<i>slot</i>	(Optional)
<i>unit</i>	(Optional)
<i>vrf</i>	(Optional)
<i>ipaddr</i>	(Optional)
<i>ipprefix</i>	(Optional)
<i>interface</i>	(Optional)
<i>reason</i>	(Optional)
<i>inconsis_routes</i>	(Optional)
TABLE_inconsistency_routes	(Optional)
<i>id</i>	(Optional)
<i>slot</i>	(Optional)
<i>unit</i>	(Optional)
<i>vrf</i>	(Optional)
<i>ipaddr</i>	(Optional)
<i>ipprefix</i>	(Optional)
<i>interface</i>	(Optional)
<i>reason</i>	(Optional)
<i>run_status</i>	(Optional)

Command Mode

- /exec

show forwarding interfaces

show forwarding interfaces [module <module>] [__readonly__ TABLE_intf_str <intf> <v4adjcnt> <v6adjcnt> <v4rpfmode> <v6rpfmode> <mac>]

Syntax Description

show	
forwarding	fib information
interfaces	show fib interface info
__readonly__	(Optional)
TABLE_intf_str	(Optional) show interface string
<i>intf</i>	(Optional) interface name
module	(Optional) slot
<i>module</i>	(Optional) slot number
<i>v4adjcnt</i>	(Optional) count of v4 adjacencies
<i>v6adjcnt</i>	(Optional) count of v6 adjacencies
<i>mac</i>	(Optional) mac address
<i>v4rpfmode</i>	(Optional) v4 uRPF mode
<i>v6rpfmode</i>	(Optional) v6 uRPF mode

Command Mode

- /exec

show forwarding ipv6

show forwarding ipv6

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | table <table_id> ] ipv6 [ route | rnadb
] [ recursive ] [ detail | summary | platform | partial | <prefix> [ longer-prefixes ] [ detail | platform ] | <address>
[ detail | platform ] | interface <interface> | next-hop <nh> | attached | unresolved | adjacency { <aif> <anh>
| drop | glean | punt } ] [ max-display-count <display_count> ] [ module <module> | vrf { <vrf-name>
<vrf-known-name> | <vrf-all> } ] + [ __readonly__ [ <prefix_count> ] [ TABLE_vrf { [ <vrfname> ]
<tblname> } [ <tableid> ] [ TABLE_prefix { [ <pxf> ] [ <num_paths> ] [ <vobj_id> ] [ TABLE_path { [
<nexthop> | <special> ] [ <intf> ] [ <route_updates> ] [ <route_inserts> ] [ <route_deletes> ] [ <route_count>
] [ <path_count> ] [ TABLE_mask { [ <mask_length> ] [ <routes_per_mask> ] } ] } ] [ <hw_handle> ] [
<flags> ] [ <holder> ] [ <nxt_obj_type> ] [ <hw_idx_v6adj> ] [ <cmn_idx> ] [ <lif> ] [ <buf_idx> ] } ] } ] [
<packet_cnt> ] [ <byte_cnt> ] ]
```

Syntax Description

show	
forwarding	display fib information
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
table	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<i>table_id</i>	(Optional) table id in hex
ipv6	ipv6
route	(Optional) display IP routing table
platform	(Optional) one command to show pi and pd info together
rnadb	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
recursive	(Optional) display routes with recursive next hops
detail	(Optional) show detailed information about the routes
summary	(Optional) display route counts
partial	(Optional) display routes with partial ECMPs
longer-prefixes	(Optional) display longer prefixes
interface	(Optional) display routes with this output i/f only
<i>interface</i>	(Optional) output interface
next-hop	(Optional) display routes with this next-hop only

attached	(Optional) display directly connected routes
unresolved	(Optional) display unresolved routes
adjacency	(Optional) display adjacency information
<i>aif</i>	(Optional) adjacency output interface
drop	(Optional) display routes via drop adjacency
glean	(Optional) display routes via glean adjacency
punt	(Optional) display routes via punt adjacency
module	(Optional) slot
<i>module</i>	(Optional) slot number
max-display-count	(Optional) displays max # of routes
<i>display_count</i>	(Optional) count
<u>__readonly__</u>	(Optional)
TABLE_vrf	(Optional) vrf table
<i>vrfname</i>	(Optional) VRF name
<i>tblname</i>	(Optional) table name
<i>tableid</i>	(Optional) table id
<i>prefix_count</i>	(Optional) total number of prefix in VRF
TABLE_prefix	(Optional) all xml prefix entries
<i>pxf</i>	(Optional) ipv6 prefix
<i>num_paths</i>	(Optional) no of paths
<i>vobj-id</i>	(Optional) vobj-id
TABLE_path	(Optional) path table
<i>nexthop</i>	(Optional) next hop address
<i>special</i>	(Optional) special adjacencies
<i>intf</i>	(Optional) output interface
<i>route_updates</i>	(Optional) route update in VRF
<i>route_inserts</i>	(Optional) route insert in VRF
<i>route_deletes</i>	(Optional) route delete in VRF
<i>route_count</i>	(Optional) total number of routes in VRF

show forwarding ipv6

<i>path_count</i>	(Optional) total number of paths in VRF
<i>TABLE_mask</i>	(Optional) mask table
<i>mask_length</i>	(Optional) length of mask
<i>routes_per_mask</i>	(Optional) routes per mask
<i>hw_handle</i>	(Optional) hw handle
<i>flags</i>	(Optional) flags
<i>holder</i>	(Optional) holder
<i>nxt_obj_type</i>	(Optional) next obj type
<i>hw_idx_v6adj</i>	(Optional) v6 adj hw idx
<i>cmn-idx</i>	(Optional) cmn idx
<i>lif</i>	(Optional) lif
<i>buf-idx</i>	(Optional) Buffer index
<i>packet_cnt</i>	(Optional) Packet count
<i>byte_cnt</i>	(Optional) Byte count

Command Mode

- /exec

show forwarding ipv6 adjacency

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] ipv6 adjacency [ mpls ] [ nve ] [ <aif> ] [ <anh> ] [ detail | stats | platform ] [ module <module> ] [ __readonly__ [ <adj-count> ] [ TABLE_adj { [ <fec> ] <nexthop> <rewinfo> [ <interface> ] [ <pkts> ] [ <bytes> ] [ <bgp_rnh> ] [ <bgp_orig_as> ] [ <bgp_peer_as> ] [ <hh> ] [ <refcount> ] } } [ TABLE_v6_adj { [ <nh> ] [ <rwinfo> ] [ <intf> ] [ <intf_idx> ] [ <hh> ] [ <refcnt> ] [ <flags> ] [ <holder> ] [ <pbr_cnt> ] [ <wccp_cnt> ] [ TABLE_index { [ <hw_adj> ] [ <cmn-idx> ] [ <lif> ] } } } ] ] ]
```

Syntax Description

show	
forwarding	display fib information
ipv6	ipv6
adjacency	display adjacency information
platform	(Optional) one command to show pi and pd info together
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>vrf-all</i>	(Optional) Display information for all VRFs
mpls	(Optional) mpls adjacency information
nve	(Optional) nve adjacency information
<i>aif</i>	(Optional) adjacency output interface
detail	(Optional) detail
stats	(Optional) adjacency statistics
module	(Optional) slot
<i>module</i>	(Optional) slot number
<u>__readonly__</u>	(Optional)
<i>adj-count</i>	(Optional) total adj count
TABLE_adj	(Optional) Table Adjacency
<i>fec</i>	(Optional) FEC info
<i>nexthop</i>	(Optional) next hop address
<i>rewinfo</i>	(Optional) rewrite information

show forwarding ipv6 adjacency

<i>interface</i>	(Optional) output interface
<i>pkts</i>	(Optional) packet stats
<i>bytes</i>	(Optional) bytes stats
<i>bgp_rnh</i>	(Optional) next hop address
<i>bgp_orig_as</i>	(Optional) bgp orig as
<i>bgp_peer_as</i>	(Optional) bgp peer as
<i>hh</i>	(Optional) Hardware Handle
<i>refcount</i>	(Optional) reference count
TABLE_v6_adj	(Optional) Table Adjacency
<i>nh</i>	(Optional) next hop address
<i>rwinf0</i>	(Optional) rewrite information
<i>intf</i>	(Optional) output interface
<i>intf_idx</i>	(Optional) Interface index
<i>hh</i>	(Optional) Hardware Handle
<i>refcnt</i>	(Optional) reference count
<i>flags</i>	(Optional) Adjacency flags
<i>holder</i>	(Optional) Holder bitmap
<i>pbr_cnt</i>	(Optional) PBR count
<i>wccp_cnt</i>	(Optional) WCCP count
TABLE_index	(Optional) HW index table
<i>hw_adj</i>	(Optional) v4 adj hw index
<i>cmn-idx</i>	(Optional) CMN Index
<i>lif</i>	(Optional) LIF

Command Mode

- /exec

show forwarding ipv6 inconsistency

```
show forwarding ipv6 [ unicast ] inconsistency [ suppress-transient ] [ vrf { <vrf-name> | all_vrfs } ] [ module { <module> | all_modules } ] [ __readonly__ [ <err_str> ] [ <cc_header> ] [ <table_id> ] [ <slot_id> ] [ <exec_time> ] [ <elapsed_time> ] [ <inconsis_adjs> ] [ TABLE_inconsistency_adjs { <idipv6> <slotipv6> [ <unitipv6> ] <vrifipv6> [ <ipv6addr> ] [ <ipv6prefix> ] [ <interfaceipv6> ] <reasonipv6> } ] [ <inconsis_routes> ] [ TABLE_inconsistency_routes { <idipv6> <slotipv6> [ <unitipv6> ] <vrifipv6> [ <ipv6addr> ] [ <ipv6prefix> ] [ <interfaceipv6> ] <reasonipv6> } ] [ <run_status> ] ]
```

Syntax Description

show	show
forwarding	Display Forwarding Information
ipv6	ipv6
unicast	(Optional) unicast
inconsistency	route inconsistency check
suppress-transient	(Optional) Supress Transient state
vrf	(Optional) check routes for a specific VRF
<i>vrf-name</i>	(Optional) VRF name
module	(Optional) check routes for a specific module
<i>module</i>	(Optional) module number
all_modules	(Optional) all module's
all_vrfs	(Optional) all vrf's
__readonly__	(Optional)
<i>err_str</i>	(Optional)
<i>cc_header</i>	(Optional)
<i>table_id</i>	(Optional)
<i>slot_id</i>	(Optional)
<i>exec_time</i>	(Optional)
<i>elapsed_time</i>	(Optional)
<i>inconsis_adjs</i>	(Optional)
TABLE_inconsistency_adjs	(Optional)
<i>idipv6</i>	(Optional)

show forwarding ipv6 inconsistency

<i>slotipv6</i>	(Optional)
<i>unitipv6</i>	(Optional)
<i>vrfipv6</i>	(Optional)
<i>interfaceipv6</i>	(Optional)
<i>reasonipv6</i>	(Optional)
<i>inconsis_routes</i>	(Optional)
TABLE_inconsistency_routes	(Optional)
<i>idipv6</i>	(Optional)
<i>slotipv6</i>	(Optional)
<i>unitipv6</i>	(Optional)
<i>vrfipv6</i>	(Optional)
<i>interfaceipv6</i>	(Optional)
<i>reasonipv6</i>	(Optional)
<i>run_status</i>	(Optional)

Command Mode

- /exec

show forwarding ipv6 multicast route

```

show forwarding [ vrf { <vrf-name> | <vrf-known-name> | all } | table <tab_id> ] ipv6 multicast route { [
group { <group> | <group_addr> } [ source { <source> | <source_addr> } ] | module <module> | vrf { <vrf-name> | all } ] + | summary [ module <module> | vrf { <vrf-name> | <vrf-known-name> | all } ] + } [ __readonly__ [ <table_type> ] [ <vrfname> ] [ <table_id> ] [ <num_routes> <num_starg_routes> <num_sg_routes> <num_gprefix_routes> ] [ <num_groups> ] [ <num_sources> ] [ <num_prefix_insert_fail> ] [ [ TABLE_MROUTE_INFO <address> [ <src_len> <grp_len> ] [ <df_ordinal> ] [ <rpfif> ] [ <rpf_ifindex> ] <flag> [ <flag_value> ] <route_pkts> <route_bytes> <oiflist_id> <oif_count> <oiflist_flag> [ TABLE_OIF_INFO <oifindex> [ <vlan> ] [ TABLE_MCAST_OIF_INTF_INFO [ <oifname> ] [ <dvif> ] [ <platform_id> ] [ <encap_id> ] [ <hw_index> ] ] ] ] ]

```

Syntax Description

show	
forwarding	display fib information
ipv6	ipv6
multicast	IPV6 related Multicast information
route	Multicast route information
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
table	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<i>tab_id</i>	(Optional) table number
group	(Optional) Multicast IPv6 Group Address
source	(Optional) Multicast IPv6 Source Address
summary	display route counts
module	(Optional) slot
<i>module</i>	(Optional) slot number
<u>__readonly__</u>	(Optional)
<i>table_type</i>	(Optional) Table Type
<i>vrfname</i>	(Optional) VRF name
<i>table_id</i>	(Optional) Table ID

show forwarding ipv6 multicast route

<i>num_routes</i>	(Optional) Number of routes
<i>num_starg_routes</i>	(Optional) Number of (*,G) routes
<i>num_sg_routes</i>	(Optional) Number of (S,G) routes
<i>num_gprefix_routes</i>	(Optional) Number of (*,G-prefix) routes
<i>num_groups</i>	(Optional) Number of group entries in the table
<i>num_prefix_insert_fail</i>	(Optional) Prefix insert fail count
<i>num_sources</i>	(Optional) Number of (S, G) entries for the group address
TABLE_MROUTE_INFO	(Optional) Mroute info
<i>address</i>	(Optional) Mcast address
<i>src_len</i>	(Optional) Source Address Mask
<i>grp_len</i>	(Optional) Group address Mask
<i>df_ordinal</i>	(Optional) DF ordinal
<i>rpfif</i>	(Optional) RPF interface
<i>rpf_ifindex</i>	(Optional) RPF Interface ifIndex
<i>flag</i>	(Optional) Route type flag
<i>flag_value</i>	(Optional) hex value of route flag
<i>route_pkts</i>	(Optional) Route packet count
<i>route_bytes</i>	(Optional) Route bytes
<i>oiflist_id</i>	(Optional) OIF list Identifier
<i>oif_count</i>	(Optional) Number of OIFs
<i>oiflist_flag</i>	(Optional) OIF List flag
TABLE_OIF_INFO	(Optional) OIF Info
<i>oifindex</i>	(Optional) OIF Interface ifIndex
<i>vlan</i>	(Optional) Vlan id
TABLE_MCAST_OIF_INTF_INFO	(Optional) OIF Interfaces
<i>oifname</i>	(Optional) OIF Interface name
<i>dvif</i>	(Optional) DVIF
<i>platform_id</i>	(Optional) Platform-index
<i>encap_id</i>	(Optional) Encap ID

<i>hw_index</i>	(Optional) Harware index
-----------------	--------------------------

Command Mode

- /exec

```
show forwarding kvfib cache on
```

show forwarding kvfib cache on

show forwarding kvfib cache { on | off }

Syntax Description

show	
forwarding	fib information
kvfib	kvfib
cache	cache
on	set variable
off	reset variable

Command Mode

- /exec

show forwarding l2 multicast

```
show forwarding l2 multicast { [ { vlan <vlan-id> [ { group <grpaddr> source <srcaddr> } | { group <v6grpaddr> source <v6srcaddr> } | destination-mac <dstmac> ] } ] [ vdc <vdc-id> ] [ module <num> ] [ __readonly__ [ TABLE_L2_MCAST_INFO <vlan_id>[ <group> ][ <group_v6> ][ <source> ][ <source_v6> ] [ <dmac> ] <epoch> <resource_id> <dest_index> [ <hw_handle> ] [ <text> ] [ <value> ] ] ] ]
```

Syntax Description

show	Show running system information
forwarding	Forwarding information
l2	L2 related information
multicast	Multicast related information
vlan	(Optional) Information Specific to a Vlan
<i>vlan-id</i>	(Optional) Vlan id value
group	(Optional) (S,G) specific information
<i>grpaddr</i>	(Optional) Group address
source	(Optional) source specific information
<i>srcaddr</i>	(Optional) Source address
destination-mac	(Optional) Destination MAC address
<i>dstmac</i>	(Optional) Ethernet MAC address
vdc	(Optional) VDC
<i>vdc-id</i>	(Optional) VDC id
module	(Optional) Slot
<i>num</i>	(Optional) Slot number
<u>__readonly__</u>	(Optional)
TABLE_L2_MCAST_INFO	(Optional) L2 Multicast Info
<i>vlan_id</i>	(Optional) Vlan Identifier
<i>group</i>	(Optional) Multicast IPv4 Group Address
<i>group_v6</i>	(Optional) Multicast IPv6 Group Address
<i>source</i>	(Optional) Multicast IPv4 Source Address
<i>source_v6</i>	(Optional) Multicast IPv6 Source Address

show forwarding l2 multicast

<i>dmac</i>	(Optional) Destination MAC address
<i>epoch</i>	(Optional) Epoch number
<i>resource_id</i>	(Optional) Resource Identifier
<i>dest_index</i>	(Optional) Destination Index Identifier
<i>hw_handle</i>	(Optional) Hardware Handle
<i>text</i>	(Optional) String
<i>value</i>	(Optional) Value

Command Mode

- /exec

show forwarding l2vpn label vpls

show forwarding l2vpn label [<label_id>] vpls [module module] [__readonly__ <label_id>]

Syntax Description

show	show
forwarding	forwarding
l2vpn	l2vpn forwarding
label	VC label
<i>label_id</i>	(Optional) VC label
vpls	VPLS
module	(Optional) slot
<i>module</i>	(Optional) slot number
__readonly__	(Optional)
<i>label_id</i>	(Optional) Label ID

Command Mode

- /exec

show forwarding l2vpn label xconnect

show forwarding l2vpn label xconnect

show forwarding l2vpn label [<label_id>] xconnect [module module] [__readonly__ <label_id>]

Syntax Description

show	show
forwarding	forwarding
l2vpn	l2vpn forwarding
label	VC label
<i>label_id</i>	(Optional) VC label
xconnect	xconnect or VPWS
module	(Optional) slot
<i>module</i>	(Optional) slot number
<u>__readonly__</u>	(Optional)
<i>label_id</i>	(Optional) Label ID

Command Mode

- /exec

show forwarding l2vpn vlan

show forwarding l2vpn vlan [<vlan_id>] [module <module>] [__readonly__ <vlan>]

Syntax Description

show	show
forwarding	forwarding
l2vpn	l2vpn forwarding
vlan	vlan
<i>vlan_id</i>	(Optional) vlan id
module	(Optional) slot
<i>module</i>	(Optional) slot number
__readonly__	(Optional)
<i>vlan</i>	(Optional) vlan

Command Mode

- /exec

show forwarding mpls

show forwarding mpls

```
show forwarding mpls [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } [ label <label-id> | <prefix> | <v6prefix> ] | table <table_id> [ label <label-id> | <prefix> | <v6prefix> ] | label-space <label-space-id> | label <label-id> | <prefix> | <v6prefix> ] [ stats ] [ module <module> ] [ implicit ] [ platform ] [ __readonly__ [ { TABLE_mpls <label> [ { TABLE_table_id [ <out-table-id> ] [ <fec> ] [ <out-ip> ] [ <out-intf> ] [ <out-label> ] [ <out-op> ] [ <hh> ] [ <ref-count> ] [ <hw-index> ] } ] [ <in-pkts> ] [ <in-bytes> ] [ <swap-out-pkts> ] [ <swap-out-bytes> ] [ <tunnel-out-pkts> ] [ <tunnel-out-bytes> ] } ] ] ]
```

Syntax Description

show	show
forwarding	forwarding
mpls	mpls forwarding
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known vrf name
vrf-all	(Optional) Display information for all VRFs
table	(Optional) display info per vpn-id
<i>table_id</i>	(Optional) table number
label-space	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<i>label-space-id</i>	(Optional) label space id
label	(Optional) mpls labels
<i>label-id</i>	(Optional) mpls label value
<i>prefix</i>	(Optional) Labels for single exact match route
module	(Optional) slot
<i>module</i>	(Optional) slot number
stats	(Optional) Label Statistics
implicit	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
platform	(Optional) Display platform information
<u>__readonly__</u>	(Optional)
TABLE_mpls	(Optional)
<i>label</i>	(Optional) mpls label value

TABLE_table_id	(Optional) Table table id
<i>out-table-id</i>	(Optional) Output table-id
<i>fec</i>	(Optional) Prefix/Tunnel ID
<i>out-ip</i>	(Optional) Output Next Hop
<i>out-intf</i>	(Optional) Output Interface
<i>out-label</i>	(Optional) Output Label
<i>out-op</i>	(Optional) Output Label op
<i>hh</i>	(Optional) Hardware Handle
<i>ref-count</i>	(Optional) Ref Count
<i>hw-index</i>	(Optional) HW index for adj
<i>in-pkts</i>	(Optional) Label Input Packet Stats
<i>in-bytes</i>	(Optional) Label Input Bytes Stats
<i>swap-out-pkts</i>	(Optional) Label Swap Output Packet Stats
<i>swap-out-bytes</i>	(Optional) Label Swap Output Bytes Stats
<i>tunnel-out-pkts</i>	(Optional) Label Tunnel Output Packet Stats
<i>tunnel-out-bytes</i>	(Optional) Label Tunnel Output Bytes Stats

Command Mode

- /exec

show forwarding mpls drop-stats

show forwarding mpls drop-stats

show forwarding mpls drop-stats [platform | label0-fwd-stats] [__readonly__ [{ TABLE_drop_stats <unit-number> <pkts> <bytes> }]]

Syntax Description

show	show
forwarding	forwarding
mpls	mpls forwarding
drop-stats	MPLS dropped packets
platform	(Optional) command to display stats per chip
label0-fwd-stats	(Optional) command to display stats for label0
__readonly__	(Optional)
TABLE_drop_stats	(Optional) Table for mpls drop stats
<i>unit-number</i>	(Optional) unit number
<i>pkts</i>	(Optional) Label Packet Stats
<i>bytes</i>	(Optional) Label Bytes Stats

Command Mode

- /exec

show forwarding mpls ecmp

```
show forwarding mpls ecmp [ module <module> ] [ platform ] [ __readonly__ [ { TABLE_ecmp [ <type> ] [ <num_paths> ] [ <ip_paths> ] [ <mpls_paths> ] [ <ecmp_hash> ] [ <holder> ] [ <refcount> ] [ <hw_index> ] [ <fec> ] [ { TABLE_ecmp_paths [ <out-intf> ] [ <out-ip> ] [ <label-info> ] [ <refcount> ] [ <hh> ] [ <ecmp-type> ] } ] } ] ]
```

Syntax Description

show	show
forwarding	display fib information
mpls	mpls forwarding
ecmp	mpls ecmpls
module	(Optional) slot
<i>module</i>	(Optional) slot number
platform	(Optional) show pd info
__readonly__	(Optional)
TABLE_ecmp	(Optional)
<i>type</i>	(Optional) ecmp type
<i>num_paths</i>	(Optional) No of paths
<i>ip_paths</i>	(Optional) No of ip paths
<i>mpls_paths</i>	(Optional) No of mpls paths
<i>ecmp_hash</i>	(Optional) ecmp hash
<i>holder</i>	(Optional) holder bitmap
<i>refcount</i>	(Optional) refcount
<i>hw_index</i>	(Optional) Hw index
<i>fec</i>	(Optional) FEC
TABLE_ecmp_paths	(Optional)
<i>out-intf</i>	(Optional) Output Interface
<i>out-ip</i>	(Optional) Output Next Hop
<i>label-info</i>	(Optional) label info
<i>refcount</i>	(Optional) refcount

```
show forwarding mpls ecmp
```

<i>hh</i>	(Optional) Hardware Handle
<i>ecmp-type</i>	(Optional) type for per path in ecmp

Command Mode

- /exec

show forwarding mpls eompls

show forwarding mpls eompls [peers { <addr> | all }] [__readonly__ [{ TABLE_peer_ip <peer_ip> <peer_id> <vlan bmp> <rx_pkts> <rx_bytes> }]]

Syntax Description

show	Show
forwarding	Forwarding information
mpls	mpls forwarding
eompls	eompls
peers	(Optional) nve peers
<i>addr</i>	(Optional) peer ipaddress
all	(Optional) Display peer info for all peers
__readonly__	(Optional)
TABLE_peer_ip	(Optional)
<i>peer_ip</i>	(Optional) peer address
<i>peer_id</i>	(Optional) peer id
<i>vlan bmp</i>	(Optional) vlan bitmap
<i>rx_pkts</i>	(Optional) packet stats
<i>rx_bytes</i>	(Optional) bytes stats

Command Mode

- /exec

show forwarding mpls eompls ir

show forwarding mpls eompls ir

```
show forwarding mpls eompls ir { [ vlan [ all | <vlan_id> ] ] | [ peer [ all | <peer_ip> ] ] } [ __readonly__ [ { TABLE_VLAN <vlan_id> <vni> <ifindex> <plt_space> <bitmap> <peer> + <marked> + } ] | { TABLE_ONE_PEER <peer> <id> <repl_id> <oif> <path_intf> + <vcnt> <vlan_id> + <plt_space> } ] ]
```

Syntax Description

show	Show running system information
forwarding	Forwarding information
mpls	mpls
eompls	eompls
ir	ir
vlan	(Optional) vlans all
all	(Optional) all
<i>vlan_id</i>	(Optional) vlan-id
peer	(Optional) peers-all
all	(Optional) all
<i>peer_ip</i>	(Optional) show detailed info for peer
<u>__readonly__</u>	(Optional)
TABLE_VLAN	(Optional) vlan peer ids table
<i>vlan_id</i>	(Optional) vlan id
<i>vni</i>	(Optional) vni
<i>ifindex</i>	(Optional) ifindex
<i>plt_space</i>	(Optional) platform space
<i>bitmap</i>	(Optional) peer bitmap
<i>peer</i>	(Optional) peer_address
<i>marked</i>	(Optional) marked
TABLE_ONE_PEER	(Optional) vlan peer ids table
<i>peer</i>	(Optional) vlan id
<i>id</i>	(Optional) vni
<i>repl_id</i>	(Optional) repli id

<i>oif</i>	(Optional) ifindex
<i>path_intf</i>	(Optional) pathintf name
<i>vcount</i>	(Optional) vlan count
<i>vlan_id</i>	(Optional) vlanid
<i>plt_space</i>	(Optional) platform space

Command Mode

- /exec

show forwarding mpls option_b

show forwarding mpls option_b

```
show forwarding mpls option_b [ label <label> ] [ module <module> ] [ platform ] [ __readonly__ [ { TABLE_mpls_opt_b <label> [ <prefix> ] [ <v6prefix> ] [ <nxpath> ] [ <out-interface> ] [ <out-op> ] } ] ]
```

Syntax Description

show	show
forwarding	forwarding
mpls	mpls forwarding
option_b	Option B
label	(Optional) mpls labels
<i>label</i>	(Optional) mpls label value
module	(Optional) slot
<i>module</i>	(Optional) slot number
platform	(Optional) show pd info
__readonly__	(Optional)
TABLE_mpls_opt_b	(Optional)
<i>label</i>	(Optional) mpls label value
<i>prefix</i>	(Optional) Output Interface
<i>nxpath</i>	(Optional) Output Next Hop
<i>out-interface</i>	(Optional) Output Label op
<i>out-op</i>	(Optional) Output Label op

Command Mode

- /exec

show forwarding mpls srte module

```
show forwarding mpls srte module [ <module> ] [ __readonly__ [ { TABLE_srte <table-id> [ { TABLE_binding_label <binding-label> <parent-table-id> <parent-vobj-id> [ { TABLE_prefix <prefix> <vrf> } ] } ] ] ]
```

Syntax Description

show	Show
forwarding	Forwarding information
mpls	mpls forwaring
s rte	SR Traffic Engineering
module	slot
<i>module</i>	(Optional) slot number
<u>__readonly__</u>	(Optional)
TABLE_srte	(Optional)
<i>table-id</i>	(Optional) table id
TABLE_binding_label	(Optional)
<i>binding-label</i>	(Optional) binding label
<i>parent-table-id</i>	(Optional) parent table id
<i>parent-vobj-id</i>	(Optional) parent vobj id
TABLE_prefix	(Optional)
<i>prefix</i>	(Optional) prefix
<i>vrf</i>	(Optional) vrf

Command Mode

- /exec

show forwarding mpls summary

show forwarding mpls summary

show forwarding mpls summary [module <module>] [__readonly__ [{ TABLE_labels <space> <count> } <total_deagg_labels> <feature_evpn_status>]]

Syntax Description

show	show
forwarding	display fib information
mpls	mpls forwarding
summary	summary
module	(Optional) slot
<i>module</i>	(Optional) slot number
__readonly__	(Optional)
TABLE_labels	(Optional)
<i>space</i>	(Optional) label space
<i>count</i>	(Optional) number of labels
<i>total_deagg_labels</i>	(Optional) total deagg labels
<i>feature_evpn_status</i>	(Optional) feature evpn status

Command Mode

- /exec

show forwarding multicast-sr loopback interface

show forwarding multicast-sr loopback interface [__readonly__ [<port-num>]]

Syntax Description

show	
forwarding	display fib information
multicast-sr	multicast service reflect information
interface	loopback interface
loopback	loopback interface
__readonly__	(Optional)
<i>port-num</i>	(Optional) Port number

Command Mode

- /exec

show forwarding multicast-sr mac-trap-db

show forwarding multicast-sr mac-trap-db

show forwarding multicast-sr mac-trap-db [__readonly__ { [TABLE_mac_trap_db <mac-addr><mac-trap-id><ref-cnt>] <total-count> }]

Syntax Description

show	Show running system information
forwarding	display platform fib information
multicast-sr	multicast service reflect information
mac-trap-db	display internal mac-trap db
__readonly__	(Optional)
TABLE_mac_trap_db	(Optional) display internal mac-trap db
mac-addr	(Optional) MAC address
mac-trap-id	(Optional) MAC trap ID
ref-cnt	(Optional) Reference Count
total-count	(Optional) total count

Command Mode

- /exec

show forwarding multicast outgoing-interface-list

```
show forwarding multicast outgoing-interface-list { L2 | L3 | vxlan-encap | vxlan-ir-dci-encap | mvpn } [ platform ] [ module <module> ] [ <index> ] [ __readonly__ [ <refcount> ] [ <total_l2_oiflist> ] [ <total_l3_oiflist> ] [ <slot> ] [ TABLE_MCAST_OIF_INFO [ <oiflist_idx> ] [ <vlan> ] [ <num_oif> ] [ TABLE_MCAST_OIF_INTF_INFO [ <intf> ] [ <dvif> ] ] [ <encap_id> ] [ <hw_oiflist_idx> ] [ <mcidx> ] ] ]
```

Syntax Description

show	
forwarding	Forwarding information
multicast	Multicast IPv4 information
outgoing-interface-list	show outgoing interface list info
L2	Layer 2 oiflist
L3	Layer 3 oiflist
vxlan-encap	vxlan-encap oiflist
vxlan-ir-dci-encap	vxlan-ir-dci-encap oiflist
mvpn	MVPN oiflist
platform	(Optional) Display PI/PD
module	(Optional) slot
<i>module</i>	(Optional) slot number
<i>index</i>	(Optional) Outgoing Interface List Index
<i>__readonly__</i>	(Optional)
<i>refcount</i>	(Optional) Reference count
<i>total_l2_oiflist</i>	(Optional) total l2 oiflist
<i>total_l3_oiflist</i>	(Optional) total l3 oiflist
<i>slot</i>	(Optional) slot number
TABLE_MCAST_OIF_INFO	(Optional) Mcast OIF Info
<i>oiflist_idx</i>	(Optional) Outgoing Interface List Index
<i>vlan</i>	(Optional) Vlan id
<i>num_oif</i>	(Optional) Number of outgoing interfaces
TABLE_MCAST_OIF_INTF_INFO	(Optional) OIF Interfaces

show forwarding multicast outgoing-interface-list

<i>intf</i>	(Optional) OIF name
<i>dvif</i>	(Optional) DVIF
<i>encap_id</i>	(Optional) encapsulation ID
<i>hw_oiflist_idx</i>	(Optional) Hardware Outgoing Interface List Index
<i>mclidx</i>	(Optional) MC Index

Command Mode

- /exec

show forwarding multicast pvlan replicated-routes

```
show forwarding multicast pvlan replicated-routes [ { group <group_addr> [ [ source <source_addr> [ vlan <vlan_id> ] ] | vlan <vlan_id> ] | vlan <vlan_id> } ] [ __readonly__ [ { TABLE_entry <sh_vlan> <sh_group> <sh_source> } ] ]
```

Syntax Description

show	
forwarding	display fib information
multicast	Multicast IPv4 information
pvlan	PVLAN information
replicated-routes	Display replicated route database
group	(Optional) group address
<i>group_addr</i>	(Optional) group address
source	(Optional) source address
<i>source_addr</i>	(Optional) source address
vlan	(Optional) vlan id
<i>vlan_id</i>	(Optional) vlan id
<u>__readonly__</u>	(Optional)
TABLE_entry	(Optional)
<i>sh_vlan</i>	(Optional) vlan id
<i>sh_group</i>	(Optional) group address
<i>sh_source</i>	(Optional) source address

Command Mode

- /exec

show forwarding multicast route

show forwarding multicast route

```

show forwarding [ vrf { <vrf-name> | <vrf-known-name> | all } | table <table_id> ] [ ipv4 ] multicast route [
platform ] { [ group { <gaddr> [ <mask> ] | <gprefix> } [ source { <saddr> [ <smask> ] | <sprefix> } ] |
module <module> | vrf { <vrf-name> | <vrf-known-name> | all } ] + | summary [ module <module> | vrf {
<vrf-name> | <vrf-known-name> | all } ] + ] [ __readonly__ [ <table_type> ] [ <vrfname> ] [ <table_id> ] [
<num_routes> <num_starg_routes> <num_sg_routes> <num_gprefix_routes> ] [ <num_groups> ] [
<num_sources> ] [ <num_prefix_insert_fail> ] [ [ TABLE_MROUTE_INFO <mcast_addr> [ <src_len>
<grp_len> ] [ <df_ordinal> ] [ <rpfif> ] [ <rpf_ifindex> ] <flag> [ <flag_value> ] <route_pkts> <route_bytes>
<oiflist_id> <oif_count> [ <refcount> ] <oiflist_flag> [ TABLE_OIF_INFO <oifindex> [
TABLE_MCAST_VLAN_INFO [ <vlan> ] [ TABLE_MCAST_OIF_INFO [ <oifname> ] [ <dvif> ] ] ] [
<platform_id> ] [ <encap_id> ] [ TABLE_MCAST_CORE_OIF_INFO [ <core_oifname> ] ] [ <hw_index>
] [ <oif_pkts> <oif_bytes> ] ] ] ]

```

Syntax Description

show	
forwarding	Forwarding information
ipv4	(Optional) ipv4
multicast	Multicast IPv4 information
route	Mcast route information
platform	(Optional) Platform Details
table	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<i>table_id</i>	(Optional) table number
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
all	(Optional) Display information for all VRFs
group	(Optional) Multicast IPv4 Group specific info
<i>gaddr</i>	(Optional) Multicast IPv4 Group Address
<i>mask</i>	(Optional) Multicast IPv4 Group Address mask
<i>gprefix</i>	(Optional) Multicast IPv4 Group Prefix
source	(Optional) Multicast IPv4 Source specific info
<i>saddr</i>	(Optional) Multicast IPv4 Source Address
<i>smask</i>	(Optional) Multicast IPv4 Source Address mask

<i>sprefix</i>	(Optional) Multicast IPv4 Source Prefix
<i>summary</i>	display route counts
<i>module</i>	(Optional) slot
<i>module</i>	(Optional) slot number
<i>__readonly__</i>	(Optional)
<i>table_type</i>	(Optional) Table Type
<i>vrfname</i>	(Optional) VRF name
<i>table_id</i>	(Optional) Table ID
<i>num_routes</i>	(Optional) Number of routes
<i>num_starg_routes</i>	(Optional) Number of (*,G) routes
<i>num_sg_routes</i>	(Optional) Number of (S,G) routes
<i>num_gprefix_routes</i>	(Optional) Number of (*,G-prefix) routes
<i>num_groups</i>	(Optional) Number of group entries in the table
<i>num_prefix_insert_fail</i>	(Optional) Prefix insert fail count
<i>num_sources</i>	(Optional) Number of (S, G) entries for the group address
TABLE_MROUTE_INFO	(Optional) Mroute info
<i>mcast_addr</i>	(Optional) Mcast address
<i>src_len</i>	(Optional) Source Address Mask
<i>grp_len</i>	(Optional) Group address Mask
<i>df_ordinal</i>	(Optional) DF ordinal
<i>rpfif</i>	(Optional) RPF interface
<i>rpf_ifindex</i>	(Optional) RPF Interface ifIndex
<i>flag</i>	(Optional) Route type flag
<i>flag_value</i>	(Optional) hex value of route flag
<i>route_pkts</i>	(Optional) Route packet count
<i>route_bytes</i>	(Optional) Route bytes
<i>oiflist_id</i>	(Optional) OIF list Identifier
<i>oif_count</i>	(Optional) Number of OIFs
<i>oiflist_flag</i>	(Optional) OIF List flag

show forwarding multicast route

<i>refcount</i>	(Optional) OIF list Reference Count
TABLE_OIF_INFO	(Optional) OIF Info
<i>oifindex</i>	(Optional) OIF Interface ifIndex
TABLE_MCAST_VLAN_INFO	(Optional) Vlan Interfaces
<i>vlan</i>	(Optional) Vlan id
TABLE_MCAST_OIF_INFO	(Optional) OIF Interfaces
<i>oifname</i>	(Optional) OIF Interface name
<i>dvif</i>	(Optional) DVIF
TABLE_MCAST_CORE_OIF_INFO	(Optional) Core-facing OIF Interfaces
<i>core_oifname</i>	(Optional) Core-facing OIF Interface name
<i>platform_id</i>	(Optional) Platform-index
<i>encap_id</i>	(Optional) Encap ID
<i>hw_index</i>	(Optional) Harware index
<i>oif_pkts</i>	(Optional) OIF packets
<i>oif_bytes</i>	(Optional) OIF bytes

Command Mode

- /exec

show forwarding nve l2 ingress-replication-peers

```

show forwarding nve l2 ingress-replication-peers [ ipv4 <peer_ip> | ipv6 <v6_peer_ip> ] + [ __readonly__ [
{ TABLE_VLAN <vlan_id> <vni> <ifindex> <plt_space> <peer_bmp> <peer> } { TABLE_PSS_VLAN
<vlan_pss_id> <VNI> <vtep> <peercnt> <pss_peer_bmp> { <pss_peer> <marked> } + } ] + [ [ <peer> <id>
<repl_id> <oif> <hash_algo> <path_intf> + <vcount> <vlan_id> + <resync_vcount> <resync_vlan_id> + [
<path> <hash> <flags> <nh> <intf> + ] ] [ <pss_peer> <pss_id> <pss_repl_id> <pss_oif> <pss_hash_algo>
<pss_path_intf> + <pss_vcount> <vlan_pss_id> + [ <pss_path> <pss_hash> <pss_flags> <pss_nh> <pss_intf>
+ ] ] ]

```

Syntax Description

show	show
forwarding	display fib information
nve	nve related info
l2	L2 info
ingress-replication-peers	ingress replication peer info
ipv4	(Optional) ipv4 peer
<i>peer_ip</i>	(Optional) show detailed info of a peer
ipv6	(Optional) ipv6 peer
<u>readonly</u>	(Optional)
TABLE_VLAN	(Optional) vlan peer ids table
<i>vlan_id</i>	(Optional) vlan id
<i>vni</i>	(Optional) vni
<i>ifindex</i>	(Optional) ifindex
<i>plt_space</i>	(Optional) platform space
<i>peer_bmp</i>	(Optional) peer bitmap
<i>peer</i>	(Optional) peer_address
TABLE_PSS_VLAN	(Optional) vlan-peer in pss
<i>vlan_pss_id</i>	(Optional) pss_peer_id
VNI	(Optional) vni
<i>vtep</i>	(Optional) vtep
<i>peercnt</i>	(Optional) peer count
<i>pss_peer_bmp</i>	(Optional) PSS peer bitmap

show forwarding nve l2 ingress-replication-peers

<i>pss_peer</i>	(Optional) peer address
<i>marked</i>	(Optional) marked
<i>peer</i>	(Optional) peer
<i>id</i>	(Optional) id
<i>repl_id</i>	(Optional) repl_id
<i>oif</i>	(Optional) oif
<i>path_intf</i>	(Optional) path intf name
<i>hash_algo</i>	(Optional) hash algo used
<i>vcount</i>	(Optional) vlan count
<i>vlan_id</i>	(Optional) vlan id
<i>resync_vcount</i>	(Optional) resync vlan count
<i>resync_vlan_id</i>	(Optional) resync vlan id
<i>path</i>	(Optional) ecmp path
<i>hash</i>	(Optional) ecmp hash
<i>flags</i>	(Optional) ecmp flags
<i>nh</i>	(Optional) ecmp nh
<i>intf</i>	(Optional) ecmp interfaces
<i>pss_peer</i>	(Optional) peer
<i>pss_id</i>	(Optional) id
<i>pss_repl_id</i>	(Optional) repl_id
<i>pss_oif</i>	(Optional) oif
<i>pss_path_intf</i>	(Optional) path intf name
<i>pss_hash_algo</i>	(Optional) hash algo used
<i>pss_vcount</i>	(Optional) vlan count
<i>vlan_pss_id</i>	(Optional) vlan id
<i>pss_path</i>	(Optional) pss path
<i>pss_hash</i>	(Optional) pss hash
<i>pss_flags</i>	(Optional) pss flags
<i>pss_nh</i>	(Optional) pss nh

<i>pss_intf</i>	(Optional) pss intf
-----------------	---------------------

Command Mode

- /exec

show forwarding nve l3 adjacency tunnel

show forwarding nve l3 adjacency tunnel

```
show forwarding nve l3 adjacency tunnel [ <tunnel_id> | all ] [ bd <bd_id> | detail | module <module> | table <table_id> ] [ __readonly__ TABLE_nvel3adj <tunnel_id> <bd_id> <table_id> <VNI> <DownStream> <Drop> <RefCount> <Origin> <State> <Del> [ <sw_index> <hw_index0> <hw_index1> <hw_index2> ] ]
```

Syntax Description

show	
forwarding	display fib information
nve	nve related info
l3	Layer 3
adjacency	Adjacency info
tunnel	VXLAN tunnel
<i>tunnel_id</i>	(Optional) tunnel_id
all	(Optional) show adjacency info for all peers
bd	(Optional) BD info
<i>bd_id</i>	(Optional) bd id
detail	(Optional) Show detailed information
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
table	(Optional) Tenant table-id
<i>table_id</i>	(Optional) tenant table-id
<u>__readonly__</u>	(Optional)
TABLE_nvel3adj	(Optional)
<i>tunnel_id</i>	(Optional) tunnel_id
<i>bd_id</i>	(Optional) bd id
<i>table_id</i>	(Optional) tenant table-id
<i>VNI</i>	(Optional) vni
<i>DownStream</i>	(Optional) DownStream
<i>Drop</i>	(Optional) Drop
<i>RefCount</i>	(Optional) Refcount

<i>Origin</i>	(Optional) origin
<i>State</i>	(Optional) state
<i>Del</i>	(Optional) del
<i>sw_index</i>	(Optional)
<i>hw_index0</i>	(Optional)
<i>hw_index1</i>	(Optional)
<i>hw_index2</i>	(Optional)

Command Mode

- /exec

show forwarding nve l3 adjacency v6-tunnel

show forwarding nve l3 adjacency v6-tunnel

```
show forwarding nve l3 adjacency v6-tunnel [ <peer-ip> | all ] [ bd <bd_id> | detail | module <num> | table <table_id> ] [ __readonly__ TABLE_nvel3adj <peer-ip> <bd_id> <table_id> <VNI> <Drop> <Refcount> <Origin> <State> <Del> <sw_index> <hw_index0> <hw_index1> <hw_index2> ]
```

Syntax Description

show	
forwarding	display fib information
nve	nve related info
l3	Layer 3
adjacency	Adjacency info
v6-tunnel	VXLAN V6 tunnel
all	(Optional) Show adjacency for all peers
bd	(Optional) BD info
<i>bd_id</i>	(Optional) bd id
detail	(Optional) Show detailed information
module	(Optional) Slot/module
<i>num</i>	(Optional) Slot/module number
table	(Optional) Tenant table-id
<i>table_id</i>	(Optional) tenant table-id
<u>__readonly__</u>	(Optional)
TABLE_nvel3adj	(Optional)
<i>bd_id</i>	(Optional) bd id
<i>table_id</i>	(Optional) tenant table-id
VNI	(Optional) vni
Drop	(Optional) Drop
Refcount	(Optional) Refcount
Origin	(Optional) origin
State	(Optional) state
Del	(Optional) del

<i>sw_index</i>	(Optional)
<i>hw_index0</i>	(Optional)
<i>hw_index1</i>	(Optional)
<i>hw_index2</i>	(Optional)

Command Mode

- /exec

show forwarding nve l3 ecmp

show forwarding nve l3 ecmp

```
show forwarding nve l3 ecmp [ __readonly__ { TABLE_nvel3ecmp <hw_index><ecmp_hash><num_paths>
<table_id><flags><adj_flags><ref_count> { TABLE_tunnel_info [ <tunnel_id> | <tunnel_ip> ] <segment_id>
} <hw_ecmp_index0><hw_ecmp_index1><hw_ecmp_index2> } ]
```

Syntax Description

show	
forwarding	display fib information
nve	nve related info
l3	Layer 3
ecmp	nve ecmp info
<u>__readonly__</u>	(Optional)
TABLE_nvel3ecmp	(Optional) nve l3 ecmp table
<i>hw_index</i>	(Optional) hw_index address pointer
<i>ecmp_hash</i>	(Optional) ecmp hash
<i>num_paths</i>	(Optional) numer of members in ECMP
<i>table_id</i>	(Optional) table id
<i>flags</i>	(Optional) flags
<i>adj_flags</i>	(Optional) adj flags
<i>ref_count</i>	(Optional) num of references
TABLE_tunnel_info	(Optional)
<i>tunnel_id</i>	(Optional) tunnel id
<i>tunnel_ip</i>	(Optional) v6 tunnel ip
<i>segment_id</i>	(Optional) segment id
<i>hw_ecmp_index0</i>	(Optional) HW ECMP Index Unit 0
<i>hw_ecmp_index1</i>	(Optional) HW ECMP Index Unit 1
<i>hw_ecmp_index2</i>	(Optional) HW ECMP Index Unit 2

Command Mode

- /exec

show forwarding nve l3 peers

```
show forwarding nve l3 peers [ peers <peer_id> | tunnel <tunnel_id> | detail | module <module> ] + [
__readonly__ { TABLE_l3peers <tunnel_id><peer_id><peer_address><interface><rmac><origin><state>
<del> <count> } ]
```

Syntax Description

show	show
forwarding	display fib information
nve	nve related info
l3	Layer 3
peers	nve peers
<i>peer_id</i>	(Optional) nve peer-id
tunnel	(Optional) VXLAN tunnel
<i>tunnel_id</i>	(Optional) Unique identifier for the tunnel
detail	(Optional) Show detailed information
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
<i>__readonly__</i>	(Optional)
TABLE_l3peers	(Optional) all l3 nve peers
<i>tunnel_id</i>	(Optional) tunnel_id
<i>peer_id</i>	(Optional) peer_id
<i>peer_address</i>	(Optional) peer_address
<i>interface</i>	(Optional) interface
<i>rmac</i>	(Optional) rmac
<i>origin</i>	(Optional) origin
<i>state</i>	(Optional) state
<i>del</i>	(Optional) del
<i>count</i>	(Optional) count

Command Mode

- /exec

show forwarding nve underlay-interfaces

show forwarding nve underlay-interfaces

```
show forwarding nve underlay-interfaces [ __readonly__ { <broadcast_status> <broadcast_level>
<multicast_status> <multicast_level> <unicast_status> <unicast_level> <no_of_uplink_interfaces> } [ {
TABLE_uplinks <ifindex> <peerid bmp> <is_dci> [ <phy_if> ] } ] ]
```

Syntax Description

show	show
forwarding	display fib information
nve	NVE related info
underlay-interfaces	underlay interfaces info
<u>__readonly__</u>	(Optional)
<i>broadcast_status</i>	(Optional) status
<i>broadcast_level</i>	(Optional) broadcast level
<i>multicast_status</i>	(Optional) multicast status
<i>multicast_level</i>	(Optional) multicast level
<i>unicast_status</i>	(Optional) unitcast status
<i>unicast_level</i>	(Optional) unicast level
<i>no_of_uplink_interfaces</i>	(Optional) Number of uplink interfaces
TABLE_uplinks	(Optional)
<i>ifindex</i>	(Optional) uplink ifindex
<i>phy_if</i>	(Optional) uplink physical interface
<i>peerid bmp</i>	(Optional) peerid bitmap
<i>is_dci</i>	(Optional) dci flag

Command Mode

- /exec

show forwarding otv

show forwarding otv <intf> [peer <peer-id>] [module <module>] [__readonly__ <vlan> <peer-id> <peer_vlan_count><tunnel_ifindex><tunnel_ifname>]

Syntax Description

show	
forwarding	fib information
otv	overlay-transport-virtualization
<i>intf</i>	overlay interface
peer	(Optional) overlay peer
<i>peer-id</i>	(Optional) overlay peer-id
module	(Optional) slot
<i>module</i>	(Optional) slot number
__readonly__	(Optional)
<i>vlan</i>	(Optional) Vlan information
<i>peer-id</i>	(Optional) peer-id

Command Mode

- /exec

show forwarding otv ipv6 multicast route

show forwarding otv ipv6 multicast route

```

show forwarding otv ipv6 multicast route [ vlan <vlan_id> ] [ module <module> ] [ __readonly__ [ <table_type> ]
] [ <vlan_id> ] [ <replicator> ] [ <num_routes> ] [ <num_starg_routes> ] [ <num_sg_routes> ] [
<num_gprefix_routes> ] [ <num_prefix_insert_fail> ] [ <num_groups> ] [ <num_sources> ] [ {
TABLE_otv_mroute [ <src_addr> ] [ <src_len> ] [ <grp_addr> ] [ <grp_len> ] [ <df_ordinal> ] [ <rpfif> ] [
<flag> ] [ <route_pkts> ] [ <route_bytes> ] [ <otv_route_pkts> ] [ <otv_route_bytes> ] [ { TABLE_OIF
<oif_count> [ <oiflist_id> ] [ <index> ] [ <refcount> ] [ { TABLE_OIFLIST <oifindex> [ <oif_pkts> ] [
<oif_bytes> ] [ <src_addr> ] [ <src_len> ] [ <oifname> ] [ <vlanid> ] [ <grp_addr> ] [ <grp_len> ] [
<otv_src_addr> ] [ <otv_grp_addr> ] } ] } ] ] ]

```

Syntax Description

show	show
forwarding	forwarding
otv	over-the-top virtualization
ipv6	ipv6
multicast	Multicast IPv6 information
route	Mcast route information
vlan	(Optional) vlan
<i>vlan_id</i>	(Optional) vlan id
module	(Optional) slot
<i>module</i>	(Optional) slot number
<u>__readonly__</u>	(Optional)
<i>table_type</i>	(Optional) Table Type
<i>vlan-id</i>	(Optional) vlan id
<i>replicator</i>	(Optional) replicator name
<i>num_routes</i>	(Optional) Number of routes
<i>num_starg_routes</i>	(Optional) Number of (*,G) routes
<i>num_sg_routes</i>	(Optional) Number of (S,G) routes
<i>num_gprefix_routes</i>	(Optional) Number of (*,G-prefix) routes
<i>num_prefix_insert_fail</i>	(Optional) Prefix insert fail count
<i>num_groups</i>	(Optional) Number of group entries in the table
<i>num_sources</i>	(Optional) Number of (S, G) entries for the group address

TABLE_otv_mroute	(Optional)
<i>src_addr</i>	(Optional) Ipv6 address string
<i>src_len</i>	(Optional) Source Address Mask
<i>grp_addr</i>	(Optional) Ipv6 address string
<i>grp_len</i>	(Optional) Group address Mask
<i>df_ordinal</i>	(Optional) DF ordinal
<i>rpfif</i>	(Optional) RPF interface
<i>flag</i>	(Optional) Route type flag
<i>route_pkts</i>	(Optional) Route packet count
<i>route_bytes</i>	(Optional) Route bytes
<i>otv_route_pkts</i>	(Optional) OTV Route packet count
<i>otv_route_bytes</i>	(Optional) OTV Route bytes
TABLE_OIF	(Optional)
<i>oif_count</i>	(Optional) Number of OIFs
<i>oiflist_id</i>	(Optional) OIF list Identifier
<i>index</i>	(Optional) outgoing interface list index
<i>refcount</i>	(Optional) reference count
TABLE_OIFLIST	(Optional)
<i>oifindex</i>	(Optional) OIF Interface ifIndex
<i>oif_pkts</i>	(Optional) OIF packets
<i>oif_bytes</i>	(Optional) OIF bytes
<i>src_addr</i>	(Optional) Multicast IPv4 Source Address
<i>src_len</i>	(Optional) Source Address Mask
<i>oifname</i>	(Optional) OIF Interface name
<i>vlanid</i>	(Optional) vlan id of the route
<i>grp_addr</i>	(Optional) Multicast IPv4 Group Address
<i>grp_len</i>	(Optional) Group address Mask
<i>otv_src_addr</i>	(Optional) Multicast IPv4 Source Address
<i>otv_grp_addr</i>	(Optional) Multicast IPv4 Group Address

```
show forwarding otv ipv6 multicast route
```

Command Mode

- /exec

show forwarding otv multicast outgoing-interface-list

```
show forwarding otv multicast outgoing-interface-list [ __readonly__ { TABLE_OIF <index> [ <refcount> ] [ <intf> ] [ { TABLE_OIFLIST <oifindex> [ <src_addr> ] [ <src_len> ] [ <oifname> ] [ <vlanid> ] [ <grp_addr> ] [ <grp_len> ] } ] } ]
```

Syntax Description

show	
forwarding	Forwarding information
otv	over-the-top virtualization
multicast	Multicast IPv4 information
outgoing-interface-list	show outgoing interface list info
__readonly__	(Optional)
TABLE_OIF	(Optional) outgoing interface list table
index	(Optional) outgoing interface list index
refcount	(Optional) reference count
intf	(Optional) interface name
TABLE_OIFLIST	(Optional) outgoing interface list table
oifindex	(Optional) OIF Interface ifIndex
src_addr	(Optional) Multicast IPv4 Source Address
src_len	(Optional) Source Address Mask
oifname	(Optional) OIF Interface name
vlanid	(Optional) vlan id of the route
grp_addr	(Optional) Multicast IPv4 Group Address
grp_len	(Optional) Group address Mask

Command Mode

- /exec

show forwarding otv multicast route

show forwarding otv multicast route

show forwarding otv multicast route [[vlan <vlan-id>] | [softwarebd <software-bd>]] [module <module>] [__readonly__ <replicator>]

Syntax Description

show	show
forwarding	forwarding
otv	over-the-top virtualization
multicast	Multicast IPv4 information
route	Mcast route information
vlan	(Optional) vlan
<i>vlan-id</i>	(Optional) vlan id
softwarebd	(Optional) Software Bridge Domain
<i>software-bd</i>	(Optional) Software bd
module	(Optional) slot
<i>module</i>	(Optional) slot number
<u>__readonly__</u>	(Optional)
<i>replicator</i>	(Optional) replicator name

Command Mode

- /exec

show forwarding otv vlan

show forwarding otv vlan [<vlan_id>] [module <module>] [__readonly__ <vlan>]

Syntax Description

show	show
forwarding	forwarding
otv	otv
vlan	vlan
<i>vlan_id</i>	(Optional) vlan id
module	(Optional) slot
<i>module</i>	(Optional) slot number
<u>__readonly__</u>	(Optional)
<i>vlan</i>	(Optional) vlan

Command Mode

- /exec

show forwarding proactive-cc inconsistencies

show forwarding proactive-cc inconsistencies

```
show forwarding proactive-cc inconsistencies [ all ] [ __readonly__ [ <cc_status> ] [ TABLE_v4adj_hdr
<incons_v4_adjs> [ TABLE_v4_adjs <id> <slot> <vrf> <ipaddr> <intf> <reason> <time> ] ] [
TABLE_v4route_hdr <incons_v4_routes> [ TABLE_v4_routes <id> <slot> <vrf> <ipprefix> <reason>
<time> ] ] [ TABLE_v6adj_hdr <incons_v6_adjs> [ TABLE_v6_adjs <id> <slot> <vrf> <ipv6addr> <intf>
<reason> <time> ] ] [ TABLE_v6route_hdr <incons_v6_routes> [ TABLE_v6_routes <id> <slot> <vrf>
<ipv6prefix> <reason> <time> ] ] ]
```

Syntax Description

show	show
forwarding	Display Forwarding Information
proactive-cc	Proactive Consistency Checker
inconsistencies	Display latest CC run inconsistencies
all	(Optional) Display all previous CC run's inconsistencies
__readonly__	(Optional)
cc_status	(Optional) proactive cc status
TABLE_v4adj_hdr	(Optional) Table v4 adjacency header
incons_v4_adjs	(Optional) Inconsistent Adjacency header
TABLE_v4_adjs	(Optional) Table for v4 Adjacency
id	(Optional) Serial number
slot	(Optional) Slot number
vrf	(Optional) Vrf name
ipaddr	(Optional) Adjacency prefix
intf	(Optional) Interface
reason	(Optional) Inconsistency reason
time	(Optional) Timestamp
TABLE_v4route_hdr	(Optional) Table v4 route header
incons_v4_routes	(Optional) Inconsistent Route Header
TABLE_v4_routes	(Optional) Table for v4 routes
id	(Optional) Serial number
slot	(Optional) Slot number

<i>vrf</i>	(Optional) Vrf name
<i>ipprefix</i>	(Optional) Route Prefix
<i>reason</i>	(Optional) Inconsistency reason
<i>time</i>	(Optional) Timestamp
TABLE_v6adj_hdr	(Optional) Table v6 adjacency header
<i>incons_v6_adjs</i>	(Optional) Inconsistent v6 Adjacency header
TABLE_v6_adjs	(Optional) Table for v6 Adjacency
<i>id</i>	(Optional) Serial Number
<i>slot</i>	(Optional) Slot Number
<i>vrf</i>	(Optional) Vrf name
<i>intf</i>	(Optional) Interface
<i>reason</i>	(Optional) Inconsistency reason
<i>time</i>	(Optional) Timestamp
TABLE_v6route_hdr	(Optional) Table v6 Route header
<i>incons_v6_routes</i>	(Optional) Inconsistent route header
TABLE_v6_routes	(Optional) Table for v6 route
<i>id</i>	(Optional) Serial number
<i>slot</i>	(Optional) Slot number
<i>vrf</i>	(Optional) Vrf name
<i>reason</i>	(Optional) Inconsistency reason
<i>time</i>	(Optional) Timestamp

Command Mode

- /exec

show forwarding security group-tag

show forwarding security group-tag

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | table <table_id> | vlan <vlan_id> ] [ ipv4 ] security group-tag [ <addr> ] [ module <module> | vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] + [ __readonly__ TABLE_sgt_vrf { <tid> <pxf-count> [ TABLE_sgt_prefix [ <ipa> ] [ <tag> ] [ <tv> ] ] } ]
```

Syntax Description

show	
forwarding	display fib information
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
table	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<i>table_id</i>	(Optional) table number
vlan	(Optional) vlan
<i>vlan_id</i>	(Optional) vlan number
ipv4	(Optional) ipv4
security	display IP security information
group-tag	ip_address->security_group_tag
<i>addr</i>	(Optional) specific ip address
module	(Optional) slot
<i>module</i>	(Optional) slot number
<u>__readonly__</u>	(Optional)
TABLE_sgt_vrf	(Optional) vrf table
<i>tid</i>	(Optional) table identifier
<i>pxf-count</i>	(Optional) total prefix count in VRF
TABLE_sgt_prefix	(Optional) all xml prefix entries
<i>ipa</i>	(Optional) ip address
<i>tag</i>	(Optional) security group tag

<i>tv</i>	(Optional) sgt valid
-----------	----------------------

Command Mode

- /exec

show forwarding security mac

```
show forwarding [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | table <table_id> ] [ ipv4 ] security
mac [ <addr> ] [ module <module> | vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] + [ __readonly__
TABLE_sec_vrf { <tid> <pfx-count> [ TABLE_sec_prefix <ipa> <mac> <p> <m> <v> <intf> ] } ]
```

Syntax Description

show	
forwarding	display fib information
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>vrf-all</i>	(Optional) Display information for all VRFs
table	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<i>table_id</i>	(Optional) table number
ipv4	(Optional) ipv4
security	display IP security information
mac	ip_address->mac_address
<i>addr</i>	(Optional) specific ip address
module	(Optional) slot
<i>module</i>	(Optional) slot number
<u>__readonly__</u>	(Optional)
TABLE_sec_vrf	(Optional) security vrf table
<i>tid</i>	(Optional) table identifier
<i>pfx-count</i>	(Optional) total prefix count in VRF
TABLE_sec_prefix	(Optional) all xml security prefix entries
<i>ipa</i>	(Optional) ip address
<i>mac</i>	(Optional) mac address
<i>m</i>	(Optional) 1 => ip->mac binding
<i>v</i>	(Optional) 1 => ip->vlan binding
<i>p</i>	(Optional) 1 => ip->port binding

<i>intf</i>	(Optional) ip->port interface
-------------	-------------------------------

Command Mode

- /exec

show forwarding srv6 adjacency decap

show forwarding srv6 adjacency decap

```
show forwarding srv6 adjacency decap [ table <table_id> ] [ module <num> ] [ __readonly__ {  
TABLE_adj_decap <locator> <function> <behavior> <tableid> <bd> <is_drop> } ]
```

Syntax Description

show	show
forwarding	display fib information
srv6	Segment routing V6
adjacency	SRV6 adjacency
decap	Decapsulation adjacency
table	(Optional) display info per vpn-id
<i>table_id</i>	(Optional) table number
<i>bd</i>	(Optional) Bridge domain
module	(Optional) Slot/module
<i>num</i>	(Optional) Slot/module number
<u>__readonly__</u>	(Optional)
TABLE_adj_decap	(Optional) all SRV6 decap adjacencies
<i>locator</i>	(Optional) Locator or binding sid
<i>function</i>	(Optional) Function
<i>behavior</i>	(Optional) Behavior
<i>tableid</i>	(Optional) tabled number
<i>is_drop</i>	(Optional) Indicates if adjacency is a drop

Command Mode

- /exec

show forwarding srv6 adjacency encapsulation

```
show forwarding srv6 adjacency encapsulation [ table <table_id> ] [ module <num> ] [ __readonly__ {  
    TABLE_adj_encap <loc_bsid> <source_ip> <function> <tableid> <is_drop> <bsid> } ]
```

Syntax Description

show	show
forwarding	display fib information
srv6	Segment routing V6
adjacency	SRV6 adjacency
encapsulation	Encapsulation adjacency
table	(Optional) display info per vpn-id
<i>table_id</i>	(Optional) table number
module	(Optional) Slot/module
<i>num</i>	(Optional) Slot/module number
__readonly__	(Optional)
TABLE_adj_encap	(Optional) all SRV6 encapsulation adjacencies
<i>loc_bsid</i>	(Optional) Locator or binding sid
<i>source_ip</i>	(Optional) Source IPv6 address
<i>function</i>	(Optional) Function
<i>tableid</i>	(Optional) table number
<i>is_drop</i>	(Optional) Indicates if adjacency is a drop
<i>bsid</i>	(Optional) binding sid

Command Mode

- /exec

show forwarding srv6 bsid-peer

show forwarding srv6 bsid-peer

show forwarding srv6 bsid-peer [<bsid_value>] [<endpoint>] [module <num>] [__readonly__ { TABLE_bsid_peer <bsid> <endpoint> <type> <table_id> <peer-id> }]

Syntax Description

show	show
forwarding	display fib information
srv6	Segment routing V6
bsid-peer	Binding SID identifier
module	(Optional) Slot/module
<i>num</i>	(Optional) Slot/module number
__readonly__	(Optional)
TABLE_bsid_peer	(Optional) BSID peer table
<i>bsid</i>	(Optional) Bsid value
<i>endpoint</i>	(Optional) Endpoint
<i>type</i>	(Optional) BSID type
<i>table_id</i>	(Optional) Table ID
<i>peer-id</i>	(Optional) Peer ID

Command Mode

- /exec

show forwarding srv6 bsid

show forwarding srv6 bsid [<bsid_value>] [module <num>] [__readonly__ { TABLE_bsid <bsid> <type> <table_id> <num_sids> <sid_list> <list_count> }]

Syntax Description

show	show
forwarding	display fib information
srv6	Segment routing V6
bsid	Binding SID
module	(Optional) Slot/module
<i>num</i>	(Optional) Slot/module number
__readonly__	(Optional)
TABLE_bsid	(Optional) BSID table
<i>table_id</i>	(Optional) Table ID
<i>type</i>	(Optional) BSID type
<i>num_sids</i>	(Optional) Number of SID's in list
<i>bsid</i>	(Optional) Bsid value
<i>sid_list</i>	(Optional) SID in list
<i>list_count</i>	(Optional) Number of dependent peer objects

Command Mode

- /exec

show forwarding srv6 ecmp

show forwarding srv6 ecmp

```
show forwarding srv6 ecmp [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } | [ table <table_id> ] | [ module <num> ] [ __readonly__ { TABLE_ecmp <num_paths> <table_id> { TABLE_adj <loc_bsid> <source_ip> <function> } } ] ]
```

Syntax Description

show	show
forwarding	display fib information
srv6	Segment routing V6
ecmp	SRV6 ecmp
vrf	(Optional) display info per VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>vrf-all</i>	(Optional) Display information for all VRFs
table	(Optional) display info per vpn-id
<i>table_id</i>	(Optional) table number
module	(Optional) Slot/module
<i>num</i>	(Optional) Slot/module number
<u>__readonly__</u>	(Optional)
TABLE_ecmp	(Optional) ecmp table
<i>num_paths</i>	(Optional) No of paths
<i>table_id</i>	(Optional) table number
TABLE_adj	(Optional) Adjacency table
<i>loc_bsid</i>	(Optional) Locator or binding sid
<i>source_ip</i>	(Optional) Source IPV6 address
<i>function</i>	(Optional) Function

Command Mode

- /exec

show forwarding srv6 local-sid

show forwarding srv6 local-sid [<sid_value>] [detail] [module <num>] [__readonly__ { TABLE_local_sid <locator> <source_ip> <function> <behavior> <sid> }]

Syntax Description

show	show
forwarding	display fib information
srv6	Segment routing V6
local-sid	local segment identifier
detail	(Optional) Details about SID
module	(Optional) Slot/module
<i>num</i>	(Optional) Slot/module number
__readonly__	(Optional)
TABLE_local_sid	(Optional) Local SID info
<i>locator</i>	(Optional) Locator
<i>source_ip</i>	(Optional) Source IPV6 address
<i>function</i>	(Optional) function
<i>behavior</i>	(Optional) Behavior
<i>sid</i>	(Optional) Segment identifier

Command Mode

- /exec

show forwarding srv6 peers

show forwarding srv6 peers

show forwarding srv6 peers [module <num>] [__readonly__ { TABLE_peers <peer_id> <locator> <source_ip> <vobj_count> }]

Syntax Description

show	show
forwarding	display fib information
srv6	Segment routing V6
peers	SRV6 peer
module	(Optional) Slot/module
<i>num</i>	(Optional) Slot/module number
__readonly__	(Optional)
TABLE_peers	(Optional) all SRV6 peers
<i>peer_id</i>	(Optional) peer_id
<i>locator</i>	(Optional) Locator
<i>source_ip</i>	(Optional) Source IPV6 address
<i>vobj_count</i>	(Optional) Number of VOBJS dependent on this peer

Command Mode

- /exec

show forwarding trace

show forwarding trace [clear] [module <module>] [__readonly__ <op>]

Syntax Description

show	
forwarding	display fib information
trace	display trace buffer
clear	(Optional) clear the trace buffer
module	(Optional) slot
<i>module</i>	(Optional) slot number
<u>__readonly__</u>	(Optional)
<i>op</i>	(Optional) output

Command Mode

- /exec

show forwarding trace profile

show forwarding trace profile

show forwarding trace profile

Syntax Description

show	
forwarding	display fib information
trace	display trace buffer
profile	show the collection profiling information

Command Mode

- /exec

show forwarding trace profile funcstats

show forwarding trace profile funcstats [enable | disable] [module <module>] [__readonly__ <op>]

Syntax Description

show	
forwarding	display fib information
trace	display trace buffer
profile	show the collection profiling information
funcstats	function statistics
enable	(Optional) enable function statistics
disable	(Optional) disable function statistics
module	(Optional) slot
<i>module</i>	(Optional) slot number
__readonly__	(Optional)
<i>op</i>	(Optional) output

Command Mode

- /exec

show frequency synchronization clock-interface brief

show frequency synchronization clock-interface brief

```
show frequency synchronization clock-interface brief [ __readonly__ [ TABLE_fsync <clock_name>
<source_class> <clock_node> <clock_id> <clock_state> <assigned_for_selection> <ssm_support>
<ssm_enabled> <loop_back> <squelched> <input_disabled> <output_disabled> <ql_recv_option> <ql_rcv>
<ql_use_option> <ql_use> <priorities> <ql_snt_option> <ql_snt> <selected_source_class> <selected_source_ifh>
<selected_source_clock_node> <selected_source_clock_id> <selected_source_clock_name> ] <fsync-end>
]
```

Syntax Description

show	Show running system information
frequency	Frequency Synchronization Manager
synchronization	Frequency Synchronization Manager
clock-interface	Display clock-interface information
brief	Displays all interfaces
__readonly__	(Optional) Read Only
TABLE_fsync	(Optional) fsync_mgr table
source_class	(Optional) class of the source
clock_node	(Optional) clock's node id
clock_id	(Optional) clock's id
clock_name	(Optional) clock name
clock_state	(Optional) clock state
assigned_for_selection	(Optional) whether assigned as selection input
ssm_support	(Optional) ssm support - enabled or disabled
ssm_enabled	(Optional) ssm enabled - enabled or disabled
loop_back	(Optional) loopback enabled or disabled
squelched	(Optional) output is squelched or not
input_disabled	(Optional) input disabled or enabled
output_disabled	(Optional) output disabled or enabled
ql_recv_option	(Optional) ql recv option
ql_rcv	(Optional) ql rcv
ql_use_option	(Optional) ql use option

<i>ql_use</i>	(Optional) ql use
<i>priority</i>	(Optional) priority of sync port
<i>ql_snt_option</i>	(Optional) ql snt option
<i>ql_snt</i>	(Optional) ql snt
<i>selected_source_class</i>	(Optional) selected source class type
<i>selected_source_ifh</i>	(Optional) selected source ifh
<i>selected_source_clock_node</i>	(Optional) selected source clock node
<i>selected_source_clock_id</i>	(Optional) selected source clock id
<i>selected_source_clock_name</i>	(Optional) selected sourced clock name
<i>fsync-end</i>	(Optional) End of table

Command Mode

- /exec

show frequency synchronization clock-interface detail

show frequency synchronization clock-interface detail

```
show frequency synchronization clock-interface detail [ __readonly__ [ TABLE_fsync <clock_name>
<source_class><clock_node><clock_id><clock_state><clock_type><pd_down_reason><selection_input>
<wtr_time><ssm_state><ssm_support><input_disabled><input_damping_state><input_damping_time>
<cfgd_in_ql_min_option><cfgd_in_ql_min><cfgd_in_ql_max_option><cfgd_in_ql_max>
<cfgd_in_ql_exact_option><cfgd_in_ql_exact><effective_in_ql_option><effective_in_ql><priority>
<tod_priority><supp_freq><supp_time><loop_back><output_disabled><selected_source_class>
<selected_source_ifh><selected_source_clock_node><selected_source_clock_id>
<selected_source_clock_name><selected_source_ql_option><selected_source_ql><cfgd_out_ql_min_option>
<cfgd_out_ql_min><cfgd_out_ql_max_option><cfgd_out_ql_max><cfgd_out_ql_exact_option>
<cfgd_out_ql_exact><effective_out_ql_option><effective_out_ql><squelched><num_next_seln_points>
<next_selection_points> + <current_clock_end> ] <fsync-end> ]
```

Syntax Description

show	Show running system information
frequency	Frequency Synchronization Manager
synchronization	Frequency Synchronization Manager
clock-interface	Display clock-interface information
detail	details
<u>__readonly__</u>	(Optional) Read Only
TABLE_fsync	(Optional) fsync_mngr table
<i>source_class</i>	(Optional) class of the source
<i>clock_node</i>	(Optional) clock's node id
<i>clock_id</i>	(Optional) clock's id
<i>clock_name</i>	(Optional) clock name
<i>clock_state</i>	(Optional) clock state
<i>clock_type</i>	(Optional) clock's type
<i>pd_down_reason</i>	(Optional) clock pd down reason
<i>selection_input</i>	(Optional) whether assigned as selection input
<i>wtr_time</i>	(Optional) wait to restore timer value
<i>ssm_state</i>	(Optional) ssm state - enabled or disabled
<i>ssm_support</i>	(Optional) ssm support
<i>input_disabled</i>	(Optional) input disabled or enabled

<i>input_damping_state</i>	(Optional) input damping state
<i>input_damping_time</i>	(Optional) input damping time
<i>cfgd_in_ql_min_option</i>	(Optional) cfg in min ql option
<i>cfgd_in_ql_min</i>	(Optional) cfg in min ql option
<i>cfgd_in_ql_max_option</i>	(Optional) cfg in max ql option
<i>cfgd_in_ql_max</i>	(Optional) cfg in max ql option
<i>cfgd_in_ql_exact_option</i>	(Optional) cfg in exact ql option
<i>cfgd_in_ql_exact</i>	(Optional) cfg in exact ql option
<i>effective_in_ql_option</i>	(Optional) cfg in ql option
<i>effective_in_ql</i>	(Optional) cfg in ql option
<i>priority</i>	(Optional) priority
<i>tod_priority</i>	(Optional) time of day priority
<i>supp_freq</i>	(Optional) supporting freq sync or time sync
<i>supp_time</i>	(Optional) supporting time sync
<i>loop_back</i>	(Optional) loopback enabled or disabled
<i>output_disabled</i>	(Optional) output disabled or enabled
<i>selected_source_class</i>	(Optional) selected source class type
<i>selected_source_ifh</i>	(Optional) selected source ifh
<i>selected_source_clock_node</i>	(Optional) selected source clock node
<i>selected_source_clock_id</i>	(Optional) selected source clock id
<i>selected_source_clock_name</i>	(Optional) selected sourced clock name
<i>selected_source_ql_option</i>	(Optional) selected source ql option
<i>selected_source_ql</i>	(Optional) effective out ql option
<i>cfgd_out_ql_min_option</i>	(Optional) cfg out min ql option
<i>cfgd_out_ql_min</i>	(Optional) cfg out min ql option
<i>cfgd_out_ql_max_option</i>	(Optional) cfg out max ql option
<i>cfgd_out_ql_max</i>	(Optional) cfg out max ql option
<i>cfgd_out_ql_exact_option</i>	(Optional) cfg out exact ql option
<i>cfgd_out_ql_exact</i>	(Optional) cfg out exact ql option

show frequency synchronization clock-interface detail

<i>effective_out ql_option</i>	(Optional) effective out ql option
<i>effective_out ql</i>	(Optional) effective out ql option
<i>squelched</i>	(Optional) output is squelched or not
<i>num_next_seln_points</i>	(Optional) num of next seln points
<i>next_selection_points</i>	(Optional) next selection points
<i>current_clock_end</i>	(Optional) cuurent clock end
<i>fsync-end</i>	(Optional) End of table

Command Mode

- /exec

show frequency synchronization configuration errors

```
show frequency synchronization configuration errors [ __readonly__ [ TABLE_fsync<fsync_src><enable_err>
<input_min_err><input_exact_err><input_max_err><output_min_err><output_exact_err><output_max_err>
<ext_ql_input_min_err><ext_ql_input_exact_err><ext_ql_input_max_err><ext_ql_output_min_err>
<ext_ql_output_exact_err><ext_ql_output_max_err><input_output_mismatch><input_min_ql_option>
<input_min_ql><input_exact_ql_option><input_exact_ql><input_max_ql_option><input_max_ql>
<output_min_ql_option><output_min_ql><output_exact_ql_option><output_exact_ql>
<output_max_ql_option><output_max_ql><cmd_src_index> ] <fsync-end> ]
```

Syntax Description

show	Show running system information
frequency	Frequency Synchronization Manager
synchronization	Frequency Synchronization Manager
configuration	configuration
errors	errors
<u>__readonly__</u>	(Optional) Read Only
TABLE_fsync	(Optional) fsync_mgr table
fsync_src	(Optional) Interface Index
enable_err	(Optional) freq sync enable error
input_min_err	(Optional) Minimum input QL option config error
input_exact_err	(Optional) Exact input QL config error
input_max_err	(Optional) Maximum input QL option config error
output_min_err	(Optional) Minimum output QL option config error
output_exact_err	(Optional) Exact output QL option config error
output_max_err	(Optional) Maximum output QL option config error
ext_ql_input_min_err	(Optional) minimum input extended Ql config error
ext_ql_input_exact_err	(Optional) exact input extended Ql config error
ext_ql_input_max_err	(Optional) maximun input extended Ql config error
ext_ql_output_min_err	(Optional) min output extended ql config error
ext_ql_output_exact_err	(Optional) exact output extended ql config error
ext_ql_output_max_err	(Optional) max output extended ql config error
input_output_mismatch	(Optional) input/output mismatch error

show frequency synchronization configuration errors

<i>input_min_ql_option</i>	(Optional) input min ql option
<i>input_min_ql</i>	(Optional) configured min input ql
<i>input_exact_ql_option</i>	(Optional) input exact ql option
<i>input_exact_ql</i>	(Optional) configured exact input ql
<i>input_max_ql_option</i>	(Optional) input exact ql option
<i>input_max_ql</i>	(Optional) configured max input ql
<i>output_min_ql_option</i>	(Optional) output min ql option
<i>output_min_ql</i>	(Optional) configured min output ql
<i>output_exact_ql_option</i>	(Optional) output exact ql option
<i>output_exact_ql</i>	(Optional) configured exact output ql
<i>output_max_ql_option</i>	(Optional) output exact ql option
<i>output_max_ql</i>	(Optional) configured max output ql
<i>cmd_src_index</i>	(Optional) index for source array
<i>fsync-end</i>	(Optional) End of table

Command Mode

- /exec

show frequency synchronization interface

```
show frequency synchronization interface <if0> [ __readonly__ <if_state> <selection_input> <wtr_time>
<ssm_state> <esmc_peer_state> <esmc_peer_time_secs> <esmc_peer_time_nsecs> <last_ssm_time_secs>
<last_ssm_time_nsecs> <peer_up_count> <peer_timeout_count> <esmc_infos_sent> <esmc_events_sent>
<esmc_dnus_sent> <esmc_infos_rcvd> <esmc_events_rcvd> <esmc_dnus_rcvd> <esmc_malformed_rcvd>
<esmc_rcvd_error> <input_damping_state> <input_damping_time> [ <last_rcvd_ql_option> ] [ <last_rcvd_ql>
] <cfgd_in_ql_min_option> <cfgd_in_ql_min> <cfgd_in_ql_max_option> <cfgd_in_ql_max>
<cfgd_in_ql_exact_option> <cfgd_in_ql_exact> [ <effective_in_ql_option> ] [ <effective_in_ql> ] <priority>
<tod_priority> [ <ql_data_rcvd_has_ext_data> ] [ <ql_data_rcvd_orig_clock_id> ] [
<ql_data_rcvd_sync_steps> ] [ <ql_data_rcvd_esync_steps> ] [ <ql_data_rcvd_all_steps_sync> ] [
<ql_data_rcvd_chain_complete> ] <supp_freq> <supp_time> [ <selected_source_class> ] [
<selected_source_ifh> ] [ <selected_source_clock_node> ] [ <selected_source_clock_id> ] [
<selected_source_clock_name> ] [ <selected_source_ql_option> ] [ <selected_source_ql> ]
<cfgd_out_ql_min_option> <cfgd_out_ql_min> <cfgd_out_ql_max_option> <cfgd_out_ql_max>
<cfgd_out_ql_exact_option> <cfgd_out_ql_exact> [ <effective_out_ql_option> ] [ <effective_out_ql> ] [
<ql_data_to_send_has_ext_data> ] [ <ql_data_to_send_orig_clock_id> ] [ <ql_data_to_send_sync_steps>
] [ <ql_data_to_send_esync_steps> ] [ <ql_data_to_send_all_steps_sync> ] [
<ql_data_to_send_chain_complete> ] <squelched> <num_next_seln_points> <next_selection_points> + ]
```

Syntax Description

show	Show running system information
frequency	Frequency Synchronization Manager
synchronization	Frequency Synchronization Manager
interface	Display interface information
<i>if0</i>	
<i>__readonly__</i>	(Optional) Read Only
<i>if_state</i>	(Optional) interface state
<i>selection_input</i>	(Optional) whether assigned as selection input
<i>wtr_time</i>	(Optional) wait to restore timer value
<i>ssm_state</i>	(Optional) ssm state - enabled or disabled
<i>esmc_peer_state</i>	(Optional) esmc peer state
<i>esmc_peer_time_secs</i>	(Optional) peer up or down time recorded secs
<i>esmc_peer_time_nsecs</i>	(Optional) peer up or down time recorded nsecs
<i>last_ssm_time_secs</i>	(Optional) last ssm received time in secs
<i>last_ssm_time_nsecs</i>	(Optional) last ssm received time in nsecs
<i>peer_up_count</i>	(Optional) no of times peer went up

show frequency synchronization interface

<i>peer_timeout_count</i>	(Optional) no of times peer timed out
<i>esmc_infos_sent</i>	(Optional) esmc infos sent
<i>esmc_events_sent</i>	(Optional) esmc events sent
<i>esmc_dnus_sent</i>	(Optional) esmc dnus sent
<i>esmc_infos_rcvd</i>	(Optional) esmc infos rcvd
<i>esmc_events_rcvd</i>	(Optional) esmc events rcvd
<i>esmc_dnus_rcvd</i>	(Optional) esmc dnus rcvd
<i>esmc malformed_rcvd</i>	(Optional) esmc malformed rcvd frames
<i>esmc_rcvd_error</i>	(Optional) esmc recv frame errors
<i>input_damping_state</i>	(Optional) input damping state
<i>input_damping_time</i>	(Optional) input damping time
<i>last_rcvd_ql_option</i>	(Optional) last ql rcv option
<i>last_rcvd_ql</i>	(Optional) last rcvd ql
<i>cfgd_in_ql_min_option</i>	(Optional) cfgd in ql min option
<i>cfgd_in_ql_min</i>	(Optional) cfgd in ql min
<i>cfgd_in_ql_max_option</i>	(Optional) cfgd in ql mAX option
<i>cfgd_in_ql_max</i>	(Optional) cfgd in max ql
<i>cfgd_in_ql_exact_option</i>	(Optional) cfgd in ql exact option
<i>cfgd_in_ql_exact</i>	(Optional) cfgd in exact ql
<i>effective_in_ql_option</i>	(Optional) effe in ql option
<i>effective_in_ql</i>	(Optional) eff in ql
<i>priority</i>	(Optional) priority
<i>tod_priority</i>	(Optional) time of day priority
<i>ql_data_rcvd_has_ext_data</i>	(Optional) ql data rcvd extended data or not
<i>ql_data_rcvd_sync_steps</i>	(Optional) ql data rcvd sync steps
<i>ql_data_rcvd_esync_steps</i>	(Optional) ql data rcvd extended sync steps
<i>ql_data_rcvd_all_steps_sync</i>	(Optional) ql data rcvd all steps sync or not
<i>ql_data_rcvd_chain_complete</i>	(Optional) ql data rcvd chain complete
<i>supp_freq</i>	(Optional) supporting freq sync or time sync

<i>supp_time</i>	(Optional) supporting time sync
<i>selected_source_class</i>	(Optional) selected source class type
<i>selected_source_ifh</i>	(Optional) selected source ifh
<i>selected_source_clock_node</i>	(Optional) selected source clock node
<i>selected_source_clock_id</i>	(Optional) selected source clock id
<i>selected_source_clock_name</i>	(Optional) selected sourced clock name
<i>selected_source_ql_option</i>	(Optional) selevted source ql option
<i>selected_source_ql</i>	(Optional) selected source ql
<i>cfgd_out_ql_min_option</i>	(Optional) cfgd out ql min option
<i>cfgd_out_ql_min</i>	(Optional) cfgd out ql min
<i>cfgd_out_ql_max_option</i>	(Optional) cfgd out ql mAX option
<i>cfgd_out_ql_max</i>	(Optional) cfgd out max ql
<i>cfgd_out_ql_exact_option</i>	(Optional) cfgd out ql exact option
<i>cfgd_out_ql_exact</i>	(Optional) cfgd out exact ql
<i>effective_out_ql_option</i>	(Optional) eff out ql option
<i>effective_out_ql</i>	(Optional) effec out ql
<i>ql_data_to_send_has_ext_data</i>	(Optional) ql data to send extended data or not
<i>ql_data_to_send_sync_steps</i>	(Optional) ql data send sync steps
<i>ql_data_to_send_esync_steps</i>	(Optional) ql data send extended sync steps
<i>ql_data_to_send_all_steps_sync</i>	(Optional) ql data send all steps sync or not
<i>ql_data_to_send_chain_complete</i>	(Optional) ql data send chain complete
<i>squelched</i>	(Optional) output is squelched or not
<i>num_next_seln_points</i>	(Optional) num of next seln points
<i>next_selection_points</i>	(Optional) next selection points

Command Mode

- /exec

show frequency synchronization interface brief

show frequency synchronization interface brief

```
show frequency synchronization interface brief [ __readonly__ [ TABLE_fsync <fsync_port> <if_state>
<assigned_for_selection> <ssm_state> <esmc_peer_state> <squelched> [ <ql_rcv_option> ] [ <ql_rcv> ] [
<ql_use_option> ] [ <ql_use> ] <prioriy> [ <ql_snt_option> ] [ <ql_snt> ] [ <selected_source_class> ] [
<selected_source_ifh> ] [ <selected_source_clock_node> ] [ <selected_source_clock_id> ] [
<selected_source_clock_name> ] <port_end> ] <fsync-end> ]
```

Syntax Description

show	Show running system information
frequency	Frequency Synchronization Manager
synchronization	Frequency Synchronization Manager
interface	Display interface information
brief	Displays all interfaces
<u>__readonly__</u>	(Optional) Read Only
TABLE_fsync	(Optional) fsync_mngr table
<i>fsync_port</i>	(Optional) Interface Index
<i>if_state</i>	(Optional) interface state
<i>assigned_for_selection</i>	(Optional) whether assigned as selection input
<i>ssm_state</i>	(Optional) ssm state - enabled or disabled
<i>esmc_peer_state</i>	(Optional) esmc peer state
<i>squelched</i>	(Optional) output is squelched or not
<i>ql_rcv_option</i>	(Optional) ql rcv option
<i>ql_rcv</i>	(Optional) ql rcv
<i>ql_use_option</i>	(Optional) ql use option
<i>ql_use</i>	(Optional) ql use
<i>prioriy</i>	(Optional) priority of sync port
<i>ql_snt_option</i>	(Optional) ql snt option
<i>ql_snt</i>	(Optional) ql snt
<i>selected_source_class</i>	(Optional) selected source class type
<i>selected_source_ifh</i>	(Optional) selected source ifh
<i>selected_source_clock_node</i>	(Optional) selected source clock node

<i>selected_source_clock_id</i>	(Optional) selected source clock id
<i>selected_source_clock_name</i>	(Optional) selected sourced clock name
<i>port_end</i>	(Optional) end of current port
<i>fsync-end</i>	(Optional) End of table

Command Mode

- /exec

show frequency synchronization selection

```
show frequency synchronization selection [ __readonly__ [ TABLE_sp <seln_pt> <num_inputs>
<num_inputs_selected> <last_programmed_secs> <last_programmed_nsecs> <last_selection_secs>
<last_selection_nsecs> [ <spa_selection_points> + ] [ <spa_selection_points_num> ] [ <node_selection_points>
+ ] [ <node_selection_points_num> ] [ <chassis_selection_points> + ] [ <chassis_selection_points_num> ] [
<router_selection_points> + ] [ <router_selection_points_num> ] <tod_sp> <local_line_output>
<local_clock_output> <local_tod_output> <stream_table_start> [ TABLE_stream <output_id> <input>
<last_sp> <ql> [ <tod_priority> ] <priority> <state> ] <stream-end> ] <sp-end> ]
```

Syntax Description

show	Show running system information
frequency	Frequency Synchronization Manager
synchronization	Frequency Synchronization Manager
selection	Display selection information
<u>__readonly__</u>	(Optional) Read Only
TABLE_sp	(Optional) fsync_mngr table
<i>seln_pt</i>	(Optional) selection points
<i>num_inputs</i>	(Optional) num of inputs
<i>num_inputs_selected</i>	(Optional) num of inputs
<i>last_programmed_secs</i>	(Optional) last programmed time:secs
<i>last_programmed_nsecs</i>	(Optional) last programmed time:nsecs
<i>last_selection_secs</i>	(Optional) last selection time:secs
<i>last_selection_nsecs</i>	(Optional) last selection time:nsecs
<i>spa_selection_points</i>	(Optional) SPA selection points
<i>spa_selection_points_num</i>	(Optional) Number of SPA selection points
<i>node_selection_points</i>	(Optional) Node selection points
<i>node_selection_points_num</i>	(Optional) Number of node selection points
<i>chassis_selection_points</i>	(Optional) chassis selection points
<i>chassis_selection_points_num</i>	(Optional) Number of chassis selection points
<i>router_selection_points</i>	(Optional) router selection points
<i>router_selection_points_num</i>	(Optional) Number of Router selection points
<i>tod_sp</i>	(Optional) Use Time of day selection point else freq sp

<i>local_line_output</i>	(Optional) used for local line output or not
<i>local_clock_output</i>	(Optional) used for local clock output or not
<i>local_tod_output</i>	(Optional) used for local time of day output or not
<i>stream_table_start</i>	(Optional) stream table start
<i>TABLE_stream</i>	(Optional) stream table
<i>output_id</i>	(Optional) output id of stream
<i>input</i>	(Optional) source input for the stream
<i>last_sp</i>	(Optional) last selection point string
<i>ql</i>	(Optional) QL of the selected source
<i>tod_priority</i>	(Optional) time of day priority
<i>priority</i>	(Optional) priority of source
<i>state</i>	(Optional) state of the stream
<i>stream-end</i>	(Optional) End of SP table
<i>sp-end</i>	(Optional) End of SP table

Command Mode

- /exec

show fspf

show fspf

show fspf

Syntax Description

show	Show running system information
------	---------------------------------

Command Mode

- /exec

show fspf database

```
show fspf database [ vsan <i0> [ [ domain <i1> ] [ detail ] ] ]
```

Syntax Description

show	Show running system information
database	Show FSPF link state database
vsan	(Optional) Enter VSAN
<i>i0</i>	(Optional) VSAN id
domain	(Optional) Show LSR of a domain
<i>i1</i>	(Optional) domain index
detail	(Optional) Gives detailed information on the LSR

Command Mode

- /exec

show fspf interface**show fspf interface****Syntax Description**

show	Show running system information
interface	Show FSPF related information about an interface

Command Mode

- /exec

show fspf vsan

show fspf vsan <i0>

Syntax Description

show	Show running system information
vsan	Enter VSAN
<i>i0</i>	VSAN id

Command Mode

- /exec

show fspf vsan interface

show fspf vsan interface

show fspf vsan <i0> interface [<if0>]

Syntax Description

show	Show running system information
vsan	Enter VSAN
<i>i0</i>	VSAN id
interface	Show FSPF related information about an interface
<i>if0</i>	(Optional) Show FSPF related information about an interface

Command Mode

- /exec

show fte event

```
show fte event [ name ] [ { <eventname> } ] [ __readonly__ [ { TABLE_fte_event <event> [ <description> ] <use_count> [ { TABLE_fte_group <events> [ <buffer_drops> ] [ <fwd_drops> ] [ <acl_drops> ] [ <flow_count> ] [ <latency_threshold> ] [ <latency_unit> ] [ <latency_flow_count> ] } ] } ] ]
```

Syntax Description

show	Show running system information
fte	Show FTE information
event	Show Event Configuration
name	(Optional) Show the configuration for a specific FTE Event
<i>eventname</i>	(Optional) Specify a event
__readonly__	(Optional)
TABLE_fte_event	(Optional) Event Table
<i>event</i>	(Optional) Fte event
<i>description</i>	(Optional) Description of FTE event
<i>use_count</i>	(Optional) Use count of FTE event
TABLE_fte_group	(Optional)
<i>events</i>	(Optional) Drop or Latency type of events
<i>buffer_drops</i>	(Optional) Capture buffer-drops
<i>fwd_drops</i>	(Optional) Capture fwd-drops
<i>acl_drops</i>	(Optional) Capture acl-drops
<i>flow_count</i>	(Optional) Drop type flow count
<i>latency_threshold</i>	(Optional) Latency threshold value
<i>latency_unit</i>	(Optional) Unit for latency threshold measurement
<i>latency_flow_count</i>	(Optional) Latency type flow count

Command Mode

- /exec

show fte exporter

show fte exporter

```
show fte exporter [ name ] [ <exportername> ] [ __readonly__ <exporter> <description> <dest> <vrf> <vrf_id>
<vrf_resolved> <dest_udp> <source_intf> <source_ip> <exporter-id> ]
```

Syntax Description

show	Show running system information
fte	Show FTE information
exporter	Show FTE Exporter Configuration
name	(Optional) Show a specific FTE Exporter
<i>exportername</i>	(Optional) Specify an exporter
<i>__readonly__</i>	(Optional)
<i>exporter</i>	(Optional)
<i>description</i>	(Optional)
<i>dest</i>	(Optional)
<i>vrf</i>	(Optional)
<i>vrf_id</i>	(Optional)
<i>vrf_resolved</i>	(Optional)
<i>dest_udp</i>	(Optional)
<i>source_intf</i>	(Optional)
<i>source_ip</i>	(Optional)
<i>exporter-id</i>	(Optional)

Command Mode

- /exec

show fte monitor

```
show fte monitor [ name ] [ <monitornname> [ cache [ detailed ] ] ] [ __readonly__ <monitor> <use_count>
<description> <record> <event> <exporter1> <exporter2> <bucket_id> <src_addr> <dest_addr> ]
```

Syntax Description

show	Show running system information
fte	Show FTE information
monitor	Show Monitor Configuration
name	(Optional) Show a specific FTE Monitor
<i>monitornname</i>	(Optional) Specify a monitor
cache	(Optional) Flow monitor cache contents
detailed	(Optional) Show the entire cache contents
__readonly__	(Optional)
<i>monitor</i>	(Optional)
<i>use_count</i>	(Optional)
<i>description</i>	(Optional)
<i>record</i>	(Optional)
<i>event</i>	(Optional)
<i>exporter1</i>	(Optional)
<i>exporter2</i>	(Optional)
<i>bucket_id</i>	(Optional)
<i>src_addr</i>	(Optional)
<i>dest_addr</i>	(Optional)

Command Mode

- /exec

show fte record

show fte record

```
show fte record [ name ] [ { <recordname> } | { fte-original } | { fte { protocol-port | layer2-switched { input } | { ipv4 | ipv6 | l2 } { original-input } } } ] [ __readonly__ [ { TABLE_fte_record <record> [ <description> ] <use_count> [ <match_ipv4_params> + ] [ <match_ipv6_params> + ] [ <match_datalink_params> + ] } ] ]
```

Syntax Description

show	Show running system information
fte	Show FTE information
record	Show Record Configuration
name	(Optional) Show the configuration for a specific FTE Record
<i>recordname</i>	(Optional) Specify a record
fte-original	(Optional) Traditional IPv4 input FTE with origin ASs
fte	(Optional) Traditional FTE collection schemes
ipv4	(Optional) IPv4 collection schemes
ipv6	(Optional) IPv6 collection schemes
l2	(Optional) L2 collection schemes
layer2-switched	(Optional) Layer2-Switched collection schemes
original-input	(Optional) Input FTE
input	(Optional) Input FTE
protocol-port	(Optional) Protocol and Ports aggregation scheme
__readonly__	(Optional)
TABLE_fte_record	(Optional) Record Table
<i>record</i>	(Optional) FTE Record
<i>description</i>	(Optional) Description for FTE description
<i>use_count</i>	(Optional) Use count for FTE record
<i>match_ipv4_params</i>	(Optional) Match IPv4 parameters under record
<i>match_ipv6_params</i>	(Optional) Match IPv6 parameters under record
<i>match_datalink_params</i>	(Optional) Match datalink parameters under record

Command Mode

- /exec

show fte record