G Show Commands

- show gnss-receiver, on page 2
- show guestshell, on page 4

show gnss-receiver

show gnss-receiver [__readonly__ [TABLE_gnss_rcvr <rcvrid-slot> <rcvrid-port> <enabled> <shutdown> <antijam_disable> <constellation> <snr_threshold> <elev_threshold> <pdop_threshold> <traim_threshold> <cable_delay_comp> <polarity_1pps> <available> <lock_status> <rx_mode> <survey_progress> <holdover_duration> <major_alarm> <minor_alarm> <pdop> <hdop> <vdop> <tdop> <latitude> <longitude> <altitude> <time> <fw_version> <utc_offset> <sat_data_known> <sat_count> [TABLE_satellite <prn> <channel_num> <acq_flag> <ephe_flag> <sv_type> <signal_strength> <elevation> <azimuth>] <gnssrcvr-end>] <gnsstable-end>]

Syntax Description

gnss-receiver	Select GNSS Receiver
__readonly__	(Optional) Read Only
TABLE_gnss_rcvr	(Optional) GNSS Receiver Table
rcvrid-slot	(Optional) 1
rcvrid-port	(Optional) 3
enabled	(Optional) 5
shutdown	(Optional) 6
antijam_disable	(Optional) 7
constellation	(Optional) 8
snr_threshold	(Optional) 9
elev_threshold	(Optional) 10
pdop_threshold	(Optional) 11
traim_threshold	(Optional) 12
cable_delay_comp	(Optional) 13
polarity_1pps	(Optional) 14
available	(Optional) 15
lock_status	(Optional) 16
rx_mode	(Optional) 17
survey_progress	(Optional) 18
holdover_duration	(Optional) 19
major_alarm	(Optional) 20
minor_alarm	(Optional) 21

pdop	(Optional) 22
hdop	(Optional) 23
vdop	(Optional) 24
tdop	(Optional) 25
latitude	(Optional) 26
longitude	(Optional) 27
time	(Optional) 29
fw_version	(Optional) 30
utc_offset	(Optional) 31
sat_data_known	(Optional) 32
sat_count	(Optional) 33
TABLE_satellite	(Optional) 34
prn	(Optional) 35
channel_num	(Optional) 36
acq_flag	(Optional) 37
ephe_flag	(Optional) 37-2
sv_type	(Optional) 38
signal_strength	(Optional) 39
elevation	(Optional) 40
azimuth	(Optional) 41
gnssrcvr-end	(Optional) 42
gnsstable-end	(Optional) 43

Command Mode

- /exec

show guestshell

show guestshell [{ detail }] [__readonly__ [TABLE_detail <name> <state> <package_name> <ova_path> <application_name> <application_version> <application_description> <key_type> <signing_method> <licensing_name> <licensing_version> <disk_reservation> <memory_reservation> <cpu_reservation> TABLE_attached_devices <type> <name> <alias>]]

Syntax Description

show	Show running system information
guestshell	Display guest shell service information
detail	(Optional) Detailed guest shell service information
__readonly__	(Optional) Read Only
TABLE_detail	(Optional) Virtual service detail table
name	(Optional) Virtual service name
package_name	(Optional) Virtual service package name
application_name	(Optional) Name of the application
application_version	(Optional) Version of the application
application_description	(Optional) Description of the application
key_type	(Optional) Virtual service key type
signing_method	(Optional) Method used to sign the package
licensing_name	(Optional) Name of the license
licensing_version	(Optional) Version of the license
ova_path	(Optional) Virtual service OVA path
state	(Optional) Virtual service state
disk_reservation	(Optional) Virtual service disk reservation
memory_reservation	(Optional) Virtual service memory reservation
cpu_reservation	(Optional) Virtual service CPU reservation
TABLE_attached_devices	(Optional) Attached devices table
type	(Optional) Type of the attached device
name	(Optional) Name of the attached device
alias	(Optional) Alias for the attached device

Command Mode

- /exec