



Field-Programmable Devices

- [Upgrading Field-Programmable Devices, page 1](#)
- [SPA FPD Image Upgrade Support, page 1](#)
- [Automatic FPD Image Upgrades, page 2](#)
- [Upgrading SPA FPD Images, page 2](#)
- [Optional FPD Procedures, page 4](#)
- [Troubleshooting FPD Image Upgrade, page 11](#)

Upgrading Field-Programmable Devices

Field-programmable devices (FPDs) are hardware devices implemented on router cards that support separate software upgrades. A field-programmable gate array (FPGA) is a type of programmable memory device that exists on most hardware components of a Cisco uBR10012 router. The term FPD was introduced to collectively and generically describe any type of programmable hardware device on SIPs and SPAs, including FPGAs.



Note

In Cisco IOS Release 12.2(33)SCB, the FPD image upgrade is supported only for the SPAs inserted in the Cisco 10000 Series SPA Interface Processor-600 on a Cisco uBR10012 router.

This chapter describes how to verify image versions and perform an upgrade for SPA or SIP FPD images when incompatibilities occur and includes the following sections:

SPA FPD Image Upgrade Support

An FPD image package is used to upgrade FPD images. Each time a Cisco IOS software image is released that supports SPAs, a companion SPA FPD image package may also be released for that Cisco IOS software release. The FPD image package is available from Cisco.com and is accessible from the Cisco Software Center page where you also go to download your Cisco IOS software image.

If you are running SPAs on your router and are upgrading your Cisco IOS image, you should download the FPD image package file before booting the router using the new Cisco IOS release. If the SPA requires an FPD upgrade and the Cisco IOS image is unable to locate an FPD image package, the system messages indicate

that the FPD image is incompatible. You will need to go to the Cisco Software Center on Cisco.com to download the FPD image package for your Cisco IOS software release. An FPD incompatibility on a SPA disables all interfaces on that SPA until the incompatibility is addressed.

Automatic FPD Image Upgrades

By default, the Cisco uBR10012 router automatically upgrades the FPD images when it detects a version incompatibility between the FPD image on the SPA and the FPD image required to run the SPA. The FPD automatic upgrade feature only searches for the FPD image package file with the same version number as the running Cisco IOS release.

Upgrading SPA FPD Images

**Note**

Upgrading the FPD image on a SPA places the SPA offline while the upgrade is taking place. The time required to complete an FPD image upgrade can be lengthy.

This section provides the procedures to perform the following SPA FPD image upgrades:

Upgrading SPA FPD Images Before Booting the New Cisco IOS Release

If you are running your old Cisco IOS release but are preparing to load a newer version of Cisco IOS, you can place the FPD image package for the new version of Cisco IOS onto one of your router's flash file systems. For example, if you are running Cisco IOS Release 12.2(33)SCA and are upgrading to Cisco IOS Release 12.2(33)SCB, place the FPD image package for Cisco IOS release 12.2(33)SCB onto a flash file system while still running Cisco IOS Release 12.2(33)SCA.

To place an FPD image package on a flash disk before upgrading IOS, perform the following steps:

-
- Step 1** While still running the Cisco IOS release that will be upgraded, place the FPD image package for the new version of Cisco IOS onto one of your router's flash file systems. The FPD image package for a specific Cisco IOS release can be located on Cisco.com from the same area where you downloaded that Cisco IOS software image. Your router and SPAs should continue to operate normally, because this action has no impact on the current FPDs.
- Caution** Do not change the filename of the FPD image package file. The Cisco IOS software searches for the FPD image package file by filename, so the FPD image package file cannot be found if it is renamed.
- Step 2** Reboot your router using the new upgraded Cisco IOS image.
- Step 3** When the router has booted, verify the upgrade was successful by entering the **show hw-module all fpd** command.
-

Upgrading SPA FPD Images After Booting the New Cisco IOS Release

The following procedure explains how to upgrade FPD images if you have already upgraded your Cisco IOS release but still need to upgrade your FPD images.



Note If multiple SPAs require upgrades, you must update the different pieces of hardware individually.

To perform an FPD upgrade after the new Cisco IOS release boots, perform the following steps:

-
- Step 1** If you are unsure if the FPD images for your SPAs are compatible, enter the **show hw-module all fpd** command to verify compatibility of all SPAs. If all of your SPAs are compatible, you do not need to perform this upgrade.
- Step 2** If an FPD upgrade is necessary, place the FPD image package for the new version of Cisco IOS onto the router's flash disk or on an accessible FTP or TFTP server. The FPD image package can be located on Cisco.com from the same area where you downloaded your Cisco IOS software image.
- Step 3** Enter the **upgrade hw-module subslot slot/subslot fpd file file-url** command in privileged EXEC mode. The *file-url* argument specifies the location of the FPD image package file. For example, if you are upgrading the FPD image in SPA subslot 0 on the SIP installed in chassis slot 1, and the FPD image package for Cisco IOS Release 12.2(33)SCB is on the TFTP server mytftpserver/myname/fpdpkg, you would enter:
- ```
Router# upgrade hw-module subslot 1/0 fpd file tftp://mytftpserver/myname/fpdpkg/ubr10k-fpd-pkg.122-122_33_SCB_20081123.pkg
```
- Step 4** Verify the upgrade was successful by entering the **show hw-module all fpd** command.
- 

## Manually Upgrading the Cisco 3 Gbps Wideband Shared Port Adapter FPD to Cisco 6 Gbps Wideband Shared Port Adapter

You can upgrade the FPD on the Cisco 3 Gbps Wideband Shared Port Adapter card to configure it as a Cisco 6 Gbps Wideband Shared Port Adapter card. You can upgrade the Cisco 3 Gbps Wideband Shared Port Adapter cards simultaneously on two SIPs. However, within a SIP, you cannot upgrade the Cisco 3 Gbps Wideband Shared Port Adapter cards simultaneously.

### Before You Begin

- The Cisco uBR10012 router must be running the Cisco IOS Release 12.2(33)SCI or a later release.
- The Cisco 3 Gbps Wideband Shared Port Adapter must be in the 10G mode.
- The Cisco 3 Gbps Wideband Shared Port Adapter must be online.

### Restrictions

- If you manually upgrade the FPD when the Cisco 3 Gbps Wideband Shared Port Adapter is in 1G mode, the Cisco 3 Gbps Wideband Shared Port Adapter resets continuously. Then, you must configure the 6 Gbps capacity and 10G mode for the SPA manually using the **card** command.
- If you are running Cisco IOS Release 12.2(33)SCI, we recommend that you upgrade to Cisco IOS Release 12.2(33)SCI1 or later release. For more information, see field notice [FN-63952](#).
- If you want to use the Cisco IOS Release 12.2(33)SCI, you must use the Cisco IOS Release 12.2(33)SCI1 FPD image for the SPA upgrade. Perform the following:
  - 1 Download the Cisco IOS Release 12.2(33)SCI1 FPD image package from Cisco.com and place it on the disk0 of the Cisco uBR10012 router.
  - 2 Rename FPD image package from **ubr10k-fpd-pkg.122-33.SCI1** to **ubr10k-fpd-pkg.122-33.SCI**.
  - 3 Use the renamed FPD image package for the SPA upgrade.

- 
- Step 1** Place the FPD image package on the disk0 of the Cisco uBR10012 router. The FPD image package can be located on Cisco.com from the same area where you downloaded your Cisco IOS software image.
- Important** Do not change the filename of the FPD image package file. The Cisco IOS software searches for the FPD image package file by file name, and the FPD image package file cannot be located if it is renamed.
- Step 2** Upgrade the FPD image on the card using the **upgrade hw-module subslot slot/bay idprom 6g** command in privileged EXEC mode.
- Note** The service interruption time is up to 1 minute during the upgrade. The upgrade can take up to 10 minutes. Do not interrupt while the upgrade is in progress. To verify the progress of the upgrade, use the **show upgrade fpd progress** command.
- Step 3** Wait for up to 8 minutes for the upgrade to complete (6 minutes for the upgrade and 2 minutes for the SPA to come online).
- Step 4** Ensure that the running configuration is automatically changed to Cisco 6 Gbps Wideband Shared Port Adapter using the **show running-config | include card** command and verify that the **6G-capacity** keyword is added in the **card** command.
- Step 5** Reload the SPA using the **hw-module bay slot/bay reload** command.
- Step 6** Wait for up to 2 minutes for the SPA to come online.
- Step 7** Verify if the upgrade is successful using the **show hw-module subslot slot/subslot fpd** command. The Eastlake FPGA version number must be 4096.56 or more.
- 

### What to Do Next

The controller configurations for controllers 0 to 2 are inherited from Cisco 3 Gbps Wideband Shared Port Adapter card. Configure controllers 3 to 5 on the Cisco 6 Gbps Wideband Shared Port Adapter. See [Entering Controller Configuration Mode for the Cisco 6 Gbps Wideband Shared Port Adapter](#).

## Optional FPD Procedures

This section provides information for optional FPD-related functions. None of the topics discussed in this section are necessary for completing FPD upgrades, but may be useful in some FPD-related scenarios. This section includes the following topics:

## Manually Upgrading SPA FPD Images

The FPD manual upgrade feature provides the ability to manually upgrade the FPD image on a SPA. To manually upgrade the current FPD version on a SPA, enter the following command in privileged EXEC mode:

```
Router# upgrade hw-module subslot slot/subslot fpd file file-url [reload]
```

In the command, *slot* is the slot where the SIP is installed, *subslot* is the subslot number where the SPA is located, *file-url* is the location and name of the FPD image package file, and **reload** is an option that forces the SPA to perform an FPD upgrade even if the FPD is compatible. The **reload** option is almost never necessary and should be entered only if requested by a technical support representative. The SPA will be reloaded automatically to complete the FPD upgrade.


**Note**

Upgrading the FPD image on a SPA places the SPA offline while the upgrade is taking place. The time required to complete an FPD image upgrade can be lengthy.

## Upgrading FPD from an FTP or TFTP Server

The recommended method to perform an FPD image upgrade is to download the FPD image package to a flash file system and use the FPD automatic upgrade. By default, the system searches the flash file systems for the FPD image package file when an FPD incompatibility is detected.

This default behavior of loading an FPD image from a flash file system can be changed using the **upgrade fpd path** global configuration command, which sets the path to search for the FPD image package file to a location other than the router's flash file systems.

For large deployments where all the systems are being upgraded to a specific Cisco IOS software release, we recommend that the FPD image package file be placed on an FTP or TFTP server that is accessible to all the affected systems, and enter the **upgrade fpd path** global configuration command to configure the routers to look for the FPD image package file from the FTP or TFTP server prior to the reloading of the system with the new Cisco IOS release.


**Note**

This approach can also be used if there is not enough disk space on the system flash card to hold the FPD image package file.

To download an FPD image package file to an FTP or TFTP server, use the following procedure:

**Step 1** Copy the FPD image package file to the FTP or TFTP server.

**Step 2** Access the router from a connection that does not use the SPA interface for access, if possible. We recommend not using the SPA interface as your connection to the router because an FPD incompatibility disables all interfaces on the SPA, making a manual FPD upgrade impossible through a SPA interface. If access through one of the SPA ports is the only access to the router you have, do not use the TFTP or FTP upgrade method. Instead, copy the FPD image package to your router's default flash card before upgrading your Cisco IOS release. This method allows the router to find the FPD image package during the first Cisco IOS boot and upgrade FPD automatically.

**Step 3** From global configuration mode, enter the upgrade fpd path command to instruct the router to locate the FPD image package file from the FTP or TFTP server location. For example, enter one of the following global configuration commands from the target system's console:

```
Router(config)# upgrade fpd path tftp://my_tftpserver/fpd_pkg_dir/
```

or

```
Router(config)# upgrade fpd path ftp://login:password@my_ftpserver/fpd_pkg_dir/
```

**Note** The slash (/) at the end of each example is required. If the path is specified without the trailing slash, the command does not work properly.

In these examples, *my\_tftpserver* or *my\_ftpserver* is the path to the server, *fpd\_pkg\_dir* is the directory on the TFTP server where the FPD image package is located, and *login:password* is your FTP login name and password.

**Step 4** Make sure that the FPD automatic upgrade feature is enabled by examining the output of the **show running-config** command (look for the *upgrade fpd auto configuration* line in the output). If there are no upgrade commands in the output, the FPD automatic upgrade feature is enabled. If automatic upgrades are disabled, use the **upgrade fpd auto** global configuration command to enable automatic FPD upgrades.

**Step 5** Enter the **show upgrade fpd file** command to ensure your router is connecting properly to the default FPD image package. If you are able to generate output related to the FPD image package using this command, the upgrade should work properly.

**Step 6** Save the configuration and reload the system with the new Cisco IOS release.

During the system startup after the reload, the necessary FPD image version check for all the SPAs will be performed and any upgrade operation will occur automatically if an upgrade is required. In each upgrade operation, the system extracts the necessary FPD images to the SPA from the FPD image package file located on the FTP or TFTP server.

## Modifying the Default Path for the FPD Image Package File Location

By default, the Cisco IOS software looks for the FPD image package file on a flash file system when performing an automatic FPD image upgrade.



**Note** Be sure there is enough space on one of your flash file systems to accommodate the FPD image package file.

Alternatively, you can store an FPD image package file elsewhere. However, because the system looks on the flash file systems by default, you need to change the FPD image package file location so that the system is directed to search an alternate location (such as an FTP or TFTP server) that is accessible by the Cisco IOS software. Enter the **upgrade fpd path fpd-pkg-dir-url** global configuration command, where *fpd-pkg-dir-url* is the alternate location, to instruct the router to search for the FPD image package elsewhere.

When specifying *fpd-pkg-dir-url*, be aware of the following:

*fpd-pkg-dir-url* is the path to the FPD image package, but the FPD image package should not be specified as part of *fpd-pkg-dir-url*. For instance, if the *ubr10k-fpd-pkg.122-122\_33\_SCB\_20081123.pkg* file can be found on the TFTP server using the path *mytftpserver/myname/myfpdpkg* and you want the router to utilize this FPD image package for FPD upgrades, the **upgrade fpd path tftp://mytftpserver/myname/myfpdpkg/** command should be entered so the router knows where to find the file. The actual filename should not be specified.

The slash (/) at the end of *fpd-pkg-dir-url* is required.

If the **upgrade fpd path** global configuration command has not been entered to direct the router to locate an FPD image package file in an alternate location, the system searches the flash file systems on the Cisco uBR10012 router for the FPD image package file.

Failure to locate an FPD image package file when an upgrade is required disables the SPA. If the automatic upgrade feature is disabled, the SPA is also disabled if it requires an FPD upgrade.

## Upgrading Multiple FPD Images

A single piece of hardware can contain multiple FPD images. The Cisco uBR10012 router can upgrade up to four FPD images simultaneously. However, only one FPD upgrade per router slot can occur at a time. All FPD images on all SPAs in a single slot wait for the previous FPD upgrade to finish before their specific FPD upgrade begins.

During manual upgrades, you specify an upgrade for a single piece of hardware each time you enter the **upgrade hw-module [slot slot | subslot slot/subslot]** command. If you individually specify multiple manual FPD upgrades, only four FPDs can be upgraded simultaneously; the upgrades can occur only when the hardware is in different router slots. The FPD upgrade process stops when all FPDs for the specified hardware are upgraded.

## Disabling Automatic FPD Upgrades

To disable automatic FPD image upgrades, enter the **no upgrade fpd auto** command in global configuration mode. If the automatic FPD image upgrade feature is disabled but an FPD image is required for a SPA, the **upgrade hw-module subslot** command can be used to manually upgrade the SPA FPD image.

**Note**

Disabling the automatic upgrade feature does not disable the version checking mechanism. This prevents SPAs with incompatible FPD images from becoming active.

## Manually Downgrading the Cisco 6 Gbps Wideband Shared Port Adapter FPD to Cisco 3 Gbps Wideband Shared Port Adapter

You can downgrade the FPD on the Cisco 6 Gbps Wideband Shared Port Adapter card to configure it as a Cisco 3 Gbps Wideband Shared Port Adapter card.

### Before You Begin

- The Cisco uBR10012 router must be running the Cisco IOS Release 12.2(33)SCI or a later release.
- The Cisco 3 Gbps Wideband Shared Port Adapter card must be up.

### Restrictions

- If you are running Cisco IOS Release 12.2(33)SCI, we recommend that you upgrade to Cisco IOS Release 12.2(33)SCI1 or later release. For more information, see field notice [FN-63952](#).

- If you want to use the Cisco IOS Release 12.2(33)SCI, you must use the Cisco IOS Release 12.2(33)SCI1 FPD image for the SPA downgrade. Perform the following:
  - 1 Download the Cisco IOS Release 12.2(33)SCI1 FPD image package from Cisco.com and place it on the disk0 of the Cisco uBR10012 router.
  - 2 Rename FPD image package from **ubr10k-fpd-pkg.122-33.SCI1** to **ubr10k-fpd-pkg.122-33.SCI**.
  - 3 Use the renamed FPD image package for the SPA downgrade.

- 
- Step 1** Place the FPD image package on the disk0 of the Cisco uBR10012 router. The FPD image package can be located on Cisco.com from the same area where you downloaded your Cisco IOS software image.
- Note** Do not change the filename of the FPD image package file. The Cisco IOS software searches for the FPD image package file by filename, so the FPD image package file cannot be found if it is renamed.
- Step 2** Downgrade the FPD image on the card using the **upgrade hw-module subslot slot/bay idprom 3g** command in privileged EXEC mode.
- Step 3** Remove the preprovisioning for the card using the **no card** command in global configuration mode.
- Step 4** Enable the card using the **no hw-module bay slot/bay shutdown** command.
- 

### What to Do Next

Configure the Cisco 3 Gbps Wideband Shared Port Adapter card. See [Configuring the Cisco 3 Gbps Wideband Shared Port Adapter](#).

## Configuring Automatic Upgrade and Downgrade of FPD Images

Effective with Cisco IOS Release 12.2(33)SCI1, you can configure the automatic upgrade and downgrade of the FPD images on the Cisco 3 Gbps Wideband Shared Port Adapter and Cisco 6 Gbps Wideband Shared Port Adapter based on the preprovisioned configuration for the slot. Once enabled, regardless of the type of the inserted SPA, automatic downgrade or upgrade is performed to ensure that the inserted SPA is consistent with the preprovisioned configuration for the slot.

**Table 1: Automatic Upgrade/Downgrade Information When Cisco 3 Gbps Wideband Shared Port Adapter is Inserted Into the Slot**

| Preprovisioned Configuration                               | FPD Upgrade/Downgrade | Post-insertion Configuration                               |
|------------------------------------------------------------|-----------------------|------------------------------------------------------------|
| Cisco 3 Gbps Wideband Shared Port Adapter in three 1G mode | N/A                   | Cisco 3 Gbps Wideband Shared Port Adapter in three 1G mode |
| Cisco 3 Gbps Wideband Shared Port Adapter in one 10G mode  | N/A                   | Cisco 3 Gbps Wideband Shared Port Adapter in one 10G mode  |
| Cisco 6 Gbps Wideband Shared Port Adapter in one 10G mode  | Upgrade               | Cisco 6 Gbps Wideband Shared Port Adapter in one 10G mode  |

| Preprovisioned Configuration | FPD Upgrade/Downgrade | Post-insertion Configuration                               |
|------------------------------|-----------------------|------------------------------------------------------------|
| None                         | N/A                   | Cisco 3 Gbps Wideband Shared Port Adapter in three 1G mode |

**Table 2: Automatic Upgrade/Downgrade Information When Cisco 6 Gbps Wideband Shared Port Adapter is Inserted Into the Slot**

| Preprovisioned Configuration                               | FPD Upgrade/Downgrade | Post-insertion Configuration                               |
|------------------------------------------------------------|-----------------------|------------------------------------------------------------|
| Cisco 3 Gbps Wideband Shared Port Adapter in three 1G mode | Downgrade             | Cisco 3 Gbps Wideband Shared Port Adapter in three 1G mode |
| Cisco 3 Gbps Wideband Shared Port Adapter in one 10G mode  | Downgrade             | Cisco 3 Gbps Wideband Shared Port Adapter in one 10G mode  |
| Cisco 6 Gbps Wideband Shared Port Adapter in one 10G mode  | N/A                   | Cisco 6 Gbps Wideband Shared Port Adapter in one 10G mode  |
| None                                                       | N/A                   | Cisco 6 Gbps Wideband Shared Port Adapter in one 10G mode  |

**Before You Begin**

- Download and place the FPD image package on the disk0 of the Cisco uBR10012 router. The FPD image package can be located on Cisco.com from the same area where you downloaded your Cisco IOS software image.



**Note** Do not change the filename of the FPD image package file. The Cisco IOS software searches for the FPD image package file by file name, and the FPD image package file cannot be located if it is renamed.

- To enable automatic upgrade or downgrade of the FPD image on the SPA, you must configure the **cable sip slot fpd-auto** command before inserting the SPA.

**DETAILED STEPS**

|               | Command or Action                                                        | Purpose                                                                      |
|---------------|--------------------------------------------------------------------------|------------------------------------------------------------------------------|
| <b>Step 1</b> | <p><b>enable</b></p> <p><b>Example:</b><br/>Router&gt; <b>enable</b></p> | <p>Enables privileged EXEC mode.</p> <p>Enter your password if prompted.</p> |

|        | Command or Action                                                                                    | Purpose                                                                                                                                                                                                                                                                  |
|--------|------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 2 | <b>configure terminal</b><br><br><b>Example:</b><br>Router# <b>configure terminal</b>                | Enters global configuration mode.                                                                                                                                                                                                                                        |
| Step 3 | <b>cable sip slot fpd-auto</b><br><br><b>Example:</b><br>Router(config)# <b>cable sip 1 fpd-auto</b> | Enables the automatic upgrade and downgrade of the FPD images based on the preprovisioned configuration for the slot. <ul style="list-style-type: none"> <li>• <i>slot</i>—Slot number of the SIP on the Cisco uBR10012 router. The valid values are 1 and 3.</li> </ul> |
| Step 4 | <b>end</b><br><br><b>Example:</b><br>Router(config)# <b>end</b>                                      | Returns to privileged EXEC mode.                                                                                                                                                                                                                                         |

## Displaying Current and Minimum Required FPD Image Versions

To display the current version of FPD images on the SPAs installed on your router, use the **show hw-module [slot/subslot | all] fpd** command, where *slot* is the slot number where the SIP is installed and *subslot* is the number of the SIP subslot where a target SPA is located. Entering the **all** keyword shows information for hardware in all router slots.

The following example shows the FPD versions on SPAs that meet the minimum requirements:

```
Router# show hw-module all fpd
=====
H/W Field Programmable Current Min. Required
Slot Card Type Ver. Device: "ID-Name" Version Version
=====
1/0 SPA-24XDS-SFP 1.0 1-Modena BLAZE FPG 1285.1444 1285.1444

1/1 SPA-24XDS-SFP 1.0 1-Modena BLAZE FPG 1285.1444 1285.1444

1/2 SPA-24XDS-SFP 1.0 1-Modena BLAZE FPG 1285.1444 1285.1444

1/3 SPA-5X1GE-V2 1.2 1-5xGE V2 I/O FPGA 1.10 1.10

3/0 SPA-24XDS-SFP 1.0 1-Modena BLAZE FPG 1285.1444 1285.1444

3/1 SPA-24XDS-SFP 1.0 1-Modena BLAZE FPG 1285.1444 1285.1444

3/2 SPA-24XDS-SFP 1.0 1-Modena BLAZE FPG 1285.1444 1285.1444

3/3 SPA-1X10GE-L-V2 1.2 1-10GE V2 I/O FPGA 1.9 1.9
=====
```

The following example shows the output when using the *slot/subslot* argument to identify a particular SPA:

```
Router# show hw-module subslot 1/0 fpd
=====
H/W Field Programmable Current Min. Required
Slot Card Type Ver. Device: "ID-Name" Version Version
=====
1/0 5xGE SPA[1/0] 1.1 1-5xGE V2 I/O FPGA 1.10 1.10
=====
```

## Displaying Information About the Default FPD Image Package

You can use the **show upgrade fpd package default** command to find out which SPAs are supported with your current Cisco IOS release and which FPD image package you need for an upgrade.

```
Router# show upgrade fpd package default

This Cisco IOS software image requires the following default FPD Image
Package for the automatic upgrade of FPD images (the package is available
from Cisco.com and is accessible from the Cisco Software Center page where
this IOS software image can be downloaded):

Version: Version: 12.2(20080919:205903)
Package Filename: ubr10k-fpd-pkg.122-test.pkg
```

List of card type supported in this package:

| No. | Card Type           | Minimal<br>HW Ver. |
|-----|---------------------|--------------------|
| 1)  | 5xGE SPA            | 0.0                |
| 2)  | 1x10GE XFP SPA      | 0.0                |
| 3)  | WIDEBAND DOCSIS SPA | 0.0                |

## Verifying the FPD Image Upgrade Progress

You can use the **show upgrade fpd progress** command to view a snapshot of the upgrade process while an FPD image upgrade is taking place. The following example shows a sample output of this command:

```
Router# show upgrade fpd progress

FPD Image Upgrade Progress Table:
=====
Slot Card Description Field Programmable Time
Device : "ID-Name" Needed Time Left State
=====
1/0 SPA-1XTENGE-XFP 1-10GE I/O FPGA 00:06:00 00:05:17 Updating...

1/0 SPA-10X1GE 1-GE I/O FPGA --:--:-- --:--:-- Waiting...
=====
```

## Troubleshooting FPD Image Upgrade

**Problem** Corrupt FPD image. The SPA is unusable by the router. The system displays the following message when it stops trying to power up the SPA:

**Problem** *02:10:10: %SPA\_OIR-3-SPA\_POWERED\_OFF: subslot 1/0: SPA 1x10GE XFP SPA powered off after 5 failures within 600 seconds*

**Possible Cause** FPD upgrade operation is interrupted by a power failure or the removal of the SPA.

**Solution** The **show hw-module subslot slot/subslot fpd** command can be used to verify that the SPA is using a corrupted FPD image.

**Solution** To find more information about FPD-related messages, see *Cisco IOS CMTS Cable System Messages Guide* at the following URL:

**Solution** [http://www.cisco.com/en/US/products/hw/cable/ps2209/products\\_system\\_message\\_guides\\_list.html](http://www.cisco.com/en/US/products/hw/cable/ps2209/products_system_message_guides_list.html)

**Problem** SPA powered off by the system.

**Possible Cause** Failed retries to initialize the SPA.

**Solution** The following example shows the output of an attempt to perform a recovery upgrade before all of the initialization retries have been attempted for the SPA in subslot 1/0.

```
02:04:08: %FPD_MGMT-4-UPGRADE_EXIT: Unexpected exit of FPD image upgrade operation for
SPA-1XTENGE-XFP card in subslot 1/0.
02:04:15: %FPD_MGMT-5-CARD_DISABLED: SPA-1XTENGE-XFP card in subslot 1/0 is being disabled
because of an incompatible FPD image version. Note that the ubr10k-fpd-pkg.122-test.pkg
package will be required if you want to perform the upgrade operation.
```

```
Router# upgrade hw-module subslot 1/0 file disk0:ubr10k-fpd-pkg.122-test.pkg
```

```
% Cannot get FPD version information for version checking. If a previous upgrade attempt
has failed for the target card, then a recovery upgrade would be required to fix the
failure.
% The following FPD(s) will be upgraded for SPA-1XTENGE-XFP (H/W ver = 2.1) in subslot 1/0:
```

```
=====
Field Programmable Current Upgrade Estimated
Device: "ID-Name" Version Version Upgrade Time
=====
1-10GE I/O FPGA ?.? 1.6 00:00:20
=====
```

```
% Do you want to perform the recovery upgrade operation? [no]: y
% Cannot perform recovery upgrade operation because the target card is not in a failed
state. Please try again later.
```

**Solution** After the following error message appears, you can perform the recovery upgrade:



**Note** **Solution** You must wait to see this error message before you attempt the upgrade.

```
%SPA_OIR-3-SPA_POWERED_OFF: subslot 1/0: SPA 1x10GE XFP SPA powered off after 5 failures
within 600 seconds
```

**Solution** Perform the manual FPD image upgrade method using the **upgrade hw-module subslot** command to recover from a corrupted image after the SPA has been powered off by the system.



**Note** **Solution** Before proceeding with this operation, make sure that the correct version of the FPD image package file has been obtained for the corresponding Cisco IOS release that the system is using.

**Solution** The following example shows the console output of a recovery upgrade operation:

```
Router# upgrade hw-module subslot 1/0 file disk0:ubr10k-fpd-pkg.122-test.pkg
```

```
% Cannot get FPD version information for version checking. If a previous upgrade attempt
has failed for the target card, then a recovery upgrade would be required to fix the
failure.
% The following FPD(s) will be upgraded for SPA-1XTENGE-XFP (H/W ver = 2.1) in subslot 1/0:
```

```

=====
Field Programmable Current Upgrade Estimated
Device: "ID-Name" Version Version Upgrade Time
=====
1-10GE I/O FPGA ?.? 1.6 00:00:20
=====

```

```

% Do you want to perform the recovery upgrade operation? [no]: y
% Proceeding with recovery upgrade operation ...

```

```

Router#
02:14:47: %FPD_MGMT-6-UPGRADE_TIME: Estimated total FPD image upgrade time for SPA-1XTENGE-XFP
card in subslot 1/0 = 00:00:20.
02:14:47: %FPD_MGMT-6-UPGRADE_START: Unknown FPD (FPD ID=1) image upgrade in progress for
SPA-1XTENGE-XFP card in subslot 1/0. Updating to version 1.6. PLEASE DO NOT INTERRUPT
DURING THE UPGRADE PROCESS (estimated upgrade completion time = 00:00:20) ...
02:15:10: %FPD_MGMT-6-UPGRADE_PASSED: Unknown FPD (FPD ID=1) image in the SPA-1XTENGE-XFP
card in subslot 2/0 has been successfully updated from version ?.? to version 1.6.
Upgrading time = 00:00:23.540
02:15:10: %FPD_MGMT-6-OVERALL_UPGRADE: All the attempts to upgrade the required FPD images
have been completed for SPA-1XTENGE-XFP card in subslot 1/0. Number of successful/failure
upgrade(s): 1/0.
02:15:10: %FPD_MGMT-5-CARD_POWER_CYCLE: SPA-1XTENGE-XFP card in subslot 1/0 is being power
cycled for the FPD image upgrade to take effect.

```

**Solution** After the upgrade process is complete, you can use the **show hw-module subslot *slot/subslot* fpd** command to verify that the FPD image is successfully upgraded. For example:

```
Router# show hw-module subslot 1/0 fpd
```

```

=====
Slot Card Type H/W Field Programmable Current Min. Required
Ver. Device: "ID-Name" Version Version
=====
1/0 5xGE SPA[1/0] 1.1 1-5xGE V2 I/O FPGA 1.10 1.10
=====

```

