



IPv6 IPsec Quality of Service

The IPv6 IPsec QoS feature allows the quality of service (QoS) policies to be applied to IPv6 IPsec.

- [Finding Feature Information, on page 1](#)
- [Information About IPv6 IPsec QoS, on page 1](#)
- [How to Configure IPv6 IPsec QoS, on page 2](#)
- [Configuration Examples for QoS, on page 6](#)
- [Additional References for IPv6 IPsec QoS, on page 8](#)
- [Feature Information for IPv6 IPsec QoS, on page 9](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Information About IPv6 IPsec QoS

IPv6 IPsec QoS Overview

The IPv6 IPsec QoS feature applies the quality of service (QoS) policies to IPv6 IPsec. This feature supports the following functionalities:

- **Crypto LLQ QoS**—Traffic that is classified by QoS and marked as priority level 1 or 2 by traditional Cisco Modular QoS CLI (MQC) QoS configuration, for example PAK priority, is enqueued to the priority queue before the crypto processor. The low latency queuing (LLQ) for IPsec encryption engines helps reduce packet latency for priority traffic.
- **IPsec QoS Pre-Classify**—QoS pre-classify is configured under a crypto map to enable IPsec to save the original Layer 3 and Layer 4 header before the encryption so that QoS can do the classification using the saved header.

- QoS group-based LLQ—The QoS group-based LLQ feature allows IPsec to check the LLQ QoS group setting to determine whether a packet is a high priority packet before it is enqueued to low latency queuing (LLQ).

How to Configure IPv6 IPsec QoS

Configuring Crypto LLQ QoS

When IPsec and QoS are configured on a physical interface and if the QoS policy has priority class, IPsec will classify the packet based on the policy attached to the interface. It will enqueue the packet matching priority class into Low Latency Queue. The high-priority packet will be enqueued to low latency queuing (LLQ).

Perform this task to attach a service policy to the output interface and enable LLQ for IPsec encryption engines.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **interface** *physical-interface-name*
4. **ipv6 address** *{ipv6-address /prefix-length | prefix-name sub-bits/prefix-length}*
5. **service-policy output** *policy-map*
6. **ipv6 crypto map** *map-name*
7. **end**

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|--|---|
| Step 1 | enable Example: Device> enable | Enables privileged EXEC mode. • Enter your password if prompted. |
| Step 2 | configure terminal Example: Device# configure terminal | Enters global configuration mode. |
| Step 3 | interface <i>physical-interface-name</i> Example: Device(config)# interface GigabitEthernet0/0/1 | Specifies the interface using the LLQ for IPsec encryption engines. |
| Step 4 | ipv6 address <i>{ipv6-address /prefix-length prefix-name sub-bits/prefix-length}</i> Example: | Configures an IPv6 address on an interface. |

| | Command or Action | Purpose |
|---------------|--|---|
| | Device(config-if)# ipv6 address 2001:DB8:FFFF::2/64 | |
| Step 5 | service-policy output <i>policy-map</i> Example: Device(config-if)# service-policy output pl | Attaches the specified service policy map to the output interface and enables LLQ for IPsec encryption engines. |
| Step 6 | ipv6 crypto map <i>map-name</i> Example: Device(config-if)# ipv6 crypto map CMAP_1 | Enables an IPv6 crypto map on an interface. |
| Step 7 | end Example: Device(config-if)# end | Exits interface configuration mode and returns to privileged EXEC mode. |

Configuring QoS Pre-classify

Configuring Pre-classify on the Crypto Map

The **qos pre-classify** command is applied on the crypto map, allowing configuration on a per-tunnel basis. QoS policy is applied to Packets based on the L3 and L4 Header before encryption.

Perform this task to apply the QoS pre-classify on the crypto map.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **ipv6 crypto map** *map-name*
4. **qos pre-classify**
5. **end**

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|--|--|
| Step 1 | enable Example: Device> enable | Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted. |
| Step 2 | configure terminal Example: Device# configure terminal | Enters global configuration mode. |

| | Command or Action | Purpose |
|---------------|---|---|
| Step 3 | ipv6 crypto map <i>map-name</i> Example: Device(config-if)# ipv6 crypto map CM_V6 | Enters crypto map configuration mode and specifies the crypto map to be configured. |
| Step 4 | qos pre-classify Example: Device(config-if)# qos pre-classify | Enables QoS pre-classify on the crypto map. |
| Step 5 | end Example: Device(config-if)# end | Exits interface configuration mode and returns to privileged EXEC mode. |

Configuring Pre-classify on the Tunnel Interface

The **qos pre-classify** command is applied on the IPv6 IPsec tunnel interface, making QoS a configuration option on a per-tunnel basis.

Perform this task to apply the QOS pre-classify on the tunnel interface.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **interface** *tunnel-interface-name*
4. **ipv6 address** *{ipv6-address /prefix-length | prefix-name sub-bits/prefix-length}*
5. **qos pre-classify**
6. **end**

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|--|--|
| Step 1 | enable Example: Device> enable | Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted. |
| Step 2 | configure terminal Example: Device# configure terminal | Enters global configuration mode. |
| Step 3 | interface <i>tunnel-interface-name</i> Example: | Enters interface configuration mode and specifies the tunnel or virtual interface to configure. |

| | Command or Action | Purpose |
|---------------|---|---|
| | Device(config)# interface Tunnel1 | |
| Step 4 | ipv6 address <i>{ipv6-address /prefix-length prefix-name sub-bits/prefix-length}</i> Example: Device(config-if)# ipv6 address 2001:DB8:FFFF::2/64 | Configures an IPv6 address on an interface. |
| Step 5 | qos pre-classify Example: Device(config-if)# qos pre-classify | Enables QoS pre-classify on the tunnel interface. |
| Step 6 | end Example: Device(config-if)# end | Exits interface configuration mode and returns to privileged EXEC mode. |

Configuring LLQ QoS Group

The **platform ipsec llq qos-group** command enables low latency queuing for traffic that matches the QoS groups configured with this command.

Perform this task to enable LLQ for QoS groups.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **platform ipsec llq qos-group** *group-number*
4. **end**

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|--|--|
| Step 1 | enable Example: Device> enable | Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted. |
| Step 2 | configure terminal Example: Device# configure terminal | Enters global configuration mode. |

| | Command or Action | Purpose |
|---------------|--|---|
| Step 3 | platform ipsec llq qos-group <i>group-number</i> Example: Device(config)# platform ipsec llq qos-group 1 | Specifies the QoS group to enable LLQ. Valid values are from 1 to 99. |
| Step 4 | end Example: Device(config-if)# end | Exits interface configuration mode and returns to privileged EXEC mode. |

Configuration Examples for QoS

Example: Configuring Crypto LLQ QoS

The following example shows how to specify the service policy map to the output interface and enable an IPv6 crypto map on an interface.

```
!
class-map match-all c2
  match precedence 5 6 7
class-map match-all c1
  match precedence 0 1 2 3

policy-map p1
  class c1
    priority percent 10
  class c2
    bandwidth remaining percent 3

crypto map ipv6 CMAP_1 1 ipsec-isakmp
  set peer address 2001:DB8:FFFF::1
  set transform-set ESP-3DES-SHA
  match address 102

interface GigabitEthernet0/0/1
  ipv6 address 2001:DB8:FFFF::2/64
  ipv6 crypto map CMAP_1
  service-policy output p1
```

Example: Configuring Pre-classify on the Crypto Map

The following example shows how to enable QoS pre-classification using the **qos pre-classify** command on the crypto map CM_V6.

```
!
crypto map ipv6 CM_V6 10 ipsec-isakmp
  match address ACL_IPV6_1
  set transform-set set1
```

```

    set peer 2001:DB8:FFFF::1
    qos pre-classify
!
interface GigabitEthernet0/0/1
    ipv6 address 2001:DB8:FFFF::2/64
    service-policy output policy1
    ipv6 crypto map CM_V6

```

Example: Configuring Pre-classify on the Tunnel Interface

The following example shows how to enable QoS pre-classification using the **qos pre-classify** command on the tunnel interface tunnel1.

```

interface GigabitEthernet1/1/2
    ipv6 address 2001:DB8:1::F/64
    service-policy output policy1
!
interface Tunnel1
    ipv6 address 2001:DB8:2::F/64
    qos pre-classify
    ipv6 mtu 1400
    tunnel protection ipsec profile greprof

```

Example: Configuring LLQ QoS Group

The following example shows how to configure low latency queuing on a QoS group.

```

!
platform ipsec llq qos-group 1
platform ipsec llq qos-group 49
!
!
crypto map ipv6 cmap 1 ipsec-isakmp
    set peer 2001:DB8:FFFF:1::E/64
    set security-association lifetime seconds 600
    set transform-set aes-192
    match address 102
!
!
class-map match-all c1
    match precedence 5
class-map match-all c2
    match precedence 2
class-map match-all c3
    match precedence 4
class-map match-all c4
    match precedence 3
!
policy-map pl
    class c3
        set qos-group 20
    class c1
        set qos-group 49
    class c4
        set qos-group 77
!

```

```

policy-map p2
  class class-default
    set qos-group 1
!
interface GigabitEthernet0/2/0
  ipv6 address
  negotiation auto
  cdp enable
  ipv6 crypto map cmap
  service-policy input p2
!
!
interface GigabitEthernet0/2/7
  ipv6 address 2001:DB8:FFFF:1::F/64
  negotiation auto
  cdp enable
  service-policy input p1
!

```

Additional References for IPv6 IPsec QoS

Related Documents

| Related Topic | Document Title |
|----------------------------------|--|
| Cisco IOS commands | <i>Cisco IOS Master Command List, All Releases</i> |
| Security commands | <ul style="list-style-type: none"> • <i>Cisco IOS Security Command Reference Commands A to C</i> • <i>Cisco IOS Security Command Reference Commands D to L</i> • <i>Cisco IOS Security Command Reference Commands M to R</i> • <i>Cisco IOS Security Command Reference Commands S to Z</i> |
| IPv6 Commands | <i>IPv6 Command Reference</i> |
| QoS Commands | <i>Cisco IOS Quality of Service Solutions Command Reference</i> |
| IPv6 Addressing and Connectivity | <i>IPv6 Configuration Guide</i> |

Technical Assistance

| Description | Link |
|---|---|
| The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password. | http://www.cisco.com/cisco/web/support/index.html |

Feature Information for IPv6 IPsec QoS

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 1: Feature Information for IPv6 IPsec QoS

| Feature Name | Releases | Feature Information |
|----------------|----------|---|
| IPv6 IPsec QoS | 15.4(1)S | <p>The IPv6 IPsec QoS feature allows the QoS policies to be applied to IPv6 IPsec. This feature supports the following functionalities:</p> <ul style="list-style-type: none">• Crypto LLQ QoS• IPsec QoS Pre-Classify• QoS group-based LLQ <p>The following command was modified: ipv6 crypto map</p> |

