

SRv6 Flex-Algo with TI-LFA and uLoop Avoidance

This document describes SRv6 Flex-Algo with TI-LFA and uLoop Avoidance.

- Feature Information for SRv6 Flex-Algo with TI-LFA and uLoop Avoidance, on page 1
- SRv6 Flex-Algo with TI-LFA and uLoop Avoidance, on page 1
- Prerequisites for SRv6 Flex-Algo with TI-LFA and uLoop Avoidance, on page 2
- Restrictions for SRv6 Flex-Algo with TI-LFA and uLoop Avoidance, on page 2
- Configure SRv6 IS-IS flexible algorithm, on page 3
- Traffic steering, on page 7

Feature Information for SRv6 Flex-Algo with TI-LFA and uLoop Avoidance

The table below provides the feature history for SRv6 Flex-Algo with TI-LFA and uLoop Avoidance.

Table 1:

Feature	Release	Description
SRv6 Flex-Algo with TI-LFA and uLoop Avoidance	Cisco IOS XE 17.18.1a	From Cisco IOS XE 17.18.1a, Flexible Algorithm enhances SRv6 by including functions like Topology Independent Loop-Free Alternate (TI-LFA) and microloop (uLoop) avoidance. This feature improves network resilience and efficiency.

SRv6 Flex-Algo with TI-LFA and uLoop Avoidance

A SRv6 flexible algorithm is a feature that

- extends the capabilities of SRv6.
- allows traffic engineering and optimization.

• improves network resilience and efficiency by incorporating functionalities like Topology Independent Loop-Free Alternate (TI-LFA) and uLoop (microloop) Avoidance.

In SRv6, the network forwards data using SRv6 SIDs and SRv6 Locators. SIDs are assigned from the locators, and forwarding entries for them exist only on the device where they are created. Locators help with network-wide reachability and forward traffic for the SIDs. Therefore, a locator represents an algorithm-specific path to a certain destination node in the SRv6 domain. Each node can advertise multiple SRv6 locators - one for each Flex-Algo it participates in, in addition to locators for the default algorithm (algo-0).

SRv6 flex-algo FRR and TI-LFA

Flex-Algo FRR and TI-LFA are network performance features that

- improve network performance by allowing network operators to compute backups within the Flex-Algo topology, and
- ensure that traffic can be rerouted quickly in the event of link or node failures.

The Forwarding Information Base (FIB) entries will include Flex-Algo specific End SIDs and End.X SIDs, which are essential for accurate traffic forwarding across the network.

SRv6 Flex-Algo Microloop-Avoidance

A Flex-Algo Microloop-Avoidance is a process that

- integrates specific processing into existing IPv6 uLoop routines,
- ensures that Forwarding Information Base (FIB) entries are tailored for each flexible algorithm by incorporating End SIDs and End.X SIDs, and
- is crucial for maintaining seamless traffic flow and avoiding microloops during network updates or changes.

Prerequisites for SRv6 Flex-Algo with TI-LFA and uLoop Avoidance

SRv6 must be enabled on the router before the Flexible Algorithm functionality is activated.

Restrictions for SRv6 Flex-Algo with TI-LFA and uLoop Avoidance

- Only up to 8 SRv6 flex-algo will be supported.
- SRv6 deployments are supported only at one level. Leaking locators between levels or redistribution of locators is not supported.

Configure SRv6 IS-IS flexible algorithm

TI-LFA and uLoop Avoidance settings are inherited from the Algo zero configuration in Flex-Algos. You cannot modify these settings for each Flex-Algo, instead, you can only disable them. For more information, see ISIS - SRv6: uLoop Avoidance and IPv6 Loop-Free Alternate Fast Reroute

Use the following configuration to set up SRv6 flex-algo. For more details, see, Enabling Segment Routing Flexible Algorithm

The following is an example of how to configure the SRv6 IS-IS flexible algorithm. The below example shows how to configure three flexible-algorithms. Algo 128 runs IGP metric, Algo 129 runs with delay metric and Algo runs with 133 TE metric.

```
ipv6 unicast-routing
ipv6 cef
interface Loopback0
ip address 1.1.1.1 255.255.255.255
ipv6 address 111::111/128
segment-routing srv6
locators
 locator loc1
   prefix FCCC:CCC1:A1::/48
   format usid-f3216
  locator F128
  prefix FCCC:F128:A1::/48
   format usid-f3216
   algorithm 128
  locator F129
  prefix FCCC:F129:A1::/48
  format usid-f3216
  algorithm 129
  locator F133
   prefix FCCC:F133:A1::/48
   format usid-f3216
   algorithm 133
router isis 1
net 50.1234.1721.1600.1001.00
is-type level-2-only
router-id Loopback0
metric-style wide
affinity-map BLACK bit-position 255
affinity-map BLUE bit-position 0
affinity-map GREEN bit-position 8
flex-algo 128
 advertise-definition
 priority 250
 affinity
   exclude-any
   name BLUE
   exit-fa-affinity-attr
flex-algo 129
  advertise-definition
 metric-type delay
 priority 250
 affinity
  include-all
```

```
name BLACK
flex-algo 133
 advertise-definition
 metric-type te
  priority 250
  affinity
  include-anv
   name GREEN
address-family ipv6
  router-id Loopback0
  segment-routing srv6
  locator loc1
   locator F128
   locator F129
   locator F133
  fast-reroute per-prefix level-2 all
  fast-reroute ti-lfa level-2
interface Ethernet1/3
ipv6 address 15:15::1/64
ipv6 router isis 1
bfd interval 50 min_rx 50 multiplier 3
isis network point-to-point
isis te-metric flex-algo 10 level-2
isis ipv6 metric 10
isis ipv6 bfd
isis affinity flex-algo
 name BLACK
 name GREEN
 name BLUE
performance-measurement
interface Ethernet1/3
delay-measurement
next-hop ipv6 15:15::2
```

Verify SRv6 Flex-Algo with TI-LFA and uLoop Avoidance

Verify the configuration by using show commands to check the status and details of Flex-Algo settings:

The following is a sample output of the **show isis ipv6 rib flex-algo value** command showing all the IS-IS IPv6 local RIB information:

```
Router# sh isis ipv6 rib flex-algo 128

IS-IS IPv6 process 1, local RIB

Repair path attributes:
    DS - Downstream, LC - Linecard-Disjoint, NP - Node-Protecting
    PP - Primary-Path, SR - SRLG-Disjoint

Flex-algo 128

* CAFE:F128:606::/48
    Algorithm: 128
    via FE80::A8BB:CCFF:FE02:5E20/Ethernet0/2, type L2 metric 10 tag 0
    (installed)
    repair path: via FE80::A8BB:CCFF:FE02:5A10/Ethernet0/1 metric: 130 (DS,SR)
    TI-LFA link-protecting
        SRv6-Fwd-Id 25165861
        P node: r604 SID CAFE:0:604:: uN (PSP/USD)
```

```
Q node: r605 SID CAFE:0:604:E002:: uA (PSP/USD) repair source: r606, metric to pfx: 150
```

The following is a sample output of the **show isis ipv6 flex-algo** command showing all the information regarding IS-IS IPv6 flexible algorithm running in multi-topology mode. If ISIS IPv6 routing runs in single-topology mode, use the **show isis flex-algo** command.

```
Router# show isis ipv6 flex-algo 128
Tag 1:
IS-IS Flex-Algo Database
Flex-Algo count: 2
 Use delay metric advertisement: Application, Legacy
    IS-IS Level-2
      Delay metric: Inactive
Flex-Algo 128:
  Topology-2
    IS-IS Level-2
     Definition Priority: 128
      Definition Source: r601.00
      Definition Equal to Local: Yes
      Definition Metric Type: IGP
      Definition Flex-Algo Prefix Metric: No
     Disabled: No
     Microloop Avoidance Timer Running: No
   Local Priority: 128
   FRR Disabled: No
   Microloop Avoidance Disabled: No
```

The following is a sample output of the **show isis ipv6 topology flex-algovalue** command showing information regarding the IS-IS paths to intermediate systems running in multi-topology mode. If ISIS IPv6 routing runs in single-topology mode, use the command **show isis topology flex-algo**.

Router# sh isis ipv6 topology flex-algo 128

```
Tag 1:
Flex-algo 128
IS-IS TID 2 paths to level-2 routers
System Id
                  Metric Next-Hop
                                                  Interface
                                                              SNPA
                                                              aabb.cc02.5a00
                    1.0
                             r602
                                                  E+0/0
r602
                             r602
                                                 Et0/1
                                                              aabb.cc02.5a10
r603
                    20
                             r602
                                                 Et0/0
                                                              aabb.cc02.5a00
                              r602
                                                  Et0/1
                                                             aabb.cc02.5a10
r604
                    30
                              r602
                                                  Et0/0
                                                             aabb.cc02.5a00
                              r602
                                                  Et0/1
                                                              aabb.cc02.5a10
                              r606
                                                  E+0/2
                                                             aabb.cc02.5e20
r605
                    20
                              r606
                                                  Et0/2
                                                             aabb.cc02.5e20
r606
                    10
                              r606
                                                  Et0/2
                                                              aabb.cc02.5e20
```

The following is a sample output of the **sh isis ipv6 fast-reroute summary flex-algo** command showing information regarding the IS-IS fast-reroute summary flex-algo:

```
Router# sh isis ipv6 fast-reroute summary flex-algo 128
Tag 1:
```

```
Flex-algo 128
IPv6 Fast-Reroute Protection Summary:
 Prefix Counts:
                                 Protected
                                            Coverage
                                            ∩%
  High priority:
                      Ω
                                Ω
  Normal priority:
                      18
                               12
                                            66%
                      18
  Total:
                                12
                                             66%
```

Use the **show isis ipv6 microloop-avoidance flex-algo** command to display the current uLoop flex-algo status

Router# sh isis ipv6 microloop-avoidance flex-algo 128

```
Tag: 1
Algo State Delay Running(L1/L2)
128 Segment-Routing 5000 NA/FALSE
```

Following is the example output for show isis srv6 locators command

Router# **sh isis srv6 locators**ISIS SRv6 Locators: Tag 1:

Name	Algo	Prefix	Level
A	0	CAFE:0:601::/48	1-2
F128	128	CAFE:F128:601::/48	1-2

Following is the example output for show isis node locators command

Router# sh isis node locators r601.00

```
Tag 1:

ISIS level-2 node information for r601.00
SRv6 locator cache:
  (MT-2) CAFE:0:601::/48, Algorithm: 0
   LSP 0, Index 1, Seq 0x45
   Metric: 0, Algoritm: 0
   End SID: CAFE:0:601:: uN (PSP/USD)
  (MT-2) CAFE:F128:601::/48, Algorithm: 128
   LSP 0, Index 1, Seq 0x45
  Metric: 0, Algoritm: 128
  End SID: CAFE:F128:601:: uN (PSP/USD)
```

Following is the example output for sh isis node internal 1sp locators command

```
Router# sh isis node internal lsp locators r601.00
```

```
Tag 1:

ISIS level-2 node information for r601.00

LSP r601.00-00 (1111.1111.1111.00-00) Seq 0x49 locator list:

(MT-2) CAFE:F128:601::/48, Algo 128

(MT-2) CAFE:0:601::/48, Algo 0
```

Monitor SRv6 Flex-Algo with TI-LFA and uLoop Avoidance

After configuring SRv6 Flex-Algo, monitor its performance and behavior using the following commands:

Use **show isis ipv6 fast-reroute summary flex-algo [number]** command to monitor Fast-reroute coverage and status.

Use **show isis ipv6 microloop-avoidance flex-algo [number]** command to check microloop avoidance settings.

Traffic steering

ISIS creates the Flex-Algo forwarding plane, which is different from the algo-0 forwarding plane due to metric and affinity constraints. The forwarding plane in SRv6 was established by installing locator IPv6 prefixes into the routing table. From Cisco IOS XE 17.17.1a, users can steer VPN traffic routed by BGP to Flex-Algo by instructing BGP to use a locator for the specific VRF that belongs to Flex-Algo. For example, locator F255 belongs to flex-algo 255 and is used for traffic in VRF V6.

Configure traffic steering

The following sample configuration shows how to configure Traffic Steering

```
segment-routing srv6
locators
locator F255
prefix CAFE:F255:601::/48
format usid-f3216
algorithm 255

router bgp 100
...
address-family ipv6 vrf V6
!
segment-routing srv6
locator F255
exit-srv6
```

BGP than creates service SID which is used to steer traffic for BGP routes onto Flex-Algo forwarding plane.

Configure traffic steering