



BGP Commands

- [additional-paths receive](#), on page 6
- [additional-paths selection](#), on page 8
- [additional-paths send](#), on page 10
- [address-family \(BGP\)](#), on page 12
- [advertise](#), on page 16
- [advertise permanent-network](#), on page 17
- [advertisement-interval](#), on page 18
- [advertise vpn-imported label-mode per-vrf](#), on page 19
- [af-group](#), on page 20
- [aggregate-address](#), on page 22
- [aigp](#), on page 24
- [aigp send-cost-community](#), on page 25
- [allocate-label](#), on page 26
- [allow vpn default-originate](#), on page 27
- [allowconfed-as-in](#), on page 28
- [allowas-in](#), on page 29
- [as-format](#), on page 30
- [as-override](#), on page 31
- [as-path-loopcheck out disable](#), on page 32
- [attribute-filter group](#), on page 33
- [bfd \(BGP\)](#), on page 34
- [bgp as-path-loopcheck](#), on page 39
- [bgp attribute-download](#), on page 40
- [bgp auto-policy-soft-reset disable](#), on page 42
- [bgp bestpath as-path ignore](#), on page 43
- [bgp bestpath compare-routerid](#), on page 44
- [bgp bestpath cost-community ignore](#), on page 45
- [bgp bestpath med always](#), on page 46
- [bgp bestpath med confed](#), on page 47
- [bgp bestpath med missing-as-worst](#), on page 49
- [bgp bestpath origin-as allow invalid](#), on page 50
- [bgp bestpath origin-as use validity](#), on page 52
- [bgp bestpath aigp ignore](#), on page 53

- [bgp bestpath as-path multipath-relax](#) , on page 54
- [bgp client-to-client reflection disable](#), on page 55
- [bgp cluster-id](#), on page 57
- [bgp confederation identifier](#), on page 58
- [bgp confederation peers](#), on page 60
- [bgp dampening](#), on page 61
- [bgp default local-preference](#), on page 63
- [bgp enforce-first-as disable](#), on page 64
- [bgp fast-external-fallover disable](#), on page 65
- [bgp graceful-restart](#), on page 66
- [bgp graceful-restart graceful-reset](#), on page 67
- [bgp graceful-restart purge-time](#), on page 68
- [bgp graceful-restart restart-time](#), on page 69
- [bgp graceful-restart stalepath-time](#), on page 70
- [bgp import-delay](#), on page 71
- [bgp label-delay](#), on page 72
- [bgp log neighbor changes disable](#), on page 73
- [bgp lpts-secure-binding](#), on page 74
- [bgp maximum neighbor](#), on page 75
- [bgp multipath as-path](#), on page 76
- [bgp nexthop resolution allow-default](#), on page 77
- [bgp redistribute-internal](#), on page 78
- [bgp router-id](#), on page 79
- [bgp scan-time](#), on page 80
- [bgp unsafe-ebgp-policy](#), on page 81
- [bgp update-delay](#), on page 82
- [bgp write-limit](#), on page 83
- [bmp activate](#), on page 84
- [bmp server](#), on page 85
- [bmp advertisement-interval](#), on page 88
- [bmp scan-time](#), on page 90
- [capability additional-paths receive](#), on page 91
- [capability additional-paths send](#), on page 92
- [capability orf prefix](#), on page 93
- [capability suppress 4-byte-as](#), on page 95
- [clear bgp](#), on page 98
- [clear bgp external](#), on page 100
- [clear bgp nexthop registration](#), on page 102
- [clear bgp peer-drops](#), on page 104
- [clear bgp performance-statistics](#), on page 105
- [clear bgp shutdown](#), on page 106
- [default-information originate \(BGP\)](#), on page 107
- [default-martian-check disable](#), on page 108
- [default-metric \(BGP\)](#), on page 110
- [default-originate](#), on page 111
- [description \(BGP\)](#), on page 113

- [distance bgp](#), on page 114
- [domain-distinguisher](#), on page 116
- [dmz-link-bandwidth](#), on page 117
- [ebgp-multihop](#), on page 118
- [ecmp-delay](#), on page 119
- [export route-policy](#), on page 120
- [export route-target](#), on page 121
- [fast-fallover](#), on page 123
- [graceful-maintenance](#), on page 124
- [hw-module profile cef bgplu-over-rsvpte enable](#), on page 126
- [ibgp policy out enforce-modifications](#), on page 127
- [import](#), on page 128
- [import route-policy](#), on page 129
- [import route-target](#), on page 130
- [ignore-connected-check](#), on page 132
- [is-best-path](#), on page 133
- [is-backup-path](#), on page 134
- [is-multi-path](#), on page 135
- [label mode](#), on page 136
- [local-as](#), on page 140
- [long-lived-graceful-restart](#), on page 142
- [multipath](#), on page 144
- [maximum-paths \(BGP\)](#), on page 145
- [maximum-prefix \(BGP\)](#), on page 147
- [neighbor \(BGP\)](#), on page 150
- [neighbor-group](#), on page 152
- [neighbor internal-vpn-client](#), on page 154
- [network \(BGP\)](#), on page 155
- [network backdoor](#), on page 156
- [next-hop-self](#), on page 157
- [next-hop-unchanged](#), on page 159
- [nexthop resolution prefix-length minimum](#), on page 160
- [nexthop route-policy](#), on page 161
- [nexthop trigger-delay](#), on page 162
- [nsr \(BGP\)](#), on page 164
- [orf](#), on page 165
- [password \(BGP\)](#), on page 166
- [password \(rpki-server\)](#), on page 168
- [password-disable](#), on page 169
- [permanent-network](#), on page 170
- [prefix-ecmp-delay](#), on page 171
- [rd](#), on page 172
- [receive-buffer-size](#), on page 174
- [redistribute \(BGP\)](#), on page 176
- [remove-private-as](#), on page 179
- [remote-as \(BGP\)](#), on page 181

- retain local-label, on page 183
- retain route-target, on page 184
- route-mirroring inbound pre-policy, on page 185
- route-monitoring inbound post-policy, on page 186
- route-monitoring inbound pre-policy, on page 187
- route-monitoring local-rib, on page 188
- route-policy (BGP), on page 189
- route-reflector-client, on page 191
- router bgp, on page 193
- rpki route, on page 194
- selective-vrf-download disable, on page 195
- send-buffer-size, on page 196
- send-community-ebgp, on page 198
- send-community-gshut-ebgp, on page 199
- send-extended-community-ebgp, on page 200
- session-group, on page 201
- show bgp, on page 203
- show bgp aggregate contributors, on page 219
- show bgp bmp, on page 221
- show bgp update out, on page 248
- show bgp update in error process, on page 252
- show bgp update out filter-group, on page 253
- show bgp update out process, on page 254
- show bgp update out sub-group, on page 255
- show bgp update out update-group, on page 256
- show bgp vrf update in error, on page 257
- show bgp advertised, on page 258
- show bgp af-group, on page 264
- show bgp as-neighbors, on page 267
- show bgp attribute-key, on page 268
- show bgp cidr-only, on page 272
- show bgp community, on page 275
- show bgp convergence, on page 280
- show bgp dampened-paths, on page 283
- show bgp flap-statistics, on page 286
- show bgp inconsistent-as, on page 291
- show bgp labels, on page 295
- show bgp l2vpn, on page 299
- show bgp l2vpn vpls, on page 303
- show bgp neighbor-group, on page 308
- show bgp neighbors, on page 311
- show bgp neighbors nsr, on page 350
- show bgp nexthops, on page 352
- show bgp nsr, on page 365
- show bgp paths, on page 370
- show bgp policy, on page 372

- [show bgp process](#), on page 379
- [show bgp regexp](#), on page 404
- [show bgp route-policy](#), on page 407
- [show bgp session-group](#), on page 411
- [show bgp sessions](#), on page 414
- [show bgp sessions version-rate](#), on page 417
- [show bgp summary](#), on page 421
- [show bgp summary nsr](#), on page 427
- [show bgp table](#), on page 431
- [show bgp truncated-communities](#), on page 434
- [show bgp update-group](#), on page 437
- [show bgp vrf](#), on page 443
- [show lpts punt excessive-flow-trap bgp](#), on page 450
- [show protocols \(BGP\)](#), on page 451
- [show svd role](#), on page 453
- [show svd state](#), on page 454
- [shutdown \(BGP\)](#), on page 455
- [site-of-origin \(BGP\)](#), on page 457
- [slow peer \(BGP router global configuration\)](#), on page 458
- [slow peer \(BGP neighbor address-family configuration\)](#), on page 460
- [soft-reconfiguration inbound](#), on page 463
- [table-policy](#), on page 465
- [tcp ip-only-preferred](#), on page 466
- [timers bgp](#), on page 467
- [timers \(BGP\)](#), on page 469
- [update limit](#), on page 471
- [update limit address-family](#), on page 472
- [update limit sub-group](#), on page 473
- [update in error-handling basic disable](#), on page 474
- [update in error-handling extended](#), on page 475
- [update out logging](#), on page 476
- [update out originator-loopcheck disable](#), on page 477
- [update-source](#), on page 479
- [update wait-install](#), on page 480
- [update wait-install delay startup](#), on page 481
- [vrf \(BGP\)](#), on page 482
- [weight](#), on page 483

additional-paths receive

To configure receive capability of multiple paths for a prefix to the capable peers, use the **additional-paths receive** command in address-family configuration mode. To disable receive capability, use the **no** form of this command. To disable add-path receive capability for all neighbors belonging to a particular VRF address-family, use the **disable** option.

additional-paths receive [**disable**]
no additional-paths receive

Syntax Description

disable Disables advertising additional paths receive capability.

Note

Use the **disable** keyword option to disable add-path receive capability for all neighbors belonging to a specified VRF address-family.

Command Modes

IPv4 address family configuration

IPv6 address family configuration

VPNv4 address family configuration

VPNv6 address family configuration

VRF IPv4 address family configuration

VRF IPv6 address family configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **additional-paths receive** command to allow add-path receive capability to be negotiated for a specified address family. When the **additional-paths receive** command is configured, the receive capability is automatically enabled for all internal BGP neighbors for a specified address family. When this command is either not configured or explicitly disabled, none of the neighbors are allowed to negotiate receive capability for the address family.

After enabling the receive capability, the session needs to be reset for the configuration to take into effect.

This example shows how to enable additional paths receive capability under VPNv4 unicast address family:

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# address-family vpnv4 unicast
Router(config-bgp-af)# additional-paths receive
```

This example shows how to disable additional paths receive capability for all neighbors belonging to a particular VRF address-family (vrf1):

```
Router#configure  
Router(config-bgp)# vrf vrfl  
Router(config-bgp-vrf)#address-family ipv4 unicast  
Router(config-bgp-vrf-af)#additional-paths receive disable
```

additional-paths selection

To configure additional paths selection mode for a prefix, use the **additional-paths selection** command in address-family configuration mode. To disable the additional-paths selection mode for a prefix, use the **no** form of this command. To disable the additional-paths selection mode for a particular VRF address-family, use the **disable** option.

additional-paths selection {**route-policy** *route-policy-name* | **disable**}
no additional-paths selection route-policy *route-policy-name*

Syntax Description	route-policy <i>route-policy-name</i>	Specifies the name of a route policy used for additional paths selection.
	disable	Disables add-path selection for a particular VRF address-family.
Command Modes	IPv4 address family configuration	
	IPv6 address family configuration	
	VPNv4 address family configuration	
	VPNv6 address family configuration	
	VRF IPv4 address family configuration	
	VRF IPv6 address family configuration	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.
Usage Guidelines	To configure additional paths selection mode for some or all prefixes, use the additional-paths selection command by specifying a route-policy.	
	Use the additional-path selection command with an appropriate route-policy to calculate backup paths and to enable Prefix Independent Convergence (PIC) functionality. Refer <i>BGP Prefix Independent Convergence Unipath Primary/Backup</i> section in <i>BGP Configuration Guide for Cisco 8000 Series Routers</i> for details on the PIC functionality.	
Task ID	Task ID	Operation
	bgp	read, write
Examples	This example shows how to enable selection of additional paths:	
	<pre>Router# configure Router#(config)# router bgp 100 Router#(config-bgp)# address-family vpnv4 unicast</pre>	


```
Router#(config-bgp-af)# additional-paths selection route-policy ap1
```

This example shows how to disable add-path selection for a particular VRF address-family (vrf1):

```
Router##configure  
Router#(config-bgp)#vrf vrf1  
Router#(config-bgp-vrf)#address-family ipv4 unicast  
Router#(config-bgp-vrf-af)#additional-paths selection disable
```

This example shows how to enable add-path selection for a particular VRF address-family (vrf2):

```
Router##configure  
Router#(config-bgp)#vrf vrf2  
Router#(config-bgp-vrf)#address-family ipv4 unicast  
Router#(config-bgp-vrf-af)#additional-paths selection route-policy ap2
```

additional-paths send

To configure send capability of multiple paths for a prefix to the capable peers, use the **additional-paths send** command in address-family configuration mode. To disable the send capability, use the **no** form of this command.

additional-paths send [**disable**]
no additional-paths send

Syntax Description

disable Disables advertising additional paths send capability.

Note

Use the **disable** option to disable add-path send capability for all neighbors belonging to a particular VRF address-family.

Command Modes

IPv4 address family configuration

IPv6 address family configuration

VPNv4 address family configuration

VPNv6 address family configuration

VRF IPv4 address family configuration

VRF IPv6 address family configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the additional-paths send command to allow add-path send capability to be negotiated for a specified address family. When the **additional-paths send** command is configured, the send capability is automatically enabled for all internal BGP neighbors for the specified address family. When the command is either not configured or explicitly disabled, none of the neighbors are allowed to negotiate send capability for the address family.

After enabling the send capability, the session needs to be reset for the configuration to take into effect.

This example shows how to enable additional paths send capability under VPNv4 4 unicast address family:

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# address-family vpnv4 unicast
Router(config-bgp-af)# additional-paths send
```

This example shows how to enable add-path selection for a particular VRF address-family (vrf1):

```
Router#configure
Router(config-bgp)#vrf vrf1
```

```
Router(config-bgp-vrf)#address-family ipv4 unicast
Router(config-bgp-vrf-af)#additional-paths send disable
```

address-family (BGP)

To enter various address family configuration modes while configuring Border Gateway Protocol (BGP), use the **address-family** command in an appropriate configuration mode. To disable support for an address family, use the **no** form of this command.

```
address-family { ipv4 { labeled-unicast | flowspec | mdt | multicast | mvpn | rt-filter | tunnel
| unicast } | ipv6 { labeled-unicast | multicast | flowspec | mvpn | unicast } | l2vpn vpls-vpws |
vpnv4 { flowspec | multicast | unicast } | vpnv6 { unicast | flowspec } | link-state link-state }
```

Syntax Description

ipv4 unicast	Specifies IP Version 4 (IPv4) unicast address prefixes.
ipv4 multicast	Specifies IPv4 multicast address prefixes.
ipv4 labeled-unicast	Specifies IPv4 labeled-unicast address prefixes. This option is available in IPv4 neighbor configuration mode and VRF neighbor configuration mode.
ipv4 tunnel	Specifies IPv4 tunnel address prefixes.
ipv4 mdt	Specifies IPv4 multicast distribution tree (MDT) address prefixes. This option is available in router configuration mode and IPv4 neighbor configuration mode.
ipv6 unicast	Specifies IP Version 6 (IPv6) unicast address prefixes.
ipv6 multicast	Specifies IP Version 6 (IPv6) multicast address prefixes.
ipv6 labeled-unicast	Specifies IPv6 labeled-unicast address prefixes. This option is available in IPv6 neighbor configuration mode.
vpnv4 unicast	Specifies VPN Version 4 (VPNv4) unicast address prefixes. This option is not available in VRF or VRF neighbor configuration mode.
vpnv6 unicast	Specifies VPN Version 6 (VPNv6) unicast address prefixes. This option is not available in VRF or VRF neighbor configuration mode.
l2vpn vpls-vpws	Specifies L2VPN vpls-vpws address prefixes.
ipv4 rt-filter	Specifies IPv4 rt-filter address prefixes.
ipv4 mvpn	Specifies IPv4 mvpn address prefixes.
ipv6 mvpn	Specifies IPv6 mvpn address prefixes.
link-state link-state	Advertises link-state database of a network via BGP.
flowspec	Specifies flowspec configuration mode.
vpnv4 multicast	Specifies VPNv4 multicast prefixes.

Command Default

An address family must be explicitly configured in the router configuration mode for the address family to be active in BGP. Similarly, an address family must be configured under the neighbor for the BGP session to

be established for that address family. An address family must be configured in router configuration mode before it can be configured under a neighbor.

Command Modes

Router configuration
 Neighbor configuration
 Neighbor group configuration
 Flowspec configuration
 VRF configuration
 VRF neighbor configuration (IPv4 address families)

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **address-family** command to enter various address family configuration modes while configuring BGP routing sessions. When you enter the **address-family** command from router configuration mode, you enable the address family and enter global address family configuration mode.

The IPv4 unicast address family must be configured in router configuration mode before configuring the IPv4 labeled-unicast address family for a neighbor in neighbor configuration mode.

The IPv4 unicast address family must be configured in router configuration mode before configuring the IPv4 labeled-unicast address family for a neighbor in neighbor configuration mode. The IPv6 unicast address family must be configured in router configuration mode before configuring the IPv6 labeled-unicast address family for a neighbor in neighbor configuration mode.

Table 1: Address Family Submode Support

Address Family	Supported in Router Submode	Supported in Neighbor Submode	Comments
ipv4 unicast	yes	yes	—
ipv4 multicast	yes	yes	—
ipv4 mdt	yes	yes	—
ipv4 tunnel	yes	yes	—
ipv4 labeled-unicast	no	yes	The ipv4 labeled-unicast address family can be configured only as a neighbor address family; however, it requires that the ipv4 unicast address family be configured as the router address family first.
vpn4 unicast	yes	yes	—
ipv6 unicast	yes	yes	—
ipv6 multicast	yes	yes	—

Address Family	Supported in Router Submode	Supported in Neighbor Submode	Comments
ipv6 labeled-unicast	no	yes	The ipv6 labeled-unicast address family can be configured only as a neighbor address family; however, it requires that the ipv6 unicast address family be configured as the router address family first.
vpnv6 unicast	yes	yes	—
l2vpn vpls-vpws	yes	yes	—
ipv4 rt-filter	yes	yes	—
ipv4 mvpn	yes	yes	—
ipv6 mvpn	yes	yes	—
link-state	yes	yes	—
flowspec	yes	yes	If you configure flowspec redirect next hop rule, IPv4 and IPv6 packets drop when there is an invalid next hop.

When you enter the **address-family** command from neighbor configuration mode, you activate the address family on the neighbor and enter neighbor address family configuration mode. IPv4 neighbor sessions support IPv4 unicast, multicast, and labeled-unicast, and VPNv4 unicast address families. IPv6 neighbor sessions support IPv6 unicast and multicast address families.

Outbound Route Filter (ORF) capability is not supported with address-family l2vpn vpls-vpws

Examples

The following example shows how to place the router in global address family configuration mode for the IPv4 address family:

```
Router#configure
Router(config)# router bgp 100
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp-af)#
```

The following example shows how to activate IPv4 multicast for neighbor 10.0.0.1 and place the router in neighbor address family configuration mode for the IPv4 multicast address family:

```
Router# configure
Router# router bgp 1
Router(config-bgp)# address-family ipv4 multicast
Router(config-bgp-af)# exit
Router(config-bgp)# neighbor 10.0.0.1
Router(config-bgp-nbr)# remote-as 1
Router(config-bgp-nbr)# address-family ipv4 multicast
Router(config-bgp-nbr-af)#
```

The following example shows how to place the router in global address family configuration mode for the IPv4 tunnel address family:

```
Router# configure  
Router(config)# router bgp 12  
Router(config-bgp)# address-family ipv4 tunnel  
Router(config-bgp-af) #
```

The following example shows how to place the router in global address family link-state configuration mode:

```
Router# configure  
Router(config)# router bgp 100  
Router(config-bgp)# address-family link-state link-state  
Router(config-bgp-af) #
```

The following example shows how to exchange link-state information with a BGP neighbor:

```
Router# configure  
Router(config)# router bgp 100  
Router(config-bgp)# neighbor 10.0.0.2  
Router(config-bgp-nbr)# remote-as 1  
Router(config-bgp-nbr)# address-family link-state link-state  
Router(config-bgp-nbr-af) #
```

The following example shows how to place the router in flowspec sub-address family configuration mode for the IPv4 address family:

```
Router# configure  
Router(config)# router bgp 100  
Router(config-bgp)# address-family ipv4 flowspec  
Router(config-bgp-af) #
```

advertise

To configure advertisement of local or re-originated VPNv4 or VPNv6 unicast routes or disable advertisement of L2VPN prefixes from a BGP router to its configured BGP neighbor, use the **advertise** command in BGP neighbor address family configuration mode. To undo this command configuration, use the **no** form of this command.

advertise { {vpn4 | vpn6} unicast {re-originated | local stitching-rt} | l2vpn evpn disable}

Syntax Description	vpn4	Specifies VPNv4 prefixes.
	vpn6	Specifies VPNv6 prefixes.
	unicast	Specifies VPNv4 or VPNv6 unicast routes.
	re-originated	Specifies advertisement of re-originated VPNv4 or VPNv6 unicast routes
	local stitching-rt	Specifies advertisement of local VPNv4 or VPNv6 unicast routes with stitching route target identifier.
	l2vpn	Specifies L2VPN address-family.
	evpn disable	Disables advertisement of L2VPN EVPN prefixes.

Command Modes BGP neighbor address family configuration mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Example

The following example shows how to configure a BGP router to advertise local VPNv4 unicast routes assigned with stitching route target identifier to the specified BGP neighbor 1.1.1.1.

```
Router# configure
Router(config)# router bgp 1
Router(config-bgp)# neighbor 1.1.1.1
Router(config-bgp-nbr)# address-family l2vpn evpn
Router(config-bgp-nbr-af)# advertise vpn4 unicast re-originated stitching-rt
```


advertise permanent-network

To identify the peers to whom the permanent paths must be advertised, use the **advertise permanent-network** command in the neighbor address family configuration mode. To stop advertising the permanent p, use the **no** form of this command. The permanent paths will always be advertised to peers having advertise permanent-network configuration, even if a different best-path is available. The permanent path is not advertised to peers that are not configured to receive permanent path.

The permanent path supports only prefixes in IPv4 unicast and IPv6 unicast address-families under the default Virtual Routing and Forwarding (VRF).

advertise permanent-network

Syntax Description	This command has no arguments or keywords.	
Command Modes	Neighbor address-family configuration.	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Examples	This example shows how to advertise permanent path:	

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# neighbor 10.1.1.1
Router(config-bgp-nbr)# remote-as 4713
Router(config-bgp-nbr)# address-family ipv4 unicast
Router(config-bgp-nbr-af)# advertise permanent-network
```

advertisement-interval

To set the minimum interval between the sending of Border Gateway Protocol (BGP) routing updates, use the **advertisement-interval** command in an appropriate configuration mode. To remove the **advertisement-interval** command from the configuration file and restore the system to its default interval values, use the **no** form of this command.

advertisement-interval *seconds*

Syntax Description	<i>seconds</i> Minimum interval between sending BGP routing updates (in seconds). Range is 0 to 600.

Command Default	Default minimum interval: For internal BGP (iBGP) peers is 0 seconds For external BGP (eBGP) peers is 30 seconds For customer edge (CE) peers is 0 seconds

Command Modes	Neighbor configuration Neighbor group configuration Session group configuration VRF neighbor configuration

Command History	<table border="1"> <tr> <th>Release</th> <th>Modification</th> </tr> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

Usage Guidelines	If this command configures a neighbor group or session group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.

Examples	The following example shows how to set the minimum time between sending BGP routing updates to 10 seconds:

```
Router(config)# router bgp 5
Router(config-bgp)# neighbor 10.1.1.1
Router(config-bgp-nbr)# remote-as 100
Router(config-bgp-nbr)# advertisement-interval 10
```

advertise vpn-imported label-mode per-vrf

To enable per-VRF label allocation for imported VPN routes, use the **advertise vpn-imported label-mode per-vrf** command in VRF address-family configuration mode.

advertise vpn-imported label-mode per-vrf

Command Default	Per-prefix is the default label allocation mode.	
Command Modes	VRF address-family configuration	
Command History	Release	Modification
	Release 24.4.1	This command was introduced.
Usage Guidelines	Use this command to override the default per-prefix label allocation behavior and enforce per-VRF label allocation.	
Task ID	Task ID	Operation
	bgp	read, write
Examples	This example shows how to enable per-VRF label allocation. Router# configure Router(config)# vrf vrf_1 Router(config-vrf)# address-family ipv4 unicast Router(config-vrf-af)# advertise vpn-imported label-mode per-vrf	

af-group

To create an address family group for Border Gateway Protocol (BGP) neighbors and enter address family group configuration mode, use the **af-group** command in XR Config mode. To remove an address family group, use the **no** form of this command.

af-group *af-group-name* **address-family**

Syntax Description

<i>af-group-name</i>	Address family group name.
address-family	Enters address family configuration mode.
ipv4 unicast	Specifies IP Version 4 (IPv4) unicast address prefixes.
ipv4 multicast	Specifies IPv4 multicast address prefixes.
ipv4 labeled-unicast	Specifies IPv4 labeled unicast address prefixes.
ipv4 tunnel	Specifies IPv4 tunnel address prefixes.
ipv4 mdt	Specifies IPv4 multicast distribution tree (MDT) address prefixes.
ipv6 unicast	Specifies IP Version 6 (IPv6) unicast address prefixes.
ipv6 multicast	Specifies IPv6 multicast address prefixes.
ipv6 labeled-unicast	Specifies IPv6 labeled unicast address prefixes.
vpnv4 unicast	Specifies VPN Version 4 (VPNv4) unicast address prefixes.
vpnv6 unicast	Specifies VPN Version 6 (VPNv6) unicast address prefixes.

Command Default

No BGP address family group is configured.

Command Modes

XR Config mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **af-group** command to group address family-specific neighbor commands within an IPv4 or IPv6 address family. Neighbors that have address family configuration are able to use the address family group. Further, neighbors inherit the configuration parameters of the entire address family group.

You cannot define two address family groups with the same name in different address families.

Examples

The following example shows how to create address family group group1 and enter address family group configuration mode for IPv4 unicast. Group1 contains the next-hop-self feature, which is inherited by neighbors that use address family group1.

```
Router(config)# router bgp 100  
Router(config-bgp)# af-group group1 address-family ipv4 unicast  
Router(config-bgp-afgrp)# next-hop-self
```

aggregate-address

To create an aggregate entry in a Border Gateway Protocol (BGP) routing table, use the **aggregate-address** command in an appropriate configuration mode. To remove the **aggregate-address** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

aggregate-address *address/mask-length* [**as-set**] [**as-confed-set**] [**summary-only**] [**route-policy** *route-policy-name*]

Syntax Description	<i>address</i>	Aggregate address.
	<i>/mask-length</i>	Aggregate address mask length.
	as-set	(Optional) Generates autonomous system set path information and community information from contributing paths.
	as-confed-set	(Optional) Generates autonomous system confederation set path information from contributing paths.
	summary-only	(Optional) Filters all more-specific routes from updates.
	route-policy <i>route-policy-name</i>	(Optional) Specifies the name of a route policy used to set the attributes of the aggregate route.

Command Default When you do not specify this command, no aggregate entry is created in the BGP routing table.

Command Modes

- IPv4 address family configuration
- IPv6 address family configuration
- VRF IPv4 address family configuration
- VRF IPv6 address family configuration

Command History	Release	Modification
	Release 7.5.4	The command output displayed to set an aggregate contributor to a specific aggregate-address route.
	Release 7.0.12	This command was introduced.

Usage Guidelines You can implement aggregate routing in BGP either by redistributing an aggregate route into BGP using the **network** command or the **aggregate-address** command.

Use the **aggregate-address** command without optional arguments to create an aggregate entry in the BGP routing table if any more-specific BGP routes are available that fall in the specified range. The aggregate route is advertised as coming from your autonomous system and has the atomic aggregate attribute set to show that information might be missing. (By default, the atomic aggregate attribute is set unless you specify the **as-set** keyword.)

Use of the **as-set** keyword creates an aggregate entry using the same rules that the command follows without this keyword. However, the advertised path for this route is an AS_SET, a set of all autonomous systems contained in all paths that are being summarized.

Do not use this form of the **aggregate-address** command when aggregating many paths because this route must be continually withdrawn and updated as autonomous system path reachability information for the summarized routes changes.

Use the **as-confed-set** keyword to create an AS_CONFED_SET in the autonomous system path of the aggregate from any confederation segments in the paths being summarized. This keyword takes effect only if the **as-set** keyword is also specified.

Use of the **summary-only** keyword creates an aggregate entry (for example, 10.0.0.0/8) but suppresses advertisements of more-specific routes to all neighbors. If you want to suppress only advertisements to certain neighbors, use the **route-policy (BGP)** command in neighbor address family configuration mode with caution. If a more-specific route leaks out, all BGP speakers (the local router) prefer that route over the less-specific aggregate you generate (using longest-match routing).

Use the **route-policy** keyword to specify a routing policy for the aggregate entry. The **route-policy** keyword is used to select which more-specific information to base the aggregate entry on and which more-specific information to suppress. You can also use the keyword to modify the attributes of the aggregate entry.

Aggregate contributor flag is set in the router where you configure it. This feature is applicable for the following Address Family Indicators (AFIs):

- IPv4 unicast
- IPv6 unicast

Examples

The following example shows how to create an aggregate address. The path advertised for this route is an autonomous system set consisting of all elements contained in all paths that are being summarized.

```
Router(config)# router bgp 100
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp-af)# aggregate-address 10.0.0.0/8 as-set
```

The following example shows to set an aggregate contributor to a specific aggregate-address route:

```
Router #config
Router(config)#router bgp 100
Router(config-bgp)#address-family ipv4 unicast
Router(config-bgp-af)#aggregate-address 250.2.2.0/24 route-policy aggregate-policy1
Router(config-bgp-af)#commit
```

aigp

To enable sending and receiving of accumulated interior gateway protocol (AiGP) attribute per eBGP neighbor, use the **aigp** command in appropriate configuration mode. To disable this functionality, either use the **disable** keyword or use the **no** form of this command.

aigp [**disable**]

Syntax Description

disable Disables sending or receiving AiGP attribute.

Command Default

Send or receive of AiGP attribute is disabled for eBGP neighbors

Command Modes

IPv4 address family configuration

IPv6 address family configuration

VRF IPv4 address family configuration

VRF IPv6 address family configuration

VPNv4 address family configuration

VPNv6 address family configuration

Neighbor address family configuration

VRF neighbor address family configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Examples

The following example shows how to enable AiGP send and receive capability under neighbor address family (IPv4 unicast):

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# neighbor 10.2.3.4
Router(config-bgp-nbr)# address-family ipv4 unicast
Router(config-bgp-nbr-af)# aigp
```


aigp send-cost-community

To send Accumulated Interior Gateway Protocol (AiGP) value in cost community, use the **aigp send-cost-community** command in appropriate configuration mode. To disable sending AiGP value in cost community, either use the **no** form of this command or the **disable** keyword.

aigp send-cost-community { *cost-id* | **disable** } **poi** { **igp-cost** | **pre-bestpath** } [**transitive**]

Syntax Description	<i>cost-comm-id</i>	Specifies the Cost community ID. The range is 0 to 255.
	poi	Point of insertion for bestpath calculation.
	igp-cost	Configures that cost community be used after iGP distance to next hop.
	pre-bestpath	Configures cost community as first step in best path calculation.
	transitive	(Optional) Enables transitive cost community
	disable	Disables sending AiGP value in cost community.
Command Default	Sending AiGP value in cost community is disabled	
Command Modes	Neighbor address family configuration	
	VRF neighbor address family configuration	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.
Usage Guidelines	Cost community point of insertion can be configured either to be pre-bestpath or after igp cost. The transitive keyword is not required for iBGP sessions. However, the transitive keyword is required for eBGP sessions to convert AiGP metric into cost-community and advertise to the eBGP neighbors.	

Examples

The following example shows how to enable sending AiGP value in cost community ID 254 under neighbor address family (IPv4 unicast):

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# neighbor 10.2.3.4
Router(config-bgp-nbr)# address-family ipv4 unicast
Router(config-bgp-nbr-af)# aigp send-cost-community 254
```

allocate-label

To allocate Multiprotocol Label Switching (MPLS) labels for specific IPv4 unicast or IPv6 unicast or VPN routing and forwarding (VRF) IPv4 unicast routes so that the BGP router can send labels with BGP routes to a neighboring router configured for labeled- or VPN routing and forwarding (VRF) IPv6 unicast sessions, use the **allocate-label** command in the appropriate configuration mode. To restore the system to its default condition, use the **no** form of this command.

allocate-label { **route-policy** *route-policy-name* | **all** }

Syntax Description	all	Allocates labels for all prefixes
	route-policy <i>route-policy-name</i>	Uses a route policy to select prefixes for label allocation.
Command Default	No default behavior or values	
Command Modes	IPv4 address family configuration	
	IPv6 address family configuration	
	VRF IPv4 address family configuration	
	VRF IPv6 address family configuration	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.
Usage Guidelines	Use the allocate-label command with a route policy to trigger BGP to allocate labels for all or a filtered set of global IPv4 routes (as dictated by the route policy). The command enables autonomous system border routers (ASBRs) that have labeled IPv4 unicast sessions to exchange Multiprotocol Label Switching (MPLS) labels with the IPv4 routes to the other autonomous system (AS) in Layer 3 Virtual Private Network (L3VPN) inter-AS deployments.	



Note The **allocate-label all** command is functionally equivalent to the **allocate-label route-policy route-policy-name** command when the route policy is a pass-all policy.

See *MPLS Configuration Guide for Cisco 8000 Series Routers* for information on using the **allocate-label** command for L3VPN inter-AS deployments and carrier-supporting-carrier IPv4 BGP label distribution.

Examples

The following example shows how to enable allocating labels for IPv4 routes:

```
Router(config)# router bgp 6
Router(config-bgp)# address family ipv4 unicast
Router(config-bgp-af)# allocate-label route-policy policy_A
```

allow vpn default-originate

To configure the router to be enabled to advertise a default route to a configured BGP VPN neighbor, use the **allow vpn default-originate** command in the BGP VRF Address-Family configuration mode. To undo this configuration, use the **no** form of this command.

allow vpn default-originate

Syntax Description					
	This command has no keywords or arguments.				
Command Default	The router cannot advertise a default route to its BGP VPN neighbors.				
Command Modes	BGP VRF Address-Family configuration mode				
Command History	<table border="1"><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Release 7.0.12</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
Usage Guidelines	This command only enables the router to advertise itself as the next-hop router for a default route to its BGP VPN neighbors. To actually forward the default route to a BGP VPN neighbor, you need to run the default-originate command under the BGP neighbor Address-Family configuration mode.				

Example

The following example configuration shows how to enable a BGP router to advertise a default route to its BGP VPN neighbors.

```
Router# configure
Router(config)# router bgp 1
Router(config-bgp)# vrf foo
Router(config-bgp-vrf)# address-family ipv4 unicast
Router(config-bgp-vrf-af)# allow vpn default-originate
```

allowconfedas-in

To enable peer routers in the same confederation to learn from each other for a specified number of times, use the **allowconfedas-in** command in neighbor address family configuration mode.

allowconfedas-in *confederation-as-count*

Syntax Description	<i>confederation-as-count</i> Number of times a provider edge (PE) confederation AS number is allowed. Range: 1 to 10. Default: 3

Command Default	Peers within the same Confederation will not learn each other's routes.

Command Modes	Neighbor address-family configuration

Command History	Release	Modification
	Release 7.11.1	This command was introduced.

Task ID	Task ID	Operation
	bgp	read, write

Examples

In this example, the peer routers in the same confederation learn from each other thrice:

```
Router# router bgp 65001
Router(config-bgp) # bgp confederation peers 65002
Router(config-bgp) # bgp confederation identifier 100
Router(config-bgp) # neighbor 198.51.100.3
Router(config-bgp-nbr) # address-family ipv4 unicast
Router(config-bgp-nbr-af) # allowconfedas-in 1
```

allowas-in

To allow an AS path with the provider edge (PE) autonomous system number (ASN) a specified number of times, use the **allowas-in** command in an appropriate configuration mode. To restore the system to its default condition, use the **no** form of this command.

allowas-in [*as-occurrence-number*]

Syntax Description

as-occurrence-number (Optional) Number of times a PE ASN is allowed. Range is 1 to 10.

Command Default

No default behavior or values

Command Modes

Address family group configuration
Neighbor address family configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Hub and spoke VPN networks require looping back of routing information to the hub PE through the hub customer edge (CE). See *MPLS Configuration Guide for Cisco 8000 Series Routers* for information on hub and spoke VPN networks. This looping back, in addition to the presence of the PE ASN, causes the looped-back information to be dropped by the hub PE.

The **allowas-in** command prevents the looped-back information from being dropped by replacing the neighbor autonomous system number (ASN) with the PE ASN in the AS path. This allows the VPN customer to see a specified number of occurrences of the PE ASN in the AS path.

Examples

The following example shows how to allow five occurrences of the PE ASN:

```
Router(config)# router bgp 6
Router(config-bgp)# af-group group_1 address-family vpnv4 unicast
Router(config-bgp-afgrp)# allowas-in 5
```

as-format

To configure the router's Autonomous system number (ASN) notation to asdot format, use the `as-format` command in Global Configuration mode and XR Config mode. To restore the system to its default condition, use the **no** form of this command.

as-format asdot

Syntax Description	asdot Specifies the Autonomous system number (ASN) notation to asdot format.

Command Default	The default value, if the <code>as-format</code> command is not configured, is <code>asplain</code> .

Command Modes	Global Configuration mode and XR Config mode.

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.

Examples	The following example shows how to configure the ASN notation to the asdot format:

```
Router(config)# as-format asdot
```

as-override

To configure a provider edge (PE) router to override the autonomous system number (ASN) of a site with the ASN of a provider, use the **as-override** command which works for both VRF and non-VRF neighbor address family configuration mode. To restore the system to its default condition, use the **no** form of this command.

as-override [**inheritance-disable**]

Syntax Description	inheritance-disable (Optional) Prevents the as-override command from being inherited from a parent group.				
Command Default	Automatic override of the ASN is disabled.				
Command Modes	VRF and non-VRF neighbor address family configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.0.12</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
Usage Guidelines	Use the as-override command in conjunction with the site-of-origin (SoO) feature, identifying the site where a route originated, and preventing routing loops between routers within a VPN.				

Examples

The following example shows how to configure an ASN override:

```
Router(config)# router bgp 6
Router(config-bgp)# vrf vrf_A
Router(config-bgp-vrf)# neighbor 192.168.70.24
Router(config-bgp-vrf-nbr)# remote-as 10
Router(config-bgp-vrf-nbr)# address-family ipv4 unicast
Router(config-bgp-vrf-nbr-af)# as-override
```

as-path-loopcheck out disable

To disable AS PATH loop checking for outbound updates, use the **as-path-loopcheck out disable** command in an appropriate address family configuration mode. To re-enable the default AS PATH loop checking, use the **no** form of this command.

as-path-loopcheck out disable

Command Default

AS PATH loop checking for outbound updates is enabled if there is only one neighbor and disabled if there are multiple neighbors in the update group.

Command Modes

IPv4 address family

IPv6 address family

L2VPN address family

VPNv4 address family

VPNv6 address family

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Configure the **as-path-loopcheck out disable** command to disable the default behavior of PE router not announcing BGP routes to the CE router if the routes contain an AS number matching the AS number of the receiving CE router.

This example shows how to configure **as-path-loopcheck out disable** under IPv6 unicast address family:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#address-family ipv6 unicast
Router(config-bgp-af)#as-path-loopcheck out disable
```


attribute-filter group

To configure attribute-filter group command mode, use the attribute-filter group command in an appropriate configuration mode. To disable attribute-filter group command mode, use the no form of this command.

attribute-filter group *group-name*

Syntax Description	<i>group-name</i> Specifies the name of the attribute-filter group.				
Command Default	Attribute-filter group command mode is disabled.				
Command Modes	Router configuration Neighbor configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.0.12</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
Usage Guidelines	Use the attribute-filter group command in neighbor configuration mode to configure a specific attribute filter group for a BGP neighbor.				

This example shows how to configure the attribute-filter group command mode:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#attribute-filter group ag_discard_med
Router(config-bgp-attrfg)#
```

This example shows how to configure the attribute filter group for a BGP neighbor:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#neighbor 10.0.1.101
Router(config-bgp-nbr)#remote-as 6461
Router(config-bgp-nbr)#update in filtering
Router(config-nbr-upd-filter)#attribute-filter group ag_discard_med
```

bfd (BGP)

To specify a bidirectional forwarding detection (BFD) **multiplier** and **minimum-interval** arguments per neighbor, use the **bfd** command in neighbor address family independent configuration mode. To return to the system defaults, use the **no** form of this command.

Previous to this enhancement, BFD could be configured only in global scope in BGP. This change makes available two new command-line arguments under neighbor address family independent configuration:

```
bfd { multiplier | minimum-interval } value
```

Syntax Description

multiplier <i>value</i>	Specifies the BFD session's multiplier value for the neighbor.
minimum-interval <i>value</i>	Specifies the BFD session's minimum-interval value for the neighbor.

Command Default

No default per neighbor parameters are set.

Command Modes

Neighbor address family independent configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

If the minimum interval is changed using the **bfd minimum-interval** command, the new parameter updates all affected BFD sessions under the command mode in which the minimum interval was changed.

If the multiplier is changed using the **bfd multiplier** command, the new parameter is used to update only the BFD sessions associated with the affected neighbor gets affected.

The assumption is that when BFD fast-detect is enabled under neighbor address family independent configuration, the values for the **multiplier** and **minimum-interval** values are always derived from the per-neighbor values if they are configured; otherwise, they are to be taken from the global BGP configuration mode. In the event that this has not been explicitly stated, then these values are taken to be the default values. Also, the **bfd** arguments can be configured under neighbor-group and session-group and the inheritance adheres to the standard way of BGP configuration inheritance.

Accordingly, there are four cases in which bfd-fast detect is enabled.

This is shown in table below where the BFD value is either multiplier or minimum-interval. Local indicates per NBR value, global is the BGP global value.

BFD value (global)	BFD value (local)	Result
Yes	Yes	BFD value (local)
Yes	No	BFD value (global)
No	Yes	BFD value (local)
No	No	BFD value (default)

Examples

The following example shows how to specify the BFD session's multiplier value for the neighbor:

```
Router# configure
Router(config)# router bgp 65000
Router(config-bgp-nbrgrp)#neighbor 3.3.3.2
Router(config-bgp-nbr)# bfd minimum-interval 311
Router(config-bgp-nbr)# bfd multiplier 7
Router(config-bgp-nbr)# neighbor 5.5.5.2
Router(config-bgp-nbr)# bfd minimum-interval 318
Router(config-bgp-nbr)# bfd multiplier 4
Router(config-bgp-nbr)# vrf one
Router(config-bgp-vrf)# neighbor 3.12.1.2
Router(config-bgp-vrf-nbr)# bfd minimum-interval 119
Router(config-bgp-vrf-nbr)# bfd multiplier 10
Router(config-bgp-vrf-nbr)# commit
```

Router# show bfd session

Interface	Dest Addr	Local det time(int*mult) Echo	Async	State
-----	-----	-----	-----	-----
Gi0/2/0/2	3.3.3.2	2177ms (311ms*7)	14s (2s*7)	UP
Gi0/2/0/2.1	3.12.1.2	1190ms (119ms*10)	20s (2s*10)	UP
PO0/3/0/6	5.5.5.2	1272ms (318ms*4)	8s (2s*4)	UP

Router# show bfd session detail

I/f: GigabitEthernet0/2/0/2, Location: 0/2/CPU0, dest: 3.3.3.2, src: 3.3.3.1
State: UP for 0d:0h:4m:44s, number of times UP: 1

Received parameters:

Version: 1, desired tx interval: 2 s, required rx interval: 2 s
Required echo rx interval: 1 ms, multiplier: 7, diag: None
My discr: 524295, your discr: 524296, state UP, D/F/P/C/A: 0/0/0/1/0

Transmitted parameters:

Version: 1, desired tx interval: 2 s, required rx interval: 2 s
Required echo rx interval: 1 ms, multiplier: 7, diag: None
My discr: 524296, your discr: 524295, state UP, D/F/P/C/A: 0/0/0/1/0

Timer Values:

Local negotiated async tx interval: 2 s
Remote negotiated async tx interval: 2 s
Desired echo tx interval: 311 ms, local negotiated echo tx interval: 311 ms
Echo detection time: 2177 ms (311 ms*7), async detection time: 14 s (2 s*7)

Local Stats:

Intervals between async packets:

Tx: Number of intervals=100, min=1664 ms, max=2001 ms, avg=1838 ms
Last packet transmitted 313 ms ago

Rx: Number of intervals=100, min=1662 ms, max=2 s, avg=1828 ms
Last packet received 1615 ms ago

Intervals between echo packets:

Tx: Number of intervals=100, min=181 ms, max=462 ms, avg=229 ms
Last packet transmitted 289 ms ago

Rx: Number of intervals=100, min=178 ms, max=461 ms, avg=229 ms
Last packet received 287 ms ago

Latency of echo packets (time between tx and rx):

Number of packets: 100, min=0 us, max=4 ms, avg=860 us

Session owner information:

Client	Desired interval	Multiplier
-----	-----	-----
bgp-0	311 ms	7

I/f: GigabitEthernet0/2/0/2.1, Location: 0/2/CPU0, dest: 3.12.1.2, src: 3.12.1.1

State: UP for 0d:0h:4m:44s, number of times UP: 1

Received parameters:

```

Version: 1, desired tx interval: 2 s, required rx interval: 2 s
Required echo rx interval: 1 ms, multiplier: 10, diag: None
My discr: 524296, your discr: 524295, state UP, D/F/P/C/A: 0/0/0/1/0
Transmitted parameters:
Version: 1, desired tx interval: 2 s, required rx interval: 2 s
Required echo rx interval: 1 ms, multiplier: 10, diag: None
My discr: 524295, your discr: 524296, state UP, D/F/P/C/A: 0/0/0/1/0
Timer Values:
Local negotiated async tx interval: 2 s
Remote negotiated async tx interval: 2 s
Desired echo tx interval: 119 ms, local negotiated echo tx interval: 119 ms
Echo detection time: 1190 ms(119 ms*10), async detection time: 20 s(2 s*10)
Local Stats:
Intervals between async packets:
Tx: Number of intervals=100, min=1664 ms, max=2001 ms, avg=1838 ms
   Last packet transmitted 314 ms ago
Rx: Number of intervals=100, min=1662 ms, max=2 s, avg=1828 ms
   Last packet received 1616 ms ago
Intervals between echo packets:
Tx: Number of intervals=100, min=120 ms, max=223 ms, avg=125 ms
   Last packet transmitted 112 ms ago
Rx: Number of intervals=100, min=119 ms, max=223 ms, avg=125 ms
   Last packet received 110 ms ago
Latency of echo packets (time between tx and rx):
Number of packets: 100, min=0 us, max=2 ms, avg=850 us
Session owner information:
Client          Desired interval      Multiplier
-----
bgp-0           119 ms                 10

I/f: GigabitEthernet0/3/0/6, Location: 0/3/CPU0, dest: 5.5.5.2, src: 5.5.5.1
State: UP for 0d:0h:4m:50s, number of times UP: 1
Received parameters:
Version: 1, desired tx interval: 2 s, required rx interval: 2 s
Required echo rx interval: 1 ms, multiplier: 4, diag: None
My discr: 786436, your discr: 786433, state UP, D/F/P/C/A: 0/0/0/1/0
Transmitted parameters:
Version: 1, desired tx interval: 2 s, required rx interval: 2 s
Required echo rx interval: 1 ms, multiplier: 4, diag: None
My discr: 786433, your discr: 786436, state UP, D/F/P/C/A: 0/0/0/1/0
Timer Values:
Local negotiated async tx interval: 2 s
Remote negotiated async tx interval: 2 s
Desired echo tx interval: 318 ms, local negotiated echo tx interval: 318 ms
Echo detection time: 1272 ms(318 ms*4), async detection time: 8 s(2 s*4)
Local Stats:
Intervals between async packets:
Tx: Number of intervals=100, min=1663 ms, max=2 s, avg=1821 ms
   Last packet transmitted 1740 ms ago
Rx: Number of intervals=100, min=1663 ms, max=2001 ms, avg=1832 ms
   Last packet received 160 ms ago
Intervals between echo packets:
Tx: Number of intervals=100, min=181 ms, max=484 ms, avg=232 ms
   Last packet transmitted 44 ms ago
Rx: Number of intervals=100, min=179 ms, max=484 ms, avg=232 ms
   Last packet received 41 ms ago
Latency of echo packets (time between tx and rx):
Number of packets: 100, min=0 us, max=3 ms, avg=540 us
Session owner information:
Client          Desired interval      Multiplier
-----
bgp-0           318 ms                 4

Router# show bgp nei 3.3.3.2

```

```

BGP neighbor is 3.3.3.2
Remote AS 500, local AS 65000, external link
Remote router ID 16.0.0.1
BGP state = Established, up for 00:05:01
BFD enabled (session up): mininterval: 311 multiplier: 7
Last read 00:00:56, hold time is 180, keepalive interval is 60 seconds
Precedence: internet
Neighbor capabilities:
  Route refresh: advertised and received
  4-byte AS: advertised and received
  Address family IPv4 Unicast: advertised and received
Received 8 messages, 0 notifications, 0 in queue
Sent 9 messages, 1 notifications, 0 in queue
Minimum time between advertisement runs is 30 seconds

For Address Family: IPv4 Unicast
BGP neighbor version 2
Update group: 0.2
AF-dependant capabilities:
  Graceful Restart Capability advertised and received
  Neighbor preserved the forwarding state during latest restart
  Local restart time is 120, RIB purge time is 600 seconds
  Maximum stalepath time is 360 seconds
  Remote Restart time is 120 seconds
Route refresh request: received 0, sent 0
Policy for incoming advertisements is pass-all
Policy for outgoing advertisements is pass-all
1 accepted prefixes, 1 are bestpaths
Prefix advertised 1, suppressed 0, withdrawn 0, maximum limit 524288
Threshold for warning message 75%
An EoR was not received during read-only mode

Connections established 1; dropped 0
Last reset 00:06:58, due to User clear requested (CEASE notification sent - administrative
reset)
Time since last notification sent to neighbor: 00:06:58
Error Code: administrative reset
Notification data sent:
  None

```

Router# **show bgp nei 5.5.5.2**

```

BGP neighbor is 5.5.5.2
Remote AS 500, local AS 65000, external link
Remote router ID 16.0.0.1
BGP state = Established, up for 00:05:04
BFD enabled (session up): mininterval: 318 multiplier: 4
Last read 00:00:58, hold time is 180, keepalive interval is 60 seconds
Precedence: internet
Neighbor capabilities:
  Route refresh: advertised and received
  4-byte AS: advertised and received
  Address family IPv4 Unicast: advertised and received
Received 8 messages, 0 notifications, 0 in queue
Sent 9 messages, 1 notifications, 0 in queue
Minimum time between advertisement runs is 30 seconds

For Address Family: IPv4 Unicast
BGP neighbor version 2
Update group: 0.2
AF-dependant capabilities:
  Graceful Restart Capability advertised and received
  Neighbor preserved the forwarding state during latest restart

```

```

        Local restart time is 120, RIB purge time is 600 seconds
        Maximum stalepath time is 360 seconds
        Remote Restart time is 120 seconds
    Route refresh request: received 0, sent 0
    Policy for incoming advertisements is pass-all
    Policy for outgoing advertisements is pass-all
    1 accepted prefixes, 0 are bestpaths
    Prefix advertised 1, suppressed 0, withdrawn 0, maximum limit 524288
    Threshold for warning message 75%
    An EoR was not received during read-only mode

    Connections established 1; dropped 0
    Last reset 00:07:01, due to User clear requested (CEASE notification sent - administrative
reset)
    Time since last notification sent to neighbor: 00:07:01
    Error Code: administrative reset
    Notification data sent:
        None

Router# show bgp vrf one nei 3.12.1.2

BGP neighbor is 3.12.1.2, vrf one
Remote AS 500, local AS 65000, external link
Remote router ID 16.0.0.1
BGP state = Established, up for 00:05:06
BFD enabled (session up): mininterval: 119 multiplier: 10
Last read 00:00:01, hold time is 180, keepalive interval is 60 seconds
Precedence: internet
Neighbor capabilities:
    Route refresh: advertised and received
    4-byte AS: advertised and received
    Address family IPv4 Unicast: advertised and received
Received 9 messages, 0 notifications, 0 in queue
Sent 9 messages, 1 notifications, 0 in queue
Minimum time between advertisement runs is 0 seconds

For Address Family: IPv4 Unicast
BGP neighbor version 2
Update group: 0.2
AF-dependant capabilities:
    Graceful Restart Capability advertised and received
        Neighbor preserved the forwarding state during latest restart
        Local restart time is 120, RIB purge time is 600 seconds
        Maximum stalepath time is 360 seconds
        Remote Restart time is 120 seconds
    Route refresh request: received 0, sent 0
    Policy for incoming advertisements is pass-all
    Policy for outgoing advertisements is pass-all
    1 accepted prefixes, 1 are bestpaths
    Prefix advertised 0, suppressed 0, withdrawn 0, maximum limit 524288
    Threshold for warning message 75%
    An EoR was not received during read-only mode

    Connections established 1; dropped 0
    Last reset 00:07:04, due to User clear requested (CEASE notification sent - administrative
reset)
    Time since last notification sent to neighbor: 00:07:04
    Error Code: administrative reset
    Notification data sent:
        None

```

bgp as-path-loopcheck

To enable loop checking in the autonomous system path of the prefixes advertised by internal Border Gateway Protocol (iBGP) peers, use the **bgp as-path-loopcheck** command in an appropriate configuration mode. To restore the system to its default condition, use the **no** form of this command.

bgp as-path-loopcheck

Command Default

When you do not specify this command, loop checking is performed only for external peers.

Command Modes

Router configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Examples

The following example shows how to configure an autonomous system path for loop checking iBGP peers:

```
Router(config)# router bgp 6  
Router(config-bgp)# bgp as-path-loopcheck
```

bgp attribute-download

To enable Border Gateway Protocol (BGP) attribute download, use the **bgp attribute-download** command in an appropriate configuration mode. To disable BGP attribute download, use the **no** form of this command.

bgp attribute-download

Command Default

BGP attribute download is not enabled.

Command Modes

IPv4 unicast address family configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

When BGP attribute download is enabled using the **bgp attribute-download** command, BGP reinstalls all routes whose attributes are not currently in the RIB. Likewise, if the user disables BGP attribute download using the **no** form of the command, BGP reinstalls previously installed routes with a null key, and removes the attributes from the RIB.

Use the **bgp attribute-download** command to enable the Netflow BGP data export function. When attribute download is enabled, BGP downloads the attribute information for prefixes (community, extended community, and as-path) to the Routing Information Base (RIB) and Forwarding Information Base (FIB). This enables FIB to associate the prefixes with attributes and send the Netflow statistics along with the associated attributes.

Examples

The following example shows the BGP routes before and after BGP attribute download is enabled and shows how to enable BGP attribute download on BGP router 50:

```
Router# show route bgp

B    100.0.1.0/24 [200/0] via 10.0.101.1, 00:00:37
B    100.0.2.0/24 [200/0] via 10.0.101.1, 00:00:37
B    100.0.3.0/24 [200/0] via 10.0.101.1, 00:00:37
B    100.0.4.0/24 [200/0] via 10.0.101.1, 00:00:37
B    100.0.5.0/24 [200/0] via 10.0.101.1, 00:00:37

Router(config)# router bgp 50
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp-af)# bgp attribute-download
!
!
!
Router# show route bgp

B    100.0.1.0/24 [200/0] via 10.0.101.1, 00:00:01
      Attribute ID 0x2
B    100.0.2.0/24 [200/0] via 10.0.101.1, 00:00:01
      Attribute ID 0x2
B    100.0.3.0/24 [200/0] via 10.0.101.1, 00:00:01
      Attribute ID 0x2
B    100.0.4.0/24 [200/0] via 10.0.101.1, 00:00:01
      Attribute ID 0x2
B    100.0.5.0/24 [200/0] via 10.0.101.1, 00:00:01
```


Attribute ID 0x2

bgp auto-policy-soft-reset disable

To disable an automatic soft reset of Border Gateway Protocol (BGP) peers when their configured route policy is modified, use the **bgp auto-policy-soft-reset disable** command in an appropriate configuration mode. To re-enable automatic soft reset of BGP peers, use the **no** form of this command.

bgp auto-policy-soft-reset disable

Command Default

Automatic soft reset of peers is enabled.

Command Modes

Router configuration
VRF configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

If the inbound policy changes, it is not always possible to perform a soft reset. This is the case if the neighbor does not support route refresh and soft-reconfiguration inbound is not configured for the neighbor. In such instances, a message is logged in the system log indicating that a manual hard reset is needed.

Examples

The following example shows how to disable an automatic soft reset of BGP peers when their configured route policy is modified:

```
Router(config)# router bgp 6
Router(config-bgp)# bgp auto-policy-soft-reset disable
```

bgp bestpath as-path ignore

To ignore the autonomous system path length when calculating preferred paths, use the **bgp bestpath as-path ignore** command in an appropriate configuration mode. To return the software to the default state in which it considers the autonomous system path length when calculating preferred paths, use the **no** form of this command.

bgp bestpath as-path ignore

Command Default

The autonomous system path length is used (not ignored) when a best path is selected.

Command Modes

Router configuration

VRF configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **bgp bestpath as-path ignore** command to ignore the length of autonomous system paths when the software selects a preferred path. When the best path is selected, if this command is specified, all steps are performed as usual except comparison of the autonomous path length between candidate paths.

Examples

The following example shows how to configure the software to ignore the autonomous system length when performing best-path selection:

```
Router(config)# router bgp 65000
Router(config-bgp)# bgp bestpath as-path ignore
```

bgp bestpath compare-routerid

To compare identical routes received from external BGP (eBGP) peers during the best-path selection process and select the route with the lowest router ID, use the **bgp bestpath compare-routerid** command in an appropriate configuration mode. To disable comparing identical routes received from eBGP peers during best-path selection, use the **no** form of this command.

bgp bestpath compare-routerid

Command Default

The software does not select a new best path if it is the same as the current best path (according to the BGP selection algorithm) except for the router ID.

Command Modes

Router configuration
VRF configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **bgp bestpath compare-routerid** command to affect how the software selects the best path, in the case where there are two paths of equal cost according to the BGP selection algorithm. This command is used to force the software to select the path with the lower router ID as the best path. If this command is not used, the software continues to use whichever path is currently the best path, regardless of which has the lower router ID.

Examples

The following example shows how to configure the BGP speaker in autonomous system 500 to compare the router IDs of similar paths:

```
Router(config)# router bgp 500
Router(config-bgp)# bgp bestpath compare-routerid
```

bgp bestpath cost-community ignore

To configure a router that is running the Border Gateway Protocol (BGP) to not evaluate the cost community attribute during the best-path selection process, use the **bgp bestpath cost-community ignore** command in an appropriate configuration mode. To restore the system to its default condition, use the **no** form of this command.

bgp bestpath cost-community ignore

Command Default	The behavior of this command is enabled by default until the cost community attribute is manually configured.

Command Modes	Router configuration VRF configuration

Command History	<table border="1"><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Release 7.0.12</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

Usage Guidelines	Use the bgp bestpath cost-community ignore command to disable the evaluation of the cost community attribute to help isolate problems and troubleshoot issues that relate to BGP path selection. This command can also be used to delay the activation of cost community attribute evaluation so that cost community filtering can be deployed in a large network at the same time.

Examples	The following example shows how to configure a router to not evaluate the cost community attribute during the best-path selection process:

```
Router(config)# router bgp 500  
Router(config-bgp)# bgp bestpath cost-community ignore
```

bgp bestpath med always

To allow the comparison of the Multi Exit Discriminator (MED) for paths from neighbors in different autonomous systems, use the **bgp bestpath med always** command in an appropriate configuration mode. To disable considering the MED attribute in comparing paths, use the **no** form of this command.

bgp bestpath med always

Command Default

The software does not compare MEDs for paths from neighbors in different autonomous systems.

Command Modes

Router configuration

VRF configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

The MED is one of the parameters that is considered by the software when selecting the best path among many alternative paths. The software chooses the path with the lowest MED.

By default, during the best-path selection process, the software makes a MED comparison only among paths from the same autonomous system. This command changes the default behavior of the software by allowing comparison of MEDs among paths regardless of the autonomous system from which the paths are received.

When the **bgp bestpath med always** command is not enabled and distributed BGP is configured, speakers calculate partial best paths only (executes the best-path steps up to the MED comparison) and send them to BGP Routing Information Base (bRIB). bRIB calculates the final best path (executes all the steps in the best-path calculation). When the **bgp bestpath med always** command is enabled and distributed BGP is configured, speakers can compare the MED across all ASs, allowing the speaker to calculate a single best path to send it to bRIB. bRIB is the ultimate process that calculates the final best path, but when the **bgp bestpath med always** command is enabled, the speakers send a single best path instead of potentially sending multiple, partial best paths

Examples

The following example shows how to configure the Border Gateway Protocol (BGP) speaker in autonomous system 100 to compare MEDs among alternative paths, regardless of the autonomous system from which the paths are received:

```
Router(config)# router bgp 100
Router(config-bgp)# bgp bestpath med always
```

bgp bestpath med confed

To enable Multi Exit Discriminator (MED) comparison among paths learned from confederation peers, use the **bgp bestpath med confed** command in an appropriate configuration mode. To disable the software from considering the MED attribute in comparing paths, use the **no** form of this command.

bgp bestpath med confed

Command Default

The software does not compare the MED of paths containing only confederation segments, or paths containing confederation segments followed by an AS_SET, with the MED of any other paths.

Command Modes

Router configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

By default, the MED of the following paths is not compared with the MED of any other path:

- Paths with an empty autonomous system path
- Paths beginning with an AS_SET
- Paths containing only confederation segments
- Paths containing confederation segments followed by an AS_SET

Use the **bgp bestpath med confed** command to affect how the following types of paths are treated in the BGP best-path algorithm:

- Paths containing only confederation segments
- Paths containing confederation segments followed by an AS_SET

The MED for paths that start with an AS_SEQUENCE or that start with confederation segments followed by an AS_SEQUENCE only is compared with the MED of other paths that share the same first autonomous system number in the autonomous system sequence (the neighbor autonomous system number). This behavior is not affected by the **bgp bestpath med confed** command.

As an example, suppose that autonomous systems 65000, 65001, 65002, and 65004 are part of a confederation, but autonomous system 1 is not. Suppose that for a particular route, the following paths exist:

- Path 1: 65000 65004, med = 2, IGP metric = 20
- Path 2: 65001 65004, med = 3, IGP metric = 10
- Path 3: 65002 1, med = 1, IGP metric = 30

If the **bgp bestpath med confed** command is enabled, the software selects path 1 as the best path because it:

- Has a lower MED than path 2
- Has a lower IGP metric than path 3

The MED is not compared with path 3 because it has an external autonomous system number (that is, an AS_SEQUENCE) in the path. If the **bgp bestpath med confed** command is not enabled, then MED is not compared between any of these paths. Consequently, the software selects path 2 as the best path because it has the lowest IGP metric.

Examples

The following command shows how to enable Border Gateway Protocol (BGP) software to compare MED values for paths learned from confederation peers:

```
Router(config)# router bgp 210  
Router(config-bgp)# bgp bestpath med confed
```


bgp bestpath med missing-as-worst

To have the software consider a missing Multi Exit Discriminator (MED) attribute in a path as having a value of infinity, making the path without a MED value the least desirable path, use the **bgp bestpath med missing-as-worst** command in an appropriate configuration mode. To disable considering the MED attribute in comparing paths, use the **no** form of this command.

bgp bestpath med missing-as-worst

Command Default

The software assigns a value of 0 to the missing MED, causing the path with the missing MED attribute to be considered as the best possible MED.

Command Modes

Router configuration

VRF configuration

Command History

Release**Modification**

Release 7.0.12 This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Examples

The following example shows how to direct the Border Gateway Protocol (BGP) software to consider a missing MED attribute in a path as having a value of infinity, making this path the least desirable path:

```
Router(config)# router bgp 210  
Router(config-bgp)# bgp bestpath med missing-as-worst
```

bgp bestpath origin-as allow invalid

To permit all paths marked with an 'invalid' origin-as by RPKI to be considered for BGP best path computation, use the **bgp bestpath origin-as allow invalid** command in the router configuration mode. This configuration can also be made in global address family, neighbor, and neighbor address family submodes. To return the device to default operation, use the **no** form of this command.

For router and global address family configuration mode:

bgp bestpath origin-as allow invalid

For neighbour and neighbor address family configuration mode:

bestpath origin-as allow invalid

Command Default

By default, prefixes marked with an 'invalid' origin-as are not considered for BGP best path computation when the router is performing origin-as validation.

Command Modes

Router configuration

Address family

Neighbor

Neighbor Address family

Command History

Release	Modification
Release 7.0.12	This command was introduced

Usage Guidelines

Configuring the **bgp bestpath origin-as allow invalid** command allows paths marked with an 'invalid' origin-as to be considered for best path computation. This can be limited to an address family by configuring it at the address-family submode.

This configuration takes effect only when the **bgp bestpath origin-as use validity** configuration is enabled.

Examples

The following example shows how to permit all invalid paths to be considered for BGP best-path selection in the global mode:

```
Router#configure
Router(config)#router bgp 50000
Router(config-bgp)#bgp bestpath origin-as allow invalid
```

The following example shows how to permit all invalid paths to be considered for BGP best-path selection in the address family submode:

```
Router#configure
Router(config)#router bgp 50000
Router(config-bgp)#address-family ipv4 unicast
Router(config-bgp-af)#bgp bestpath origin-as allow invalid
```

The following example shows how to permit all invalid paths to be considered for best-path selection in the neighbor submode:

```
Router#configure
Router(config)#router bgp 50000
Router(config-bgp)#neighbor 1.1.1.1
Router(config-bgp-nbr)#bestpath origin-as allow invalid
```

The following example shows how to permit all invalid paths to be considered for best-path selection in the neighbour address-family submode:

```
Router#configure
Router(config)#router bgp 50000
Router(config-bgp)#neighbor 1.1.1.1
Router(config-bgp-nbr)#address-family ipv4 unicast
Router(config-bgp-nbr-af)#bestpath origin-as allow invalid
```

bgp bestpath origin-as use validity

To enable the BGP Origin AS Validation feature (RPKI) and allow the validity states of BGP paths to be taken into consideration in the bestpath process, use the **bgp bestpath origin-as use validity** command. This can be configured in router configuration mode and address family submode. To return the device to default operation, use the **no** form of this command.

bgp bestpath origin-as use validity

Command Default

By default, the best path computation does not take RPKI states into account.

Command Modes

Router configuration

Address family configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced

Usage Guidelines

There are three RPKI states - valid, invalid, and not found. When the **bgp bestpath origin-as use validity** command is configured, only paths marked with 'valid' or 'not found' are considered as best path candidates. When the **bgp bestpath origin-as allow invalid** command is configured, paths marked as 'invalid' are also considered but preference is given to routes marked 'valid' over those marked 'invalid'.

Examples

The following example shows how to enable the validity states of BGP paths to affect the path's preference when performing best-path selection:

```
Router#configure
Router(config)#router bgp 50000
Router(config-bgp)#bgp bestpath origin-as use validity
```

bgp bestpath aigp ignore

To configure a device that is running the Border Gateway Protocol (BGP) to not evaluate the accumulated interior gateway protocol (AIGP) metric during the best path selection process between two paths when one path does not have the AIGP metric, use the **bgp bestpath aigp ignore** command in router configuration mode. To return the device to default operation, use the **no** form of this command.

bgp bestpath aigp ignore

Command Default

AIGP is enabled by default.

If this command is not configured, then the accumulated interior gateway protocol (AIGP) metric is evaluated (not ignored) during the best path selection.

Command Modes

Router configuration

VRF configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

By default, BGP always prefers a path with the AIGP metric. When there are two paths, one with the AIGP metric and the other without, then executing the **bgp bestpath aigp ignore** command results in BGP performing best path computation as if neither paths has the AIGP metric.

Examples

The following example shows how to configure the software to ignore the accumulated interior gateway protocol (AIGP) metric when performing best-path selection:

```
Router#configure
Router(config)#router bgp 50000
Router(config-bgp)#bgp bestpath aigp ignore
```

bgp bestpath as-path multipath-relax

To configure a Border Gateway Protocol (BGP) routing process to consider the different autonomous system (AS) paths and load balance multiple paths during best path route selection, use the **bgp bestpath as-path multipath-relax** command. To return the BGP routing process to the default operation, use the **no** form of this command.

bgp bestpath as-path multipath-relax

Command Modes

Router BGP configuration

VRF configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

When BGP multi-pathing is enabled, BGP load-balances user traffic within a single autonomous system (AS). The criteria are that all attributes must match (weight, AS path, etc). However when a device is multi-homed to multiple autonomous systems, BGP cannot load balance traffic between them by default. In order to enable load-balancing of traffic among the multi-homed autonomous systems, the **bgp bestpath as-path multipath-relax** command needs to be enabled. The criteria required for this is that the AS-path length should be equal.

Before you use this command, ensure that BGP is enabled

Examples

This example shows how to configure multipath load sharing on paths from different autonomous systems in router mode:

```
Router#configure
Router(config)#router bgp 120
Router(config-bgp)#bgp bestpath as-path multipath-relax
```

bgp client-to-client reflection disable

To disable reflection of routes between route-reflection clients using a Border Gateway Protocol (BGP) route reflector, use the **bgp client-to-client reflection disable** command in address family configuration mode. To re-enable client-to-client reflection, use the **no** form of this command.

bgp client-to-client reflection [**cluster-id** *cluster-id*] **disable**

Syntax Description	cluster-id <i>cluster-id</i> (Optional) Cluster ID for which intra-cluster route reflection is to be disabled; maximum of 4 bytes. Cluster ID can be entered either as an IP address or value. Range is 1 to 4294967295.

Syntax Description	This command has no keywords or arguments.

Command Default	Client-to-client reflection is enabled.

Command Modes	Address family configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	By default, the clients of a route reflector are not required to be fully meshed and the routes from a client are reflected to other clients. However, if the clients are fully meshed, route reflection is not required.

By default, the clients of a route reflector that are part of the same cluster are not required to be fully meshed and the routes from a client are reflected to other clients. However, if the clients are fully meshed, route reflection is not required. If the cluster-id is not specified, then this command disables intra-cluster route reflection for all clusters.

Examples

In this example, the three neighbors are fully meshed, so client-to-client reflection is disabled:

```
RP/0/RP0/CPU0:router(config)# router bgp 65534
RP/0/RP0/CPU0:router(config-bgp)# bgp cluster-id 2
RP/0/RP0/CPU0:router(config-bgp)# address-family ipv4 unicast
RP/0/RP0/CPU0:router(config-bgp-af)# bgp client-to-client reflection cluster-id 2 disable
RP/0/RP0/CPU0:router(config-bgp-af)# exit
RP/0/RP0/CPU0:router(config-bgp)# neighbor-group rrclients
RP/0/RP0/CPU0:router(config-bgp-nbrgrp)# remote-as 65534
RP/0/RP0/CPU0:router(config-bgp-nbrgrp)# bgp cluster-id 2
RP/0/RP0/CPU0:router(config-bgp-nbrgrp)# address-family ipv4 unicast
RP/0/RP0/CPU0:router(config-bgp-nbrgrp-af)# route-reflector-client
RP/0/RP0/CPU0:router(config-bgp-nbrgrp-af)# exit
RP/0/RP0/CPU0:router(config-bgp-nbrgrp)# exit

RP/0/RP0/CPU0:router(config-bgp)# neighbor 192.168.253.21 use neighbor-group rrclients
RP/0/RP0/CPU0:router(config-bgp)# neighbor 192.168.253.22 use neighbor-group rrclients
RP/0/RP0/CPU0:router(config-bgp)# neighbor 192.168.253.23 use neighbor-group rrclients
```

Examples

In this example, the three neighbors are fully meshed, so client-to-client reflection is disabled:

```
RP/0/RP0/CPU0:router(config)# router bgp 65534
RP/0/RP0/CPU0:router(config-bgp)# address-family ipv4 unicast
RP/0/RP0/CPU0:router(config-bgp-af)# bgp client-to-client reflection disable
RP/0/RP0/CPU0:router(config-bgp-af)# exit
RP/0/RP0/CPU0:router(config-bgp)# neighbor-group rrclients
RP/0/RP0/CPU0:router(config-bgp-nbrgrp)# remote-as 65534
RP/0/RP0/CPU0:router(config-bgp-nbrgrp)# address-family ipv4 unicast
RP/0/RP0/CPU0:router(config-bgp-nbrgrp-af)# route-reflector-client
RP/0/RP0/CPU0:router(config-bgp-nbrgrp-af)# exit
RP/0/RP0/CPU0:router(config-bgp-nbrgrp)# exit

RP/0/RP0/CPU0:router(config-bgp)# neighbor 192.168.253.21 use neighbor-group rrclients
RP/0/RP0/CPU0:router(config-bgp)# neighbor 192.168.253.22 use neighbor-group rrclients
```


bgp cluster-id

To configure the cluster ID if the Border Gateway Protocol (BGP) cluster has more than one route reflector, use the **bgp cluster-id** command in an appropriate configuration mode. To remove the cluster ID, use the **no** form of this command.

bgp cluster-id *cluster-id*

Syntax Description

cluster-id Cluster ID of this router acting as a route reflector; maximum of 4 bytes. Cluster ID can be entered either as an IP address or value. Range is 1 to 4294967295.

Command Default

A cluster ID is not configured.

Command Modes

Router configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Together, a route reflector and its clients form a *cluster*. A cluster of clients usually has a single route reflector. In such instances, the cluster is identified by the software as the router ID of the route reflector. To increase redundancy and avoid a single point of failure in the network, a cluster might have more than one route reflector. If it does, all route reflectors in the cluster must be configured with the same 4-byte cluster ID so that a route reflector can recognize updates from route reflectors in the same cluster.

A single route reflector can also support multiple clusters. Each cluster is identified by a unique cluster-id. The cluster-id configured by the **bgp cluster-id** command is taken as the default. If **bgp cluster-id** is not configured, the router ID for the default VRF identifies the default cluster. A neighbor can be associated with one cluster only, and the corresponding cluster-id is configured in neighbor configuration mode. If the cluster-id is not configured for a neighbor and the neighbor is a route reflector client, then the neighbor is assigned to the default cluster.

Examples

The following example shows how to configure the local router as one of the route reflectors serving the cluster. Neighbor 192.168.70.24 is assigned to the default cluster with cluster-id 1.

```
Router(config)# router bgp 65534
Router(config-bgp)# bgp cluster-id 1
Router(config-bgp)# neighbor 192.168.70.24
Router(config-bgp-nbr)# remote-as 65534
Router(config-bgp-nbr)# address-family ipv4 unicast
Router(config-bgp-nbr-af)# route-reflector-client
```

bgp confederation identifier

To specify a Border Gateway Protocol (BGP) confederation identifier, use the **bgp confederation identifier** command in an appropriate configuration mode. To remove the confederation identifier, use the **no** form of this command.

bgp confederation identifier *as-number*

Syntax Description

as-number Autonomous system (AS) number that internally includes multiple autonomous systems.

- Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535.
- Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295.
- Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535.

Command Default

No confederation identifier is configured.

Command Modes

Router configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

One way to reduce the internal BGP (iBGP) mesh is to divide an autonomous system into multiple autonomous systems and group them into a single confederation. Each autonomous system is fully meshed within itself, and has a few connections to another autonomous system in the same confederation. Although the peers in different autonomous systems have external BGP (eBGP) sessions, they exchange routing information as if they are iBGP peers. Specifically, the confederation maintains the next hop and local preference information, and that allows you to retain a single Interior Gateway Protocol (IGP) for all autonomous systems. To the outside world, the confederation looks like a single autonomous system.

Use the **bgp confederation identifier** command to specify the autonomous system number for the confederation. This autonomous system number is used when BGP sessions are established with external peers in autonomous systems that are not part of the confederation.

Examples

The following example shows how to divide the autonomous system into autonomous systems 4001, 4002, 4003, 4004, 4005, 4006, and 4007 with the confederation identifier 5. Neighbor 10.2.3.4 is a router inside the confederation. Neighbor 172.20.16.6 is outside the routing domain confederation. To the outside world, there appears to be a single autonomous system with the number 5.

```
Router(config)# router bgp 4001
Router(config-bgp)# bgp confederation identifier 5
Router(config-bgp)# bgp confederation peers 4002
Router(config-bgp)# bgp confederation peers 4003
Router(config-bgp)# bgp confederation peers 4004
Router(config-bgp)# bgp confederation peers 4005
Router(config-bgp)# bgp confederation peers 4006
```

```
Router(config-bgp)# bgp confederation peers 4007  
Router(config-bgp)# neighbor 10.2.3.4  
Router(config-bgp-nbr)# remote-as 4002  
Router(config-bgp-nbr)# exit  
Router(config-bgp)# exit  
Router(config-bgp-nbr)# neighbor 172.20.16.6  
Router(config-bgp-nbr)# remote-as 4009
```

bgp confederation peers

To configure the autonomous systems that belong to the confederation, use the **bgp confederation peers** command in an appropriate configuration mode. To remove the autonomous system from the confederation, use the **no** form of this command.

bgp confederation peers [*as-number*]

Syntax Description

as-number Autonomous system (AS) numbers for Border Gateway Protocol (BGP) peers that belong to the confederation.

- Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535.
- Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295.
- Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535.

Command Default

No BGP peers are identified as belonging to the confederation.

Command Modes

Router configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

The autonomous systems specified in this command are visible internally to a confederation. Each autonomous system is fully meshed within itself. The [bgp confederation identifier, on page 58](#) command specifies the confederation to which the autonomous systems belong.

To specify multiple autonomous systems, enter BGP confederation peer configuration mode then enter one *autonomous-system-number* for each command line.

Examples

The following example shows that autonomous systems 1090 and 1093 belong to a single confederation:

```
Router(config)# router bgp 1090
Router(config-bgp)# bgp confederation peers 1093
```

The following example shows that autonomous systems 1095, 1096, 1097, and 1098 belong to a single confederation:

```
Router(config)# router bgp 1095
Router(config-bgp)# bgp confederation peers
Router(config-bgp-confed-peers)# 1096
Router(config-bgp-confed-peers)# 1097
Router(config-bgp-confed-peers)# 1098
```

bgp dampening

To enable Border Gateway Protocol (BGP) route dampening or change various BGP route dampening factors, use the **bgp dampening** command in an appropriate configuration mode. To disable route dampening and reset default values, use the **no** form of this command.

bgp dampening [*half-life* [*reuse* *suppress* *max-suppress-time*] | **route-policy** *route-policy-name*]

Syntax Description		
	<i>half-life</i>	(Optional) Time (in minutes) after which a penalty is decreased. Once the route has been assigned a penalty, the penalty is decreased by half after the half-life period (which is 15 minutes by default). Penalty reduction happens every 5 seconds. Range of the half-life period is from 1 to 45 minutes.
	<i>reuse</i>	(Optional) Value for route reuse if the flapping route penalty decreases and falls below the reuse value. When this happens, the route is unsuppressed. The process of unsuppressing routes occurs at 10-second increments. Range is 1 to 20000.
	<i>suppress</i>	(Optional) Maximum penalty value. Suppress a route when its penalty exceeds the value specified. When this happens, the route is suppressed. Range is 1 to 20000.
	<i>max-suppress-time</i>	(Optional) Maximum time (in minutes) a route can be suppressed. Range is 1 to 255. If the <i>half-life</i> value is allowed to default, the maximum suppress time defaults to 60 minutes.
	route-policy <i>route-policy-name</i>	(Optional) Specifies the route policy to use to set dampening parameters.

Command Default	Route dampening is disabled.
	<i>half-life</i> : 15 minutes
	<i>reuse</i> : 750
	<i>suppress</i> : 2000
	<i>max-suppress-time</i> : four times <i>half-life</i> value

Command Modes	IPv4 address family configuration
	IPv6 address family configuration
	VPNv4 address family configuration
	VRF IPv4 address family configuration
	VPNv6 address family configuration
	VRF IPv6 address family configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **bgp dampening** command without arguments to enable BGP route dampening with the default parameters. The parameters can be changed by setting them on the command line or specifying them with a routing policy.

Examples

The following example shows how to set the *half-life* value to 30 minutes, the *reuse* value to 1500, the *suppress* value to 10000, and the *max-suppress-time* to 120 minutes:

```
Router(config)# router bgp 50  
Router(config-bgp)# address-family ipv4 unicast  
Router(config-bgp-af)# bgp dampening 30 1500 10000 120
```

bgp default local-preference

To change the default local preference value, use the **bgp default local-preference** command in an appropriate configuration mode. To reset the local preference value to the default of 100, use the **no** form of this command.

bgp default local-preference *value*

Syntax Description

value Local preference value. Range is 0 to 4294967295. Higher values are preferable.

Command Default

Enabled with a value of 100.

Command Modes

Router configuration

VRF configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Generally, the default value of 100 allows you to easily define a particular path as less preferable than paths with no local preference attribute. The preference is sent to all networking devices in the local autonomous system.

Examples

The following example shows how to raise the default local preference value from the default of 100 to 200:

```
Router(config)# router bgp 200  
Router(config-bgp)# bgp default local-preference 200
```

bgp enforce-first-as disable

To disable the software from enforcing the first autonomous system path (known as the AS path) of a route received from an external Border Gateway Protocol (eBGP) peer to be the same as the configured remote autonomous system, use the **bgp enforce-first-as disable** command in an appropriate configuration mode. To re-enable enforcing the first AS path of a received route from an eBGP peer to be the same as the remote autonomous system, use the **no** form of this command.

bgp enforce-first-as disable

Command Default

By default, the software requires the first autonomous system (in the AS path) of a route received from an eBGP peer to be the same as the remote autonomous system configured.

Command Modes

Router configuration

VRF configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

By default, the software ignores any update received from an eBGP neighbor that does not have the autonomous system configured for that neighbor at the beginning of the AS path. When configured, the command applies to all eBGP peers of the router.

Examples

The following example shows a configuration in which incoming updates from eBGP neighbors are not checked to ensure the first AS number in the AS path is the same as the configured AS number for the neighbor:

```
Router(config)# router bgp 100
Router(config-bgp)# bgp enforce-first-as disable
```


bgp fast-external-fallover disable

To disable immediately resetting the Border Gateway Protocol (BGP) sessions of any directly adjacent external peers if the link used to reach them goes down, use the **bgp fast-external-fallover disable** command in an appropriate configuration mode. To disable this function and perform an immediate reset of BGP sessions when a link between peers is lost, use the **no** form of this command.

bgp fast-external-fallover disable
no bgp fast-external-fallover disable

Syntax Description	disable Disables BGP fast external failover.				
Command Default	BGP sessions of any directly adjacent external peers are immediately reset if the link used to reach them goes down.				
Command Modes	Router configuration				
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. By default, BGP sessions of any directly adjacent external peers are immediately reset, which allows the network to recover faster when links go down between BGP peers.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>bgp</td><td>read, write</td></tr> </table>	Task ID	Operations	bgp	read, write
Task ID	Operations				
bgp	read, write				
Examples	The following example shows how to disable the automatic resetting of BGP sessions: <pre>Router(config)# router bgp 109 Router(config-bgp)# bgp fast-external-fallover disable</pre>				

bgp graceful-restart

To enable graceful restart support, use the **bgp graceful-restart** command in an appropriate configuration mode. To disable this function, use the **no** form of this command.

bgp graceful-restart

Command Default	Graceful restart support is not enabled.

Command Modes	Router configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	Use the bgp graceful-restart command to enable graceful restart functionality on the router, and also to advertise graceful restart to neighboring routers.



Note The **bgp graceful-restart** command with no options must be used to enable graceful restart before using the **bgp graceful-restart purge-time** , **bgp graceful-restart restart-time** , **bgp graceful-restart stalepath-time** , or **bgp graceful-restart graceful-reset** commands.

When graceful restart is enabled, the BGP graceful restart capability is negotiated with neighbors in the BGP OPEN message when the session is established. If the neighbor also advertises support for graceful restart, then graceful restart is activated for that neighbor session. If the neighbor does not advertise support for graceful restart, then graceful restart is not activated for that neighbor session even though it is enabled locally.

If you enter the **bgp graceful-restart** command after some BGP sessions are established, you must restart those sessions before graceful restart takes effect. Use the **clear bgp** command to restart sessions.

Unconfiguring a neighbor (**no neighbor** command) or BGP (**no router bgp** command) may trigger a graceful restart (GR) on the neighboring router. If you do not want the BGP to perform a graceful restart, disable the BGP neighbor by configuring an [administrative shutdown](#) under the neighbor settings before unconfiguring the neighbor or BGP.

Examples

The following example shows how to enable graceful restart:

```
Router(config)#router bgp 3
Router(config-bgp)#bgp graceful-restart
```

bgp graceful-restart graceful-reset

To invoke a graceful restart when configuration changes force a peer reset, use the **bgp graceful-restart graceful-reset** command in an appropriate configuration mode. To disable this function, use the **no** form of this command.

bgp graceful-restart graceful-reset

Command Default

Graceful restart is not invoked when a configuration change forces a peer reset.

Command Modes

Router configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

BGP graceful restart must be enabled using the **bgp graceful-restart** command before enabling graceful reset using the **bgp graceful-restart graceful-reset** command.

Examples

The following example shows how to enable graceful reset:

```
Router(config)#router bgp 3
Router(config-bgp)# bgp graceful-restart graceful-reset
```

bgp graceful-restart purge-time

To specify the maximum time before stale routes are purged from the routing information base (RIB) when the local BGP process restarts, use the **bgp graceful-restart purge-time** command in an appropriate configuration mode. To set the purge timer time to its default value, use the **no** form of this command.

bgp graceful-restart purge-time *seconds*

Syntax Description

seconds Maximum time before stale routes are purged. Time in seconds. Range is 0 to 6000.

Command Default

seconds : 600

Command Modes

Router configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

BGP graceful restart must be enabled using the **bgp graceful-restart** command before setting the purge time using the **bgp graceful-restart purge-time** command.

Examples

The following example shows how to change the BGP purge time to 800 seconds:

```
Router(config)# router bgp 3
Router(config-bgp)# bgp graceful-restart purge-time 800
```

bgp graceful-restart restart-time

To specify a user-predicted local BGP process maximum restart time, which is advertised to neighbors during session establishment, use the **bgp graceful-restart restart-time** command in an appropriate configuration mode. To set this restart time to its default value, use the **no** form of this command.

bgp graceful-restart restart-time *seconds*

Syntax Description	<i>seconds</i> Maximum time advertised to neighbors. Time in seconds. Range is 1 to 4095.				
Command Default	<i>seconds</i> : 120				
Command Modes	Router configuration				
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 7.0.12</td><td>This command was introduced.</td></tr></table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
Usage Guidelines	BGP graceful restart must be enabled using the bgp graceful-restart command before setting the restart timer using the bgp graceful-restart restart-time command.				
Examples	The following example shows how to change the BGP graceful restart time to 400 seconds:				

```
Router(config)#router bgp 3  
Router(config-bgp)# bgp graceful-restart restart-time 400
```

bgp graceful-restart stalepath-time

To specify the maximum time to wait for an End-of-RIB message after a neighbor restarts, use the **bgp graceful-restart stalepath-time** command in an appropriate configuration mode. To set the stalepath timer time to its default value, use the **no** form of this command.

bgp graceful-restart stalepath-time *seconds*

Syntax Description	<i>seconds</i> Maximum wait time. Time in seconds. Range is 1 to 4095.	
Command Default	<i>seconds</i> : 360	
Command Modes	Router configuration	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.
Usage Guidelines	BGP graceful restart must be enabled using the bgp graceful-restart command before setting the stalepath time using the bgp graceful-restart stalepath-time command. If the stalepath time is exceeded before an End-of-RIB message is received from a neighbor, paths learned from the neighbor are purged from the BGP routing table.	
Examples	The following example shows how to change the stalepath time to 750 seconds: <pre>Router(config)# router bgp 3 Router(config-bgp)# bgp graceful-restart stalepath-time 750</pre>	

bgp import-delay

To enable delay for Border Gateway Protocol (BGP) batch import processing, use the **bgp import-delay** command in an appropriate configuration mode. To disable delay in batch import processing, use the no form of this command.

bgp import-delay *seconds milliseconds*

Syntax Description	<i>seconds</i>	Specifies batch import processing delay in seconds. Range is 0 to 10 seconds.
	<i>milliseconds</i>	Specifies batch import processing delay in milliseconds. Range is 0 to 999 seconds.
Command Default	No delay is configured.	
Command Modes	Address-family VPNv4 Unicast	
	Address-family VPNv6 Unicast	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.

This example shows how to set delay in batch import processing as two seconds and zero milliseconds:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#address-family vpnv4 unicast
Router(config-bgp-af)#bgp import-delay 2 0
```

bgp label-delay

To enable delay for Border Gateway Protocol (BGP) batch label processing, use the **bgp label-delay** command in an appropriate configuration mode. To disable delay in batch import processing, use the no form of this command.

bgp label-delay *seconds milliseconds*

Syntax Description	<i>seconds</i>	Specifies batch label processing delay in seconds. Range is 0 to 10 seconds.
	<i>milliseconds</i>	Specifies batch label processing delay in milliseconds. Range is 0 to 999 seconds.
Command Default	No delay is configured.	
Command Modes	Address-family IPv4 Unicast	
	Address-family IPv6 Unicast	
	Address-family IPv4 Multicast	
	Address-family IPv6 Multicast	
	Address-family VPNv4 Unicast	
	Address-family VPNv6 Unicast	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.

This example shows how to set delay in batch import processing as two seconds and zero milliseconds:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#address-family ipv4 unicast
Router(config-bgp-af)#bgp label-delay 2 0
```


bgp log neighbor changes disable

To disable logging of Border Gateway Protocol (BGP) neighbor resets, use the **bgp log neighbor changes disable** command in an appropriate configuration mode. To re-enable logging of BGP neighbor resets, use the **no** form of this command.

bgp log neighbor changes disable

Command Default

BGP neighbor changes are logged.

Command Modes

Router configuration

VRF configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Logging of BGP neighbor status changes (up or down) and resets is used for troubleshooting network connectivity problems and measuring network stability. Unexpected neighbor resets might indicate high error rates or high packet loss in the network, and should be investigated.

Status change message logging does not substantially affect performance, unlike, for example, enabling per-BGP update debugging. If the UNIX syslog facility is enabled, messages are sent by the software to the UNIX host running the syslog daemon so that the messages can be stored and archived on disk. If the UNIX syslog facility is not enabled, the status change messages are kept in the internal buffer of the router, and are not stored to disk.

The neighbor status change messages are not tracked if the **bgp log neighbor changes disable** command is disabled, except for the last reset reason, which is always available as output of the **show bgp neighbors** command.

Up and down messages for BGP neighbors are logged by the software by default. Use the **bgp log neighbor changes disable** command to stop logging BGP neighbor changes.

Examples

The following example shows how to prevent the logging of neighbor changes for BGP:

```
Router(config)# router bgp 65530
Router(config-bgp)# bgp log neighbor changes disable
```

bgp lpts-secure-binding

To enable Local Packet Transport Services (LPTS) secure binding, use the **bgp lpts-secure-binding** command in BGP configuration mode. To disable the LPTS secure binding, use the **no** form of this command.

bgp lpts-secure-binding

Syntax Description	This command has no arguments or keywords.

Command Default	LPTS secure binding is not enabled.

Command Modes	Router BGP Configuration

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

Usage Guidelines	None.

Example

This example shows how to configure LPTS secure binding:

```
Router# router bgp 100
Router(config-bgp)# bgp lpts-secure-binding
```

bgp maximum neighbor

To control the maximum number of neighbors that can be configured on the router, use the **bgp maximum neighbor** command in an appropriate configuration mode. To set the neighbor limit to the default value, use the **no** form of this command.

bgp maximum neighbor limit

Syntax Description	<i>limit</i> Maximum number of neighbors. Range is 1 to 15000.

Command Default	Default limit is 4000

Command Modes	Router configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	Any attempt to configure the neighbor limit below 1 or above 15000 fails. Similarly, attempting to configure the limit below the number of neighbors currently configured fails. For example, if there are 3250 neighbors configured, you cannot set the <i>limit</i> below 3250.

Examples	The following example shows how to change the default maximum neighbor limit and set it to 1200:

```
Router(config)#router bgp 65530
Router(config-bgp)# bgp maximum neighbor 1200
```

bgp multipath as-path

To ignore as-path onwards while computing multipath, use the **bgp multipath as-path** command in Global Configuration mode and XR Config mode.

bgp multipath as-path ignore onwards

Syntax Description	ignore	Ignores as-path related check for multipath selection.
	onwards	Ignores everything as-path onwards for multipath selection.
Command Modes	Global Configuration mode and XR Config mode	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.
Usage Guidelines	When multiple connected routers start ignoring as-path onwards while computing multipath, it causes routing loops. Therefore, you should not configure the bgp multipath as-path ignore onwards command on routers that can form a loop.	
Examples	This example shows how to ignore as-path while computing multipath.	

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# bgp multipath as-path ignore onwards
```

bgp nexthop resolution allow-default

By default, the next hop resolution in BGP does not take the default route into account. By configuring this command, the default route is used for resolving the next-hop of BGP routes. The next hop resolution is important in deciding if the next hop for a BGP route is accessible or not.

If the BGP route has an inaccessible next hop, the route does not have a best path and will not be advertised.



Warning

Applying or removing this command will reset all BGP neighbors. Starting from Release 25.3.1, the command does not reset BGP neighbor sessions.

bgp nexthop resolution allow-default

Syntax Description

allow-default Enable nexthops resolution using default route.

Command Default

This applies to IPv4 and IPv6. The default route is 0.0.0.0/0 for IPv4 and ::/0 for IPv6.

Command Modes

XR Config mode

Command History

Release	Modification
Release 6.2	This command was introduced.

Task ID

Task ID	Operation
bgp	read, write

The following example shows how to configure BGP with `nexthop resolution allow-default` :

```
RP/0/0/CPU0:R1(config)#router bgp 65000
RP/0/0/CPU0:R1(config-bgp)#nexthop resolution allow-default
```

"NEXTHOP configuration changed" is seen as the last reset reason with the `show bgp neighbor` command when the `nexthop resolution allow-default` command is applied or removed:

```
RP/0/0/CPU0:R1#show bgp neighbor 10.0.0.2
...
Last reset 00:01:59, due to NEXTHOP configuration changed

RP/0/0/CPU0:R1#show bgp neighbor 2001:db8:1::2
...
Last reset 00:02:47, due to NEXTHOP configuration changed
```

bgp redistribute-internal

To allow the redistribution of internal Border Gateway Protocol (iBGP) routes into an Interior Gateway Protocol (IGP), such as Intermediate System-to-Intermediate System (IS-IS) or Open Shortest Path First (OSPF), use the **bgp redistribute-internal** command in an appropriate configuration mode. To disable the redistribution of iBGP routes into IGPs, use the **no** form of this command.

bgp redistribute-internal

Command Default By default, iBGP routes are not redistributed into IGPs.

Command Modes Router configuration
VRF configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines Use of the **bgp redistribute-internal** command requires the **clear route *** command to be issued to reinstall all BGP routes into the IP routing table.



Note Redistributing iBGP routes into IGPs may cause routing loops to form within an autonomous system. Use this command with caution.

Examples

The following example shows how to redistribute iBGP routes into OSPF:

```
Router(config)#router bgp 1
Router(config-bgp)# bgp redistribute-internal
Router(config-bgp)# exit
Router(config)# router ospf area1
Router(config-router)# redistribute bgp 1
Router(config-router)# end
Router# clear route *
```

bgp router-id

To configure a fixed router ID for a Border Gateway Protocol (BGP)-speaking router, use the **bgp router-id** command in an appropriate configuration mode. To disable a fixed router ID, use the **no** form of this command.

bgp router-id *ip-address*

Syntax Description	<i>ip-address</i> IP Version 4 (IPv4) address to use as the router ID. Normally, this should be an IPv4 address assigned to the router.				
Command Default	If no router ID is configured in BGP, BGP attempts to use the global router ID if one is configured and available. Otherwise, BGP uses the highest IP address configured on a loopback interface.				
Command Modes	Router configuration VRF configuration				
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 7.0.12</td><td>This command was introduced.</td></tr></table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
Usage Guidelines	If you do not use the bgp router-id command to configure a router ID, an IP address is not configured on any loopback interface, and no global router ID is configured, BGP neighbors remain down. For more details on router IDs, see the <i>BGP Configuration Guide for Cisco 8000 Series Routers</i>				
Examples	The following example shows how to configure the local router with the router ID of 192.168.70.24: <pre>Router(config)# router bgp 100 Router(config-bgp)#bgp router-id 192.168.70.24</pre>				

bgp scan-time

To configure scanning intervals of Border Gateway Protocol (BGP)-speaking networking devices, use the **bgp scan-time** command in an appropriate configuration mode. To restore the scanning interval to its default value, use the **no** form of this command.

bgp scan-time *seconds*

Syntax Description	<i>seconds</i> Scanning interval (in seconds) of BGP routing information. Range is 5 to 3600 seconds.

Command Default	The default scanning interval is 60 seconds.

Command Modes	Router configuration IPv4 address family configuration IPv6 address family configuration VPNv4 address family configuration VPNv6 address family configuration

Command History	<table border="1"> <tr> <th>Release</th> <th>Modification</th> </tr> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

Usage Guidelines	Use the bgp scan-time command to change how frequently the software processes scanner tasks, such as conditional advertisement, dynamic MED changes, and periodic maintenance tasks.

Examples	The following example shows how to set the scanning interval for IPv4 unicast to 20 seconds:

```
Router(config)# router bgp 64500
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp-af)# bgp scan-time 20
```

This example shows how to set the scanning interval to 20 seconds:

```
Router(config)# router bgp 64500
Router(config-bgp-af)# bgp scan-time 20
```


bgp unsafe-ebgp-policy

To pass all routes on the eBGP neighbors, use the **bgp unsafe-ebgp-policy** command in router configuration mode.

bgp unsafe-ebgp-policy

Syntax Description	This command has no keywords or arguments.

Command Default	None

Command Modes	Router configuration

Command History	Release	Modification
	Release 7.5.1	This command was introduced.

Usage Guidelines	Configuring the bgp unsafe-ebgp-policy command enables passing all routes on the eBGP neighbors without the need to configure route policies.

Task ID	Task ID	Operations
	bgp	read, write

Examples

The following example shows how to enable the unsafe ebgp policy:

```
Router# configure
Router(config)# router bgp 65000
Router(config-bgp)# bgp unsafe-ebgp-policy
```

bgp update-delay

To set the maximum initial delay for a Border Gateway Protocol (BGP)-speaking router to send the first updates, use the **bgp update-delay** command in an appropriate configuration mode. To restore the initial delay to its default value, use the **no** form of this command.

bgp update-delay *seconds* [**always**]

Syntax Description

seconds Delay in seconds for the router to send the first updates. Range is 0 to 3600.

always (Optional) Specifies that the router always wait for the update delay time, even if all neighbors have finished sending their initial updates sooner.

Command Default

120 seconds

Command Modes

Router configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

When BGP is started, it waits a specified period of time for its neighbors to establish peering sessions and to complete sending their initial updates. After all neighbors complete their initial updates, or after the update delay timer expires, the best path is calculated for each route, and the software starts sending advertisements out to its peers. This behavior improves convergence time. If the software were to advertise a route as soon as it learned it, it would have to readvertise the route each time it learned a new path that was preferred over all previously learned paths.

Use the **bgp update-delay** command to tune the maximum time the software waits after the first neighbor is established until it starts calculating best paths and sending out advertisements.

Examples

The following example shows how to set the maximum initial delay to 240 seconds:

```
Router(config)#router bgp 64530
Router(config-bgp)# bgp update-delay 240
```

bgp write-limit

To modify the upper bounds on update message queue lengths or to enable desynchronization, use the **bgp write-limit** command in an appropriate configuration mode. To return the bounds to their default values and to disable desynchronization, use the **no** form of this command.

bgp write-limit *group-limit* *global-limit* [**desynchronize**]

Syntax Description	<i>group-limit</i>	Per-update group limit on the number of update messages the software queues. Range is 500 to 100000000. Group limit cannot be greater than the global limit.
	<i>global-limit</i>	Global limit on the number of update messages the software queues. Range is 500 to 100000000.
	desynchronize	(Optional) Enables desynchronization.

Command Default

group-limit : 50,000
global-limit : 250,000
 Desynchronization is off.

Command Modes Router configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **bgp write-limit** command to configure both a per-update group and a global limit on the number of messages the software queues when updating peers. Increasing these limits can result in faster Border Gateway Protocol (BGP) convergence, but also may result in higher memory use during convergence. In addition, this command can be used to enable desynchronization. Desynchronization can decrease memory use and speed up convergence for the fastest neighbors if one or more neighbors in an update group process updates significantly slower than other neighbors in the same group. However, enabling desynchronization can cause a significant degradation in overall convergence time, especially if the router is experiencing high CPU utilization. For this reason, enabling desynchronization is discouraged.

Examples

The following example shows how to configure BGP to operate with a per-update group limit of 9000 messages and a global limit of 27,000 messages:

```
Router(config)# router bgp 65000
Router(config-bgp)#bgp write-limit 9000 27000
```

bmp-activate

To enable Border Gateway Protocol (BGP) Monitoring Protocol (BMP) logging for a neighbor, use the **bmp-activate server** command in neighbor configuration mode. To disable BMP logging for a neighbor, use the **no** form of this command.

bmp-activate server *server-id*

Syntax Description

server *server-id* Enables monitoring by the BMP server specified by the *server-id* variable. You can configure multiple **bmp-activate** commands under same neighbor with different server IDs to enable monitoring by multiple BMP servers.

Command Default

No default behavior or values

Command Modes

Neighbor configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Examples

The following example shows how to activate BMP on a neighbor with IP address 1.1.1.1, which is monitored by BMP server with server ID as 4:

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# neighbor 1.1.1.1
Router(config-bgp-nbr)# bmp-activate server 4
```

bmp server

To configure Border Gateway Protocol (BGP) Monitoring Protocol (BMP) server and to enter BMP server configuration mode, use the **bmp server** command in Global Configuration mode and XR Config mode. To remove a particular BMP server configuration, use **no** form of this command.

bmp server { *server-id* | **all** }

Syntax Description		
	<i>server-id</i>	Specifies BMP server ID. Server ID range is 1 to 8.
	all	Specifies all BMP servers.
	description <i>LINE</i>	Specifies BMP server description. Description can be up to 250 alphanumeric characters.
	dscp	Sets IP DiffServ CodePoint (DSCP). The DSCP value can be a number from 0 to 63, or it can be one of the following keywords: default, ef, af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, cs1, cs2, cs3, cs4, cs5, cs6, or cs7.
	host <i>host-name</i>	Specifies the hostname of BMP server. The hostname of the BMP server can be specified in IP address format (standard dot-decimal notation for IPv4 or colon-hexadecimal notation for IPv6) format or the string name which can be resolved into an IP address by the router.
	initial-delay <i>delay-time</i>	Sets the delay, in seconds, before initial connect request is sent to a BMP server. The delay that you can set ranges from 1 to 3600 seconds. The default is 7 seconds.
	initial-refresh { delay skip }	Delay to initiate route refresh requests to BMP enabled neighbors. Configures the initial refresh options to handle refresh requests sent by the router to its BMP-enabled neighbors. Sets the delay, in seconds, before an initial refresh request is sent by the router to its BMP-enabled neighbors. The delay range is 1 to 3600 seconds with a default of 1 second. The default is not to skip refresh requests. Configures the router to skip sending any refresh requests to its BMP-enabled neighbors.

precedence	Sets the precedence values in the IP header. The precedence value can be a number from 0 to 7, or it can be one of the following keywords: critical —Set packets with critical precedence (5) flash — Set packets with flash precedence (3) flash-override —Set packets with flash override precedence (4) immediate —Set packets with immediate precedence (2) internet —Set packets with internetwork control precedence (6) network —Set packets with network control precedence (7) priority —Set packets with priority precedence (1) routine —Set packets with routine precedence (0) The default is internet (6) .
shutdown	Shuts down the TCP connection to BMP server.
stats-reporting-period	Specifies statistics reporting period, in seconds, to BMP servers. The reporting period that you can set ranges from 1 to 3600 seconds. The default is 0.
update-source <i>type</i> <i>interface-path-id</i>	Specifies the source (physical or virtual interface) to reach the BMP server. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
vrf <i>vrf-name</i>	Specifies VPN routing and forwarding (VRF) instance.

Command Default For default values refer Syntax Description table.

Command Modes Global Configuration mode and XR Config mode.

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Examples

This example shows how to configure initial refresh delay of 30 seconds for BGP neighbors on BMP server with server ID as 4:

```
Router# configure
Router(config)# bmp server 4 initial-refresh delay 30
```

This example shows how to configure hostname of BMP server as 192.168.10.1:

```
Router# configure
Router(config)# bmp server 8 host 192.168.10.1 port 56
```

This example shows how to configure at location 0/0/0/1 as source interface to reach BMP server:

```
Router# configure  
Router(config)# bmp server 5 update-source HundredGigE 0/0/0/1  
tenGigE 0/0/0/1
```

bmp advertisement-interval

To set the minimum interval between the sending of BMP routing updates, use the **advertisement-interval** command in router configuration mode.

Use the **no** form of this command to remove the **advertisement-interval** command from the configuration file and restore the system to its default interval values.

advertisement-interval *seconds*

Syntax Description

seconds Minimum interval between sending BMP routing updates (in seconds).

The range of the advertisement-interval of the route-monitoring inbound post-policy and the Local-RIB is from 2 seconds to 600 seconds.

The default value is 15 seconds.

Command Default

None

Command Modes

Router configuration

Command History

Release	Modification
Release 7.5.4	This command was introduced.

Usage Guidelines

- To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
- You can configure **advertisement-interval** command for the following sub-modes to configure the interval between BMP route-monitoring updates:
 - route-monitoring inbound post-policy**
 - route-monitoring local-rib**

Task ID

Task ID	Operations
bgp	read, write

The following example configures an **advertisement-interval** for 15 seconds. This is to configure the interval between BMP route-monitoring updates for Inbound Post-Policy and Local-RIB:

```
Router#config
Router(config)#bmp server all
Router(config-bgp-bmp)#route-monitoring inbound post-policy
Router(config-bgp-bmp-rmon)#advertisement-interval 15
Router(config-bgp-bmp-rmon)#commit
```



```
Router#config  
Router(config)#bmp server all  
Router(config-bgp-bmp)#route-monitoring local-rib  
Router(config-bgp-bmp-rmon)#advertisement-interval 15  
Router(config-bgp-bmp-rmon)#commit
```

bmp scan-time

To configure scanning intervals of BMP-speaking networking devices, use the **scan-time** command in router configuration mode.

Use the **no** form of this command to restore the scanning interval to its default value.

scan-time *seconds*

Syntax Description

seconds Scanning interval (in seconds) of BMP routing information.

The range of the scan time of route-monitoring inbound post-policy is from 5 seconds to 3600 seconds.

The default value is 60 seconds.

Command Default

None

Command Modes

Router configuration

Command History

Release	Modification
Release 7.5.4	This command was introduced.

Usage Guidelines

- To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
bgp	read, write

The following example displays the **scan-time** configuration for 60 seconds.

```
Router##config
Router#(config)#bmp server all
Router#(config-bgp-bmp)#route-monitoring inbound post-policy
Router#(config-bgp-bmp-rmon)#scan-time 60
Router#(config-bgp-bmp-rmon)#commit
```

capability additional-paths receive

To advertise capability of receiving additional paths to the peer, use the **capability additional-paths receive** command in neighbor or neighbor-group or session-group configuration mode. To disable the capability of receiving additional paths, use the **no** form of this command.

capability additional-paths receive [**disable**]

Syntax Description	disable Disables advertising capability of receiving additional paths.				
Command Default	Capability is disabled.				
Command Modes	Neighbor configuration Neighbor group configuration Session group configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.0.12</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
Usage Guidelines	Use the capability additional-paths receive command to selectively enable or disable additional paths receive capability negotiation for a particular neighbor or neighbor-group or session-group. Configuring additional-paths receive command in global address-family mode is a pre-requisite for negotiating additional paths receive capability with the peer. If you enter the capability additional-paths receive command after some BGP sessions are established, you must restart those sessions for the new configuration to take effect. Use the clear bgp command to restart sessions.				

The following example shows how to advertise capability of receiving additional paths:

```
Router(config)#router bgp 100
Router(config-bgp)#neighbor 10.2.3.4
Router(config-bgp-nbr)#capability additional-paths receive
```

capability additional-paths send

To advertise capability of sending additional paths to the peer, use the **capability additional-paths send** command in neighbor or neighbor-group or session-group configuration mode. To disable the capability of sending additional paths, use the **no** form of this command.

capability additional paths send [**disable**]

Syntax Description

disable Disables advertise additional paths send capability

Command Default

Capability is disabled.

Command Modes

Neighbor configuration

Neighbor group configuration

Session group configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **capability additional paths send** command to selectively enable or disable additional paths send capability negotiation for a particular neighbor or neighbor-group or session-group. Configuring the **additional-paths send** command in global address-family mode is a pre-requisite for negotiating additional paths send capability with the peer.

You must restart the BGP sessions for the new configuration to take effect. Use the **clear bgp** command to restart sessions.

The following example shows how to advertise capability of sending additional paths to the peer:

```
Router(config)# router bgp 100
Router(config-bgp)# neighbor 10.2.3.4
Router(config-bgp-nbr)# capability additional-paths send
```

capability orf prefix

To advertise prefix list-based Outbound Route Filter (ORF) capability to the Border Gateway Protocol (BGP) peer, use the **capability orf prefix** command in an appropriate configuration mode. To remove the **capability orf prefix** command from the configuration file and restore the system to its default condition in which the software does not advertise the capability, use the **no** form of this command.

capability orf prefix { **receive** | **send** | **both** | **none** }

Syntax Description	receive	Sets the capability to receive the ORF from a specified neighbor.
	send	Sets the capability to send the ORF to a specified neighbor.
	both	Sets the capability to receive and send the ORF from or to a specified neighbor.
	none	Sets the capability to no for ORF receive or send from or to a specified neighbor.

Command Default The routing device does not receive or send route prefix filter lists.

Command Modes

- IPv4 address family group configuration
- IPv6 address family group configuration
- IPv4 neighbor address family configuration
- VRF neighbor IPv4 address family configuration
- IPv4 neighbor group address family configuration
- IPv6 neighbor group address family configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines

The advertisement of the prefix list ORF capability by a BGP speaker indicates whether the speaker can send prefix lists to the specified neighbor and whether it accepts prefix lists from the neighbor. The speaker sends a prefix list if it indicated the ability to send them, and if the neighbor indicated it was willing to accept them. Similarly, the neighbor sends a prefix list to the speaker if it indicated the ability to send them and the speaker indicated the willingness to accept them.



Note The capability orf and prefix list filter specified by orf route-policy must be explicitly configured.

If the neighbor sends a prefix list and the speaker accepts it, the speaker applies the received prefix list, plus any locally configured outbound filters, to limit its outbound routing updates to the neighbor. Increased filtering prevents unwanted routing updates between neighbors and reduces resource requirements for routing update generation and processing.

Use the **capability orf prefix** command to set whether to advertise send and receive capabilities to the specified neighbor.



Note Sending a receive capability can adversely affect performance, because updates sent to that neighbor cannot be replicated for any other neighbors.

If this command is configured for a neighbor group or neighbor address family group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.

Examples

The following example shows how to configure the **capability orf prefix** command:

```
Router# configure
Router(config)# route-policy orfqq
Router(config-rpl)# if orf prefix in (10.0.0.0/8 ge 20) then
Router(config-rpl)# pass
Router(config-rpl)# endif
Router(config-rpl)# if orf prefix in (1910::16 ge 120) then
Router(config-rpl)# pass
Router(config-rpl)# endif
Router(config-rpl)# end-policy
Router(config)# router bgp 65530
Router(config-bgp)# neighbor 10.0.101.1
Router(config-bgp-nbr)# remote-as 65534
Router(config-bgp-nbr)# address-family ipv4 unicast
Router(config-bgp-nbr-af)# route-policy pass-all out
Router(config-bgp-nbr-af)# capability orf prefix both
Router(config-bgp-nbr-af)# orf route-policy orfqq
```

capability suppress 4-byte-as

To suppress 4-byte AS capability from being advertised to the BGP peer, use the **capability suppress 4-byte-as** command in the appropriate configuration mode. To remove the **capability suppress 4-byte-as** command from the configuration and restore the system to the default condition, in which the software advertises the capability, use the **no** form of this command.

capability suppress 4-byte-as [inheritance-disable]

Syntax Description	inheritance-disable Prevents capability suppress 4-type-as being inherited from the parent.				
Command Default	4-byte-as capability is advertised to the BGP peer.				
Command Modes	Neighbor configuration Neighbor group configuration Session group configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.0.12</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
Usage Guidelines	By default, the software advertises the 4-byte AS capability to BGP peers. To override this default behavior, use the capability suppress 4-byte-as command under the command modes listed in the "Command Modes" section. If configured under the neighbor group or session group, all neighbors using the group inherit the configuration. Use the no option to remove the command.				



Caution The BGP session resets automatically, if the 4-byte AS capability of an existing BGP session is changed by configuring **capability suppress 4-byte-as** or **capability suppress 4-byte-as inheritance-disable**.

Examples

The following example shows how to configure the **capability suppress 4-byte-as** command:

```
Router# show bgp nei 10.3.3.3 conf
neighbor 10.3.3.3
  remote-as 65000 [n:internal]
  description PE3 []
  update-source Loopback0 [n:internal]
  address-family ipv4 unicast [n:internal]

Router#show bgp nei 10.3.3.3
BGP neighbor is 10.3.3.3
  Remote AS 65000, local AS 65000, internal link
  Description: PE3
  Remote router ID 10.3.3.3
  BGP state = Established, up for 1w0d
  Last read 00:00:17, hold time is 180, keepalive interval is 60 seconds
  Precedence: internet
  Neighbor capabilities:
```

```

    Route refresh: advertised and received
    4-byte AS: advertised and received
    Address family IPv4 Unicast: advertised and received
    Received 25962 messages, 0 notifications, 0 in queue
    Sent 25968 messages, 1 notifications, 0 in queue
    Minimum time between advertisement runs is 0 seconds

For Address Family: IPv4 Unicast
BGP neighbor version 1
Update group: 0.3
Route refresh request: received 0, sent 0
0 accepted prefixes, 0 are bestpaths
Prefix advertised 0, suppressed 0, withdrawn 0, maximum limit 524288
Threshold for warning message 75%
An EoR was received during read-only mode

Connections established 2; dropped 1
Last reset 1w0d, due to BGP Notification sent: hold time expired
Time since last notification sent to neighbor: 1w0d
Error Code: hold time expired
Notification data sent: None

Router(config)#router bgp 65000
Router(config-bgp)#neighbor 10.3.3.3
Router(config-bgp-nbr)#capability suppress 4-byte-as
Router(config-bgp-nbr)#commit
Router(config-bgp-nbr)#end

Router# show bgp nei 10.3.3.3

BGP neighbor is 10.3.3.3
Remote AS 65000, local AS 65000, internal link
Description: PE3
Remote router ID 10.3.3.3
BGP state = Established, up for 00:00:16
Last read 00:00:11, hold time is 180, keepalive interval is 60 seconds
Precedence: internet
Neighbor capabilities:
  Route refresh: advertised and received
  Address family IPv4 Unicast: advertised and received
  Capability 4-byte-as suppress is configured
  Received 25966 messages, 0 notifications, 0 in queue
  Sent 25972 messages, 1 notifications, 0 in queue
  Minimum time between advertisement runs is 0 seconds

For Address Family: IPv4 Unicast
BGP neighbor version 1
Update group: 0.2
Route refresh request: received 0, sent 0
0 accepted prefixes, 0 are bestpaths
Prefix advertised 0, suppressed 0, withdrawn 0, maximum limit 524288
Threshold for warning message 75%
An EoR was received during read-only mode

Connections established 3; dropped 2
Last reset 00:00:43, due to Capabilty 4-byte-as configuration changed
Time since last notification sent to neighbor: 1w0d
Error Code: hold time expired
Notification data sent: None

```

With the **inheritance-disable** keyword:


```
Router(config-bgp)# neighbor 10.0.101.1
Router(config-bgp-nbr)# capability suppress 4-byte-as inheritance-disable

Router# show bgp neighbor 10.0.101.1 config
neighbor 10.0.101.1
  remote-as 1 []
  address-family ipv4 unicast []

Router# show bgp neighbor 10.0.101.1
BGP neighbor is 10.0.101.1
Remote AS 1, local AS 100, external link
Remote router ID 0.0.0.0
  BGP state = Idle
  Last read 00:00:00, hold time is 180, keepalive interval is 60 seconds
  Precedence: internet
  Received 0 messages, 0 notifications, 0 in queue
  Sent 0 messages, 0 notifications, 0 in queue
  Minimum time between advertisement runs is 30 seconds
```

clear bgp

To reset a group of Border Gateway Protocol (BGP) neighbors, use the **clear bgp** command in XR EXEC mode.

```
clear bgp [ ipv4 { unicast | multicast | labeled-unicast | all | tunnel | mdt } | ipv6 { unicast
| multicast | all | labeled-unicast } | all { unicast | multicast | all | labeled-unicast | mdt | tunnel }
| vpnv4 unicast | vrf { vrf-name | all } { ipv4 { unicast | labeled-unicast } | ipv6 unicast }
| vpnv6 unicast ]
```

Syntax Description

ipv4	(Optional) Specifies IP Version 4 address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.
tunnel	(Optional) Specifies tunnel address prefixes.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
all	(Optional) For address family, specifies prefixes for all address families.
vpn4 unicast	(Optional) Specifies VPNv4 unicast address families.
vrf	(Optional) Specifies VPN routing and forwarding (VRF).
<i>vrf-name</i>	Name of a VRF.
all	(Optional) For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast and labeled-unicast address families.
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address prefixes.

Command Default

No default behavior or values

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **clear bgp** command to reset the sessions of the specified group of neighbors (hard reset); it removes the TCP connection to the neighbor, removes all routes received from the neighbor from the BGP table, and then re-establishes the session with the neighbor.

If the **graceful** keyword is specified, the routes from the neighbor are not removed from the BGP table immediately, but are marked as stale. After the session is re-established, any stale route that has not been received again from the neighbor is removed.

Examples

The following example shows how to hard reset neighbor 10.0.0.1:

```
Router# clear bgp 10.0.0.1
```

clear bgp external

To clear all Border Gateway Protocol (BGP) external peers, use the **clear bgp external** command in XR EXEC mode.

clear bgp external

Syntax Description		
	ipv4	(Optional) Specifies IP Version 4 address prefixes.
	unicast	(Optional) Specifies unicast address prefixes.
	multicast	(Optional) Specifies multicast address prefixes.
	labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
	all	(Optional) For subaddress families, specifies prefixes for all subaddress families.
	ipv6	(Optional) Specifies IP Version 6 address prefixes.
	all	(Optional) For address family, specifies prefixes for all address families.
	vpn4 unicast	(Optional) Specifies VPNv4 unicast address families.
	vrf	(Optional) Specifies VPN routing and forwarding (VRF).
	<i>vrf-name</i>	(Optional) Name of a VRF.
	all	(Optional) For VRF, specifies all VRFs.
	ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
	ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.
	vpn6 unicast	(Optional) Specifies VPNv6 unicast address families.
	graceful	(Optional) Clears all external peers with a hard reset and a graceful restart. This option is available when an address family is not specified.

Command Default No default behavior or value

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Examples

The following example shows how to clear all BGP external peers:

```
Router# clear bgp external
```

clear bgp nexthop registration

To reregister a specified next hop with the Routing Information Base (RIB), use the **clear bgp nexthop registration** command in EXEC mode and XR EXEC mode.

clear bgp nexthop registration nexthop-address *nexthop-address*

Syntax Description		
	ipv4	Specifies IP Version 4 address prefixes.
	unicast	Specifies unicast address prefixes.
	multicast	Specifies multicast address prefixes.
	labeled-unicast	Specifies labeled-unicast address prefixes.
	all	For subaddress families, specifies prefixes for all subaddress families.
	tunnel	Specifies tunnel address prefixes.
	mdt	Specifies IPv4 multicast distribution tree (MDT) address prefixes.
	ipv6	Specifies IP Version 6 address prefixes.
	all	For address family, specifies prefixes for all address families.
	vpn4 unicast	Specifies VPNv4 unicast address families.
	vrf	Specifies VPN routing and forwarding (VRF).
	<i>vrf-name</i>	Name of a VRF.
	all	For VRF, specifies all VRFs.
	ipv4 { unicast labeled-unicast }	For VRF, specifies IPv4 unicast or labeled-unicast address families.
	ipv6 unicast	For VRF, specifies IPv6 unicast address families.
	vpn6 unicast	Specifies VPNv6 unicast address families.
	<i>nexthop-address</i>	Address of the next hop.
Command Default	No default behavior or values	
Command Modes	EXEC mode and XR EXEC mode	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **clear bgp nexthop registration** command to perform an asynchronous registration of the next hop with the RIB. The **show bgp nexthops** command output shows a critical notification as the LastRIBEvent for the next hop when the **clear bgp nexthop registration** command is used.

Examples

The following example shows how to reregister the next hop with the RIB:

```
Router# clear bgp nexthop registration 10.1.1.1
```

clear bgp peer-drops

To clear the connection-dropped counter, use the **clear bgp peer-drops** command in EXEC mode and XR EXEC mode.

clear bgp peer-drops *{*ip-address}*

Syntax Description	*	Specifies all BGP neighbors.
	<i>ip-address</i>	IP address of a specific network neighbor.
Command Default	No default behavior or values	
Command Modes	EXEC mode and XR EXEC mode	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Examples

The following example shows how to clear the connection-dropped counter for all BGP neighbors:

```
Router# clear bgp peer-drops *
```


clear bgp performance-statistics

To clear the performance statistics for all address families, use the **clear bgp performance-statistics** command.

clear bgp performance-statistics

Syntax Description

vrf	Specifies VPN routing and forwarding (VRF).
<i>vrf-name</i>	Name of a VRF.
all	For VRF, specifies all VRFs.

Command Default

No default behavior or values

Examples

The following example shows how to clear the performance statistics for all address families:

```
Router# clear bgp performance-statistics
```

clear bgp shutdown

To clear all Border Gateway Protocol (BGP) neighbors that shut down due to low memory, use the **clear bgp shutdown** command in EXEC mode and XR EXEC mode.

```
clear bgp {ipv4 {unicast | multicast | labeled-unicast | all} | ipv6 {unicast | multicast |
labeled-unicast | all } | all {unicast | multicast | labeled-unicast | all} | vpnv4 unicast | vrf
{vrf-name | all} | vpnv6 unicast} shutdown
```

Syntax Description		
ipv4		Specifies IP Version 4 address prefixes.
unicast		Specifies unicast address prefixes.
multicast		Specifies multicast address prefixes.
labeled-unicast		Specifies labeled unicast address prefixes.
all		For subaddress families, specifies prefixes for all subaddress families.
ipv6		Specifies IP Version 6 address prefixes.
all		For address family, specifies prefixes for all address families.
vpnv4 unicast		Specifies VPNv4 unicast address families.
vrf		Specifies VPN routing and forwarding (VRF).
<i>vrf-name</i>		Name of a VRF.
all		For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }		For VRF, specifies IPv4 unicast or labeled-unicast address families.
ipv6 unicast		For VRF, specifies IPv6 unicast address families.
vpnv6 unicast		Specifies VPNv6 unicast address families.

Command Default No default behavior or values

Command Modes EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Examples

The following example shows how to clear all shut-down BGP neighbors:

```
Router# clear bgp shutdown
```

default-information originate (BGP)

To allow origination of a default route to be redistributed into the Border Gateway Protocol (BGP) from another protocol, use the **default-information originate** command in an appropriate configuration mode. To disable this function, use the **no** form of this command.

default-information originate

Syntax Description

This command has no arguments or keywords.

Command Default

BGP does not permit redistribution of a default route into BGP.

Command Modes

Router configuration

VRF configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **redistribute** command to redistribute routes from another protocol into BGP. By default, if these routes include the default route (0.0.0.0/0 for IPv4 or ::/0 for IPv6), the default route is ignored. Use the **default-information originate** command to change this behavior so that the default route is not ignored and is redistributed into BGP along with the other routes for the protocol being redistributed.

Examples

The following example shows how to configure BGP to redistribute the default route into BGP:

```
Router(config)#router bgp 164  
Router(config-bgp)# default-information originate
```

default-martian-check disable

To disable the Martian address check on the following IPv4 and IPv6 prefixes, use the **default-martian-check disable** command in BGP IPv4 or BGP IPv6 address-family configuration mode:

- IPv4 address prefixes
 - 0.0.0.0/8
 - 127.0.0.0/8
 - 224.0.0.0/4
- IPv6 address prefixes
 - ::
 - ::0002 - ::ffff
 - ::ffff:a.b.c.d
 - fe80:xxxx
 - ffxx:xxxx

default-martian-check disable

Syntax Description	This command has no keywords or arguments.				
Command Default	None				
Command Default	None				
Command Modes	BGP IPv4 address family configuration mode. BGP IPv6 address family configuration mode.				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 7.0.12</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

Examples

This example shows how to disable a Martian check for an IPv4 address prefix.

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# address-family ipv4 multicast
Router(config-bgp-af)# default-martian-check disable
```

This example shows how to disable a Martian check for an IPv6 address prefix.

```
Router# configure
```

```
Router(config)# router bgp 100  
Router(config-bgp)# address-family ipv6 multicast  
Router(config-bgp-af)# default-martian-check disable
```

default-metric (BGP)

To set default metric values for the Border Gateway Protocol (BGP), use the **default-metric** command in an appropriate configuration mode. To disable metric values, use the **no** form of this command.

default-metric *value*

Syntax Description	<i>value</i> Default metric value appropriate for the specified routing protocol. Range is 1 to 4294967295.

Command Default	A metric is not set.

Command Modes	Router configuration VRF configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	Use the default-metric command to set the Multi Exit Discriminator (MED) to advertise to peers for routes that do not already have a metric set (routes that were received with no MED attribute).



Note	The metric values that you apply using the default-metric command take effect only for a new prefix which gets into the BGP table. The metrics for the existing prefixes in the BGP table remain the same. Also, when you remove the default-metric command from the configuration, the metrics which were previously assigned for prefixes are not updated. To get out of this condition, clear the BGP neighborship.

Examples

The following example shows how to set the BGP default metric:

```
Router(config)# router bgp 109
Router(config-bgp)# default-metric 10
```

default-originate

To cause a Border Gateway Protocol (BGP) speaker (the local router) to send the default route 0.0.0.0/0 to a neighbor for use as a default route, use the **default-originate** command in an appropriate configuration mode. To disable this function, use the **no** form of this command.

default-originate [**inheritance-disable** | **route-policy** *route-policy-name*]

Syntax Description	inheritance-disable (Optional) Prevents the default-originate command characteristics from being inherited from a parent group. route-policy <i>route-policy-name</i> (Optional) Specifies the name of a route policy. The route policy allows route 0.0.0.0 to be injected conditionally. IPv6 address family is supported.	
Command Default	The default route is not advertised to BGP neighbors.	
Command Modes	IPv4 neighbor address family configuration IPv6 neighbor address family configuration IPv4 neighbor group address family configuration IPv6 neighbor group address family configuration IPv4 address family group configuration IPv6 address family group configuration L2VPN EVPN address family group configuration VRF IPv4 neighbor address family configuration VRF IPv6 neighbor address family configuration	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.
Usage Guidelines	The default-originate command does not require the presence of the default route (0.0.0.0/0 for IPv4 or ::/0 for IPv6) in the local router. When the default-originate command is used with a route policy, the default route is advertised if any route in the BGP table matches the policy. In the L2VPN EVPN address-family group configuration mode, you can configure either default-originate or default-originate inheritance-disable commands.	
Examples	The following example shows how to unconditionally advertise the route 0.0.0.0/0 to the neighbor 172.20.2.3: <pre>Router(config)# router bgp 109 Router(config-bgp)#address-family ipv4 unicast Router(config-bgp)# neighbor 172.20.2.3</pre>	

```
Router(config-bgp-nbr)# remote-as 200  
Router(config-bgp-nbr)# address-family ipv4 unicast  
Router(config-bgp-nbr-af)# default-originate
```

The following example shows how to advertise the route 0.0.0.0/0 to the neighbor 172.20.2.3 only if a route exists in the BGP table that matches the route policy called default-default-policy:

```
Router(config)# router bgp 109  
Router(config-bgp)# neighbor 172.20.2.3  
Router(config-bgp-nbr)# remote-as 200  
Router(config-bgp-nbr)# address-family ipv4 unicast  
Router(config-bgp-nbr-af)# default-originate route-policy default-default-policy
```


description (BGP)

To annotate a neighbor, neighbor group, VPN routing and forwarding (VRF) neighbor, or session group, use the **description** command in an appropriate configuration mode. To remove the annotation, use the **no** form of this command.

description *text*

Syntax Description

text Meaningful description or comment. Maximum of 80 characters.

Command Default

No comment or description exists.

Command Modes

Neighbor group configuration

Neighbor configuration

Session group configuration

VRF neighbor configuration

Command History

Release	Modification

Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **description** command to provide a description of a neighbor, neighbor group, VRF neighbor, or session group. The description is used to save user comments and does not affect software function.

Examples

The following example shows how to configure the description “Our best customer” on the neighbor 192.168.13.4:

```
Router# configure
Router(config)#router bgp 65000
Router(config-bgp)#neighbor 192.168.13.4
Router(config-bgp-nbr)#description Our best customer
```

distance bgp

To allow the use of external, internal, and local administrative distances that could be used to prefer one class of routes over another, use the **distance bgp** command in an appropriate configuration mode. To disable the use of administrative distances, use the **nono** form of this command.

distance bgp *external-distance internal-distance local-distance*

Syntax Description

<i>external-distance</i>	Administrative distance for Border Gateway Protocol (BGP) external routes. External routes are routes for which the best path is learned from a neighbor external to the autonomous system. Range is 1 to 255. Routes with a distance of 255 are not installed in the routing table.
<i>internal-distance</i>	Administrative distance for BGP internal routes. Internal routes are those routes that are learned from another BGP entity within the same autonomous system. Range is 1 to 255. Routes with a distance of 255 are not installed in the routing table.
<i>local-distance</i>	Administrative distance for BGP local routes. The <i>local-distance</i> argument applies to locally generated aggregate routes (such as the routes generated by the aggregate-address command) and backdoor routes installed in the routing table. Range is 1 to 255. Routes with a distance of 255 are not installed in the routing table.

Command Default

external-distance : 20
internal-distance : 200
local-distance : 200

Command Modes

IPv4 address family configuration
 IPv6 address family configuration
 VRF IPv4 address family configuration
 VRF IPv6 address family configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **distance bgp** command if another protocol is known to be able to provide a better route to a node than was actually learned using external BGP, or if some internal routes should be preferred by BGP.



Note

Changing the administrative distance of BGP internal routes is considered risky and is not recommended. One problem that can arise is the accumulation of routing table inconsistencies, which can interfere with routing.

An administrative distance is a rating of the trustworthiness of a routing information source. Numerically, an administrative distance is an integer from 1 to 255. In general, the higher the value, the lower the trust rating. An administrative distance of 255 means the routing information source cannot be trusted at all and should be ignored.

Examples

The following example shows that iBGP routes are preferable to locally generated routes, so the administrative distance values are set accordingly:

```
Router(config)# router bgp 109  
Router(config-bgp)# address-family ipv4 unicast  
Router(config-bgp-af)#distance bgp 20 20 200
```

domain-distinguisher

To configure globally unique identifier ASN for IGP domain, use the **domain-distinguisher** command in address-family link-state configuration mode. To remove unique identifier, use the **no** form of this command.

domain-distinguisher *unique-id*

Syntax Description	<i>unique-id</i> Specifies four-octet unique identifier ASN. Range is from 1 to 4294967295.

Command Default	None

Command Modes	Address-family link-state configuration.

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Examples

This example shows how to configure a unique identifier ASN:

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# address-family link-state link-state
Router(config-bgp-af)# domain-distinguisher 1234
```

dmz-link-bandwidth

To originate a demilitarized zone (DMZ) link bandwidth extended community for the link to an eBGP neighbor, use the **dmz-link-bandwidth** command in an Neighbor configuration mode. To stop origination of the DMZ link bandwidth extended community, use the **no** form of this command.

dmz-link-bandwidth [**inheritance-disable**]

Syntax Description

inheritance-disable (Optional) Prevents the **dmz-link-bandwidth** command from being inherited from a parent group.

Command Default

BGP does not originate the DMZ link bandwidth extended community.

Command Modes

Neighbor configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **dmz-link-bandwidth** command to advertise the bandwidth of links that are used to exit an autonomous system.

Examples

This example shows how to advertise the bandwidth of links to eBGP neighbors from router bgp 1:

```
Router(config)# router bgp 1  
Router(config-bgp)#neighbor 10.67.89.01  
Router(config-bgp-nbr)#dmz-link-bandwidth
```

ebgp-multihop

To accept and attempt Border Gateway Protocol (BGP) connections to external peers residing on networks that are not directly connected, use the **ebgp-multihop** command in an appropriate configuration mode. To disable connections to external peers and allow only direct connections between neighbors, use the **no** form of this command.

ebgp-multihop [*ttl-value*] [**mpls**]

Syntax Description	<i>ttl-value</i> (Optional) Time-to-live (TTL) value. Range is 1 to 255 hops. mpls (Optional) Disables BGP label rewrite.				
Command Default	Default TTL value is 255.				
Command Modes	Neighbor configuration VRF neighbor configuration Neighbor group configuration Session group configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 7.0.12</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
Usage Guidelines	Use the ebgp-multihop command to enable multihop peerings with external BGP neighbors. The BGP protocol states that external neighbors must be directly connected (one hop away). The software enforces this by default; however, the ebgp-multihop command can be used to override this behavior. Use of the mpls option in the ebgp-multihop command prevents BGP from enabling MPLS on the peering interface and also prevents allocation of Implicit-NULL rewrite labels for nexthop addresses learned from the peer. This is useful in some scenarios in which MPLS forwarding labels to the nexthops have already been learned via BGP labeled-unicast or LDP. If this command is configured for a neighbor group or session group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.				
Examples	The following example shows how to allow a BGP connection to neighbor 172.20.16.6 of up to 255 hops away:				

```
Router(config)# router bgp 109
Router(config-bgp)# neighbor 172.20.16.6
Router(config-bgp-nbr)# ebgp-multihop
```

ecmp-delay

To configure delay in best path calculation for prefixes with ECMP paths in BGP, use the **ecmp-delay** submode in the address-family configuration mode.

ecmp-delay { **fixed** **delay** *delay_interval_value* | **as-based** **delay** *delay_interval_value* [**as-list** *as_list_name*] | **platform-oor-based** **delay** *delay_interval_value* **threshold** *threshold_value* }

Syntax Description		
as-based		Enables ECMP delay based on the neighbor AS.
as-list <i>as_list_name</i>		Enables ECMP delay for neighbor AS included in the AS list.
fixed		Enables ECMP delay with a fixed delay.
platform-oor-based		Enables ECMP delay with an OOR threshold.
delay		Specifies the delay interval in milliseconds.
<i>delay_interval_value</i>		Specifies the duration that the router delays the RIB or FIB installation for BGP prefixes. The range is 10–300000.
threshold <i>threshold_value</i>		Applies ECMP delay with an OOR threshold value, only when the platform resource usage is above the specified threshold value.

Command Default No default behavior or values

Command Modes IPv4 or IPv6 address-family configuration

Command History	Release	Modification
	Release 25.1.1	This command was introduced.

Usage Guidelines None.

Task ID	Task ID	Operations
	bgp	read, write

Examples

The following example shows how to configure an ECMP delay of 10 milliseconds based on the neighbor AS:

```
Router(config)#router bgp 100
Router(config-bgp)#address-family ipv4 unicast
Router(config-bgp-af)#maximum-paths eibgp 1024 selective route-policy mp_rpl
Router(config-bgp-af)#ecmp-delay
Router(config-bgp-af-ecmpdelay)#as-based delay 10
Router(config-bgp-af)#commit
```

export route-policy

To configure an export route policy, use the **export route-policy** command in an appropriate configuration mode. To restore the system to its default condition, use the **no** form of this command.

export route-policy *policy-name*

Syntax Description	<i>policy-name</i> Name of the configured route policy.

Command Default	No default behavior or values

Command Modes	Global VRF IPv4 address family configuration Global VRF IPv6 address family configuration

Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 7.0.12</td><td>This command was introduced.</td></tr></table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

Usage Guidelines	Use the export route-policy command to define the conditions that allow specified routes to be tagged with specified route-targets.

You cannot use this **route-policy** to drop a route.

Examples

The following example shows how to configure an export route policy:

```
Router(config)# vrf vrf-1
Router(config-vrf)#address-family ipv4 unicast
Router(config-vrf-af)# export route-policy policy-A
```


export route-target

To configure a VPN routing and forwarding (VRF) export route-target extended community, use the **export route-target** command in an appropriate configuration mode. To restore the system to its default condition, use the **no** form of this command.

export route-target [*as-number:nn* *ip-address:nn*]

Syntax Description	<i>as-number:nn</i> (Optional) <i>as-number</i> —Autonomous system (AS) number of the route-target extended community. <i>as-number</i> • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535. • <i>nn</i> —32-bit number. <i>ip-address:nn</i> (Optional) IP address of the route-target extended community. • <i>ip-address</i> —32-bit IP address. • <i>nn</i> —16-bit number .				
Command Default	No default behavior or values				
Command Modes	Global VRF IPv4 address family configuration Global VRF IPv6 address family configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.0.12</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
Usage Guidelines	Export route-target extended communities are associated with prefixes when advertised to remote provider edge (PE) routers. The remote PE routers import the route-target extended communities into a VRF instance that has the import route-targets that match the exported route-target extended communities. To specify multiple route targets, enter export route target configuration mode then enter one route target for each command line.				
Examples	The following example shows how to specify an export route-target: <pre>Router(config)# vrf vrf-1 Router(config-vrf)# address-family ipv4 unicast</pre>				

```
Router(config-vrf-af)# export route-target 500:1
```

fast-fallover

To invalidate routes and reset the BGP sessions immediately when the IP interface of a directly connected neighbor goes down, use the **fast-fallover** command in an appropriate configuration mode.

fast-fallover [inheritance-disable]

Syntax Description	inheritance-disable Prevents the fast fallover setting from being inherited from a higher-level neighbor group or session group.				
Command Default	When an interface attached to a directly connected BGP neighbor fails, the routes learned from that neighbor persist until the hold time expires.				
Command Modes	Neighbor configuration Neighbor group configuration Session group configuration				
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 24.2.11</td><td>This command was introduced.</td></tr></table>	Release	Modification	Release 24.2.11	This command was introduced.
Release	Modification				
Release 24.2.11	This command was introduced.				
Usage Guidelines	By default, fast fallover is enabled for eBGP neighbors and disabled for iBGP neighbors. If the bgp fast-external-fallover disable command is configured under BGP global or VRF configuration modes, fast fallover will be disabled for eBGP neighbors, but it can still be overridden for specific eBGP neighbors using the fast-fallover command.				
Examples	<pre>Router# configure Router(config)# router bgp 120 Router(config-bgp)# neighbor 209.165.201.0 Router(config-bgp-nbr)# fast-fallover</pre>				

graceful-maintenance

To allow the network to perform convergence before the router or link is taken out of service, use the **graceful-maintenance** command in the router BGP, neighbor or neighbor group configuration mode, as appropriate. To disable the command, use the **no** form of this command.

graceful-maintenance **activate** [**all-neighbors** | **retain-routes**]



Note This command is executed in the router BGP configuration mode.

graceful-maintenance { **activate** [**as-prepends** *as-prepends-value*] [**inheritance-disable**] | [**local-preference** *local-pref-value*] **inheritance-disable** }



Note This command is executed in either the neighbor configuration or neighbor group configuration mode.

Syntax Description

activate	Announces routes with the graceful maintenance attributes while activated either under the neighbor or router BGP configuration. While activated, all routes to this neighbor are announced with the attribute configured here and all routes from this neighbor are announced to other neighbors with the graceful maintenance attributes configured under those neighbors. The GSHUT community is announced regardless of the other attributes configured here. To allow the GSHUT community to be announced to eBGP neighbors, you must configure the send-community-gshut-ebgp command.
all-neighbors	If you use the all-neighbors keyword, Graceful Maintenance is activated even for those neighbors that do not have Graceful Maintenance activated.
retain-routes	Choosing retain-routes causes RIB to retain BGP routes when the BGP process is stopped. You would use retain-routes when only BGP is being brought down instead of the entire router and if it is known that neighboring routers are being kept in operation during the maintenance of the local BGP. If RIB has alternative routes provided by another protocol or a default route, then it is recommended not to retain BGP routes after the BGP process stops.

as-prepends
as-prepends-value
inheritance-disable

Indicates the number of times to prepend the local AS number to the AS path of routes. The default value is 0. The keyword **inheritance-disable** prevents AS prepends from being inherited from the parent.

Specifies the number of times to prepend the local AS number to the AS path of routes and advertises the GSHUT community with the local preference value specified for the routes. When the router adds the GSHUT community to a route as it advertises it, it also changes the LOCAL_PREF attribute and prepends the local AS number as specified in the commands. Sending GSHUT provides flexibility in how neighboring routers handle the lower preference: they can match it in a route policy and do the most appropriate thing with it. On the other hand, in simple networks, it is recommended to set local-preference to 0, rather than to create route policies everywhere else.

Note

LOCAL_PREF is not sent to real eBGP neighbors, but sent to confederation member AS eBGP neighbors. To lower preference to eBGP neighbors, as-prepends is required.

local-preference
local-pref-value
inheritance-disable

Indicates the range of values for Local Preference. The keyword **inheritance-disable** prevents local preference from being inherited from the parent.

Command Default

None

Command Modes

router BGP
 neighbor configuration
 neighbor group configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

hw-module profile cef bgplu-over-rsvpte enable

To enable BGP labeled unicast over RSVP-TE, use this command in interface configuration mode. Use the **no** form of the command to disable the feature.

hw-module profile cef bgplu-over-rsvpte enable

This command has no arguments or keywords.

Command Default

None

Command Modes

Interface configuration

Command History

Release	Modification
Release 7.11.1	This command was introduced.

Usage Guidelines

After configuring the command, you must reload the router for the feature to take effect.

```
Router#config
```

```
Router(config)#hw-module profile cef bgplu-over-rsvpte enable
```

ibgp policy out enforce-modifications

To allow an outbound route policy for an internal BGP (iBGP) peer to modify all BGP route attributes, only when an iBGP route is sent to another iBGP peer (only on route-reflectors), use the **ibgp policy out enforce-modifications** command in XR Config mode. To disable this feature, use the **no** form of this command.

ibgp policy out enforce-modifications

Syntax Description	This command has no arguments or keywords.

Command Default	ibgp policy out enforce-modifications is disabled.

Command Modes	XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	Use the ibgp policy out enforce-modifications command to set and modify BGP route attributes for updates to iBGP peers.

If the **ibgp policy out enforce-modifications command** is configured under router BGP configuration, then all the changes made by the outbound policy for an iBGP peer will be present in an update message sent to the peer.

Examples

The following example shows how to set the ibgp policy out enforce-modifications:

```
Router# configure
Router(config)# router bgp 6500
Router(config-bgp)# ibgp policy out enforce-modifications
```

import

To configure the import and export of BGP NLRI between two BGP neighbors with respect to the route target identifiers, use the **import** command in the BGP neighbor address family configuration mode. To undo this command configuration, run the **no** form of this command.

import [**stitching-rt**] **reoriginate** [**stitching-rt**]

Syntax Description	reoriginate		Imports NLRI that match normal route target identifier and exports re-originated NLRI assigned with the normal route target identifier.
	reoriginate stitching-rt		Imports NLRI that match normal route target identifier and exports re-originated NLRI assigned with the stitching route target identifier
	stitching-rt reoriginate		Imports NLRI that match stitching route target identifier and exports re-originated NLRI assigned with the normal route target identifier.
	stitching-rt reoriginate stitching-rt		Imports NLRI that match stitching route target identifier and exports re-originated NLRI assigned with the stitching route target identifier.
Command Default	None		
Command Modes	BGP neighbour address family configuration mode		
Command History	Release	Modification	
	Release 7.0.12	This command was introduced.	

Example

The following example shows how to configure DCI router to import BGP NLRI that match normal route target identifier and to export re-originated BGP NLRI assigned with the stitching route target identifier.

```
Router# configure
Router(config)# router bgp 1
Router(config-bgp)# neighbor 1.1.1.1
Router(config-bgp-nbr)# address-family l2vpn evpn
Router(config-bgp-nbr-af)# import reoriginate stitching-rt
```


import route-policy

To configure an import route policy, use the **import route-policy** command in an appropriate configuration mode. To restore the system to its default condition, use the **no** form of this command.

import route-policy *policy-name*

Syntax Description	<i>policy-name</i> Name of the configured route policy.

Command Default	No default behavior or values

Command Modes	Global VRF IPv4 address family configuration Global VRF IPv6 address family configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	Use the import route-policy command to define the conditions that allow specified routes to be imported into the VPN routing and forwarding (VRF) instance if the routes are tagged with specified route-targets.

Examples	The following example shows how to allow only policy-B to be imported to VRF:

```
Router(config)# vrf vrf-1
Router(config-vrf)# address-family ipv4 unicast
Router(config-vrf-af)# import route-policy policy-B
```

import route-target

To configure a VPN routing and forwarding (VRF) import route-target extended community, use the **import route-target** command in an appropriate configuration mode. To restore the system to its default condition, use the **no** form of this command.

import route-target [*as-number:nn ip-address:nn*]

Syntax Description

as-number:nn (Optional) Autonomous system (AS) number of the route-target extended community.

- *as-number*
- Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535.
- Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295.
- Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535.
- *nn* —32-bit number.

ip-address:nn (Optional) IP address of the route-target extended community.

- *ip-address* —32-bit IP address.
- *nn* —16-bit number.

Command Default

No default behavior or values

Command Modes

Global VRF IPv4 address family configuration

Global VRF IPv6 address family configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **import route-target** command to specify that prefixes associated with the configured import route-target extended communities are imported into the VRF instance.

To specify multiple route targets, enter import route target configuration mode, then enter one route target for each command line.

Task ID

Task ID	Operations
bgp	read, write
ip-services	read, write

Examples

The following example shows how to specify an import route-target:

```
RP/0/RP0/CPU0:router(config)#vrf vrf-1
RP/0/RP0/CPU0:router(config-vrf)# address-family ipv4 unicast
RP/0/RP0/CPU0:router(config-vrf-af)# import route-target 500:99
```

ignore-connected-check

To enable the software to bypass the directly connected next hop check for single-hop eBGP peering, use the **ignore-connected-check** command in an appropriate configuration mode. To re-enable the directly connected next hop check, use the **no** form of this command.

ignore-connected-check [**inheritance-disable**]

Syntax Description

inheritance-disable Prevents the **ignore-connected-check** command from being inherited from the parent.

Command Default

Ability to bypass the directly connected next hop check is disabled.

Command Modes

Neighbor configuration

Neighbor group configuration

Session group configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Examples

The following example shows how to enable ignore-connected check configuration for neighbor 10.2.3.4:

```
Router(config)# router bgp 100
Router(config-bgp)# neighbor 10.2.3.4
Router(config-bgp-nbr)# ignore-connected-check
```

is-best-path

To tag the path selected as the best path use the **is-best-path** command in route policy configuration mode.

is-best-path

Syntax Description	is-best-path Checks and tags the path selected as best-path.	
Command Default	No default behavior or values.	
Command Modes	Route-policy configuration	
Command History	Release	Modification
	Release 5.3.2	This command was introduced.

Example

```
RP/0//CPU0:router(config)# route-policy
WORD Route Policy name
RP/0//CPU0:router(config)# route-policy sample
RP/0//CPU0:router(config-rpl)# if destination i
in is-backup-path is-best-external is-best-path

if destination is-best-path then
set community community
endif
end-policy
!
RP/0//CPU0:router# sh version
Wed Jul 8 16:08:34.286 IST
Cisco IOS XR Software, Version 5.3.2.14I[EnXR]
Copyright (c) 2015 by Cisco Systems, Inc.
Built on Fri Jun 26 17:35:45 IST 2015
By router in RP/0//CPU0
```

is-backup-path

To tag all the paths equal to the back up path use, **is-backup-path** command in route policy configuration mode.

is-backup-path

Syntax Description	is-backup-path Checks and tags the path selected as backup path.
Command Default	No default behavior or values.
Command Modes	Route-policy configuration

Example

```
RP/0//CPU0:router(config)# route-policy
WORD Route Policy name
RP/0//CPU0:router(config)# route-policy sample
RP/0//CPU0:router(config-rpl)# if destination i
in      is-backup-path is-best-external is-best-path

RP/0//CPU0:router(config)# route-policy
WORD Route Policy name
RP/0//CPU0:router(config)# route-policy sample
RP/0//CPU0:router(config-rpl)# if destination i
in      is-backup-path is-best-external is-best-path
```

is-multi-path

To tag all the paths equal to the best path based on multi-path context use, **is-multi-path** command in route policy configuration mode.

is-multi-path

Syntax Description	is-multi-path Checks and tag all the path equal to the as best-path.	
Command Default	No default behavior or values.	
Command Modes	Route-policy configuration	
Command History	Release	Modification
	Release 5.3.2	This command was introduced.

Example

```
RP/0//CPU0:router(config)#route-policy
WORD Route Policy name
RP/0//CPU0:router(config)#route-policy sample
RP/0//CPU0:router(config-rpl)#if destination i
in          is-backup-path is-best-external is-best-path

is-multi-path
RP/0//CPU0:router(config-rpl)#if destination is-
is-backup-path is-best-external is-best-path is-multi-path
RP/0//CPU0:router(config-rpl)#if destination is-best-path then
RP/0//CPU0:router(config-rpl-if)#set l
label          label-index label-mode level
community lsm-root
RP/0//CPU0:router(config-rpl-if)#set community community
RP/0//CPU0:router(config-rpl-if)#endif
RP/0//CPU0:router(config-rpl)#end-policy
RP/0//CPU0:router(config)#commit
Wed Jul  8 16:08:23.436 IST
```

label mode

To set the MPLS/VPN label mode based on prefix value, use the **label mode** command in an appropriate configuration mode. To remove the **label mode** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

Use this syntax for VPNv4 and VPNv6 unicast address-family configuration mode:

label mode per-nexthop-received-label [allocate-secondary-label]

Use this syntax for **vrf all** configuration mode under VPN IPv4/IPv6 AF (address family) mode or global IPv6 AF configuration mode:

label mode { per-ce | per-vrf | per-vrf-46 | route-policy }

Use this syntax for IPv4/IPv6 AF configuration mode under vrf mode:

label mode { per-prefix | per-ce | per-vrf | per-vrf-46 | route-policy }
no label mode { per-prefix | per-ce | per-vrf | per-vrf-46 | route-policy }

Syntax Description

per-nexthop-received-label	Specifies that the same label is used for all prefixes received with the same next-hop and same received-label.
allocate-secondary-label	Enables allocating a secondary label in addition to the local label at the route reflectors to avoid label churn issue in Prefix Independent Convergence (PIC) scenario.
per-ce	Specifies that the same label is used for all routes advertised from a unique customer edge (CE) peer or route.
per-vrf	Specifies that the same label is used for all routes advertised from a unique VRF.
per-vrf-46	Specifies that the same label is used for all routes advertised from a unique VRF or global routing table.
per-prefix	Specifies that the same label is used for all routes advertised from a unique prefix. Note This keyword is applicable only for IPv4/IPv6 AF configuration mode under vrf mode.
route-policy	Specifies a route policy to select prefixes for setting the label mode.

Command Default

Per-prefix label mode.



Note If a policy attached at label-mode attachpoint evaluates to pass and a **label mode** is not explicitly set, **per-prefix** is used as the default label mode.

If a policy attached at label-mode attachpoint evaluates to a drop, **per-prefix** is used as a default label mode. If any **label mode** is set explicitly in this case, it will be ignored.

Command Modes

VPNv4 unicast address family configuration

VPNv4 address family configuration

VPNv6 address family configuration

VRF IPv4 address family configuration

VRF IPv6 address family configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.
Release 7.4.1	This command was deprecated in the VRF IPv4, VRF IPv6, VPNv4 unicast, and VPNv6 unicast address-family configuration modes. The function of this deprecated command can be carried out using label mode command under address-family mode.
Release 24.1.1	The per-vrf-46 keyword was introduced.

Usage Guidelines

To configure label mode at VPN-AF level and to have all the VRF AFs inherit that configuration, you must use **vrf all**, which is available under VPN-AF mode.

The inheritance rules followed are:

- **label mode** configuration under VRF-AF, overrides **label-allocation-mode** configuration under VRF and **label mode** configuration under VPN-AF.
- **label-allocation-mode** configuration under VRF, overrides **label mode** configuration under VPN-AF.



Note **label-allocation-mode** has been deprecated from release 7.4.1.

The function of this command can be carried out using label mode command under configured [address-family](#).

- The order of priority to determine the label mode in the configurations is:
 1. VRF-AF: **label mode**
 2. VRF: **label-allocation-mode**
 3. VPN-AF: **label mode**
 4. N/A: **per-prefix**



Note Even if **label mode** is in use, **per-vrf** label is allocated for connected, aggregate, and local prefixes.

The per-nexthop-received-label mode falls back to per-prefix label mode in the following scenarios:

- When there is a best path and a backup path, and one of these paths is received from an external BGP (eBGP) peer.
- When the best-external path feature is configured using the [advertise best-external](#) command.
- When an Autonomous System Boundary Router (ASBR) receives remote VPN routes with a Route Distinguisher (RD) (for example, RD1), and the ASBR is also functioning as a local PE router with a local VRF configured for the same RD1.

When configuring the **label mode per-nexthop-received-label** command at the VPN level, you must explicitly configure the local retention time for the **retain local-label** command.

The example shows how to configure label mode selection at VPNv4 AF level:

```
Router# configure
Router(config)# router bgp 65550
Router(config-bgp)# address-family vpnv4 unicast
Router(config-bgp-af)# vrf all
Router(config-bgp-af)# label mode route-policy policy_A
```

The example shows how to configure label mode selection at VRF IPv4 AF level:

```
Router# configure
Router(config)# router bgp 65550
Router(config-bgp)# vrf vrf-1
Router(config-bgp-vrf)# rd 1:1
Router(config-bgp-vrf)# address-family ipv4 unicast
Router(config-bgp-vrf)# label mode route-policy policy_B
```

The example shows how to enable the per-vrf-46 label mode for global table IPv4 unicast:

```
Router# configure
Router(config)# router bgp 65550
Router(config-bgp-vrf)# address-family ipv4 unicast
Router(config-bgp-vrf)# label mode per-vrf-46
```

The example shows how to enable the per-vrf-46 label mode for global table IPv6 unicast:

```
Router# configure
Router(config)# router bgp 65550
Router(config-bgp-vrf)# address-family ipv6 unicast
Router(config-bgp-vrf)# label mode per-vrf-46
```

The example shows how to enable the per-vrf-46 label mode for global table VPNv4 unicast:

```
Router# configure
Router(config)# router bgp 65550
```

```
Router(config-bgp-vrf)# address-family vpnv4 unicast
Router(config-bgp-vrf)# vrf-all
Router(config-bgp-vrf)# label mode per-vrf-46
```

The example shows how to enable the per-vrf-46 label mode for global table VPNv6 unicast:

```
Router# configure
Router(config)# router bgp 65550
Router(config-bgp-vrf)# address-family vpnv6 unicast
Router(config-bgp-vrf)# vrf-all
Router(config-bgp-vrf)# label mode per-vrf-46
```

The example shows how to enable the per-vrf-46 label mode for VRF IPv6 unicast:

```
Router# configure
Router(config)# router bgp 65550
Router(config-bgp-vrf)# vrf INET
Router(config-bgp-vrf)# address-family ipv6 unicast
Router(config-bgp-vrf)# label mode per-vrf-46
```

If route policy B_rp is applied within route policy A_rp, execution continues from policy A_rp to policy B_rp and back to policy A_rp provided prefix is not dropped by policy B_rp.

```
route-policy A_rp
  set community (10:10)
  apply B_rp
end-policy
!

route-policy B_rp
  if destination in (121.23.0.0/16 le 32, 155.12.0.0/16 le 32) then
    set community (121:155) additive
  endif
end-policy
!
```

This example shows the label mode selection at VPNv4 AF (address family) level and at VRF IPv4 AF level:

```
route-policy set_label_mode
  set label-mode per-prefix
end-policy
!
router bgp 65550
  address-family vpnv4 unicast
    vrf all
    label mode route-policy pass-all
  !
!
vrf abc
  rd 1:1
  address-family ipv4 unicast
    label mode route-policy set_label_mode
  !
!
end
```

local-as

To allow customization of the autonomous system number for external Border Gateway Protocol (eBGP) neighbor peerings, use the **local-as** command in an appropriate configuration mode. To disable customization of local autonomous system values for eBGP neighbor peerings, use the **no** form of this command.

local-as { *as-number* [**no-prepend** [**replace-as** [**dual-as**]]] | **inheritance-disable** }

Syntax Description	
<i>as-number</i>	Valid autonomous system number. Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535. Cannot be the autonomous system number to which the neighbor belongs.
no-prepend	(Optional) Specifies that local autonomous system values are not prepended to announcements from the neighbor.
replace-as	(Optional) Specifies that prepend only local autonomous system values to announcements to the neighbor.
dual-as	(Optional) Dual-AS mode.
inheritance-disable	Prevents local AS from being inherited from the parent.

Command Default	The BGP autonomous system number specified in the router bgp command is used, except when confederations are in use. The confederation autonomous system is used for external neighbors in an autonomous system that is not part of the confederation.

Command Modes	Neighbor configuration VRF neighbor configuration Neighbor group configuration Session group configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	You can specify the autonomous system number the local BGP uses to peer with each neighbor. The autonomous system number specified with this command cannot be the local BGP autonomous system number (specified with the router bgp command) or the autonomous system number of the neighbor (specified with the remote-as command). However, from Release 5.2.2, the autonomous system number for local-as and remote-as can be the same, which makes the resulting neighbor peering being treated as iBGP. This command cannot be specified for internal neighbors or for external neighbors in an autonomous system that is part of a confederation.

If this command is configured for a neighbor group or session group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.

In case the router is an ASBR and adding the **local-as** configuration changes the BGP neighbor from being an eBGP to iBGP, incremental addition of the **local-as** command is not supported. Remove the neighbor configuration, then configure the entire neighbor, including **remote-as** configuration and the new **local-as** configuration, in one commit.

Examples

The following example shows BGP using autonomous system 30 for the purpose of peering with neighbor 172.20.1.1:

```
Router(config)# router bgp 140  
Router(config-bgp)# neighbor 172.20.1.1  
Router(config-bgp-nbr)# remote-as 300  
Router(config-bgp-nbr)# local-as 30
```

long-lived-graceful-restart

To enable long lived graceful restart (LLGR) on the BGP neighbors, use the **long-lived-graceful-restart** command in neighbor `address family` mode. To disable LLGR, use the **no** form of this command.

```
long-lived-graceful-restart { capable | stale-time send { time | default } accept { time | any } }
```

Syntax Description

capable	Treats the neighbor as LLGR capable even if it does not advertise the capabilities.
stale-time	Causes the local router to advertise the LLGR capability to the neighbor and to enable LLGR for prefixes received from the neighbor.
send time	Specifies stale-time sent in LLGR capability. The range is from 0 through 4294967 seconds.
send default	Specifies that the router sends a default value for the LLGR time.
accept time	Specifies maximum stale-time acceptable from neighbor. The range is from 0 through 4294967 seconds.
accept any	Specifies that the router accepts the LLGR stale time provided by the peer without setting its own threshold for acceptance.

Command Default

The long-lived-graceful-restart functionality is disabled by default.

Command Modes

Address family configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.
Release 24.3.1	This was modified. These changes were made: The default, any, and advertise-internal-only keywords were added.

Usage Guidelines

When this command is configured, the BGP session is reset, because the changes need to be advertised to the neighbor in a BGP OPEN message.

When the BGP session to a neighbor goes down the routes received from it will be marked LLGR stale if all of the following conditions are met:

- Either the neighbor is configured as capable or the neighbor sent the LLGR capability in its BGP OPEN message
- The neighbor session was not brought down with a clear command on the local router.
- The neighbor session was brought down and restarting speaker did not advertise notification to receiving speaker

- The neighbor sent either the LLGR or graceful restart capability in its BGP OPEN message.
- The restart-timer of Graceful Restart expires.
- Routes from the peer do not have the NO_LLGR community.

LLGR routes will only be advertised to a neighbor that is LLGR capable, either because it is configured as capable or because it has sent the LLGR capability in its BGP OPEN message. An LLGR route is either one that has been marked as LLGR stale, because the BGP session from which it was received went down or because it has the LLGR_STALE community and does not have the NO_LLGR community.

Examples

This example shows how to configure the neighbor to be LLGR capable for the given address family:

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# neighbor 10.3.3.3
Router(config-bgp-nbr)# address-family vpnv4 unicast
Router(config-bgp-nbr-af)# long-lived-graceful-restart capable
```

The **long-lived-graceful-restart capable** command enables the LLGR capability on the neighbor; even though the neighbor does not advertise the LLGR capabilities during session information.

. The **long-lived-graceful-restart stale-time send default accept any** command is used to configure the LLGR on the neighbor.

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# neighbor 10.3.3.3
Router(config-bgp-nbr)# address-family vpnv4 unicast
Router(config-bgp-nbr-af)# long-lived-graceful-restart stale-time send default accept any
```

The **long-lived-graceful-restart stale-time send 20 accept 30** command is used to configure the LLGR on the neighbor. When this command is configured the configured device will retain routes from the neighbor.

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# neighbor 10.3.3.3
Router(config-bgp-nbr)# address-family vpnv4 unicast
Router(config-bgp-nbr-af)# long-lived-graceful-restart stale-time send 20 accept 30
```

multipath

Enables multiple paths for a BGP neighbor.

To disable this function, use the **no** form of this command.

multipath

no multipath

Command Default

Multipath is disabled by default.

Command Modes

Router BGP neighbor configuration

Usage Guidelines

To configure BGP selective multipath feature, the **multipath** option must be enabled on the required BGP neighbor. The **multipath** configuration for a neighbor works when configured with the **selective** option of the **maximum-paths** command.

Examples

The following example shows how to enable multiple paths for a BGP neighbor.

```
Router# configure
Router(config)# router bgp 1
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp-af)# maximum-paths ibgp 4 selective
Router(config-bgp-af)# maximum-paths ebgp 5 selective
Router(config-bgp-af)# neighbor 1.1.1.1
Router(config-bgp-nbr)# address-family ipv4 unicast
Router(config-bgp-nbr-af)# multipath
Router(config-bgp-nbr-af)# commit
```


maximum-paths (BGP)

To control the maximum number of parallel routes that Border Gateway Protocol (BGP) installs in the routing table, use the **maximum-paths** command in an appropriate configuration mode. To set the maximum number of parallel routes the software installs to the default value, use the **no** form of this command.

```
maximum-paths { { ebgp | ibgp } maximum [ unequal-cost ] | eibgp maximum [ equal-cost ] }
route-policy route-policy-name [ selective ] }
```

Syntax Description		
ebgp		Specifies external BGP multipath peers.
ibgp		Specifies internal BGP multipath peers.
eibgp		Specifies internal and external BGP multipath peers. eiBGP allows simultaneous use of internal and external paths.
<i>maximum</i>		Maximum number of parallel routes that BGP installs in the routing table. Range is 2 to 8
unequal-cost		(Optional) Allows iBGP multipaths to have different BGP next-hop Interior Gateway Protocol (IGP) metrics. This option is available when either the ibgp or ebgp keywords are used.
equal-cost		(Optional) Allows eiBGP multipaths to have same BGP next-hop Interior Gateway Protocol (IGP) metrics. This option is available when the eibgp keyword is used.
route-policy		(Optional) Specifies the route policy to select multipath.
<i>route-policy-name</i>		(Optional) Name of the route policy.
selective		(Optional) Allow multipaths only from marked neighbors.

Command Default	One path is installed in the routing table.

Command Modes	IPv4 address family configuration IPv6 address family configuration VRF IPv4 address family configuration VRF IPv6 address family configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.
	Release 7.10.1	This command was modified. The equal-cost , route-policy keywords and <i>route-policy-name</i> argument were added.

Usage Guidelines	Use the maximum-paths command to allow the BGP protocol to install multiple paths into the routing table for each prefix. Multiple paths are installed for external peers that are from the same autonomous system and

are equal cost (according to the BGP best-path algorithm). Similarly, multiple paths are installed for internal peers that are equal cost based on the BGP best-path algorithm. The IGP metric to the BGP next hop is the same as the best-path IGP metric unless the router is configured for unequal cost iBGP multipath or eBGP multipath.

Use the **equal-cost** keyword to maintain consistent nexthop IGP metric criteria for multipath eligibility among iBGP path types.

See *Implementing BGP* in the *BGP Configuration Guide for Cisco 8000 Series Routers* for information on the BGP best-path algorithm.



Note The **maximum-paths** command with the **eibgp** keyword cannot be configured if the **ibgp** or **ebgp** keywords have been configured, because the **eibgp** keyword is a superset of the **ibgp** or **ebgp** keywords.

Examples

The following example shows how to allow a maximum of four paths to a destination installed into the IPv4 unicast routing table:

```
Router(config)# router bgp 109
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp-af)# maximum-paths ebgp 4
```

The following example shows how to preserve consistent nexthop IGP metric criteria for multipath eligibility among similar path types, either iBGP or eBGP.

```
Router(config)# router bgp 109
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp-af)# maximum-paths eibgp 32 equal-cost route-policy EIBGP
```

maximum-prefix (BGP)

To control how many prefixes can be received from a neighbor, use the **maximum-prefix** command in an appropriate configuration mode. To set the prefix limits to the default values, use the **no** form of this command.

maximum-prefix *maximum* [*threshold*] [**discard-extra-paths**] [**warning-only**] [**restart** *time-interval*]

Syntax Description

maximum

Maximum number of prefixes allowed from this neighbor. Range is from 1 to 4294967295.

Note

When using additional-paths feature, each path with a unique path ID received from a peer is counted separately for the purpose of maximum-prefix functionality. Hence, the *maximum* value should be configured appropriately when the peer is capable of sending additional-paths.

discard-extra-paths

(Optional) Drops all the excess prefixes received from the neighbor when the prefixes exceed the configured maximum value.

threshold

(Optional) Integer specifying at what percentage of the *maximum* argument value the software starts to generate a warning message. Range is from 1 to 100.

warning-only

(Optional) Instructs the software to only generate a log message when the *maximum* argument value is exceeded, and not to terminate the peering.

restart *time-interval*

(Optional) Sets the time interval (in minutes) after which peering session should be reestablished.

Configure restart time interval in minutes. Range is from 1 to 65535.

Command Default

The default threshold, when a warning message is generated, is 75 percent.

Command Modes

IPv4 address family group, neighbor address family, and neighbor group address family configuration

IPv6 address family group, neighbor address family, and neighbor group address family configuration

IPv4 tunnel address family group, neighbor group address family, and neighbor address family configuration

IPv4 flowspec under neighbor address family, neighbor group address family, and address family group configuration

IPv6 flowspec under neighbor address family, neighbor group address family, and address family group configuration

VPNv4 flowspec under neighbor address family, neighbor group address family, and address family group configuration

VPNv6 flowspec under neighbor address family, neighbor group address family, and address family group configuration

L2VPN EVPN under neighbor address family, neighbor group address family, and address family group configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **maximum-prefix** command to configure a maximum number of prefixes that a BGP router is allowed to receive from a neighbor. It adds another mechanism (besides routing policy) to control prefixes received from a peer.

When the number of received prefixes exceeds the maximum number configured, the software terminates the peering, by default, after sending a cease notification to the neighbor. However, if the **warning-only** keyword is configured, the software writes only a log message, but continues peering with the sender. If the peer is terminated, the peer stays down until the **clear bgp** command is issued or the **restart time-interval** option is used.

This command takes effect immediately if configured on an established neighbor, unless the number of prefixes received from the neighbor already exceeds the configured limits.

If this command is configured for a neighbor group or neighbor address family group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.

Examples

This example shows the maximum number of IP Version 6 (IPv6) unicast prefixes allowed from neighbor 192.168.40.25 set to 5000, threshold value 80%, and restart time interval 20 minutes:

```
Router(config)#router bgp 100
Router(config-bgp)#neighbor 192.168.40.25
Router(config-bgp-nbr)#remote-as 1
Router(config-bgp-nbr)#address-family ipv6 unicast
Router(config-bgp-nbr-af)#maximum-prefix 5000 80 restart 20
```

This example shows the maximum number of IP Version 4 (IPv4) unicast prefixes allowed from the neighbor 192.168.40.24 set to 1000:

```
Router(config-bgp)# router bgp 109
Router(config-bgp)# neighbor 192.168.40.24
```

```
Router(config-bgp-nbr)# remote-as 1
Router(config-bgp-nbr)#address-family ipv4 unicast
Router(config-bgp-nbr-af)# maximum-prefix 1000
```

The following example shows how to configure discard extra paths:

```
Router#configure
Router(config)#router bgp 10
Router(config-bgp)#neighbor 10.0.0.1
Router(config-bgp-nbr)#address-family ipv4 unicast
Router(config-bgp-nbr-af)#maximum-prefix 5000 discard-extra-paths
```

neighbor (BGP)

To enter neighbor configuration mode for configuring Border Gateway Protocol (BGP) routing sessions, use the **neighbor** command in an appropriate configuration mode. To delete all configuration for a neighbor and terminate peering sessions with the neighbor, use the **no** form of this command.

neighbor *ip-address*
no neighbor *ip-address*

Syntax Description	<i>ip-address</i> IPv4 or IPv6 IP address of the BGP-speaking neighbor.
Command Default	Neighbor mode is not specified.
Command Modes	Router configuration
Usage Guidelines	From router configuration mode, you can use this command to enter neighbor configuration mode. From neighbor configuration mode, you can enter address family configuration for the neighbor by using the address-family command, which allows you to configure routing sessions for IP Version 4 and IP Version 6 address prefixes. The neighbor command does not cause the neighbor to be configured and does not result in a peering to be established with the neighbor. To create the neighbor, you configure a remote autonomous system number by entering the remote-as command, or the neighbor can inherit a remote autonomous system from a neighbor group or session group if the use command is applied.



Note A neighbor must have a remote autonomous system number, and an IP address and address family must be enabled on the neighbor.

Unlike IPv4, IPv6 must be enabled before any IPv6 neighbors can be defined. Enable IPv6 in router configuration mode using the **address-family** command.



Note Configuration for the neighbor cannot occur (peering is not established) until the neighbor is given a remote as-number and neighbor address.

The **no** form of this command causes the peering with the neighbor to be terminated and all configuration that relates to the neighbor to be removed.

Task ID	Task ID	Operations
	bgp	read, write

Examples

The following example shows how to place the router in neighbor configuration mode for BGP routing process 1 and configure the neighbor IP address 172.168.40.24 as a BGP peer:

```
Router(config)# router bgp 1  
Router(config-bgp)# neighbor 172.168.40.24  
Router(config-bgp-nbr)# remote-as 65000
```

The following example shows how to enable IPv6 for BGP, then place the router in neighbor configuration mode for an IPv6 neighbor, 3000::1, and configure neighbor 3000::1 as a BGP peer:

```
Router(config)# router bgp 100  
Router(config-bgp)# address-family ipv6 unicast  
Router(config-bgp-af)# exit  
Router(config-bgp)# neighbor 3000::1  
Router(config-bgp-nbr)# remote-as 2002  
Router(config-bgp-nbr)# address-family ipv6 unicast
```

Related Commands

Command	Description
Address family	Enters address family configuration mode for configuring BGP routing sessions.
Remote	Adds an entry to the BGP neighbor table.
Use	Inherits characteristics from a neighbor group, session group, or address family group.

neighbor-group

To create a neighbor group and enter neighbor group configuration mode, use the **neighbor-group** command in Global Configuration mode and XR Config mode. To remove a neighbor group and delete all configuration associated with the group, use the **no** form of this command.

neighbor-group *name*

Syntax Description

name Neighbor group name.

Command Default

No neighbor group mode is specified.

Command Modes

Global Configuration mode and XR Config mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

The **neighbor-group** command puts the router in neighbor group configuration mode and creates a neighbor group.

A neighbor group helps you apply the same configuration to one or more neighbors. After a neighbor group is configured, each neighbor can inherit the configuration through the **use** command. If a neighbor is configured to use a neighbor group, the neighbor, by default, inherits the entire configuration of the neighbor group, which includes the address family-independent and address family-specific configurations. The inherited configuration can be overridden if you directly configure commands for the neighbor or if you configure session groups or address family groups with the **use** command.

From neighbor group configuration mode, you can configure address family-independent parameters for the neighbor group. To enter address family-specific configuration for the neighbor group, use the **address-family** command when in the neighbor group configuration mode.



Note If an address family is configured for a neighbor group, neighbors that use the neighbor group attempt to exchange routes in that address family.

The **no** form of this command ordinarily causes all configuration for the neighbor group to be removed. If using the **no** form would result in a neighbor losing its remote autonomous system number, the configuration is rejected. In this scenario, the neighbor configuration must be either removed or configured with a remote autonomous system number before the neighbor group configuration can be removed.



Note Neighbor groups should not be configured with a mixture of IPv4 and IPv6 address families, because such a neighbor group is not usable by any neighbor. Note that within the Cisco IOS XR system configuration architecture, it is possible to create such a neighbor group; however, any attempt to use it is rejected.

Examples

The following example shows how to create a neighbor group called group1 that has IP Version 4 (IPv4) unicast and IPv4 multicast activated along with various configuration features. The neighbor group is used by neighbor 10.0.0.1 and neighbor 10.0.0.2, which allows them to inherit the entire group1 configuration.

```
Router(config)# router bgp 65530
Router(config-bgp)# neighbor-group group1
Router(config-bgp-nbrgrp)# remote-as 65535
Router(config-bgp-nbrgrp)# advertisement-interval 2
Router(config-bgp-nbrgrp)# address-family ipv4 unicast
Router(config-bgp-nbrgrp-af)# send-community-ebgp
Router(config-bgp-nbrgrp-af)# exit
Router(config-bgp-nbrgrp)# address-family ipv4 multicast
Router(config-bgp-nbrgrp-af)# next-hop-self
Router(config-bgp-nbrgrp-af)# exit
Router(config-bgp-nbrgrp)# exit
Router(config-bgp)#neighbor 10.0.0.1
Router(config-bgp-nbr)# use neighbor-group group1
Router(config-bgp-nbr)# exit
Router(config-bgp)# neighbor 10.0.0.2
Router(config-bgp-nbr)# use neighbor-group group1
Router(config-bgp-nbr)# exit
```

neighbor internal-vpn-client

To preserve the iBGP-CE (customer edge) attributes inside the VPN attribute set (ATTR-SET) and send it across to the core, use the **neighbor internal-vpn-client** command in the VRF neighbor configuration mode. To disable the command, use the **no** form of this command.

neighbor *ip-address* **internal-vpn-client**

no neighbor *ip-address* **internal-vpn-client**

Syntax Description

neighbor <i>ip-address</i>	IP address of the neighboring device.
internal-vpn-client	Stacks the iBGP-CE neighbor path in the VPN attribute set.

Command Default

None

Command Modes

VRF neighbor configuration

Usage Guidelines

The **neighbor** *ip-address* **internal-vpn-client** command enables PE devices to make the entire VPN cloud act as an internal VPN client to the CE devices connected internally. This command is used so that existing internal BGP VRF lite scenarios are not affected. You need not configure autonomous system override for CE devices after enabling this command.

Examples

The following example shows how to configure L3VPN iBGP PE-CE:

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# vrf blue neighbor 10.10.10.1
Router(config-bgp-vrf-nbr)# internal-vpn-client
```

network (BGP)

To specify that the Border Gateway Protocol (BGP) routing process should originate and advertise a locally known network to its neighbors, use the **network** command in an appropriate configuration mode. To disable originating or advertising the network to neighbors, use the **no** form of this command.

network { *ip-address/prefix-length* *ip-address mask* } [**route-policy** *route-policy-name*]
no network { *ip-address/prefix-length* *ip-address mask* } [**route-policy** *route-policy-name*]

Syntax Description	<i>ip-address</i>	Network that BGP advertises.
	<i>/prefix-length</i>	Length of the IP address prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash (/) must precede the decimal value.
	<i>ip-address mask</i>	Network mask applied to the <i>ip-address</i> argument.
	route-policy <i>route-policy-name</i>	(Optional) Specifies a route policy to use to modify the attributes of the network.

Command Default No networks are specified.

Command Modes IPv4 address family configuration
 IPv6 address family configuration

Usage Guidelines A network specified with this command is originated and advertised to neighbors only if there exists a route for the network in the routing table. That is, there must be a route learned using local or connected networks, static routing, or a dynamic IGP such as IS-IS or OSPF.

Other than the available system resources on the router, no limit exists on the number of network commands that can be configured.

Examples

The following example shows how to configure the local router to originate the IPv4 unicast network 172.20.0.0/16:

```
Router(config)#router bgp 120
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp-af)# network 172.20.0.0/16
```

Related Commands

Command	Description
Network backdoor	Specifies a backdoor route to a BGP border router that provides better information about the network.
Route BGP	Redistributes routes from one routing domain into another routing domain.

network backdoor

To set the administrative distance on an external Border Gateway Protocol (eBGP) route to that of a locally sourced BGP route, causing it to be less preferred than an Interior Gateway Protocol (IGP) route, use the **network backdoor** command in an appropriate configuration mode. To disable setting the administrative distance to the value for locally sourced BGP routes, use the **no** form of this command.

network { *ip-address/prefix-length ip-address mask* } **backdoor**
no network { *ip-address/prefix-length ip-address mask* } **backdoor**

Syntax Description

<i>ip-address</i>	Network that provides a backdoor route.
<i>/ prefix-length</i>	Length of the IP address prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash (/) must precede the decimal value.
<i>mask</i>	Network mask applied to the <i>ip-address</i> argument.

Command Default

No backdoor routes are installed.

Command Modes

IPv4 address family configuration
 IPv6 address family configuration

Usage Guidelines

Configuring the **network backdoor** command does not cause BGP to originate a network, even if an IGP route for the network exists. Ordinarily, the backdoor network would be learned through both an eBGP and IGP. The BGP best-path selection algorithm does not change when a network is configured as a backdoor network.

Examples

The following example shows IP Version 4 (IPv4) unicast network 192.168.40.0/24 configured as a backdoor network:

```
Router(config)# router bgp 109
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp-af)# network 192.168.40.0/24 backdoor
```

Related Commands

Command	Description
Network BGP	Specifies a local network that the BGP routing process should originate and advertise to its neighbors.

next-hop-self

To disable next-hop calculation and insert your own address in the next-hop field of Border Gateway Protocol (BGP) updates, use the **next-hop-self** command in an appropriate configuration mode. To enable next-hop calculation, use the **no** form of this command.

```
next-hop-self [ inheritance-disable ]
no next-hop-self [ inheritance-disable ]
```

Syntax Description	inheritance-disable (Optional) Allows a next-hop calculation override when this feature may be inherited from a neighbor group or address family group.
Command Default	When this command is not specified, the software calculates the next hop for BGP updates accepted by the router.
Command Modes	IPv4 address family group configuration IPv6 address family group configuration IPv4 neighbor address family configuration IPv4 neighbor group address family configuration IPv6 neighbor group address family configuration
Usage Guidelines	Use the next-hop-self command to set the BGP next-hop attribute of routes being advertised over a peering session to the local source address of the session. This command is useful in nonmeshed networks in which BGP neighbors may not have direct access to all other neighbors on the same IP subnet. If this command is configured for a neighbor group or address family group, a neighbor using the group inherits the configuration. Configuring the command specifically for a neighbor overrides any inherited value.
Examples	The following example shows how to set the next hop of the update field for all IP Version 4 (IPv4) unicast routes advertised to neighbor 172.20.1.1 to an address of the local router: <pre>Router(config)# router bgp 140 Router(config-bgp)# neighbor 172.20.1.1 Router(config-bgp-nbr)# remote-as 1 Router(config-bgp-nbr)# address-family ipv4 unicast Router(config-bgp-nbr-af)# next-hop-self</pre> The following example shows how to disable the next-hop-self command for neighbor 172.20.1.1. If not overridden, the next hop would be inherited from address family group group1: <pre>Router(config)# router bgp 140 Router(config-bgp)# af-group group1 address-family ipv4 unicast Router(config-bgp-afgrp)# next-hop-self Router(config-bgp-afgrp)# exit Router(config-bgp)# neighbor 172.20.1.1 Router(config-bgp-nbr)# remote-as 1</pre>

```
Router(config-bgp-nbr)# address-family ipv4 unicast  
Router(config-bgp-nbr-af)# use af-group group1  
Router(config-bgp-nbr-af)# next-hop-self inheritance-disable
```

Related Commands

Command	Description
Address Family	Creates an address family group for BGP neighbors and enters address family group configuration mode.
Neighbor Group	Creates a neighbor group and enters neighbor group configuration mode.
Use	Inherits characteristics from a neighbor group, session group, or address family group.

next-hop-unchanged

To disable overwriting of the next hop before advertising to external Border Gateway Protocol (eBGP) peers, use the **next-hop-unchanged** command in an appropriate configuration mode. To enable overwriting of the next hop, use the **no** form of this command.

next-hop-unchanged [**inheritance-disable**]
no next-hop-unchanged [**inheritance-disable**]

Syntax Description	inheritance-disable (Optional) Allows overwriting of the next hop before advertising to eBGP peers when this feature may be inherited from a neighbor group or address family group.
Command Default	Overwriting of the next hop is allowed.
Command Modes	IPv4 labeled-unicast address family configuration IPv6 labeled-unicast address family configuration IPv4 address family configuration IPv6 address family configuration
Usage Guidelines	Use the next-hop-unchanged command to propagate the next hop unchanged for multihop eBGP peering sessions. This command should not be configured on a route reflector, and the next-hop-self command should not be used to modify the next-hop attribute for a route reflector when this feature is enabled for a route reflector client.



Note Incorrectly setting BGP attributes for a route reflector can cause inconsistent routing, routing loops, or a loss of connectivity. Setting BGP attributes for a route reflector should be attempted only by an experienced network operator.

Examples

The following example shows how to disable the overwriting of next hops before advertising to eBGP peers:

```
Router(config)# router bgp 140
Router(config-bgp)# af-group group1 address-family ipv4 unicast
Router(config-bgp-afgrp)# next-hop-unchanged disable
Router(config-bgp-afgrp)# exit
```

Related Commands	Command	Description
	Next-hop Self	Disables next-hop calculation and allows you to insert your own address in the next-hop field of BGP updates.
	Use	Inherits characteristics from a neighbor group, session group, or address family group.

nexthop resolution prefix-length minimum

To set minimum prefix-length for nexthop resolution, use the **nexthop resolution prefix-length minimum** command in an appropriate configuration mode. To disable the minimum prefix-length for nexthop resolution, use the **no** form of this command.

nexthop resolution prefix-length minimum *prefix-length-value*
no nexthop resolution prefix-length minimum *prefix-length-value*

Syntax Description	<i>prefix-length-value</i> Sets the minimum prefix-length. Range is 0 to 32.

Command Default	Nexthop resolution for minimum prefix-length is disabled.

Command Modes	VPNv4 Unicast address family VRF IPv4 Unicast address family

This example shows how to set the minimum prefix-length for nexthop resolution as 32:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#address-family vpnv4 unicast
Router(config-bgp-af)#nexthop resolution prefix-length minimum 32
```


nexthop route-policy

To specify that BGP routes are resolved using only next hops whose routes match specific characteristics, use the **nexthop route-policy** command in the appropriate configuration mode. To remove the **nexthop route-policy** command from the configuration file and restore the system to its default behavior, use the **no** form of this command.

```
nexthop route-policy route-policy-name
no nexthop route-policy route-policy-name
```

Syntax Description

route-policy-name Route policy to use for filtering based on next hops.

Command Default

No default behavior or values

Command Modes

IPv4 address family configuration
IPv6 address family configuration

Usage Guidelines

Use the **nexthop route-policy** command to configure route policy filtering using next hops.

The BGP next-hop tracking feature allows you to specify that BGP routes are resolved using only next hops whose routes have the following characteristics:

- To avoid the aggregate routes, the prefix length must be greater than a specified value.
- The source protocol must be from a selected list, ensuring that BGP routes are not used to resolve next hops that could lead to oscillation.

This route policy filtering is possible because RIB identifies the source protocol of a route that resolves a next hop as well as the mask length associated with the route.

The next-hop attach point supports matching using the protocol name and mask length. BGP marks all next hops that are rejected by the route policy as invalid, and no best path is calculated for the routes that use the invalid next hop. The invalid next hops continue to stay in the active cache and can be displayed as part of the **show bgp nexthop** command with an invalid status.

Examples

The following example shows how to specify the route policy nexthop_A as the policy to use for filtering next hops:

```
Router(config)# router bgp 109
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp-af)# nexthop route-policy nexthop_A
```

Related Commands

Command	Description
route-policy (RPL)	Defines a route policy and enters route-policy configuration mode.
BGP Next-hops	Display statistical information about the BGP next hops.

nexthop trigger-delay

To specify the delay for triggering next-hop calculations, use the **nexthop trigger-delay** command in the appropriate configuration mode. To set the trigger delay to the default value, use the **no** form of this command.

```
nexthop trigger-delay { critical delay | non-critical delay }
no nexthop trigger-delay { critical delay | non-critical delay }
```

Syntax Description	critical	Specifies critical next-hop events. For example, when the next hop is unreachable.
	delay	Trigger delay, in milliseconds. Range is 0 to 4294967295.
	non-critical	Specifies noncritical next-hop events. For example, Interior Gateway Protocol (IGP) metric changes.
Command Default	critical : 3000 msec for all address families, except VPNv4 and VPNv6 address families critical : 50 msec for VPNv4 and VPNv6 address families non-critical : 10000 msec for all address families	
Command Modes	All address families	
Usage Guidelines	Use the nexthop trigger-delay command to allow for a dynamic way for Interior Gateway Protocol (IGP) to converge. This convergence allows BGP to accumulate all notifications and trigger fewer walks, resulting in fewer interprocess communications (IPCs) to the Routing Information Base (RIB) for route addition, deletion, and modification and fewer updates to peers.	



Note A high *delay* value can be configured to effectively turn off next-hop tracking.

The **non-critical delay** value must always be set to at least equal or greater than the **critical delay value**.

The *delay* should be slightly higher than the time it takes for the IGP to settle into a steady state after some event (IGP convergence time).

Avoid configuring the **nexthop trigger-delay critical 0** as it is not suitable on:

- Scaled deployments where a long BGP next-hop walk time duration is inevitable.
- Deployments where BGP next-hop changes are frequent.

Disadvantages of nexthop trigger-delay critical 0 configuration

- High CPU utilization as each change notification triggers a BGP next-hop walk for address families configured with **nexthop trigger-delay critical 0**.
- BGP next-hop change notifications are not batched. This disallows interleaving of next-hop walks in address families with the non-zero delay configuration as these address families wait until the address families with the zero critical delay value complete their next-hop walks.

- Extended wait time before the BGP next-hop walk starts on address families with the non-zero critical delay configuration, leading to potential traffic blackholing.

Starting with Cisco IOS XR Release 7.10.1, the default critical delay configuration in VPNv4 address family was changed from 0 msec to 50 msec. With this change, all address families have a default non-zero critical delay value. To see the critical delay value of each address family, run the **show bgp all all nexthops** command.

After you have upgraded to Cisco IOS XR Release 7.10.1 or later, if you configure the default critical delay value in the IPv4 address family to 0 msec, you will observe a considerable delay in VPNv4 convergence for the following reasons:

- The IPv4 address families are walked as many times as the number of next-hop critical alerts raised to BGP.
- The BGP next-hop updates for the IPv4 address family prefixes take precedence over VPNv4 address family prefixes.

Advantages of configuring **nexthop trigger-delay critical** with a non-zero default value

- Provides next-hop change notification batching which reduces the number of BGP next-hop walks.
- Allows interleaving different active BGP next-hop walks for the respective address families while prioritizing some address families over the others.

Therefore, we strongly recommend you to configure **nexthop trigger-delay critical** with a non-zero value.

Examples

The following example shows how to set the critical next-hop trigger delay to 3500 milliseconds:

```
Router(config)# router bgp 109  
Router(config-bgp)# address-family ipv4 unicast  
Router(config-bgp-af)# nexthop trigger-delay critical 3500
```

nsr (BGP)

To activate Border Gateway Protocol (BGP) nonstop routing (NSR), use the **nsr** command in BGP mode. To deactivate BGP NSR, use the **no** form of this command.

nsr

Syntax Description

This command has no arguments or keywords.

Command Default

BGP NSR is not activated.

Command Modes

Usage Guidelines

Use the **nsr** command to enable the Border Gateway Protocol (BGP) Nonstop Routing (NSR) with Stateful Switchover (SSO). This enables all bgp peerings to maintain the BGP state to ensure continuous packet forwarding during events that could interrupt service.

Task ID

Task Operations

bgp read,
write

Examples

The following example shows how to enable BGP NSR:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# router bgp 120
RP/0/RP0/CPU0:router(config-bgp)# nsr
```

The following example shows how to disable BGP NSR:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# router bgp 120
RP/0/RP0/CPU0:router(config-bgp)# no nsr
```

orf

To specify Outbound Route Filter (ORF) and inbound filtering criteria, use the **orf route-policy** command in an appropriate configuration mode. To restore the system to its default condition, use the **no** form of this command.

```
orf route-policy route-policy-name
no orf route-policy route-policy-name
```

Syntax Description	<i>route-policy-name</i> Name of the route policy.

Command Default	No ORF route policy is defined.

Command Modes	IPv4 address family group configuration IPv6 address family group configuration IPv4 neighbor address family configuration IPv4 neighbor group address family configuration IPv6 neighbor group address family configuration

Examples

The following example shows how to configure outbound and inbound filtering criteria:

```
Router(config)#router bgp 6
Router(config-bgp)# neighbor 172.20.1.1
Router(config-bgp-nbr)# remote-as 1
Router(config-bgp-nbr)# address-family ipv4 unicast
Router(config-bgp-nbr-af)#orf route-policy policy_A
```

Related Commands

Command	Description
Routing Policy	Applies a routing policy to updates advertised to or received from a BGP neighbor.

password (BGP)

To enable Message Digest 5 (MD5) authentication on a TCP connection between two Border Gateway Protocol (BGP) neighbors, use the **password** command in an appropriate configuration mode. To disable MD5 authentication, use the **no** form of this command.

```
password { clear | encrypted } password
no password [ clear password | encrypted password ]
```

Syntax Description

clear	Specifies that an unencrypted password follows. The password must be a case-sensitive, clear-text unencrypted password.
encrypted	Specifies that an encrypted password follows. The password must be a case-sensitive, encrypted password.
<i>password</i>	Password of up to 80 characters. The password can contain any alphanumeric characters. However, if the first character is a number or the password contains a space, the password must be enclosed in double quotation marks; for example, "2 password."

Command Default

When this command is not specified in the appropriate configuration mode, MD5 authentication is not enabled on a TCP connection between two BGP neighbors.

Command Modes

Neighbor configuration
 Neighbor group configuration
 Session group configuration

Usage Guidelines

Configure a password to enable authentication between two BGP peers. Use the **password** command to verify each segment sent on the TCP connection between the peers. The same password must be configured on both networking devices, otherwise a connection cannot be made. The authentication feature uses the MD5 algorithm. Specifying this command causes the software to generate and check the MD5 digest on every segment sent on the TCP connection.

Configuring a neighbor password does not cause the existing session for a neighbor to end. However, until the new password is configured on the remote router, the local BGP process does not receive keepalive messages from the remote device. If the password is not updated on the remote device by the end of the hold time, the session ends. The hold time can be changed using the **timers** command or the **timers bgp** command.

If this command is configured for a neighbor group or neighbor address family group, a neighbor using the group inherits the configuration. Values of commands configured specifically for a neighbor overrides inherited values.

Examples

The following example shows how to configure neighbor 172.20.1.1 to use MD5 authentication with the password password1:

```
Router(config)# router bgp 140
Router(config-bgp)#neighbor 172.20.1.1
Router(config-bgp-nbr)#remote-as 1
Router(config-bgp-nbr)#password clear password1
```

Related Commands

Command	Description
Neighbor Group	Creates a neighbor group and enters neighbor group configuration mode.
Password Disable	Overrides any inherited password configuration from a neighbor group or session group for BGP neighbors.
Session Group	Creates a session group and enters session group configuration mode.
Timers BGP	Set the timers for a specific BGP neighbor.

password (rpki-server)

To specify a SSH password for the RPKI cache-server, use the **password** command in rpki-server configuration mode. To remove the SSH passwords, use the **no** form of this command.

```
password password
no password password
```

Syntax Description

password Enters a password to be used for the SSH transport mechanism.

Command Default

Password is not configured.

Command Modes

RPKI server configuration

Usage Guidelines

SSH expects to use an authentication method to connect to a remote server. The SSH authentication method to connect to RPKI server is password-based. So, the RPKI cache-server must be configured with username and password. A username and password must be configure for each server configured under BGP that uses the SSH transport

This example shows how to configure a username (*rpki-user*) and password (*rpki-ssh-pass*) for the RPKI cache-server SSH transport mechanism:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#rpki server 172.168.35.40
Router(config-bgp-rpki-server)# transport ssh port 22
Router(config-bgp-rpki-server)#username rpki-user
Router(config-bgp-rpki-server)#password rpki-ssh-pass
```


password-disable

To override any inherited password configuration from a neighbor group or session group for Border Gateway Protocol (BGP) neighbors, use the **password-disable** command in an appropriate configuration mode. To disable overriding any inherited password command, use the **no** form of this command.

password-disable
no password-disable

Syntax Description	This command has no arguments or keywords.
Command Default	Configured passwords for neighbor and session groups are inherited.
Command Modes	Neighbor configuration Neighbor group configuration Session group configuration
Usage Guidelines	If you specify a password on a neighbor group or session group, all users of the group inherit the password. Specifying a different password command specifically on a neighbor that uses the group overrides the inherited value. Specifying password-disable on a neighbor that uses the group disables password authentication for the neighbor.

Examples

The following example shows how to disable MD5 authentication for neighbor 172.20.1.1, preventing it from inheriting the password password1 from session group group1:

```
Router(config)# router bgp 140
Router(config-bgp)# session-group group1
Router(config-bgp-sngrp)# password clear password1
Router(config-bgp-sngrp)# exit
Router(config-bgp)# neighbor 172.20.1.1
Router(config-bgp-nbr)# remote-as 2
Router(config-bgp-nbr)# use session-group group1
Router(config-bgp-nbr)# password-disable
```

Related Commands	Command	Description
	Neighbor Group	Creates a neighbor group and enters neighbor group configuration mode.
	BGP Password	Enables MD5 authentication on a TCP connection between two BGP neighbors.
	Session Group	Creates a session group and enters session group configuration mode.
	Use	Inherits characteristics from a neighbor group, a session group, or an address family group.

permanent-network

To define a prefix set as permanent, use the **permanent-network** command in the global address family configuration mode. To remove a prefix set as permanent, use the **no** form of this command. The **permanent-network** command uses a route-policy to identify the set of prefixes (networks) for which permanent paths needs to be created.

The permanent network feature supports only prefixes in IPv4 unicast and IPv6 unicast address-families under the default Virtual Routing and Forwarding (VRF).

permanent-network *route-policy route-policy-name*
no permanent-network

Syntax Description	route-policy <i>route-policy-name</i>	Specifies a configured routing policy.

Command Default	None

Command Modes	Address-family configuration.

Examples

This example shows how to define permanent path for a route policy named POLICY-PERMANENT-NETWORK-IPv4:

```
Router# configure
Router(config)# router bgp 100
Router(config-bgp)# address-family ipv4 unicast
Router(config-af)# permanent-network route-policy POLICY-PERMANENT-NETWORK-IPv4
```

prefix-ecmp-delay

To configure ECMP delay duration and the resource usage threshold limit in BGP, use the **prefix-ecmp-delay** *interval_value* **oor-threshold** *threshold_value* command in address-family configuration mode.

prefix-ecmp-delay *interval_value* **oor-threshold** *threshold_value*

Syntax Description	<i>interval_value</i>	Specifies the duration at which the route updates are delayed.
	<i>threshold_value</i>	Specifies the resource usage threshold.

Command Default	No default behavior or values

Command Modes	IPv4/IPv6 address-family configuration

Command History	Release	Modification
	Release 24.2.1	This command was introduced.

Usage Guidelines	None.

Examples

The following example shows how to configure a delay of 10 seconds when the resource usage exceeds a threshold of 30%:

```
router bgp 100
  address-family ipv4 unicast
    prefix-ecmp-delay 10000 oor-threshold 30
```

rd

To configure a route distinguisher, use the **rd** command in VRF configuration mode. To disable the route distinguisher, use the **no** form of this command.

```
rd { as-number : nn | ip-address : nn | auto }
no rd { as-number : nn | ip-address : nn | auto }
```

Syntax Description

<i>as-number:nn</i>	<i>as-number</i> —16-bit Autonomous system (AS) number of the route distinguisher - Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. - Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. - Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535. <i>nn</i> —32-bit number
<i>ip-address:nn</i>	IP address of the route distinguisher. <i>ip-address</i> —32-bit IP address <i>nn</i> —16-bit number
auto	Automatically assigns a unique route distinguisher.

Command Default

No default behavior or values

Command Modes

VRF configuration

Usage Guidelines

Use the **rd** command to make the prefix unique across multiple VRFs.

Auto assignment of route distinguishers can be done only if a router ID is assigned using the **bgp router-id** command in BGP router configuration mode. The unique router ID is used for automatic route distinguisher generation.

The following are restrictions when configuring route distinguishers:

- BGP router-id must be configured before **rd auto** can be configured.
- Route distinguisher cannot be changed or removed when an IPv4 unicast address family is configured under VRF.
- BGP router-id cannot be changed or removed when **rd auto** is configured under a VRF.
- When **rd auto** is configured under a VRF, the IP address for the router distinguisher configured under another VRF must be different from that of the BGP router-id.
- If a route distinguisher with same IP address as BGP router-id exists, the **rd auto** is not permitted.

Examples

The following example shows how to automatically assign a unique route distinguisher to VRF instance vrf-1:

```
Router(config)# router bgp 1  
Router(config-bgp)# vrf vrf-1  
Router(config-bgp-vrf)# rd auto
```

Related Commands

Command	Description
BGP Router ID	Configures a fixed router ID for a BGP-speaking router.
Export Route Target	Configures a VRF export route-target extended community.
Import ROute Target	Configures a VRF import route-target extended community.

receive-buffer-size

To set the size of the receive buffers for a Border Gateway Protocol (BGP) neighbor, use the **receive-buffer-size** command in an appropriate configuration mode. To remove the **receive-buffer-size** command from the configuration file and restore the system to its default condition in which the software uses the default size, use the **no** form of this command.

```
receive-buffer-size socket-size [ bgp-size ]
no receive-buffer-size [ socket-size ] [ bgp-size ]
```

Syntax Description

socket-size Size, in bytes, of the receive-side socket buffer. Range is 512 to 131072.

bgp-size (Optional) Size, in bytes, of the receive buffer in BGP. Range is 512 to 131072.

Command Default

socket-size : 32,768 bytes

bgp-size : 4,032 bytes

Command Modes

Neighbor configuration

Neighbor group configuration

Session group configuration

Usage Guidelines

Use the **receive-buffer-size** command to increase the buffer size when receiving updates from a neighbor. Using larger buffers can improve convergence time because it allows the software to process a larger number of packets simultaneously. However, allocating larger buffers consumes more memory on the router.



Note Increasing the socket buffer size uses more memory only when more messages are waiting to be processed by the software. In contrast, increasing the BGP buffer size uses extra memory indefinitely.

If this command is configured for a neighbor group or session group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.

Examples

The following example shows how to set the receive buffer sizes for neighbor 172.20.1.1 to be 65,536 bytes for the socket buffer and 8192 bytes for the BGP buffer:

```
Router(config)# router bgp 1
Router(config-bgp)# neighbor 172.20.1.1
Router(config-bgp-nbr)# remote-as 1
Router(config-bgp-nbr)# receive-buffer-size 65536 8192
```

Related Commands

Command	Description
Neighbor Group	Creates a neighbor group and enters neighbor group configuration mode.
Send Buffer Size	Sets the size of the send buffers for a BGP neighbor.

Command	Description
Session Group	Creates a session group and enters session group configuration mode.
Receive Buffer Size	Sets the size of the receive buffers for all BGP neighbors.

redistribute (BGP)

To redistribute routes from one routing domain into Border Gateway Protocol (BGP), use the **redistribute** command in an appropriate configuration mode. To disable route redistribution, use the **no** form of this command.

Connected

```
redistribute connected [metric metric-value] [route-policy route-policy-name]
no redistribute connected [metric metric-value] [route-policy route-policy-name]
```

Enhanced Interior Gateway Routing Protocol (EIGRP)

```
redistribute eigrp process-id [match {external | internal}] [metric metric-value] [
route-policy route-policy-name]
no redistribute eigrp process-id [match {external | internal}] [metric metric-value]
[route-policy route-policy-name]
```

Intermediate System-to-Intermediate System (IS-IS)

```
redistribute isis process-id [level {1 | 1-inter-area | 2}] [metric metric-value] [
route-policy route-policy-name]
no redistribute isis process-id [level {1 | 1-inter-area | 2}] [metric metric-value]
[route-policy route-policy-name]
```

Open Shortest Path First (OSPF)

```
redistribute ospf process-id
no redistribute ospf process-id
```

Routing Information Protocol

```
redistribute rip [metric metric-value] [route-policy route-policy-name]
no redistribute rip [metric metric-value] [route-policy route-policy-name]
```

Static

```
redistribute static [metric metric-value] [route-policy route-policy-name]
no redistribute static [metric metric-value] [route-policy route-policy-name]
```

Syntax Description		
connected		Redistributes connected routes. Connected routes are established automatically when IP is enabled on an interface.
metric <i>metric-value</i>		(Optional) Specifies the Multi Exit Discriminator (MED) attribute used for the redistributed route. Range is 0 to 4294967295. Use a value consistent with the destination protocol. By default, the Interior Gateway Protocol (IGP) metric is assigned to the route. For connected and static routes the default metric is 0.
route-policy <i>route-policy-name</i>		(Optional) Specifies a configured routing policy to filter redistributed routes. A route policy is used to filter the importation of routes from this source routing protocol to BGP.
eigrp		Specifies that routes are distributed from EIGRP. You must be in IPv4 unicast address family configuration mode.

<i>process-id</i>	For the eigrp keyword, an EIGRP instance name from which routes are to be redistributed. For the isis keyword, an IS-IS instance name from which routes are to be redistributed. For the ospf keyword, an OSPF instance name from which routes are to be redistributed. The <i>process-id</i> value takes the form of a string. A decimal number can be entered, but it is stored internally as a string.
match { internal external [1 2] nssa-external [1 2] }	(Optional) Specifies the criteria by which OSPF routes are redistributed into other routing domains. It can be one or more of the following: • internal —Routes that are internal to a specific autonomous system (intra- and inter-area OSPF routes). • external [1 2]—Routes that are external to the autonomous system, but are imported into OSPF as Type 1 or Type 2 external routes. • nssa-external [1 2]—Routes that are external to the autonomous system, but are imported into OSPF as Type 1 or Type 2 not-so-stubby area (NSSA) external routes. For the external and nssa-external options, if a type is not specified, then both Type 1 and Type 2 are assumed.
isis	Specifies that routes are distributed from the IS-IS protocol. Redistribution from IS-IS is allowed under IPv4 unicast, IPv6 unicast, and address-families.
level { 1 1-inter-area 2 }	(Optional) Specifies the IS-IS level from which routes are redistributed. It can be one of the following: • 1 —Routes are redistributed from Level 1 routes. • 1-inter-area —Routes are redistributed from Level 1 interarea routes. • 2 —Routes are redistributed from Level 2 routes.
ospf	Specifies that routes are distributed from the OSPF protocol. You must be in IPv4 unicast address family configuration mode.
rip	Specifies that routes are distributed from RIP. You must be in IPv4 unicast address family configuration mode.
static	Redistributes IP static routes.

Command Default

Route redistribution is disabled.

For IS-IS, the default is to redistribute Level 1 and Level 2 routes.

For OSPF, the default is to redistribute internal, external, and NSSA external routes of Type 1 and Type 2.

By default, the Interior Gateway Protocol (IGP) metric is assigned to the route. For connected and static routes the default metric is 0.

metric *metric-value*: 0

match { **internal** | **external** [1 | 2] | **nssa-external** [1 | 2] }: If no match is specified, the default is to match all routes.

Command Modes

IPv4 address family configuration (**connected**, **eigrp**, **isis**, **ospf**, **rip**, and **static** are supported)

IPv6 address family configuration (**connected**, **eigrp**,
isis,

ospfv3,
and **static** are supported)

Usage Guidelines



Note When redistributing routes (into BGP) using both command keywords for setting or matching of attributes and a route policy, the routes are run through the route policy first, followed by the keyword matching and setting.

Each instance of a protocol may be redistributed independently of the others. Changing or removing redistribution for a particular instance does not affect the redistribution capability of other protocols or other instances of the same protocol.

Networks specified using the **network** command are not affected by the **redistribute** command; that is, the routing policy specified in the **network** command takes precedence over the policy specified through the **redistribute** command.

Examples

The following example shows how to redistribute IP Version 4 (IPv4) unicast OSPF routes from OSPF instance 110 into BGP:

```
Router(config)# router bgp 109
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp-af)# redistribute ospf 110
```

Related Commands

Command	Description
Network BGP	Specifies a local network that the BGP routing process should originate and advertise to its neighbors.

remove-private-as

To remove private autonomous system numbers from autonomous system paths when generating updates to external neighbors, use the **remove-private-as** command in an appropriate configuration mode. To place the router in the default state in which it does not remove private autonomous system numbers, use the **no** form of this command.

```
remove-private-as [ inheritance-disable ] [ entire-aspath ]
no remove-private-as [ inheritance-disable ] [ entire-aspath ]
```

Syntax Description	inheritance-disable (Optional) Permits the feature to be disabled from a neighbor group or address family group instead of being inherited. entire-aspath (Optional) Removes the entire private autonomous system numbers from an autonomous system path only if all ASes in the path are private.
Command Default	When this command is not specified in the appropriate configuration mode, private autonomous system numbers are not removed from updates sent to external neighbors.
Command Modes	IPv4 address family group configuration IPv6 address family group configuration IPv4 neighbor address family configuration IPv4 neighbor group address family configuration IPv6 neighbor group address family configuration
Usage Guidelines	This feature is available for external BGP (eBGP) neighbors only. When an update is passed to the external neighbor, the system drops any private autonomous system numbers. This happens irrespective of whether the autonomous system numbers are at the beginning or in the middle of the AS_SEQUENCE. If this command is used in a BGP confederation, the element following the confederation portion of the autonomous system path, if a sequence, is considered the leading sequence. The private autonomous system values range from 64512 to 65535. If this command is configured for a neighbor group or address family group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values. Use the entire-aspath to removes the entire private autonomous system numbers from an autonomous system path only if all ASes in the path are private.

Examples

The following example shows a configuration that removes the private autonomous system number from the IP Version 4 (IPv4) unicast updates sent to 172.20.1.1:

```
Router(config)# router bgp 140
Router(config-bgp)# neighbor 172.20.1.1
Router(config-bgp-nbr)# remote-as 1
Router(config-bgp-nbr)# address-family ipv4 unicast
```

```
Router(config-bgp-nbr-af) # remove-private-as
```

The following example shows how to disable the remove private autonomous system number feature for neighbor 172.20.1.1, preventing this feature from being automatically inherited from address family group group1:

```
Router(config)# router bgp 140
Router(config-bgp) # af-group group1 address-family ipv4 unicast
Router(config-bgp-afgrp) # remove-private-as
Router(config-bgp-afgrp) # exit
Router(config-bgp) # neighbor 172.20.1.1
Router(config-bgp-nbr) # remote-as 1
Router(config-bgp-nbr) # address-family ipv4 unicast
Router(config-bgp-nbr-af) # use af-group group1
Router(config-bgp-nbr-af) # remove-private-as inheritance-disable
```

Related Commands

Command	Description
AF Group	Creates an address family group for BGP neighbors and enters address family group configuration mode.
Neighbor Group	Creates a neighbor group and enters neighbor group configuration mode.
Remote as BGP	Allows entries to the BGP neighbor table.

remote-as (BGP)

To create a Border Gateway Protocol (BGP) neighbor and begin the exchange of routing information, use the **remote-as** command in an appropriate configuration mode. To delete the entry for the BGP neighbor, use the **no** form of this command.

```
remote-as as-number
no remote-as [ as-number ]
```

Syntax Description	<i>as-number</i> Autonomous system (AS) to which the neighbor belongs. • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535.
Command Default	No BGP neighbors exist.
Command Modes	Neighbor configuration Neighbor group configuration Session group configuration
Usage Guidelines	Use the remote-as command to create a neighbor and assign it a remote autonomous system number. A neighbor must have a remote autonomous system number before any other commands can be configured for it. Removing the remote autonomous system from a neighbor causes the neighbor to be deleted. You cannot remove the autonomous system number if the neighbor has other configuration.
	
Note	We recommend that you use the no neighbor command rather than the no remote-as command to delete a neighbor. A neighbor specified with a remote autonomous system number that matches the autonomous system number specified in the router bgp command identifies the neighbor as internal to the local autonomous system. Otherwise, the neighbor is considered external. Configuration of the remote-as command for a neighbor group or session group using the neighbor-group command or session-group command causes all neighbors using the group to inherit the characteristics configured with the command. Configuring the command directly for the neighbor overrides the value inherited from the group. In the neighbor configuration submode, configuring use of a session group or neighbor group for which remote-as is configured creates a neighbor and assigns it an autonomous system number if the neighbor has not already been created.



Note Do not combine **remote-as** commands and **no use neighbor-group** commands, or **remote-as** commands and **no use session-group** commands, in the same configuration commit.

Task ID

Task ID

bgp read,
write

Examples

The following example shows how to assign autonomous system numbers on two neighbors, neighbor 10.0.0.1, (internal) and neighbor 192.168.0.1 (external), setting up a peering session that shares routing information between this router and each of these neighbors:

```
Router(config)# router bgp 1
Router(config-bgp) # session-group group2
Router(config-bgp-sngrp) # remote-as 1
Router(config-bgp-sngrp) #exit
Router(config-bgp) # neighbor 10.0.0.1
Router(config-bgp-nbr) #use session-group group2
```

The following example shows how to configure a session group called group2 with an autonomous system number 1. Neighbor 10.0.0.1 is created when it inherits the autonomous system number 1 from session group group2.

```
Router(config)#router bgp 1
Router(config-bgp) # session-group group2
Router(config-bgp-sngrp) # remote-as 1
Router(config-bgp-sngrp) # exit
Router(config-bgp) # neighbor 10.0.0.1
Router(config-bgp-nbr) # use session-group group2
```

Related Commands

Command	Description
Neighbor BGP	Enters neighbor configuration mode for configuring BGP routing sessions.
Neighbor Group	Creates a neighbor group and enters neighbor group configuration mode.
Router BGP	Configures the BGP routing process.
Session Group	Creates a session group and enters session group configuration mode.
Use	Inherits characteristics from a neighbor group, session group, or address family group.

retain local-label

To retain the local label until the network is converged, use the **retain local-label** command in an appropriate address family configuration mode. To disable the retaining of the local label, use the **no** form of this command.

retain local-label *minutes*

Syntax Description	<i>minutes</i> Local retention time in minutes. The range is 3 to 60 minutes. The default retention time is 5 minutes.				
Command Default	<i>minutes</i> : 5				
Command Modes	L2VPN address family configuration VPNv4 address family configuration VPNv6 address family configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.0.12</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
Usage Guidelines	No specific guidelines impact the use of this command. When configuring the label mode per-nexthop-received-label command at the VPN level, you must explicitly configure the local retention time for the retain local-label command.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>bgp</td><td>read, write</td></tr> </table>	Task ID	Operations	bgp	read, write
Task ID	Operations				
bgp	read, write				
Examples	The following example shows how to enable local label retention for 5 minutes: <pre>Router# configure Router(config)# router bgp 100 Router(config-bgp)# address-family vpnv4 unicast Router(config-bgp-af)# retain local-label 5</pre>				

retain route-target

To accept received updates with specified route targets, use the **retain route-target** command in an appropriate configuration mode. To disable the retaining of routes tagged with specified route targets, use the **no** form of this command.

```
retain route-target { all | route-policy route-policy-name }
no retain route-target [ all | route-policy route-policy-name ]
```

Syntax Description	all Accepts received updates containing at least one route target. route-policy <i>route-policy-name</i> Accepts received updates accepted by a specified route filter policy.
Command Default	The default is to accept all route targets.
Command Modes	VPNv4 address family configuration
Usage Guidelines	Use the retain route-target command to configure a route reflector (RR) to retain routes tagged with specific route targets (RT). The retain route-target is a required command for Inter-AS option B ASBR. By default, an Inter-AS option B ASBR needs the retain route-target configured to get VPNv4 BGP table from PE routers, either with the all or with the route-policy option. A provider edge (PE) router is not required to hold all VPNv4 routes. The PE router holds only routes that match the import RT of the VPNs configured on it, but a RR must retain all VPNv4 routes because it may peer with PE routers and different PEs may require different RT-tagged VPNv4 routes. Configuring an RR to hold only routes that have a defined set of RT communities and configuring some of these RRs to service a different set of VPNs provides scalability to the RRs. A PE can be configured to peer with all RRs that service the VPN routing and forwarding (VRF) instances configured on the PE. When a new VRF is configured with an RT for which the PE does not already hold routes, the PE issues route refresh requests to the RRs and gets the relevant VPN routes. The route-policy <i>route-policy-name</i> keyword and argument takes the policy name that lists the extended communities that a path should have for the RR to retain the path.

Examples

The following example shows how to configure RR to retain all routes with the route filter policy ft-policy-A:

```
Router(config)# router bgp 140
Router(config-bgp)# address-family vpnv4 unicast
Router(config-bgp-af)# retain route-target route-filter ft-policy-A
```

Related Commands

Command	Description
Import Route Target	Configures a VRF import route-target extended community.

route-mirroring inbound pre-policy

To enable the route mirroring mode for inbound pre-policy view, run the **route-mirroring inbound pre-policy** command in router configuration mode. Use the **no** form of the command to disable the feature.

route-mirroring inbound pre-policy

Syntax Description	inbound pre-policy Inbound pre-policy route-mirroring mode	
Command Default	None	
Command Modes	Router configuration	
Command History	Release	Modification
	Release 24.4.1	This command was introduced.
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
Task ID	Task ID	Operations
	bgp	read, write

The following example shows how to configure the route-mirroring inbound pre-policy:

```
Router#config
Router(config)#bmp server all
Router(config-bgp-bmp)#route-mirroring inbound pre-policy
Router(config-bgp-bmp-rmon)#commit
```

route-monitoring inbound post-policy

To enable the Adj-RIB-In post-policy (inbound post-policy) view for all the address families, run the **route-monitoring inbound post-policy** command in router configuration mode. Use the **no** form of the command to disable the feature.

route-monitoring inbound post-policy

Syntax Description	inbound post-policy Inbound post-policy route-monitoring mode	
Command Default	None	
Command Modes	Router configuration	
Command History	Release	Modification
	Release 24.1.1	Starting from Cisco IOS XR Release 24.1.1, the route-monitoring policy post inbound command is not supported. The route-monitoring inbound post-policy command replaces the old command route-monitoring policy post inbound .
	Release 7.5.4	The syntax of this command was modified to enable the Adj-RIB-In post-policy (inbound post-policy) view for all the address families.
	Release 5.2.2	This command was introduced.
Usage Guidelines	• To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. • Adj-RIB-In Pre-policy view for all the AFIs is available by default if at least one BMP server is configured. • Adj-RIB-In Pre-policy cannot be configured with route-monitoring inbound post-policy or Local-RIB.	
Task ID	Task ID	Operations
	bgp	read, write

The following example shows how to configure the route-monitoring inbound post-policy:

```
Router#config
Router(config)#bmp server all
Router(config-bgp-bmp)#route-monitoring inbound post-policy
Router(config-bgp-bmp-rmon)#commit
```

route-monitoring inbound pre-policy

To enable the Adj-RIB-In pre-policy (inbound pre-policy) view for all the address families, run the **route-monitoring inbound pre-policy** command in router configuration mode. Use the **no** form of the command to disable the feature.

route-monitoring inbound pre-policy

Syntax Description	inbound pre-policy Inbound pre-policy route-monitoring mode	
Command Default	None	
Command Modes	Router configuration	
Command History	Release	Modification
	Release 24.4.1	This command was introduced.
Usage Guidelines	• To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. • Adj-RIB-In Pre-policy view for all the AFIs is available by default if at least one BMP server is configured.	
Task ID	Task ID	Operations
	bgp	read, write

The following example shows how to configure the route-monitoring inbound pre-policy:

```
Router#config
Router(config)#bmp server all
Router(config-bgp-bmp)#route-monitoring inbound pre-policy
Router(config-bgp-bmp-rmon)#commit
```

route-monitoring local-rib

To enable the local RIB view for all the address families, run the **route-monitoring local-rib** command in router configuration mode. Use the **no** form of the command to disable the feature.

route-monitoring local-rib

Syntax Description	local-rib Local-RIB route-monitoring mode				
Command Default	None				
Command Modes	Router configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.5.4</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 7.5.4	This command was introduced.
Release	Modification				
Release 7.5.4	This command was introduced.				
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>bgp</td><td>read, write</td></tr> </table>	Task ID	Operations	bgp	read, write
Task ID	Operations				
bgp	read, write				

The following example shows how to configure the route-monitoring local-rib:

```
Router#config
Router(config)#bmp server all
Router(config-bgp-bmp)#route-monitoring local-rib
Router(config-bgp-bmp-rmon)#commit
```

route-policy (BGP)

To apply a routing policy to updates advertised to or received from a Border Gateway Protocol (BGP) neighbor, use the **route-policy** command in an appropriate configuration mode. To disable applying routing policy to updates, use the **no** form of this command.

```
route-policy route-policy-name [ parameter1, parameter2, . . . , parametern ] { in | out }
no route-policy route-policy-name [ parameter1, parameter2, . . . , parametern ] { in | out }
```

```
route-policy aggregate-route-policy-name [ set aggregate-contributor ]
```

Syntax Description		
	<i>route-policy-name</i>	Name of route policy. Up to 16 parameters can follow the route-policy-name, enclosed in brackets ([]).
	in	Applies policy to inbound routes.
	out	Applies policy to outbound routes.
	set aggregate-contributor	Sets the specific routes as aggregate contributors.

Command Default	No policy is applied.

Command Modes	IPv4 address family group configuration IPv6 address family group configuration IPv4 neighbor address family configuration IPv4 neighbor group address family configuration IPv6 neighbor group address family configuration Global family IPv4 unicast Global family IPv6 unicast

Command History	Release	Modification
	Release 7.5.4	The set aggregate-contributor keyword is added.
	Release 3.7.2	This command was introduced.

Usage Guidelines	Use the route-policy command to specify a routing policy for an inbound or outbound route. The policy can be used to filter routes or modify route attributes. The route-policy command is used to define a policy.



Note Configuring a large number of uniquely named outbound neighbor policies can adversely affect performance. This is true even if the uniquely named route policies are functionally identical. The user is discouraged from configuring multiple functionally identical route policies for use with this command. For example, if Policy A and Policy B are identical but named for different neighbors, the two policies should be configured as a single policy.

If the **route-policy** command is configured for a neighbor group or neighbor address family group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.

Examples

The following example shows how to apply the In-Ipv4 policy to inbound IP Version 4 (IPv4) unicast routes from neighbor 172.20.1.1:

```
Router(config)# router bgp 1
Router(config-bgp)# neighbor 172.20.1.1
Router(config-bgp-nbr)# remote-as 1
Router(config-bgp-nbr)# address-family ipv4 unicast
Router(config-bgp-nbr-af)# route-policy In-Ipv4 in
```

The following example shows how to set an aggregate contributor to a route policy:

```
Router1# config
Router1(config)#route-policy aggregate-policy1
Router1(config-rpl)#set aggregate-contributor
Router1(config-rpl)#end
Router1(config-rpl)#commit
```

Related Commands

Command	Description
AF Group	Creates an address family group for BGP neighbors and enters address family group configuration mode.
Neighbor Group	Creates a neighbor group and enters neighbor group configuration mode.
route-policy (RPL)	Defines a route policy and enters route-policy configuration mode.

route-reflector-client

To configure the router as a Border Gateway Protocol (BGP) route reflector and configure the specified neighbor as its client, use the **route-reflector-client** command in an appropriate configuration mode. To disable configuring the neighbor as a client, use the **no** form of this command.

route-reflector-client [**inheritance-disable**]
no route-reflector-client [**inheritance-disable**]

Syntax Description	inheritance-disable (Optional) Allows the configuration inherited from a neighbor group or address family group to be overridden.
Command Default	The neighbor is not treated as a route reflector client.
Command Modes	IPv4 address family group configuration IPv6 address family group configuration IPv4 neighbor address family configuration IPv4 neighbor group address family configuration IPv6 neighbor group address family configuration
Usage Guidelines	This command is restricted to internal BGP (iBGP) neighbors only. Use the route-reflector-client command to configure the local router as the route reflector and the specified neighbor as one of its clients. All neighbors configured with this command are members of the client group, and the remaining iBGP peers are members of the nonclient group for the local route reflector. By default, all iBGP speakers in an autonomous system must be fully meshed with each other, and neighbors do not readvertise iBGP learned routes to other iBGP neighbors. With route reflection, all iBGP speakers need not be fully meshed. An iBGP speaker, the route reflector, passes learned iBGP routes to some number of iBGP client neighbors. Learned iBGP routes eliminate the need for each router running BGP to communicate with every other device running BGP in the autonomous system. The local router is a route reflector as long as it has at least one route reflector client. If this command is configured for a neighbor group or neighbor address family group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.
Examples	The following example shows neighbor at 172.20.1.1 configured as a route reflector client for IP Version 4 (IPv4) unicast routes: <pre>Router(config)# router bgp 140 Router(config-bgp)# neighbor 172.20.1.1 Router(config-bgp-nbr)# remote-as 140 Router(config-bgp-nbr)# address-family ipv4 unicast Router(config-bgp-nbr-af)# route-reflector-client</pre>

The following example disables the route-reflector client for neighbor 172.20.1.1, preventing this feature from being automatically inherited from address family group group1:

```
Router(config)# router bgp 140
Router(config-bgp)# af-group group1 address-family ipv4 unicast
Router(config-bgp-afgrp)# route-reflector-client
Router(config-bgp-afgrp)#exit
Router(config-bgp)# neighbor 172.20.1.1
Router(config-bgp-nbr)# remote-as 140
Router(config-bgp-nbr)# address-family ipv4 unicast
Router(config-bgp-nbr-af)# use af-group group1
Router(config-bgp-nbr-af)# route-reflector-client inheritance-disable
```

Related Commands

Command	Description
AF Group	Creates an address family group for BGP neighbors and enters address family group configuration mode.
BGP Cluster	Configures the cluster ID if the BGP cluster has more than one route reflector.
Neighbor Group	Creates a neighbor group and enters neighbor group configuration mode.

router bgp

To configure the Border Gateway Protocol (BGP) routing process, use the **router bgp** command in XR Config mode. To remove all BGP configurations and terminate the BGP routing process, use the **no** form of this command.

router bgp *as-number* [**instance** *instance-name*]

Syntax Description	<i>as-number</i>	Number that identifies the autonomous system (AS) in which the router resides. • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535.
	instance <i>instance-name</i>	Specifies an instance and instance name. The maximum length for the instance name is 32 characters. The router bgp instance <i>instance-name</i> command replaced the distributed speaker command.
Command Default	No BGP routing process is enabled.	
Command Modes	XR Config mode	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.
Usage Guidelines	Use the router bgp command to set up a distributed routing core that automatically guarantees the loop-free exchange of routing information between autonomous systems.	
Task ID	Task ID	Operations
	bgp	read, write
	rib	read, write
Examples	The following example shows how to configure a BGP process for autonomous system 120: <pre>RP/0/RP0/CPU0:router(config)# router bgp 120</pre>	

rpki route

To statically configure an RPKI route, use the **rpki route** command in the router BGP configuration submode. The **no** form of this command removes the RPKI routes.

```
rpki route ip-address-length { max max-prefix-length | origin origin-autonomous-system-number }
no rpki route ip-address-length { max max-prefix-length | origin origin-autonomous-system-number }
```

Syntax Description	<i>ip-address/length</i>	Specifies the IP address of the network along with the minimum prefix length.
	max <i>max-prefix-length</i>	Specifies the maximum prefix length (32 for IPv4 and 128 for IPv6).
	origin <i>origin-autonomous-system-number</i>	Specifies the autonomous system number.

Command Default RPKI route configuration is disabled.

Command Modes Router BGP configuration

Command History	Release	Modification
	Release 4.2.1	This command was introduced.

Usage Guidelines In general, BGP receives the Route-Origin-Attestation (ROA) information from RPKI cache. However, the **rpki route** command is used for verification. This command can be used to configure both IPv4 and IPv6 ROAs.

This command contains all the essential attributes of an ROA record, that is, the prefix-block (IP address/length (minimum/maximum)) and the origin AS authorized to create the prefix-block.

Multiple static ROAs can be configured through this command and these entries will be included in the routers RPKI database, as if they were fetched from an RPKI cache.

This example shows how to configure an rpki route:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#rpki route 192.168.1.0/24 max 30 origin 65001
Router(config-bgp)#rpki route 172.200.0.0/16 max 24 origin 300
Router(config-bgp)#
```

selective-vrf-download disable

To disable selective VRF download (SVD) on a line card to enable download all prefixes and labels to the line card, use the **selective-vrf-download disable** command in `mode`. To enable the SVD, use the **no** form of this command.

```
selective-vrf-download  disable
no  selective-vrf-download  disable
```

Command Default

SVD is enabled.

Command Modes

Usage Guidelines

You must failover the active RP or reload the router after disabling SVD for the configuration change to get activated.

This example shows how to disable selective vrf download:

```
Router#configure
Router(config)#selective-vrf-download disable
```

send-buffer-size

To set the size of the send buffers for a Border Gateway Protocol (BGP) neighbor, use the **send-buffer-size** command in an appropriate configuration mode. To set the size of the send buffers to the default values, use the **no** form of this command.

send-buffer-size *socket-size* [*bgp-size*]
no send-buffer-size [*socket-size*] [*bgp-size*]

Syntax Description	<i>socket-size</i> Size, in bytes, of the send-side socket buffer. Range is 4096 to 131072.
	<i>bgp-size</i> (Optional) Size, in bytes, of the BGP process send buffer. Range is 4096 to 131072.

Command Default	<i>socket-size</i> : 10240 bytes
	<i>bgp-size</i> : 4096 bytes
	Use the socket send-buffer-size command to change the defaults.

Command Modes	Neighbor configuration
	Neighbor group configuration
	Session group configuration

Usage Guidelines	Use the send-buffer-size command to increase the buffer size employed when sending updates to a neighbor. Using larger buffers can improve convergence time because the software can process more packets simultaneously. However, allocating larger buffers uses more memory on the router.



Note	Increasing the socket buffer size uses more memory only when more messages are waiting to be processed by the software. In contrast, increasing the BGP buffer size uses more memory indefinitely.

If this command is configured for a neighbor group or session group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.

Examples	The following example shows how to set the send buffer sizes for neighbor 172.20.1.1 to be 8192 bytes for both the socket buffer and the BGP buffer:

```
Router(config)# router bgp 1
Router(config-bgp)# neighbor 172.20.1.1
Router(config-bgp-nbr)# remote-as 1
Router(config-bgp-nbr)# send-buffer-size 8192 8192
```

Related Commands	Command	Description
	Neighbor Group	Creates a neighbor group and enters neighbor group configuration mode.

Command	Description
Receive Buffers Size	Sets the size of the receive buffers for a BGP neighbor.
Session Group	Creates a session group and enters session group configuration mode.
Socket Send Buffer Size	Sets the size of the send buffers for all BGP neighbors.

send-community-ebgp

To specify that community or the large community attributes should be sent to an external Border Gateway Protocol (eBGP) neighbor, use the **send-community-ebgp** command in an appropriate configuration mode. To disable sending community or large community attributes to an eBGP neighbor, use the **no** form of this command.

```
send-community-ebgp [ inheritance-disable ]
no send-community-ebgp [ inheritance-disable ]
```

Syntax Description	inheritance-disable (Optional) Allows configuration inherited from a neighbor group or address family group to be overridden.									
Command Default	Community (COMM) attributes are NOT sent to eBGP peers (including PE-CE peers).									
Command Modes	IPv4 address family group configuration IPv6 address family group configuration IPv4 neighbor address family configuration IPv4 neighbor group address family configuration IPv6 neighbor group address family configuration									
Usage Guidelines	Use the send-community-ebgp command to control whether community or large community attributes are sent to eBGP neighbors. This command cannot be configured for iBGP neighbors as community or large community attributes are always sent to iBGP neighbors. If this command is configured for a neighbor group or address family group, all neighbors using the group inherit the configuration. Configuring the command specifically for a neighbor overrides inherited values.									
Task ID	Task ID	Operations								
	bgp	read, write								
Related Commands	<table><tr><th>Command</th><th>Description</th></tr><tr><td>AF Group</td><td>Creates an address family group for BGP neighbors and enters address family group configuration mode.</td></tr><tr><td>Neighbor Group</td><td>Creates a neighbor group and enters neighbor group configuration mode.</td></tr><tr><td>Send Extended Community</td><td>Specifies that extended community attributes are sent to eBGP neighbors.</td></tr></table>		Command	Description	AF Group	Creates an address family group for BGP neighbors and enters address family group configuration mode.	Neighbor Group	Creates a neighbor group and enters neighbor group configuration mode.	Send Extended Community	Specifies that extended community attributes are sent to eBGP neighbors.
Command	Description									
AF Group	Creates an address family group for BGP neighbors and enters address family group configuration mode.									
Neighbor Group	Creates a neighbor group and enters neighbor group configuration mode.									
Send Extended Community	Specifies that extended community attributes are sent to eBGP neighbors.									

send-community-gshut-ebgp

To direct the router to add the gshut community to the path having the gshut attribute or the path being sent to a connection that has graceful maintenance activated, use the **send-community-gshut-ebgp** command in the neighbor address family configuration mode. To disable the g-shut community from being announced to ebgp neighbors, use the **no** form of this command.

send-community-gshut-ebgp [**inheritance-disable**]

Syntax Description	inheritance-disable (Optional) Prevent send-community-gshut-ebgp from being inherited from the parent.
Command Default	g-shut community attribute is not sent to eBGP neighbors.
Command Modes	IPv4 address family group configuration IPv6 address family group configuration IPv4 neighbor address family configuration IPv4 neighbor group address family configuration IPv6 neighbor group address family configuration
Usage Guidelines	Under neighbor address family configuration, use the send-community-gshut-ebgp command to allow the g-shut community to be sent if it is an ebgp neighbor. A path acquires the gshut attribute when it is received from a connection that has graceful maintenance activated. The sending of the gshut community if it is present because the path was received with that community or if it was added by outbound policy is governed like all other communities by the send-community-ebgp configuration.

send-extended-community-ebgp

To specify that extended community attributes should be sent to external Border Gateway Protocol (eBGP) neighbors, use the **send-extended-community-ebgp** command in an appropriate configuration mode. To disable sending extended community attributes to eBGP neighbors, use the **no** form of this command.

send-extended-community-ebgp [**inheritance-disable**]
no send-extended-community-ebgp [**inheritance-disable**]

Syntax Description	inheritance-disable (Optional) Allows configurations inherited from a neighbor group or address family group to be overridden.								
Command Default	Extended community (EXTCOMM) attributes are NOT sent to eBGP peers (including PE-CE peers).								
Command Modes	IPv4 address family group configuration IPv6 address family group configuration IPv4 neighbor address family configuration IPv4 neighbor group address family configuration IPv6 neighbor group address family configuration								
Usage Guidelines	Use the send-extended-community-ebgp command to control whether extended community attributes are sent to eBGP neighbors. This command cannot be used for iBGP neighbors as extended community attributes are always sent to iBGP neighbors. If this command is configured for a neighbor group or neighbor address family group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.								
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>AF Group</td><td>Creates an address family group for BGP neighbors and enters address family group configuration mode.</td></tr> <tr> <td>Neighbor Group</td><td>Creates a neighbor group and enters neighbor group configuration mode.</td></tr> <tr> <td>Send Community eBGP</td><td>Specifies that community attributes should be sent to an eBGP neighbor.</td></tr> </tbody> </table>	Command	Description	AF Group	Creates an address family group for BGP neighbors and enters address family group configuration mode.	Neighbor Group	Creates a neighbor group and enters neighbor group configuration mode.	Send Community eBGP	Specifies that community attributes should be sent to an eBGP neighbor.
Command	Description								
AF Group	Creates an address family group for BGP neighbors and enters address family group configuration mode.								
Neighbor Group	Creates a neighbor group and enters neighbor group configuration mode.								
Send Community eBGP	Specifies that community attributes should be sent to an eBGP neighbor.								

session-group

To create a session group and enter session group configuration mode, use the **session-group** command in router configuration mode. To remove a session group and delete all configurations associated with it, use the **no** form of this command.

session-group *name*
no session-group *name*

Syntax Description	name Name of the session group.
Command Default	No session groups are created.
Command Modes	Router configuration
Usage Guidelines	Use the session-group command to create a session group from which neighbors can inherit configuration that is address family-independent. That is, session groups cannot have address family-specific configuration. This command enters the session group configuration mode in which configuration for a session group is entered. Many commands can be configured in both session group configuration mode and neighbor configuration mode. Use of session groups saves time and reduces the router configuration size. Because the configuration of a session group can be inherited by any number of neighbors, use of the group can eliminate the need to copy long or complex configurations on each of a large number of neighbors. A neighbor can inherit all configuration from a session group simply by configuring the use command. Specific inherited session group configuration commands can be overridden for a specific neighbor by explicitly configuring the command for the specific neighbor. The no form of this command causes all of the configuration for the session group to be removed. You cannot use the no form of this command if removing the group would leave one or more neighbors without a configured remote autonomous system number.

Examples

The following example shows a session group called group1 that is used by two neighbors, 10.0.0.1 and 10.0.0.2. Because group1 is a session group, it contains only address family-independent configuration. And because group1 is used by neighbors 10.0.0.1 and 10.0.0.2, they inherit the configuration of the group.

```
RP/0/RSP0RP0/CPU0:router(config)# router bgp 1
RP/0/RSP0RP0/CPU0:router(config-bgp)# session-group group1
RP/0/RSP0RP0/CPU0:router(config-bgp-sngrp)# remote-as 1
RP/0/RSP0RP0/CPU0:router(config-bgp-sngrp)# advertisement-interval 2
RP/0/RSP0RP0/CPU0:router(config-bgp-sngrp)# exit
RP/0/RSP0RP0/CPU0:router(config-bgp)# neighbor 10.0.0.1
RP/0/RSP0RP0/CPU0:router(config-bgp-nbr)# use session-group group1
RP/0/RSP0RP0/CPU0:router(config-bgp-nbr)# exit
RP/0/RSP0RP0/CPU0:router(config-bgp)# neighbor 10.0.0.2
RP/0/RSP0RP0/CPU0:router(config-bgp-nbr)# use session-group group1
```

The following example shows a session group called group1 used by two neighbors, 10.0.0.1 and 10.0.0.2. Because group1 is a session group, it contains only address family-independent configuration. And because group1 is used by neighbors 10.0.0.1 and 10.0.0.2, they inherit the configuration of the group. However, the **password password1** configuration from group1 is overridden for neighbor 10.0.0.2, using the **password-disable** command in the neighbor 10.0.0.2 configuration submode.

```
Router(config)# router bgp 1
Router(config-bgp)# session-group group1
Router(config-bgp-sngrp)# remote-as 1
Router(config-bgp-sngrp)# advertisement-interval 2
Router(config-bgp-sngrp)# password password1
Router(config-bgp-sngrp)# exit
Router(config-bgp)# neighbor 10.0.0.1
Router(config-bgp-nbr)# use session-group group1
Router(config-bgp-nbr)# exit
Router(config-bgp)# neighbor 10.0.0.2
Router(config-bgp-nbr)# use session-group group1
Router(config-bgp-nbr)# password-disable
```

show bgp

To display entries in the Border Gateway Protocol (BGP) routing table, use the **show bgp** command in XR EXEC mode.

```
show bgp [ipv4 {unicast | multicast | labeled-unicast | all | tunnel | mdt | | flowspec} | ipv6 {unicast |
| multicast | all | labeled-unicast | | flowspec} | all {unicast | multicast | all | labeled-unicast | mdt |
tunnel} | vpnv4 { flowspec | multicast | unicast | rt-set} [rd rd-address] | vrf {vrf-name | all} | [ipv4
{unicast | labeled-unicast} | ipv6 {unicast | flowspec}] | vpnv6 { flowspec | unicast | rt-set} | [instance]
| [instances] | flowspec] [ip-address [ {mask} /prefix-length} [longer-prefixes | unknown-attributes
| bestpath-compare]]] [standby] [detail] rt-set
```

Syntax Description

ipv4	(Optional) Specifies IP Version 4 address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.
tunnel	(Optional) Specifies tunnel address prefixes.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
all	(Optional) For address family, specifies prefixes for all address families.
vpnv4 unicast	(Optional) Specifies VPNv4 unicast address families.
instances	(Optional) Displays information of all BGP instances.
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
<i>vrf-name</i>	(Optional) Name of a VRF.
all	(Optional) For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.
<i>ip-address</i>	(Optional) Network address, entered to display a particular network in the BGP routing table. If the network address is omitted, then all networks in the BGP routing table are displayed. If the network mask and prefix length is omitted, then the software displays the longest matching prefix for the network address.
<i>mask</i>	(Optional) Network mask of the BGP route to match.

<i>/prefix-length</i>	(Optional) Prefix length of the BGP route to match. A slash (/) must precede the decimal value.
longer-prefixes	(Optional) Displays a route with the specified prefix length and more-specific routes if available. The longer-prefixes keyword is available when the <i>ip-address</i> and <i>mask</i> or <i>/prefix-length</i> arguments are specified.
unknown-attributes	(Optional) Includes unknown, transitive attributes. The unknown-attributes keyword is available when the <i>ip-address</i> and <i>mask</i> or <i>/prefix-length</i> arguments are specified.
bestpath-compare	(Optional) Displays route and best-path comparison information. The bestpath-compare keyword is available when the <i>ip-address</i> and <i>mask</i> or <i>/prefix-length</i> arguments are specified.
rt-set	Displays all RT-sets for a given address-family.
flowspec	Displays flowspec configuration information.
vpn4 multicast	Displays VPNv4 multicast prefixes.

Command Default

If no address family or subaddress family is specified, the default address family and subaddress family specified using the **set default-afi** and **set default-safi** commands are used.

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 25.1.1	The command is enhanced to display link bandwidth information in bytes per second.
Release 24.3.1	These fields were added to the show output: • Long-lived Graceful Restart Stale Time Send Default is ON (<i>or OFF</i>) • Default advertised long-lived stale time is 172800 seconds • Long-lived Graceful Restart Stale Time Accept Any is ON (<i>or OFF</i>)
Release 7.0.12	This command was introduced.

Usage Guidelines**Note**

The **set default-afi** command is used to specify the default address family for the sessions and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

BGP contains a separate routing table for each address family and subaddress family combination that has been configured. The address family and subaddress family options specify the routing table to be examined. If the **all** keyword is specified for an address family or a subaddress family, each matching routing table is examined in turn.



Note Running the **show bgp** command immediately after configuring a large and complex route policy may result in timeout of the system database shown through an error message (SYSDB-SYSDB-6-TIMEOUT_EDM). It is recommended, that the show command be run, after the new route policy takes effect.

Use the **show bgp ip-address { mask | / prefix-length }** command to display detailed information for a specific route. If the mask and prefix length are omitted, the details of the longest matching prefix for the IP address are displayed.

Use the **show bgp** command to display all routes in the specified BGP routing table. Use the **show bgp ip-address { mask | / prefix-length } longer-prefixes** command to display those routes more specific than a particular prefix.

Use the **unknown-attributes** keyword to display details of any transitive attributes associated with a route that are not understood by the local system.

Use the **show bgp ip-address/prefix-length detail** command to display details of the specified prefix.

Examples

The following is sample output from the **show bgp** command in EXEC mode and XR EXEC mode with the BGP Persistence or long lived graceful restart (LLGR) status:

```
Router# show bgp vpnv4 uni rd 2:1 3.0.0.0/24
[KBGP routing table entry for 3.0.0.0/24, Route Distinguisher: 2:1
Versions:
  Process          bRIB/RIB   SendTblVer
  Speaker          350584     350584
    Local Label: 16010
Last Modified: Jun 23 06:22:12.821 for 00:03:27
Paths: (1 available, best #1)
  Not advertised to any peer
  Path #1: Received by speaker 0
  Not advertised to any peer
  6913, (Received from a RR-client), (long-lived stale)
  4.4.4.4 (metric 3) from 3.3.3.3 (4.4.4.4)
    Received Label 16000
    Origin EGP, localpref 100, valid, internal, best, group-best, import-candidate,
not-in-vrf
    Received Path ID 0, Local Path ID 1, version 350584
    Extended community: RT:2:1
    Originator: 4.4.4.4, Cluster list: 3.3.3.3
```

The following is the sample output from the **show bgp <IP address>** command displaying the graceful-shutdown community and the graceful-shut path attribute with BGP graceful maintenance feature activated:

```
RP/0/0/CPU0:R4#show bgp 5.5.5.5
...
  10.10.10.1 from 10.10.10.1 (192.168.0.5)
    Received Label 24000
    Origin incomplete, metric 0, localpref 100, valid, internal, best, group-best,
import-candidate
    Received Path ID 0, Local Path ID 1, version 4
    Community: graceful-shutdown
```

```
Originator: 192.168.0.5, Cluster list: 192.168.0.1
```

```
...
```

The following is sample output from the **show bgp** command in EXEC mode and XR EXEC mode:

```
Router#show bgp
BGP router identifier 172.20.1.1, local AS number 1820
BGP generic scan interval 60 secs
BGP table state: Active
Table ID: 0xe0000000
BGP main routing table version 3
Dampening enabled
BGP scan interval 60 secs

Status codes: s suppressed, d damped, h history, * valid, > best
               i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete

Network        Next Hop           Metric LocPrf Weight Path
* i10.3.0.0/16  172.20.22.1         0      100      0 1800 1239 ?
*>i             172.20.16.1         0      100      0 1800 1239 ?
* i10.6.0.0/16  172.20.22.1         0      100      0 1800 690 568 ?
*>i             172.20.16.1         0      100      0 1800 690 568 ?
* i10.7.0.0/16  172.20.22.1         0      100      0 1800 701 35 ?
*>i             172.20.16.1         0      100      0 1800 701 35 ?
*               192.168.40.24         0      100      0 1878 704 701 35 ?
* i10.8.0.0/16  172.20.22.1         0      100      0 1800 690 560 ?
*>i             172.20.16.1         0      100      0 1800 690 560 ?
*               192.168.40.24         0      100      0 1878 704 701 560 ?
* i10.13.0.0/16 172.20.22.1         0      100      0 1800 690 200 ?
*>i             172.20.16.1         0      100      0 1800 690 200 ?
*               192.168.40.24         0      100      0 1878 704 701 200 ?
* i10.15.0.0/16 172.20.22.1         0      100      0 1800 174 ?
*>i             172.20.16.1         0      100      0 1800 174 ?
* i10.16.0.0/16 172.20.22.1         0      100      0 1800 701 i
*>i             172.20.16.1         0      100      0 1800 701 i
*               192.168.40.24         0      100      0 1878 704 701 i

Processed 8 prefixes, 8 paths
```

This table describes the significant fields shown in the display.

Table 2: show bgp Field Descriptions

Field	Description
BGP router identifier	BGP identifier for the local system.
local AS number	Autonomous system number for the local system. • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535.
BGP generic scan interval	Interval (in seconds) between scans of the BGP table by a generic scanner.

Field	Description
BGP table state	State of the BGP database.
Table ID	BGP database identifier.
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.
Dampening enabled	Dampening is enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between BGP scans for the specified address family and subaddress family.
Status codes	Status of the table entry. The status is displayed as a three-character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): >—Path is the best path to use for that network. d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.
Origin codes	Origin of the path. The origin code is displayed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was sourced by BGP using a network or aggregate-address command. e—Path originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP prefix and prefix length for a network.
Next Hop	IP address of the next system that is used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network.
Metric	Value of the interautonomous system metric, otherwise known as the Multi Exit discriminator (MED) metric.

Field	Description
LocPrf	Local preference value. This is used to determine the preferred exit point from the local autonomous system. It is propagated throughout the local autonomous system.
Weight	Path weight. Weight is used in choosing the preferred path to a route. It is not advertised to any neighbor.
Path	Autonomous system path to the destination network. At the end of the path is the path origin code.

The following is sample output from the **show bgp** command with the network specified:

```
Router# show bgp 11.0.0.0/24
BGP router table entry for 11.0.0.0/24
Versions:
  Process          bRIB/RIB  SendTblVer
  Speaker          2         2
Last Modified: Mar  3 16:12:07.147 for 2d21h
Paths: (3 available, best #1)
  Advertised to update-groups (with more than one peer):
    0.1
  Advertised to peers (in unique update groups):
    10.4.101.1
  Received by speaker 0
  Local
    0.0.0.0 from 0.0.0.0 (10.4.0.1)
      Origin IGP, metric 0, localpref 100, weight 32768, valid, local, best
  Received by speaker 0
  2 3 4
    10.4.101.1 from 10.4.101.1 (10.4.101.1)
      Origin IGP, localpref 100, valid, external
  Received by speaker 0
  Local
    10.4.101.2 from 10.4.101.2 (10.4.101.2)
      Origin IGP, localpref 100, valid, internal
```

This table describes the significant fields shown in the display.

Table 3: show bgp prefix length Field Descriptions

Field	Description
BGP router table entry	Network that is being displayed.
Versions	List of the network versions in each BGP process.
Process	Name of the BGP process.
bRIB/RIB	Version of the network for sending to the RIB. You can compare this version with the bRIB/RIB version for the process (at the top of show bgp summary) to verify whether the network has been sent to the RIB.
SendTblVer	Version of the network for advertising to neighbors. This can be compared with the neighbor version to determine whether the network has been advertised to a particular neighbor.

Field	Description
Last Modified	Timestamp when this route was last modified.
Paths	List of paths for the network (that is, routes to reach the network). The number of paths and the index of the best path are given.
not advertised to any peer	Best path was received with a NO_ADVERTISE community and is not advertised to any neighbor.
not advertised to EBGp peer	Best path was received with a NO_EXPORT community and is not advertised to any eBGP neighbor.
not advertised outside local AS	Best path was received with a LOCAL_AS community and is not advertised to peers outside the local AS.
Advertisements of this net are suppressed by an aggregate	Network is a more-specific prefix of a configured aggregate and has been suppressed. It is not advertised to any neighbors unless they have an unsuppress-map configured.
Advertised to update-groups	List of update-groups to which the net has been advertised. Update-groups that have only one peer are not listed here.
Advertised to peers	List of neighbors to which the net has been advertised to. Neighbors that are in one of the update-groups listed above are not listed separately. Only neighbors that are in unique update-groups are listed.
Received by speaker 0	BGP process where the path originated. This is always “speaker 0” for standalone mode. It will be the speaker-id when BGP is in distributed mode.
AS Path	Autonomous system (AS) path that was received for the path. If the AS path is empty, then “Local” is displayed. This is the case for paths that are locally generated on this router or on a neighboring router within the same AS.
aggregated by	If the path is an aggregate, the router-id of the router that performed the aggregation.
suppressed due to dampening	Path has been suppressed due to the configured path dampening.
history entry	Path is withdrawn, but a copy is kept to store the dampening information.
Received from a RR-client	Path was received from a route reflector client.
received-only	If soft reconfiguration inbound is configured, the path was received but dropped by inbound policy, or was accepted and modified. In either event, the received-only value is a copy of the original, unmodified path.
received & used	If soft reconfiguration inbound is configured, the path was received and accepted by inbound policy, but not modified.
stale	Neighbor from which the path was received is down, and the path is kept and marked as stale to support graceful restart.

Field	Description
<nexthop> from <neighbor> (<router-id>)	Next hop for the path. If the next hop is known by a mechanism outside BGP (for example, for redistributed paths), then 0.0.0.0 is displayed. After the next hop, the neighbor from whom the path was received is displayed, along with the neighbor's router-id. If the path was locally generated (for example, an aggregate or redistributed path), then 0.0.0.0 is displayed for the neighbor address.
Origin	IGP: the path originated from an IGP. EGP: the path originated from an EGP. incomplete: the origin of the path is unknown.
metric	MED value of the path.
localpref	Local preference value. This is used to determine the preferred exit point from the local autonomous system. It is propagated throughout the local autonomous system.
weight	Locally assigned weight (if not 0) of the path. Weight is used in choosing the preferred path to a route. It is not advertised to any neighbor.
valid	Path is valid and can be considered in the best-path calculation.
redistributed	Path is redistributed through a redistribute command.
aggregated	Path is a locally generated aggregate created due to an aggregate-address command.
local	Path is a local network source due to a network command.
internal	Path was received from an iBGP neighbor.
external	Path was received from an eBGP neighbor.
atomic-aggregate	Path was received with the atomic-aggregate flag set. Some path information has been removed through aggregation.
best	Path is the best path for the network and is used for routing and advertised to peers.
multipath	Path is a multipath and is installed into the RIB along with the best path.
Community	List of communities attached to the path.
Extended community	List of extended communities attached to the path.
Originator	Originator of the path within the AS Cluster list if the path is reflected.
AS Cluster list	List of RR clusters the path has passed through if the path is reflected
Dampinfo	Penalty and reuse information if the path is dampened.
penalty	Current penalty for the path.

Field	Description
flapped	Number of times the path has flapped and the time since the first flap.
reuse in	Time until the path is re-used (undampened).
half life	Configured half-life for the path.
suppress value	Penalty at which the path is suppressed.
reuse value	Penalty at which the path is re-used.
Maximum suppress time	Maximum length of time for which the path can be suppressed.

The following is sample output from the **show bgp** command with the *ip-address/prefix-length detail* options:

```
Router# show bgp 51.0.0.0/24 detail

Sat Mar 14 00:37:14.109 PST PDT

BGP routing table entry for 51.0.0.0/24

Versions:

    Process          bRIB/RIB  SendTblVer

    Speaker              3          3

    Flags: 0x3e1000, label_retention: not enabled

Last Modified: Mar 13 19:32:17.976 for 05:04:56

Paths: (1 available, best #1)

    Advertised to update-groups (with more than one peer):

        0.3 0.4 0.7 0.8

    Advertised to peers (in unique update groups):

        201.48.20.1

    Path #1: Received by speaker 0

    Flags: 0x1000003

    200 201

    213.0.0.6 from 213.0.0.6 (200.200.3.1)

    Origin IGP, localpref 100, valid, external, best
```

The following is sample output from the **show bgp** command with the additional paths received from:

```
BGP routing table entry for 51.0.1.0/24, Route Distinguisher: 2:1
Versions:
    Process          bRIB/RIB  SendTblVer
    Speaker              63          63
```

```

Flags: 0x040630f2
Last Modified: Nov 11 12:44:05.811 for 00:00:16
Paths: (3 available, best #2)
  Advertised to CE peers (in unique update groups):
    10.51.0.10
  Path #1: Received by speaker 0
  Flags: 0x3
  Not advertised to any peer
  111 111 111 111 111 111 111 111
    10.51.0.10 from 10.51.0.10 (11.11.11.11)
      Origin IGP, metric 0, localpref 100, valid, external
      Received Path ID 0, Local Path ID 0, version 0
      Extended community: RT:55:1
  Path #2: Received by speaker 0
  Flags: 0x5060007
  Advertised to CE peers (in unique update groups):
    10.51.0.10
  561 562 563 564 565
    13.0.6.50 from 13.0.6.50 (13.0.6.50)
      Received Label 16
      Origin IGP, localpref 100, valid, internal, best, group-best, import-candidate,
imported
      Received Path ID 0, Local Path ID 1, version 63
      Extended community: RT:55:1
  Path #3: Received by speaker 0
  Flags: 0x4060007
  Not advertised to any peer
  591 592 593 594 595
    13.0.9.50 from 13.0.9.50 (13.0.9.50)
      Received Label 16
      Origin IGP, localpref 100, valid, internal, backup, add-path, import-candidate,
imported
      Received Path ID 0, Local Path ID 4, version 63
      Extended community: RT:22:232 RT:55:1

```

This is sample output to explain 'import suspect' state and 'import-suspect' field in **show bgp** command output:

```

Router#show bgp vpnv4 unicast rd 11:111 100.16.11.0/24
BGP routing table entry for 100.16.11.0/24, Route Distinguisher: 11:111
Versions:
  Process          bRIB/RIB  SendTblVer
  Speaker          1834195   1834195
Paths: (2 available, best #1)
  Advertised to update-groups (with more than one peer):
    0.1
  Path #1: Received by speaker 0
  11
    1:16.16.16.16 (metric 30) from 55.55.55.55 (16.16.16.16)
      Received Label 19602
      Origin incomplete, localpref 100, valid, internal, best, import-candidate, not-in-vrf,
import suspect
      Extended community: RT:11:11
      Originator: 16.16.16.16, Cluster list: 55.55.55.55
  Path #2: Received by speaker 0
  11
    1:16.16.16.16 (metric 30) from 88.88.88.88 (16.16.16.16)
      Received Label 19602
      Origin incomplete, localpref 100, valid, internal, not-in-vrf, import suspect
      Extended community: RT:11:11
      Originator: 16.16.16.16, Cluster list: 88.88.88.88

```

The **show bgp** command output displays 'import suspect' when potential import oscillation has been detected for the prefix. Import of such a prefix is not affected. However, import of the prefix can be dampened in future if the oscillation continues. If the oscillation stops during the next import run, the prefix will no longer be marked 'import suspect'.

This is sample output of **show bgp {ipv4 | vpnv4} unicast summary** when the **update wait-install** command was configured for an address family. The output displays the "RIBAckVer" field.

```
Router#show bgp summary
```

```
BGP router identifier 10.1.1.2, local AS number 100
BGP generic scan interval 60 secs
BGP table state: Active
Table ID: 0xe0000000 RD version: 5
BGP main routing table version 5
BGP scan interval 60 secs
```

BGP is operating in STANDALONE mode.

Process	RcvTblVer	RIBVer/RIBAckVer	LabelVer	ImportVer	SendTblVer	StandbyVer
Speaker	5	5/5	5	5	5	5

Neighbor	Spk	AS	MsgRcvd	MsgSent	TblVer	InQ	OutQ	Up/Down	St/PfxRcd
10.1.1.1	0	500	0	0	0	0	0	00:00:00	Idle

This is sample output from **show bgp vpnv4 unicast rd prefix/length** command that displays Accept Own prefix information:

```
Router#show bgp vpnv4 unicast rd 10.10.10.10:1 110.1.1.1/32 detail
```

```
BGP routing table entry for 110.1.1.1/32, Route Distinguisher: 10.10.10.10:1
```

```
Versions:
```

```
Process          bRIB/RIB    SendTblVer
Speaker          1412487    1412487
```

```
Local Label: 137742 (no rewrite);
```

```
Flags: 0x04043001+0x00000000;
```

```
Last Modified: Jul 19 14:42:43.690 for 00:56:34
```

```
Paths: (2 available, best #1)
```

```
Advertised to peers (in unique update groups):
```

```
45.1.1.1
```

```
Path #1: Received by speaker 0
```

```
Flags: 0xd040003, import: 0x1f
```

```
Advertised to peers (in unique update groups):
```

```
45.1.1.1
```

```
101
```

```
10.5.1.2 from 10.5.1.2 (10.5.1.2)
```

```
Origin incomplete, localpref 100, valid, external, best, group-best, import-candidate
```

```
Received Path ID 0, Local Path ID 1, version 1412487
```

```
Extended community: RT:100:1
```

```
Path #2: Received by speaker 0
```

```
Flags: 0x324020005, import: 0x01
```

```
Not advertised to any peer
```

```
101
```

```
15.1.1.1 from 55.1.1.1 (15.1.1.1)
```

```
Received Label 137742
```

```
Origin incomplete, localpref 100, valid, internal, import-candidate, not-in-vrf,
```

accept-own-self

```
Received Path ID 0, Local Path ID 0, version 0
```

```
Community: accept-own
```

```
Extended community: RT:100:1 RT:1000:1
Originator: 15.1.1.1, Cluster list: 55.1.1.1, 75.1.1.1, 45.1.1.1
```

In the example show output, BGP advertises a link bandwidth value of 16,000.0 bytes per second for the link bandwidth weight 128 and 8,000 bytes per second for the link bandwidth weight 64.

```
Router#show bgp 209.165.201.1/27
Thu Mar  6 09:22:09.823 UTC
BGP routing table entry for 209.165.201.1/27
Versions:
  Process          bRIB/RIB    SendTblVer
  Speaker          160385     160385
Last Modified: Mar  6 09:14:55.098 for 00:07:14
Paths: (2 available, best #1)
  Not advertised to any peer
  Path #1: Received by speaker 0
  Not advertised to any peer
  2, (received & used)
    1.1.1.1 (metric 20) from 1.1.1.1 (1.1.1.5)
      Origin IGP, localpref 100, valid, internal, best, group-best, multipath
      Received Path ID 1, Local Path ID 1, version 160385
      Extended community: LB:1000:128
                          (LB non-transitive AS:bytes/sec:1000:16000.0)
      Originator: 1.1.1.5, Cluster list: 1.1.1.1
  Path #2: Received by speaker 0
  Not advertised to any peer
  2, (received & used)
    1.1.1.2 (metric 20) from 1.1.1.2 (1.1.1.5)
      Origin IGP, localpref 100, valid, internal, multipath
      Received Path ID 1, Local Path ID 0, version 0
      Extended community: LB:1000:64
                          (LB non-transitive AS:bytes/sec:1000:8000.0)
      Originator: 1.1.1.5, Cluster list: 1.1.1.2
```

This is sample output from **show bgp vrf vrf-name ipv4unicast prefix/length** command that displays Accept Own prefix information on a customer (originating) VRF:

```
Router#show bgp vrf customer1 ipv4 uni 110.1.1.1/32
BGP routing table entry for 110.1.1.1/32, Route Distinguisher: 10.10.10.10:1
Versions:
  Process          bRIB/RIB    SendTblVer
  Speaker          1412487     1412487
  Local Label: 137742
Last Modified: Jul 19 14:42:43.690 for 01:01:22
Paths: (2 available, best #1)
  Advertised to PE peers (in unique update groups):
    45.1.1.1
  Path #1: Received by speaker 0
  Advertised to PE peers (in unique update groups):
    45.1.1.1
  101
    10.5.1.2 from 10.5.1.2 (10.5.1.2)
      Origin incomplete, localpref 100, valid, external, best, group-best, import-candidate

      Received Path ID 0, Local Path ID 1, version 1412487
      Extended community: RT:100:1
  Path #2: Received by speaker 0
  Not advertised to any peer
  101
    15.1.1.1 from 55.1.1.1 (15.1.1.1)
      Received Label 137742
```

```

Origin incomplete, localpref 100, valid, internal, import-candidate, not-in-vrf,
accept-own-self
Received Path ID 0, Local Path ID 0, version 0
Community: accept-own
Extended community: RT:100:1 RT:1000:1
Originator: 15.1.1.1, Cluster list: 55.1.1.1, 75.1.1.1, 45.1.1.1

```

This is sample output from **show bgp vrf vrf-name ipv4unicast prefix/length** command that displays Accept Own prefix information on a service VRF:

```

Router#show bgp vrf service1 ipv4 uni 110.1.1.1/32
BGP routing table entry for 110.1.1.1/32, Route Distinguisher: 11.11.11.11:1
Versions:
  Process          bRIB/RIB   SendTblVer
  Speaker          1412497    1412497
Last Modified: Jul 19 14:43:08.690 for 01:39:22
Paths: (1 available, best #1)
  Advertised to CE peers (in unique update groups):
    10.8.1.2
  Path #1: Received by speaker 0
  Advertised to CE peers (in unique update groups):
    10.8.1.2
101
  10.5.1.2 from 55.1.1.1 (15.1.1.1)
  Origin incomplete, localpref 100, valid, internal, best, group-best, import-candidate,
  imported, accept-own
  Received Path ID 0, Local Path ID 1, version 1412497
  Community: accept-own
  Extended community: RT:100:1 RT:1000:1
  Originator: 15.1.1.1, Cluster list: 55.1.1.1, 75.1.1.1, 45.1.1.1

```

This table describes the significant fields shown in the display:

Field	Description
accept-own-self	The Accept Own path in the customer VRF contains the "accept-own-self" keyword/flag.
accept-own	The Accept Own path contains the "accept-own" keyword/flag.
Community:accept-own	List of communities attached to the path: accept-own.
Extended community	List of extended communities attached to the path.
Cluster list	Router ID or cluster ID of all route reflectors through which the route has passed.

The output of **show bgp {vpn4 | vpn6} unicast rd** command may display the optional BGP attribute `not-in-vrf`. If a path in a VPNvX net is marked as `not-in-vrf`, it may be due to any of the following conditions:

- The RD of the VPNvX net is not the same as any of the RDs configured for VRFs on the router.
- The RD of the VPNvX net is the same as the RD configured for a specific VRF on the router, but the path is not imported to the specified VRF. For example, the route-targets attached to the path do not match any of the **import route-target** [*as-number:nn* | *ip-address:nn*] configured for VRF, *vrf_1*.

If the not-in-vrf net is set, it indicates that the path does not belong to the VRF.

This is sample output from the **show bgp ipv4 unicast** command showing the status of the permanent network:

```
Router# show bgp ipv4 unicast 1.0.0.0/24
BGP routing table entry for 1.0.0.0/24
Versions:
  Process          bRIB/RIB  SendTblVer
  Speaker          90113    90113
Last Modified: Sep  6 04:46:03.650 for 00:14:19
Permanent Network
Paths: (2 available, best #2)
  Advertised to peers (in unique update groups):
    2.2.2.2
  Path #1: Received by speaker 0
  Advertised to peers (in unique update groups):
    3.3.3.3
  Local
    0.0.0.0 from 0.0.0.0 (1.1.1.1)
      Origin incomplete, metric 0, localpref 100, local, permanent-path
      Received Path ID 0, Local Path ID 4, version 90113
      Origin-AS validity: not-found
  Path #2: Received by speaker 0
  Advertised to peers (in unique update groups):
    2.2.2.2
  7813 7814
    11.11.22.22 from 11.11.22.22 (192.1.1.1)
      Origin EGP, localpref 100, valid, external, best, group-best, import-candidate
      Received Path ID 0, Local Path ID 1, version 4
      Origin-AS validity: not-found
```

This is a sample output of **show bgp** command that displays large-communities in the list of attributes:

```
Router#show bgp 3.3.3.3/32
Thu Mar 23 14:36:15.301 PDT
BGP routing table entry for 3.3.3.3/32
Versions:
  Process          bRIB/RIB  SendTblVer
  Speaker          42        42
Last Modified: Mar 22 20:04:46.000 for 18:31:30
Paths: (1 available, best #1)
  Advertised to peers (in unique update groups):
    11.11.11.5
  Path #1: Received by speaker 0
  Advertised to peers (in unique update groups):
    11.11.11.5
  Local
    10.10.10.3 from 10.10.10.3 (3.3.3.3)
      Origin incomplete, metric 0, localpref 94, valid, internal, best, group-best
      Received Path ID 0, Local Path ID 0, version 42
      Community: 258:259 260:261 262:263 264:265
      Large Community: 1:2:3 5:6:7 4123456789:4123456780:412345678
```

This example shows a sample output of **show bgp ip-address** command.

This example shows that the route is not preferred for outbound traffic within the AS and is used as a last resort. Additionally, it will not be advertised to external BGP peers, thereby limiting its propagation to within the local AS.


```

Router# show bgp 10.1.1.1

Path #32: Received by speaker 0
...
192.0.2.254 (metric 30) from 10.1.1.1 (192.0.2.254)
  Origin IGP, localpref 0, valid, internal, add-path
  Received Path ID 40, Local Path ID 9, version 14321
  Community: llgr-stale no-export
  Originator: 192.0.2.254, Cluster list: 10.1.1.1

```

This table describes the significant fields shown in the display.

Table 4: show bgp ip-address Field Descriptions

Field	Description
localpref 0	Indicates that the local preference value for this route is set to 0. Local preference is used to prefer one route over another within the same AS. A lower local preference value indicates a less preferred route.
llgr-stale	Route marked as llgr-stale community.
no-export	Route marked as no-export community.

This example shows a sample output of **show bgp ipv4 flowspec** and **show bgp ipv6 flowspec** commands.

```

Router# show bgp ipv4 flowspec
Wed Apr 23 18:27:57.484 PDT
BGP router identifier 192.0.2.2, local AS number 64540
BGP generic scan interval 60 secs
Non-stop routing is enabled
BGP table state: Active
Table ID: 0x0 RD version: 972
BGP table nexthop route policy:
BGP main routing table version 972
BGP NSR Initial initsync version 2 (Reached)
BGP NSR/ISSU Sync-Group versions 0/0
BGP scan interval 60 secs

Status codes: s suppressed, d damped, h history, * valid, > best
               i - internal, r RIB-failure, S stale, N Nexthop-discard
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network          Next Hop              Metric LocPrf Weight Path
*>iDest:209.165.201.5/27/48
                10.1.3.2                  100         0 i
* i              10.1.3.2                  100         0 i
-snip-
*>iSource:209.165.201.2/27/40
                10.1.2.1                  100         0 i
* i              10.1.2.1                  100         0 i

Processed 240 prefixes, 480 paths

Router# show bgp ipv6 flowspec
Wed Apr 23 18:28:13.518 PDT
BGP router identifier 192.0.2.2, local AS number 64540
BGP generic scan interval 60 secs
Non-stop routing is enabled
BGP table state: Active
Table ID: 0x0 RD version: 242

```

```

BGP table nexthop route policy:
BGP main routing table version 242
BGP NSR Initial initsync version 2 (Reached)
BGP NSR/ISSU Sync-Group versions 0/0
BGP scan interval 60 secs

Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, r RIB-failure, S stale, N Nexthop-discard
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network                Next Hop                Metric LocPrf Weight Path
*>iDest:2001:DB8::3/0-128/152
                2001:DB8::2                        100          0 i
* i                2001:DB8::2                        100          0 i
-snip-
*>iSource:2001:DB8::1/0-64/88
                2001:DB8::3                        100          0 i
* i                2001:DB8::3                        100          0 i

Processed 60 prefixes, 120 paths

```

This table describes the significant fields shown in the display.

Table 5: show bgp ipv4/ipv6 flowspec field descriptions

Field	Description
Network	Indicates the IPv4 or IPv6 FlowSpec prefix or route being advertised. IPv4: In the example 209.165.201.5/27/48, • 209.165.201.5/27/48 indicates the IPv4 prefix. • /27 indicates the netmask, meaning the first 27 bits of the IP address define a single, specific host address. This netmask helps specify the exact range of IP addresses that the flowspec rule applies to. • /48 indicates the Network Layer Reachability Information (NLRI) length, representing the total length of the FlowSpec NLRI including match fields. The format is: <match fields>:<prefix>/<netmask>/<NLRI length> IPv6: In the example 2001:DB8::1/0-64/88, • 2001:DB8:: indicates the IPv6 prefix. • 0-64 indicates the offset and prefix length in the FlowSpec match fields. • /88 indicates the NLRI length, representing the total length of the FlowSpec NLRI including match fields. The format is: <match fields>:<prefix>/<offset>-<prefix length>/<NLRI length>

show bgp aggregate contributors

To view the aggregate contributors for a specific aggregate address, run the **show bgp aggregate-contributors** command in EXEC mode.

show bgp *address/mask-length* **aggregate-contributors**

Syntax Description	aggregate-contributors Displays the aggregate contributors of an aggregate address.	
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	Release 7.5.4	This command was introduced.
Usage Guidelines	- To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. - The command is applicable for the following Address Family Indicators (AFIs): - IPv4 unicast - IPv6 unicast	
Task ID	Task ID	Operation
	bgp	read

The following output displays all aggregate contributors of the BGP address 250.2.2.0/24:

```
Router1#show bgp 250.2.2.0/24 aggregate-contributors
Thu Dec 1 10:15:20.393 EST
BGP router identifier 192.168.0.2, local AS number 100
BGP generic scan interval 60 secs
Non-stop routing is enabled
BGP table state: Active
Table ID: 0xe0000000 RD version: 247
BGP main routing table version 247
BGP NSR Initial initsync version 22 (Reached)
BGP NSR/ISSU Sync-Group versions 247/0
BGP scan interval 60 secs

Status codes: s suppressed, d damped, h history, * valid, > best
               i - internal, r RIB-failure, S stale, N Nexthop-discard
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network        Next Hop           Metric LocPrf Weight Path
*> 250.2.2.1/32    13.0.1.1                      0 105 i
*> 250.2.2.2/32    13.0.2.1                      0 105 i
```

show bgp aggregate contributors

```
*> 250.2.2.3/32      13.0.3.1      0 101 i
*> 250.2.2.4/32      13.0.4.1      0 101 i
*> 250.2.2.5/32      13.0.5.1      0 102 i
*> 250.2.2.6/32      13.0.6.1      0 102 i
*> 250.2.2.7/32      13.0.7.1      0 103 i
*> 250.2.2.8/32      13.0.8.1      0 103 i
*> 250.2.2.9/32      13.0.9.1      0 104 i
*> 250.2.2.10/32     13.0.10.1     0 104 i
*> 250.2.2.11/32     0.0.0.0       0 32768 ?
*> 250.2.2.12/32     0.0.0.0       0 32768 ?
*> 250.2.2.13/32     0.0.0.0       0 32768 ?
```

Processed 13 prefixes, 13 paths

show bgp bmp

To display Border Gateway Protocol (BGP) Monitoring Protocol (BMP) information, use the **show bgp bmp** command in EXEC mode.

```
show bgp bmp { server server-id [detail] | summary }
```

```
show bgp bmp server <server-id> [[vrf <vrf> ] neighbor <neighbor-ip> ] [detail | wide]
```

```
show bgp bmp [mode route-monitoring { inbound pre-policy | inbound post-policy | local-rib | all}]  
[<afi> <safi>] table [rd <rd> | vrf <vrf-name> ] [neighbor <address> | version begin <begin-version>  
end <end-version> | prefix <prefix-length> | summary]
```

```
show bgp bmp [mode route-monitoring { inbound pre-policy | inbound post-policy | local-rib | all}] vrf  
<vrf-name> [<afi> <safi>] table [neighbor <address> | version begin <begin-version> end  
<end-version> | prefix <prefix-length>]
```

```
show bgp bmp mode route-monitoring local-rib [vrf <vrf-name> ] emulated-peers  
<emulated-peer-address> [detail | performance-statistics | brief]
```

```
show bgp bmp mode route-monitoring local-rib [vrf <vrf-name> ] internal update-group  
<update-group-index> [summary] | emulated-peer <emulated-peer-address> ] [performance-statistics]
```

```
show bgp bmp mode route-monitoring local-rib internal update out [emulated-peer emulated-peer-address  
]
```

```
show bgp bmp [mode route-monitoring { inbound pre-policy | inbound post-policy | local-rib | all}]  
[<afi> <safi>] convergence
```

```
show bgp bmp [mode route-monitoring { inbound pre-policy | inbound post-policy | local-rib | all}] vrf  
<vrf-name> [<afi> <safi>] table prefix <prefix-length> detail
```

```
show bgp bmp mode route-monitoring inbound pre-policy [<afi> <safi>] convergence
```

```
show bgp bmp mode route-mirroring convergence
```

Syntax Description		
server <i>server-id</i>		Displays information about BMP server as specified by the <i>server-id</i> variable.
detail		(Optional) Displays detailed BMP server information.
summary		Displays summary information about all the configured BMP servers.
wide		Wide tabular formatting of the BMP neighbor details.
table		Show prefixes and paths from the Inbound Post-Policy and Local RIB tables.
ipv4		IP Version 4 address prefixes
ipv6		IP Version 6 address prefixes
vpn4		VPN version 4 address family

vpnv6	VPN version 6 address family
unicast	Unicast sub-address family
labeled-unicast	Labeled Unicast sub-address family
all	• When used as address family, the command is executed for all address families. • When used as sub-address family, the command is executed for all sub-address families.
neighbor	Output of the command is filtered for a specific neighbor.
mode	Execute the command for the specified BMP monitoring mode.
rd	Output of the command is filtered for a specific route distinguisher.
vrf	Output of the command is filtered for a specific VRF.
summary	Show only the summary information
begin	Begin version of a version range that is used for filtering the prefixes within that range.
end	End version of a version range that is used for filtering the prefixes within that range.
emulated-peers	BMP Local-RIB emulated peers
brief	Display the output in brief tabular format.
detail	Display detailed information
performance-statistics	Display performance statistics

Command Default	No default behavior or values

Command Modes	Router Configuration

Command History	Release	Modification
	Release 24.4.1	The structure of the show bgp bmp mode command has been enhanced to include the new route-mirroring mode, allowing you to select between route-mirroring and route-monitoring at the mode selection level.
	Release 24.1.1	The option to specify AFI and SAFI after the table keyword is completely removed from Cisco IOS XR Release 24.1.1.

Release	Modification
Release 7.5.4	The syntax of the show bgp bmp table vpnv4 unicast command was modified. Specifying AFI and SAFI after the table keyword option is not supported from Release 7.5.4. So, it is recommended to specify AFIs and SAFIs before the table keyword.
Release 7.5.4	This command was modified with Inbound Post-Policy and Local RIB view.
Release 5.2.2	This command was introduced.

Usage Guidelines

Inbound Pre-Policy, Inbound Post-Policy and Local-RIB tables

- If AFI/SAFI is not specified while running the commands, the default IPv4 Unicast AFI/SAFI is considered.
Starting Release 24.4.1, the default AFI/SAFI is deprecated. While the default AFI/SAFI will still be used if none is specified, specifying AFI/SAFI will become mandatory in a future release.
- If mode is not specified, the default mode inbound post-policy is considered.
Starting Release 24.4.1, the default mode is deprecated. While the default mode will still be used if none is specified, specifying mode will become mandatory in a future release.
- Specifying AFIs and SAFIs after the **table** keyword option is not supported from Release 7.5.4. So, you can specify the same before the **table** keyword as follows:
show bgp bmp [mode route-monitoring <bmp-mode>] [<afi> <safi>] table
- Starting from Release 7.5.4, if AFIs or SAFIs are specified before and after the **table** keyword, the AFIs or SAFIs after the **table** keyword are considered.
- The following filters are only available for **vpnv4 unicast** and **vpnv6 unicast** AFIs:
 - **rd**
 - **vrf**
- The *begin-version* of the **bmp table version** can be smaller than or greater than or equal to *end-version*.

Emulated-Peers

- The keyword **brief** can be used only when **vrf** is not specified.
- The keyword **emulated-peers** is only applicable for Local-RIB.

BGP BMP Convergence

Use the **show bgp bmp mode <mode> convergence** command to see if there is any pending work for BGP to perform. The software checks the following conditions to determine whether the specified address family has converged:

- Table copy is not pending (applicable only in case of Inbound Post-Policy)
- Update generation is not pending

- All BMP servers that are not administratively shutdown are *Up* state
- All BMP servers have caught up to the table version
- Write queues of all BMP servers are empty

If all the above conditions are true, the address family is considered converged.

Task ID

Task ID

bgp read

Examples

The following example shows sample output from the **show bgp bmp** command when the **summary** keyword is used:

```
Router# show bgp bmp summary
ID  Host          Port    State   Time        NBRs
1   10.0.101.1    16666  ESTAB   00:29:52    1
2   10.0.101.2    16667  ESTAB   00:29:52    0
3   fed0::1001    26666  ESTAB   00:29:52    0
4   fed0::1002    26667  ESTAB   00:29:52    0
5   10.0.101.1    16666  ESTAB   00:21:49    0
6   10.0.101.1    16666  ESTAB   00:29:52    0
7   fed0::1001    26666  ESTAB   00:29:52    0
8   fed0::1001    26666  ESTAB   00:29:52    0
```

The **show bgp bmp summary** command displays BMP server summary information such as server address and port number, server state, time for which server is up and the number of neighbors the server is monitoring.

The **show bgp bmp server <ID>** command displays BMP server details, BMP update modes exported to the BMP server, configured (or default) values specific to the update modes, update generation details, TCP connection status, BMP server specific message statistics, and statistics of the neighbors monitored by the BMP server.

```
Router#show bgp bmp server 1
BMP server 1
Host 12.1.2.1 Port 16001
Connected for 01:19:20
Last Disconnect event received : 00:00:00
Precedence: internet
BGP neighbors: 14
VRF: - (0x60000000)
Update Source: - (-)
Update Source Vrf ID: 0x0
Update Mode                               : In-Post-Policy, Local-RIB
  In-Post-Policy
    Advertisement interval                 : 15 secs
    Scanner interval                       : 60 secs
  Local-RIB
    Advertisement interval                 : 15 secs
    Scanner interval                       : 60 secs
    Global
      IPv4 Unicast                         : 60 secs
      VPNv4 Unicast                       : 60 secs
      IPv6 Unicast                         : 60 secs
```



```

      VPNv6 Unicast                : 60 secs
Flapping Delay                    : 300 secs
Initial Delay                     : 0 secs
Initial Refresh Delay             : 1 secs
Initial Refresh Spread            : 1 secs
Stats Reporting Period            : 0 secs
Queue Route Mon Msg buffer limit  : 133693 KB (Current Server Up Count: 2)
Queue Route Mon Msg buffer usage  : 0 B
Queue write pulse sent            : Feb  6 12:32:13.676, not set (all)
Queue write pulse received        : Feb  6 12:32:13.676
Update Generation in Progress     : No
Reset Walk in Progress            : No
IPv4 Unicast
  Version                         : 11
  Init EOR Version                : 11
  Init EOR Pending count          : 0
  Update Generation
    Last Run                      : Feb  6 12:32:04.615, Count 1
    Walk Currently Stalled        : No, Last Stalled : not set, Count 0
VPNv4 Unicast
  Version                         : 14
  Init EOR Version                : 14
  Init EOR Pending count          : 0
  Update Generation
    Last Run                      : Feb  6 12:32:04.615, Count 1
    Walk Currently Stalled        : No, Last Stalled : not set, Count 0
IPv6 Unicast
  Version                         : 12
  Init EOR Version                : 12
  Init EOR Pending count          : 0
  Update Generation
    Last Run                      : Feb  6 12:32:04.615, Count 1
    Walk Currently Stalled        : No, Last Stalled : not set, Count 0
VPNv6 Unicast
  Version                         : 16
  Init EOR Version                : 16
  Init EOR Pending count          : 0
  Update Generation
    Last Run                      : Feb  6 12:32:04.615, Count 1
    Walk Currently Stalled        : No, Last Stalled : not set, Count 0

TCP:
  Last message sent: Feb  6 12:32:04.615, Status: No Pending Data
  Last write pulse received: Feb  6 12:32:04.863, Waiting: FALSE

Message Stats:
Total msgs dropped                : 0
Total msgs pending                : 0, Max: 19 at Feb  6 12:32:04.615
Total messages sent                : 100
Total bytes sent                  : 13148, Time spent: 0.000 secs
  INITIATION                      : 1
  TERMINATION                     : 0
  STATS-REPORT                    : 0
  PER-PEER messages               : 99
  ROUTE-MON messages              : 88
  EOR messages                    : 30
  Update messages                 : 58 (Prefixes: 41, Err: 0)
Update gen time spent: 0.000 secs

Neighbor 12.100.0.1 (vrf foo)
  Messages pending                : 0
  Messages dropped                : 0
  Messages sent                   : 5
  PEER-UP                        : 1

```

```

        PEER-DOWN      : 0
        ROUTE-MON      : 4
        EOR            : 2
        Update         : 2 (Prefixes: 4, Err: 0)

Neighbor 12:100::1 (vrf foo)
  Messages pending : 0
  Messages dropped : 0
  Messages sent    : 3
    PEER-UP        : 1
    PEER-DOWN      : 0
    ROUTE-MON      : 2
    EOR            : 1
    Update         : 1 (Prefixes: 2, Err: 0)

Neighbor 12.101.0.1 (vrf bar)
  Messages pending : 0
  Messages dropped : 0
  Messages sent    : 5
    PEER-UP        : 1
    PEER-DOWN      : 0
    ROUTE-MON      : 4
    EOR            : 2
    Update         : 2 (Prefixes: 4, Err: 0)

Neighbor 12.0.0.1 (vrf default)
  Messages pending : 0
  Messages dropped : 0
  Messages sent    : 7
    PEER-UP        : 1
    PEER-DOWN      : 0
    ROUTE-MON      : 6
    EOR            : 4
    Update         : 2 (Prefixes: 4, Err: 0)

```

From Release 24.4.1, the output of the **show bgp bmp server 1 detail** command is updated to include **Rmon-In-Pre-Policy**, and **Rmon-In-Post-Policy** details. For example,

```

Router# show bgp bmp server 1 detail
Thu Nov 28 10:53:10.659 UTC
BMP server 1
Host 12::2 Port 17001
NOT Connected
Last Disconnect event received : 00:15:10
Flap count : 1
Precedence: internet
BGP neighbors: 68
VRF: - (0x60000000)
Update Source: - (-)
Update Source Vrf ID: 0x0
Update Mode                               : Rmon-In-Pre-Policy, Rmon-In-Post-Policy
  Rmon-In-Pre-Policy
    Advertisement interval                  : 15 secs
    Advertisement interval (Oper)          : 15 secs
    Scanner interval                       : 60 secs
    Scanner interval (Oper)                : 60 secs
  Rmon-In-Post-Policy
    Advertisement interval                  : 15 secs
    Advertisement interval (Oper)          : 15 secs
    Scanner interval                       : 60 secs
    Scanner interval (Oper)                : 60 secs
Flapping Delay                            : 300 secs
Initial Delay                             : 0 secs
Initial Refresh Delay                      : 1 secs

```

```

Initial Refresh Spread      : 1 secs
Stats Reporting Period     : 0 secs
Queue Route Mon Msg buffer limit : 503316 KB (Current Server Up Count: 0)
Queue Route Mon Msg buffer usage : 0 B
Queue write pulse sent      : Nov 28 10:33:23.988, Nov 28 10:38:00.258 (all)
Queue write pulse received   : Nov 28 10:38:00.258
Update Generation in Progress : No
Reset Walk in Progress      : No

IPv4 Unicast
  Version                   : 416
  Rmon-In-Pre-Policy:
    Init EOR Version        : 416
    Init EOR Pending count   : 0
  Rmon-In-Post-Policy:
    Init EOR Version        : 416
    Init EOR Pending count   : 0
  Update Generation
    Last Run                 : Nov 28 10:33:23.982, Count 1
    Walk Currently Stalled   : No, Last Stalled : not set, Count 0

VPNv4 Unicast
  Version                   : 200
  Rmon-In-Pre-Policy:
    Init EOR Version        : 200
    Init EOR Pending count   : 0
  Rmon-In-Post-Policy:
    Init EOR Version        : 200
    Init EOR Pending count   : 0
  Update Generation
    Last Run                 : Nov 28 10:33:23.984, Count 1
    Walk Currently Stalled   : No, Last Stalled : not set, Count 0

IPv6 Unicast
  Version                   : 505
  Rmon-In-Pre-Policy:
    Init EOR Version        : 505
    Init EOR Pending count   : 0
  Rmon-In-Post-Policy:
    Init EOR Version        : 505
    Init EOR Pending count   : 0
  Update Generation
    Last Run                 : Nov 28 10:33:23.985, Count 1
    Walk Currently Stalled   : No, Last Stalled : not set, Count 0

VPNv6 Unicast
  Version                   : 320
  Rmon-In-Pre-Policy:
    Init EOR Version        : 320
    Init EOR Pending count   : 0
  Rmon-In-Post-Policy:
    Init EOR Version        : 320
    Init EOR Pending count   : 0
  Update Generation
    Last Run                 : Nov 28 10:33:23.987, Count 1
    Walk Currently Stalled   : No, Last Stalled : not set, Count 0

TCP:
  Last message sent: Nov 28 10:33:24.215, Status: Not Connected
  Last write pulse received: Nov 28 10:33:24.311, Waiting: FALSE

Message Stats:
Total msgs dropped   : 0
Total msgs pending   : 0, Max: 587 at Nov 28 10:33:23.988
Total messages sent  : 712
Total bytes sent     : 133462, Time spent: 0.006 secs
  INITIATION         : 1
  TERMINATION         : 0

```

show bgp bmp

```

STATS-REPORT      : 0
PER-PEER messages : 711

PEER UP messages   : 68
PEER DOWN messages : 0
ROUTE-MIR messages : 0
ROUTE-MON messages : 643
  Last RMon EnQ     : Nov 28 10:33:23.988
  EOR messages      : 278
  Update messages   : 365 (Prefixes: 3254, Err: 0)
Update gen time spent: 0.005 secs

Neighbor 2001:DB8:1:5 (vrf vrf1)
Last BMP Activate   : Nov 28 10:33:15.065
First Peer Up EnQ   : Nov 28 10:33:15.065
Last Peer Up EnQ    : Nov 28 10:33:15.065
Last EOR Pending    : not set
Last EOR EnQ        : not set
Last RMon EnQ       : Nov 28 10:33:23.988
Messages pending    : 0
Messages dropped     : 0
Messages sent       : 3
  PEER-UP           : 1
  PEER-DOWN         : 0

Rmon-In-Pre-Policy:
ROUTE-MON           : 1
  Update            : 1 (Prefixes: 10, Err: 0)

Rmon-In-Post-Policy:
ROUTE-MON           : 1
  Update            : 1 (Prefixes: 10, Err: 0)

Neighbor 2001:DB8:3:5 (vrf vrf1)
Last BMP Activate   : Nov 28 10:33:15.065
First Peer Up EnQ   : Nov 28 10:33:15.065
Last Peer Up EnQ    : Nov 28 10:33:15.065
Last EOR Pending    : not set
Last EOR EnQ        : not set
Last RMon EnQ       : Nov 28 10:33:23.988
Messages pending    : 0
Messages dropped     : 0
Messages sent       : 3
  PEER-UP           : 1
  PEER-DOWN         : 0

Rmon-In-Pre-Policy:
ROUTE-MON           : 1
  Update            : 1 (Prefixes: 10, Err: 0)

Rmon-In-Post-Policy:
ROUTE-MON           : 1
  Update            : 1 (Prefixes: 10, Err: 0)

Neighbor 2001:DB8:2:5 (vrf vrf1)
Last BMP Activate   : Nov 28 10:33:15.065
First Peer Up EnQ   : Nov 28 10:33:15.065
Last Peer Up EnQ    : Nov 28 10:33:15.065
Last EOR Pending    : not set
Last EOR EnQ        : not set
Last RMon EnQ       : Nov 28 10:33:23.988
Messages pending    : 0
Messages dropped     : 0
Messages sent       : 3

```

```

PEER-UP          : 1
PEER-DOWN        : 0

```

....

The mode names are prefixed with **Rmon** (Route Monitoring) or **Rmir** (Route Mirroring). In addition, the ROUTE-MON statistics are now specified on a per mode basis.

The **show bgp bmp server <ID>** command with the **wide** command displays the same information as **show bgp bmp server <ID>** except that it displays the neighbor information in a wide tabular format.

The **show bgp bmp server <ID>** command displays the advertisement-interval time that you configured.

```

Router#show bgp bmp server 1
BMP server 1
Host 12.1.2.1 Port 16001
Connected for 04:22:39
Last Disconnect event received : 00:00:00
Precedence: internet
BGP neighbors: 10
VRF: - (0x60000000)
Update Source: - (-)
Update Source Vrf ID: 0x0
Update Mode                               : In-Post-Policy, Local-RIB
  In-Post-Policy
    Advertisement interval                 : 15 secs
    Scanner interval                       : 60 secs
  Local-RIB
    Advertisement interval                 : 15 secs
    Scanner interval
      Global                               : 60 secs
      IPv4 Unicast                         : 60 secs
      VPNv4 Unicast                       : 60 secs
      IPv6 Unicast                         : 60 secs
      VPNv6 Unicast                       : 60 secs
    Flapping Delay                        : 300 secs
    Initial Delay                         : 0 secs
    Initial Refresh Delay                  : 1 secs
    Initial Refresh Spread                  : 1 secs
    Stats Reporting Period                  : 0 secs
    Queue Route Mon Msg buffer limit       : 133693 KB (Current Server Up Count: 2)
    Queue Route Mon Msg buffer usage       : 0 B
    Queue write pulse sent                 : Dec 16 15:19:36.755, not set (all)
-----More-----

```

The **show bgp bmp server <ID>** command displays the BMP scan time that you configured.

```

Router#show bgp bmp server 1
BMP server 1
Host 12.1.2.1 Port 16001
Connected for 04:22:39
Last Disconnect event received : 00:00:00
Precedence: internet
BGP neighbors: 10
VRF: - (0x60000000)
Update Source: - (-)
Update Source Vrf ID: 0x0
Update Mode                               : In-Post-Policy, Local-RIB
  In-Post-Policy
    Advertisement interval                 : 15 secs

```

show bgp bmp

```

Scanner interval           : 60 secs
Local-RIB
Advertisement interval     : 15 secs
Scanner interval
  Global                   : 60 secs
  IPv4 Unicast             : 60 secs
  VPNv4 Unicast            : 60 secs
  IPv6 Unicast             : 60 secs
  VPNv6 Unicast            : 60 secs
Flapping Delay            : 300 secs
Initial Delay              : 0 secs
Initial Refresh Delay     : 1 secs
Initial Refresh Spread    : 1 secs
Stats Reporting Period    : 0 secs
Queue Route Mon Msg buffer limit : 133693 KB (Current Server Up Count: 2)
Queue Route Mon Msg buffer usage : 0 B
Queue write pulse sent    : Dec 16 15:19:36.755, not set (all)
-----More-----

```

Starting from Release 24.4.1, the **show bgp bmp mode inbound post-policy table** command is modified to **show bgp bmp mode route-monitoring inbound post-policy table**. The output of this command is modified as well.

```

Router# show bgp bmp mode route-monitoring inbound post-policy table
Thu Nov 28 10:54:35.570 UTC

```

```

-----
Route monitoring mode : Inbound Post-Policy
-----

```

```

Bitmap and Status Codes:
  u: Update send pending      U: Update sent
  w: Withdraw send pending    W: Withdraw sent, path awaiting deletion
  D: Server down              .: Server not configured or mode not applicable

```

```

Address-Family : IPv4 Unicast
-----

```

```

BMP prefix table version : 1196

```

Network	Version	Neighbor	Adv Status	Flags	Path ID
			87654321		
10.2.2.2/8	1	10.2.2.2	DD	0x0e	1
10.2.0.0/8	2	10.2.2.2	DD	0x0e	1
10.0.1.0/8	3	10.2.2.2	DD	0x0e	1
10.0.2.0/8	4	10.2.2.2	DD	0x0e	1
10.0.0.0/8	5	10.2.2.2	DD	0x0e	1
192.168.0.1/16	6	10.2.2.2	DD	0x0e	1
209.165.201.1/27	7	10.2.2.2	DD	0x0e	4
209.165.201.1/27	7	10.2.2.2	DD	0x0e	3
209.165.201.1/27	7	10.2.2.2	DD	0x0e	2
209.165.201.1/27	7	10.2.2.2	DD	0x0e	1
209.165.201.1/27	7	10.2.2.2	DD	0x0e	7
209.165.201.1/27	7	10.2.2.2	DD	0x0e	6
209.165.201.1/27	7	10.2.2.2	DD	0x0e	5
209.165.201.1/27	7	10.2.2.2	DD	0x0e	10
209.165.201.1/27	7	10.2.2.2	DD	0x0e	8
209.165.201.2/27	8	10.2.2.2	DD	0x0e	4
209.165.201.2/27	8	10.2.2.2	DD	0x0e	3
....					

The send bitmap and advertisement bitmap have been replaced with a more readable method to determine whether the prefix is advertised to each of the configured servers or is pending advertisement. Additionally, the output now includes the interpretation of advertised status codes.

The following example shows a brief summary of the prefixes for BMP mode **Local-RIB** and **IPv4 Unicast AFI**:

```
Router#show bgp bmp mode route-monitoring local-rib table
-----
Route monitoring mode : Local-RIB
-----
Address-Family : IPv4 Unicast
-----
BGP main routing table version : 9
Number of prefixes: 4, paths: 4

      Network          Next Hop          Metric LocPrf Path
-----
10.1.1.3/32           10.0.1.3             0      100 ?
10.1.2.3/32           10.0.2.3             0      100 ?
10.1.1.1/32           10.0.0.1             0       1 ?
10.2.1.1/32           10.0.0.1             0       1 ?
Processed 4 prefixes, 4 paths
```

The following example shows a brief summary of the prefixes for BMP mode **Inbound Post-Policy** and **VPNv4 Unicast AFI**:

```
Router# show bgp bmp mode route-monitoring inbound pre-policy vpnv4 unicast table

Thu Nov 28 10:56:13.122 UTC

-----
Route monitoring mode : Inbound Pre-Policy
-----

Bitmap and Status Codes:
  u: Update send pending      U: Update sent
  w: Withdraw send pending    W: Withdraw sent, path awaiting deletion
  D: Server down              .: Server not configured or mode not applicable

Address-Family : VPNv4 Unicast
-----
BMP prefix table version : 500

      Network          Version      Neighbor      Adv Status  Flags  Path ID
-----
Route Distinguisher: 65000:2 (default for vrf vrf1), Version 200
209.165.201.1/27      7           10.2.2.2      .....DD     0x0e
209.165.201.1/27      7           10.2.2.2      .....DD     0x0e
209.165.201.1/27      7           10.2.2.2      .....DD     0x0e
209.165.201.1/27      7           10.2.2.2      .....DD     0x0e
209.165.201.1/27      7           10.2.2.2      .....DD     0x0e
209.165.201.1/27      7           10.2.2.2      .....DD     0x0e
209.165.201.1/27      7           10.2.2.2      .....DD     0x0e
209.165.201.1/27      7           10.2.2.2      .....DD     0x0e
209.165.201.2/27      8           10.2.2.2      .....DD     0x0e
209.165.201.2/27      8           10.2.2.2      .....DD     0x0e
```

The following example shows a brief summary of the prefixes for **all** BMP modes and **all** AFIs:

```
Router# show bgp bmp mode route-monitoring inbound all table
```

```
Thu Nov 28 10:55:03.096 UTC
```

```
-----
Route monitoring mode : Inbound All
-----
```

```
Bitmap and Status Codes:
```

```
u: Update send pending      U: Update sent
w: Withdraw send pending    W: Withdraw sent, path awaiting deletion
D: Server down              .: Server not configured or mode not applicable
```

```
Address-Family : IPv4 Unicast
```

```
-----
BMP prefix table version : 1196
```

Network	Version	Neighbor	Adv Status (Pre)	Adv Status (Post)	Flags	Path ID
			87654321	87654321		
10.2.2.2/8	1	10.2.2.2	DD	DD	0x0e	1
10.2.0.0/8	2	10.2.2.2	DD	DD	0x0e	1
10.0.1.0/8	3	10.2.2.2	DD	DD	0x0e	1
10.0.2.0/8	4	10.2.2.2	DD	DD	0x0e	1
10.0.0.0/8	5	10.2.2.2	DD	DD	0x0e	1
192.168.0.1/16	6	10.2.2.2	DD	DD	0x0e	1
209.165.201.1/27	7	10.2.2.2	DD	DD	0x0e	4
209.165.201.1/27	7	10.2.2.2	DD	DD	0x0e	3
209.165.201.1/27	7	10.2.2.2	DD	DD	0x0e	2
209.165.201.1/27	7	10.2.2.2	DD	DD	0x0e	1
209.165.201.1/27	7	10.2.2.2	DD	DD	0x0e	7
209.165.201.1/27	7	10.2.2.2	DD	DD	0x0e	6
209.165.201.1/27	7	10.2.2.2	DD	DD	0x0e	5
209.165.201.1/27	7	10.2.2.2	DD	DD	0x0e	10
209.165.201.1/27	7	10.2.2.2	DD	DD	0x0e	9
209.165.201.1/27	7	10.2.2.2	DD	DD	0x0e	8
209.165.201.11/27	8	10.2.2.2	DD	DD	0x0e	4
209.165.201.11/27	8	10.2.2.2	DD	DD	0x0e	3
....						



Note Specifying AFI and SAFI after the **table** keyword option is not supported from Release 7.5.4. So, you can specify the same before the **table** keyword as follows:

```
show bgp bmp [mode route-monitoring <bmp-mode>] [<afi> <safi>] table
```

The option to specify AFI and SAFI after the **table** keyword is completely removed from Cisco IOS XR Release 24.1.1.

The tables for VPN AFI can be filtered on a Route Distinguisher (RD) or a VRF.

The following example shows the **show bgp bmp mode route-monitoring inbound pre-policy vpnv4 unicast table** filtered based on route distinguisher:

```
Router#show bgp bmp mode route-monitoring inbound pre-policy vpnv4 unicast table rd all
```

```
Thu Nov 28 10:57:02.219 UTC
```

```
-----
Route monitoring mode : Inbound Pre-Policy
-----
```

```
Bitmap and Status Codes:
```



```

u: Update send pending      U: Update sent
w: Withdraw send pending    W: Withdraw sent, path awaiting deletion
D: Server down              .: Server not configured or mode not applicable

```

Address-Family : VPNv4 Unicast

BMP prefix table version : 500

Network	Version	Neighbor	Adv Status	Flags	Path ID
87654321					
Route Distinguisher: 65000:2 (default for vrf vrf1), Version 200					
209.165.201.1/27	171	10.2.2.2	DD	0x06	
209.165.201.2/27	172	10.2.2.2	DD	0x06	
209.165.201.3/27	173	10.2.2.2	DD	0x06	
209.165.201.4/27	174	10.2.2.2	DD	0x06	
209.165.201.5/27	175	10.2.2.2	DD	0x06	
209.165.201.6/27	176	10.2.2.2	DD	0x06	
209.165.201.7/27	177	10.2.2.2	DD	0x06	
209.165.201.8/27	178	10.2.2.2	DD	0x06	

...

The following example shows the **show bgp bmp mode route-monitoring inbound pre-policy vpnv4 unicast table** filtered on VRF *vrf1*:

```
Router# show bgp bmp mode route-monitoring inbound pre-policy vpnv4 unicast table vrf vrf1
```

Thu Nov 28 10:57:33.052 UTC

Route monitoring mode : Inbound Pre-Policy

Bitmap and Status Codes:

```

u: Update send pending      U: Update sent
w: Withdraw send pending    W: Withdraw sent, path awaiting deletion
D: Server down              .: Server not configured or mode not applicable

```

Address-Family : VPNv4 Unicast

BMP prefix table version : 500

Network	Version	Neighbor	Adv Status	Flags	Path ID
87654321					
Route Distinguisher: 65000:2 (default for vrf vrf1), Version 200					
209.165.201.1/27	15	10.2.2.2	DD	0x06	
209.165.201.2/27	16	10.2.2.2	DD	0x06	
209.165.201.3/27	17	10.2.2.2	DD	0x06	
209.165.201.4/27	19	10.2.2.2	DD	0x06	
209.165.201.5/27	21	10.2.2.2	DD	0x06	
209.165.201.6/27	25	10.2.2.2	DD	0x06	
209.165.201.7/27	7	10.2.2.2	DD	0x06	
209.165.201.8/27	8	10.2.2.2	DD	0x06	

...

When the **show bgp bmp mode route-monitoring inbound pre-policy table** command is run with prefix filter, it displays the details of the specified prefix as shown in the following example:

```
Router#show bgp bmp mode route-monitoring inbound pre-policy table 209.165.202.129/27
```

Thu Nov 28 11:02:15.942 UTC

Route monitoring mode : Inbound Pre-Policy

```

-----
BGP routing table entry for 209.165.202.129/27
Versions:
  Process          Net
  Speaker          7
Last Modified: Nov 28 10:33:09.428 for 00:29:06
Paths: (10 available)
  Path #1: Received by speaker 0
  Local
  from 10.2.2.2
  Nexthop: 10.0.8.5
  Received Path ID: 4
  Received Local Preference: 0
  Path advertised to BMP server(s) - Server ID: None
  Path pending send to BMP server(s) - Server ID: 1, 2
  Path #2: Received by speaker 0
  Local
  from 10.2.2.2
  Nexthop: 10.0.6.5
  Received Path ID: 3
  Received Local Preference: 0
  Path advertised to BMP server(s) - Server ID: None
  Path pending send to BMP server(s) - Server ID: 1, 2
  Path #3: Received by speaker 0
  Local
  from 10.2.2.2
  Nexthop: 10.0.4.5
  Received Path ID: 2
  Received Local Preference: 0
  Path advertised to BMP server(s) - Server ID: None
  Path pending send to BMP server(s) - Server ID: 1, 2
  Path #4: Received by speaker 0
  Local
  from 10.2.2.2
  Nexthop: 10.0.2.5
  Received Path ID: 1
  Received Local Preference: 0
  Path advertised to BMP server(s) - Server ID: None
  Path pending send to BMP server(s) - Server ID: 1, 2
  Path #5: Received by speaker 0
  Local
  from 10.2.2.2
  Nexthop: 10.0.5.5
  Received Path ID: 7
  Received Local Preference: 0
  Path advertised to BMP server(s) - Server ID: None
  Path pending send to BMP server(s) - Server ID: 1, 2
  Path #6: Received by speaker 0
  Local
  from 10.2.2.2
  Nexthop: 10.0.11.5
  Received Path ID: 6
  Received Local Preference: 0
  Path advertised to BMP server(s) - Server ID: None
  Path pending send to BMP server(s) - Server ID: 1, 2
  Path #7: Received by speaker 0
  Local
  from 10.2.2.2
  Nexthop: 10.0.10.5
  Received Path ID: 5
  Received Local Preference: 0
  Path advertised to BMP server(s) - Server ID: None
  Path pending send to BMP server(s) - Server ID: 1, 2
  Path #8: Received by speaker 0

```

```

Local
  from 10.2.2.2
  Nexthop: 10.0.7.5
  Received Path ID: 10
  Received Local Preference: 0
  Path advertised to BMP server(s) - Server ID: None
  Path pending send to BMP server(s) - Server ID: 1, 2
  Path #9: Received by speaker 0
Local
  from 10.2.2.2
  Nexthop: 10.0.3.5
....

```

The following examples displays the output when you run the **show bgp bmp mode route-monitoring inbound pre-policy table** command with the **neighbor** filter. It displays the prefixes learned from the specified neighbor.

```

Router#show bgp bmp mode route-monitoring inbound pre-policy table neighbor 10.2.2.2
Thu Nov 28 11:01:43.487 UTC

```

```

-----
Route monitoring mode : Inbound Pre-Policy
-----

```

```

Bitmap and Status Codes:
  u: Update send pending      U: Update sent
  w: Withdraw send pending    W: Withdraw sent, path awaiting deletion
  D: Server down              .: Server not configured or mode not applicable

```

```

Address-Family : IPv4 Unicast
-----

```

```

BMP prefix table version : 1196

```

Network	Version	Neighbor	Adv Status	Flags	Path ID
			87654321		
10.2.2.2/8	1	10.2.2.2	DD	0x0e	1
10.2.0.0/8	2	10.2.2.2	DD	0x0e	1
10.0.1.0/8	3	10.2.2.2	DD	0x0e	1
10.0.2.0/8	4	10.2.2.2	DD	0x0e	1
10.0.0.0/8	5	10.2.2.2	DD	0x0e	1
192.168.0.1/16	6	10.2.2.2	DD	0x0e	1
209.165.201.1/27	7	10.2.2.2	DD	0x0e	4
209.165.201.1/27	7	10.2.2.2	DD	0x0e	3
209.165.201.1/27	7	10.2.2.2	DD	0x0e	2
209.165.201.1/27	7	10.2.2.2	DD	0x0e	1
209.165.201.1/27	7	10.2.2.2	DD	0x0e	7
209.165.201.1/27	7	10.2.2.2	DD	0x0e	6
209.165.201.1/27	7	10.2.2.2	DD	0x0e	5
209.165.201.1/27	7	10.2.2.2	DD	0x0e	10
209.165.201.1/27	7	10.2.2.2	DD	0x0e	8
209.165.201.2/27	8	10.2.2.2	DD	0x0e	4
209.165.201.2/27	8	10.2.2.2	DD	0x0e	3
....					

The following example displays filtering of prefixes based on prefix version range. Only the prefixes with version within the specified range are displayed.

```

Router#show bgp bmp mode route-monitoring inbound pre-policy table version begin 1 end 6
Thu Nov 28 11:01:43.487 UTC

```

```

-----

```

```

Route monitoring mode : Inbound Pre-Policy
-----

Bitmap and Status Codes:
  u: Update send pending      U: Update sent
  w: Withdraw send pending    W: Withdraw sent, path awaiting deletion
  D: Server down              .: Server not configured or mode not applicable

Address-Family : IPv4 Unicast
-----
BMP prefix table version : 1196

      Network          Version   Neighbor      Adv Status  Flags  Path ID
      10.2.2.2/8       1       10.2.2.2      87654321
      10.2.0.0/8       2       10.2.2.2      .....DD    0x0e    1
      10.0.1.0/8       3       10.2.2.2      .....DD    0x0e    1
      10.0.2.0/8       4       10.2.2.2      .....DD    0x0e    1
      10.0.0.0/8       5       10.2.2.2      .....DD    0x0e    1
      192.168.0.1/16   6       10.2.2.2      .....DD    0x0e    1

```

The command **show bgp bmp mode <mode> convergence** displays whether there is any pending work for BMP to perform and whether a specific address family has reached convergence. The command is applicable to **Inbound Post-Policy** as well as **Local-RIB** modes. Convergence is declared when the following conditions are met.

- Table copy is not pending (applicable only for **Inbound Post-Policy**)
- Update generation is not pending
- All BMP servers that are not administratively shutdown are *Up* state
- All BMP servers have caught up to the table version
- Write queues of all BMP servers are empty

```

Router#show bgp bmp all all convergence
-----
Route monitoring mode : Inbound Post-Policy
-----
Address-Family : IPv4 Unicast
-----
Converged.

```

All paths from monitored neighbors are sent to the BMP servers that are not administratively shutdown.
BMP write queue is empty.

The following example displays an address family that is converged. Since BMP mode is not specified, convergence details are shown for the default mode inbound post-policy.

```

Router#show bgp bmp vpngv4 unicast convergence
-----
Route monitoring mode : Inbound Post-Policy
-----
Address-Family : VpNv4 Unicast
-----
Converged.

```

All paths from monitored neighbors are sent to the BMP servers that are not administratively

```
shutdown.
BMP write queue is empty.
```

The following example displays the convergence details for all AFIs and SAFIs. Since BMP mode is not specified, convergence information is shown for the default mode inbound post-policy.

```
Router#show bgp bmp all all convergence
Thu Nov 28 11:03:03.579 UTC
```

```
-----
Route monitoring mode : Inbound Post-Policy
-----
```

```
Address-Family : VPNv4 Unicast
-----
```

```
Not converged.
```

```
All paths from monitored neighbors may not be sent to the BMP servers
that are not administratively shutdown.
```

```
Table copy pending: N
Update generation pending: N
Table version: 500
```

Server	Caught-Up	Version	Queue Size	State
1		0	0	Down
2		0	0	Down

```
Address-Family : VPNv6 Unicast
-----
```

```
Not converged.
```

```
All paths from monitored neighbors may not be sent to the BMP servers
that are not administratively shutdown.
```

```
Table copy pending: N
Update generation pending: N
Table version: 860
```

Server	Caught-Up	Version	Queue Size	State
1		0	0	Down
2		0	0	Down

```
Address-Family : IPv4 Labeled-unicast
-----
```

```
Not converged.
```

```
All paths from monitored neighbors may not be sent to the BMP servers
```

The following example displays the convergence details for BMP mode **inbound post-policy** explicitly specified. The output of this command is same as that of **show bgp bmp mode convergence** as the explicitly specified mode is same as the default mode.

```
Router# show bgp bmp mode all all all convergence
Thu Nov 28 11:04:19.608 UTC
```

```
-----
Route monitoring mode : Inbound Pre-Policy
-----
```

```
Address-Family : VPNv4 Unicast
-----
```

```
Not converged.
```

```
All paths from monitored neighbors may not be sent to the BMP servers
```

that are not administratively shutdown.

Table copy pending: N
Update generation pending: N
Table version: 500

Server	Caught-Up	Version	Queue Size	State
1		0	0	Down
2		0	0	Down

Address-Family : VPNv6 Unicast

Not converged.

All paths from monitored neighbors may not be sent to the BMP servers that are not administratively shutdown.

Table copy pending: N
Update generation pending: N
Table version: 860

Server	Caught-Up	Version	Queue Size	State
1		0	0	Down
2		0	0	Down

Address-Family : IPv4 Labeled-unicast

Not converged.

All paths from monitored neighbors may not be sent to the BMP servers that are not administratively shutdown.

Table copy pending: N
Update generation pending: N
Table version: 1196

Server	Caught-Up	Version	Queue Size	State
1		0	0	Down
2		0	0	Down

Address-Family : IPv6 Labeled-unicast

Not converged.

All paths from monitored neighbors may not be sent to the BMP servers that are not administratively shutdown.

Table copy pending: N
Update generation pending: N
Table version: 1465

Server	Caught-Up	Version	Queue Size	State
1		0	0	Down
2		0	0	Down

Address-Family : IPv4 Unicast

Not converged.

All paths from monitored neighbors may not be sent to the BMP servers that are not administratively shutdown.

Table copy pending: N
Update generation pending: N

Table version: 1196

Server	Caught-Up	Version	Queue Size	State
1		0	0	Down

Router#**show bgp bmp mode all vpnv4 unicast convergence**
 Thu Nov 28 11:06:07.167 UTC

 Route monitoring mode : Inbound Pre-Policy

Address-Family : VPNv4 Unicast

Not converged.

All paths from monitored neighbors may not be sent to the BMP servers that are not administratively shutdown.

Table copy pending: N
 Update generation pending: N
 Table version: 500

Server	Caught-Up	Version	Queue Size	State
1		0	0	Down
2		0	0	Down

 Route monitoring mode : Inbound Post-Policy

Address-Family : VPNv4 Unicast

Not converged.

All paths from monitored neighbors may not be sent to the BMP servers that are not administratively shutdown.

Table copy pending: N
 Update generation pending: N
 Table version: 500

Server	Caught-Up	Version	Queue Size	State
1		0	0	Down
2		0	0	Down

The following examples displays the convergence details for **BMP Local-RIB**.

Router#**show bgp bmp mode route-monitoring local-rib convergence**

 Route monitoring mode : **Local-RIB**

Address-Family : **IPv4 Unicast**

Converged.

All paths from monitored neighbors are sent to the BMP servers that are not administratively

shutdown.
BMP write queue is empty.

The following examples displays the convergence details for non-default address family **VPNv4 Unicast**.

```
Router#show bgp bmp mode route-monitoring local-rib vpnv4 unicast convergence
```

```
-----  
Route monitoring mode : Local-RIB  
-----
```

```
Address-Family : VPNv4 Unicast  
-----
```

Converged.

All paths from monitored neighbors are sent to the BMP servers that are not administratively shutdown.
BMP write queue is empty.

The following examples displays the convergence details for all address families for BMP mode **Local-RIB**.

```
Router#show bgp bmp mode route-monitoring local-rib all all convergence
```

```
-----  
Route monitoring mode : Local-RIB  
-----
```

```
Address-Family : VPNv4 Unicast  
-----
```

Converged.

All paths from monitored neighbors are sent to the BMP servers that are not administratively shutdown.
BMP write queue is empty.

```
Address-Family : VPNv6 Unicast  
-----
```

Converged.

All paths from monitored neighbors are sent to the BMP servers that are not administratively shutdown.
BMP write queue is empty.

```
Address-Family : IPv4 Labeled-unicast  
-----
```

Converged.

All paths from monitored neighbors are sent to the BMP servers that are not administratively shutdown.

BMP write queue is empty.

```
Address-Family : IPv6 Labeled-unicast  
-----
```

Converged.

All paths from monitored neighbors are sent to the BMP servers that are not administratively shutdown.
BMP write queue is empty.

```
Address-Family : IPv4 Unicast  
-----
```


Converged.

All paths from monitored neighbors are sent to the BMP servers that are not administratively shutdown.
BMP write queue is empty.

Address-Family : **IPv6 Unicast**

Converged.

All paths from monitored neighbors are sent to the BMP servers that are not administratively shutdown.
BMP write queue is empty.

The following example shows the convergence details of an address family that has not converged (in this case the default address family **ipv4 unicast** since it is not specified in the command). In this example, in case of **Inbound Post-Policy**, convergence is not reached as the servers are in Down state and they have not caught up to the **Table** version:

Router#**show bgp bmp mode all convergence**

Route monitoring mode : **Inbound Post-Policy**

Address-Family : **IPv4 Unicast**

Not converged.

All paths from monitored neighbors may not be sent to the BMP servers that are not administratively shutdown.

Table copy pending: N
Update generation pending: N
Table version: 108

Server	Caught-Up	Version	Queue Size	State
1		0	0	Down
2		0	0	Down

Route monitoring mode : **Local-RIB**

Address-Family : **IPv4 Unicast**

Not converged.

All paths from monitored neighbors may not be sent to the BMP servers that are not administratively shutdown.

Table copy pending: N
Update generation pending: N
Table version: 28

Server	Caught-Up	Version	Queue Size	State
1		0	0	Down
2		0	0	Down

In the following example of the **show bgp bmp mode all convergence** command, convergence is reached for BMP mode local-rib and address-family ipv4 unicast. However, the same is not yet reached for BMP mode inbound post-policy and address-family ipv4 unicast.

```
Router#show bgp bmp mode all convergence
```

```
-----
Route monitoring mode : Inbound Post-Policy
-----
```

```
Address-Family : IPv4 Unicast
-----
```

Not converged.

All paths from monitored neighbors may not be sent to the BMP servers that are not administratively shutdown.

```
Table copy pending: N
Update generation pending: Y
Table version: 108
```

Server	Caught-Up	Version	Queue Size	State
1		0	0	Up
2		0	0	Up

```
-----
Route monitoring mode : Local-RIB
-----
```

```
Address-Family : IPv4 Unicast
-----
```

Converged.

All paths from monitored neighbors are sent to the BMP servers that are not administratively shutdown.

BMP write queue is empty.

In the following example of the same command, convergence is still not reached for BMP mode inbound post-policy. In this case the server are in *Up* state and they have caught up to the **Table** version. However, the queue for Server 1 is not empty.

```
Router#show bgp bmp mode all convergence
```

```
-----
Route monitoring mode : Inbound Post-Policy
-----
```

```
Address-Family : IPv4 Unicast
-----
```

Not converged.

All paths from monitored neighbors may not be sent to the BMP servers that are not administratively shutdown.

```
Table copy pending: N
Update generation pending: N
Table version: 108
```

Server	Caught-Up	Version	Queue Size	State
1		108	432	Up
2		108	0	Up

```
-----
Route monitoring mode : Local-RIB
-----
```

```
Address-Family : IPv4 Unicast
-----
```

Converged.

All paths from monitored neighbors are sent to the BMP servers that are not administratively shutdown.

BMP write queue is empty.



Note The origin of prefixes conveyed in the **Inbound Post-Policy** view conveys is the actual BGP peers. Whereas the origin of prefixes conveyed in the **Local-RIB** view is the **Local-RIB** itself. The **Local-RIB** is viewed as a set of **emulated** peers from which the prefixes originate. Each emulated peer is associated with the prefixes belonging to one VRF (all address families inclusive) that are conveyed to one BMP server. In other words, one emulated peer is per-VRF per-BMP server. So, if BGP has n VRFs and there are m BMP servers, then $n \times m$ emulated peers are created automatically.

The internal construct of the emulated peer is largely same as that of the normal BGP peer. So, the output of some of the emulated peers related commands resembles that of the BGP peer related commands.

The following example shows the details of the Local RIB emulated peers.



Note This keyword **emulated-peers** is applicable only to BMP mode **Local RIB**.

```
Router#show bgp bmp mode route-monitoring local-rib emulated-peers
BGP emulated peer is 0.0.0.1
Remote AS 2, local AS 2, internal link
Remote router ID 100.1.1.2
  BGP state = Established, up for 08:05:38
  Previous State: Idle
  Last Received Message: None
  BGP Monitoring(BMP) activated for servers:
    1
  Multi-protocol capability received
  Emulated peer capabilities:
    Route refresh: advertised (old + new)
    4-byte AS: advertised and received
    Address family IPv4 Unicast: advertised and received
    Address family IPv4 Labeled-unicast: advertised and received
    Address family VPNv4 Unicast: advertised and received
    Address family IPv6 Unicast: advertised and received
    Address family IPv6 Labeled-unicast: advertised and received
    Address family VPNv6 Unicast: advertised and received
  Received 0 messages, 0 notifications, 0 in queue
  Sent 20 messages, 0 notifications, 0 in queue
  Minimum time between advertisement runs is 15 secs

For Address Family: IPv4 Unicast
  BMP emulated peer version 9
  Update group: 0.9 Filter-group: 0.8 No Refresh request being processed
  Route-Reflector Client
    Extended Nexthop Encoding: advertised and received
  Route refresh request: received 0, sent 0
  Prefix advertised 4, suppressed 0, withdrawn 0
  AIGP is enabled
  Last ack version 9, Last synced ack version 0
  Outstanding version objects: current 0, max 1, refresh 0
  Additional-paths operation: None
```

```

Send Multicast Attributes
Advertise routes with local-label via Unicast SAFI

```

For Address Family: **IPv4 Labeled-unicast**

```

BMP emulated peer version 9
Update group: 0.10 Filter-group: 0.9 No Refresh request being processed
Route-Reflector Client
    Extended Nexthop Encoding: advertised and received
Route refresh request: received 0, sent 0
Prefix advertised 1, suppressed 0, withdrawn 0
AIGP is enabled
Last ack version 9, Last synced ack version 0
Outstanding version objects: current 0, max 1, refresh 0
Additional-paths operation: None
Send Multicast Attributes

```

For Address Family: **VPNv4 Unicast**

```

BMP emulated peer version 33
Update group: 0.7 Filter-group: 0.6 No Refresh request being processed
Route-Reflector Client
    Extended Nexthop Encoding: advertised and received
Route refresh request: received 0, sent 0
Prefix advertised 6, suppressed 0, withdrawn 0
AIGP is enabled
Last ack version 33, Last synced ack version 0
Outstanding version objects: current 0, max 1, refresh 0
Additional-paths operation: None
Send Multicast Attributes

```

For Address Family: **IPv6 Unicast**

```

BMP emulated peer version 9
Update group: 0.11 Filter-group: 0.9 No Refresh request being processed
Route-Reflector Client
    Extended Nexthop Encoding: advertised and received
Route refresh request: received 0, sent 0
Prefix advertised 4, suppressed 0, withdrawn 0
AIGP is enabled
Last ack version 9, Last synced ack version 0
Outstanding version objects: current 0, max 1, refresh 0
Additional-paths operation: None
Send Multicast Attributes
Advertise routes with local-label via Unicast SAFI

```

For Address Family: **IPv6 Labeled-unicast**

```

BMP emulated peer version 9
Update group: 0.12 Filter-group: 0.10 No Refresh request being processed
Route-Reflector Client
    Extended Nexthop Encoding: advertised and received
Route refresh request: received 0, sent 0
Prefix advertised 1, suppressed 0, withdrawn 0
AIGP is enabled
Last ack version 9, Last synced ack version 0
Outstanding version objects: current 0, max 1, refresh 0
Additional-paths operation: None
Send Multicast Attributes

```

For Address Family: **VPNv6 Unicast**

```

BMP emulated peer version 31
Update group: 0.7 Filter-group: 0.6 No Refresh request being processed
Route-Reflector Client
    Extended Nexthop Encoding: advertised and received
Route refresh request: received 0, sent 0
Prefix advertised 6, suppressed 0, withdrawn 0
AIGP is enabled

```

```

Last ack version 31, Last synced ack version 0
Outstanding version objects: current 0, max 1, refresh 0
Additional-paths operation: None
Send Multicast Attributes

```

```

Connections established 1; dropped 0
Last reset 00:00:00

```

The **show bgp bmp mode route-monitoring local-rib emulated peers** command with additional keyword **brief** is used to display a brief summary of the Local RIB emulated peers.

```
Router#show bgp bmp mode route-monitoring local-rib emulated-peers brief
```

EmuPeerId	BMPServer	VRF	Spk	AS	OutQ	State
0.0.0.1	1	default	0	2	0	Established
0.0.0.2	2	default	0	2	0	Established
0.0.0.1	1	bar	0	2	0	Established
0.0.0.2	2	bar	0	2	0	Established
0.0.0.1	1	foo	0	2	0	Established
0.0.0.2	2	foo	0	2	0	Established

The following example shows the detailed summary about Local RIB emulated peers when the **detail** keyword is used.

```
Router#show bgp bmp mode route-monitoring local-rib emulated-peers detail
```

```

BGP emulated peer is 0.0.0.1
Remote AS 2, local AS 2, internal link
Remote router ID 100.1.1.2
BGP state = Established, up for 2d20h
Previous State: Idle
Last Received Message: None
BGP Monitoring(BMP) activated for servers:
  1
Multi-protocol capability received
Emulated peer capabilities:      Adv      Rcvd
Route refresh:                  Yes      No
4-byte AS:                      Yes      Yes
Address family IPv4 Unicast:    Yes      Yes
Address family IPv4 Labeled-unicast: Yes      Yes
Address family VPNv4 Unicast:   Yes      Yes
Address family IPv6 Unicast:    Yes      Yes
Address family IPv6 Labeled-unicast: Yes      Yes
Address family VPNv6 Unicast:   Yes      Yes

Message stats:
  OutQ depth: 0
Minimum time between advertisement runs is 15 secs

```

The following example shows the detailed summary of a **Local RIB** emulated peer specified by VRF and emulated-peer address.

```
Router#show bgp bmp mode route-monitoring local-rib vrf foo emulated-peers 10.0.0.1 detail
```

```

BGP emulated peer is 10.0.0.1, vrf foo
Remote AS 2, local AS 2, internal link
Remote router ID 100.1.1.2
BGP state = Established, up for 2d21h
Previous State: Idle
Last Received Message: None
BGP Monitoring(BMP) activated for servers:

```

```

1
Multi-protocol capability received
Emulated peer capabilities:      Adv      Rcvd
Route refresh:                  Yes      No
4-byte AS:                      Yes      Yes
Address family IPv4 Unicast:    Yes      Yes
Address family IPv6 Unicast:    Yes      Yes

Message stats:
  OutQ depth: 0
  Minimum time between advertisement runs is 15 secs

```

The following example shows the performance statistics information of a **Local RIB** emulated peer specified with VRF and emulated-peer address.

```
Router#show bgp bmp mode route-monitoring local-rib vrf foo emulated-peers 10.0.0.1
performance-statistics
```

```

BGP neighbor is 10.0.0.1, vrf foo
Remote AS 2
  Read 0 messages (0 bytes) in 0 calls (time spent: 0.000 secs)
  Read partly throttled 0 times
  Max socket read size: 0 bytes
  Processed 0 inbound update messages (time spent: 0.000 secs)
  Wrote 750 bytes in 2 calls (time spent: 0.000 secs)
  Processing sub-group: wrote 6 messages in 4 calls (time spent: 0.000 secs)
  Processing write queue: wrote 0 messages in 0 calls (time spent: 0.000 secs)

Received 0 messages, 0 notifications, 0 in queue
Sent 6 messages, 0 notifications, 0 in queue
NSR State: None
Nbr Primary fd:-1 Reset flags:0x0 Sync flags:0x0 Nbr-flags:0x3000c0 Rst retries:0

For Address Family: IPv4 Unicast
Message statistics:
  Update messages processed: 3
  Update messages sent: 3
  Split-horizon Advertisement messages: sent 0, blocked 0
  Split-horizon Withdraw messages: sent 0, blocked 0

For Address Family: IPv6 Unicast
Message statistics:
  Update messages processed: 3
  Update messages sent: 3
  Split-horizon Advertisement messages: sent 0, blocked 0
  Split-horizon Withdraw messages: sent 0, blocked 0

```

The following example displays the details of all emulated peers belonging to all VRFs.

```
Router#show bgp bmp mode route-monitoring local-rib vrf all emulated-peers
```

```

VRF: bar
-----

BGP emulated peer is 10.0.0.1, vrf bar
Remote AS 2, local AS 2, internal link
Remote router ID 100.1.1.2
BGP state = Established, up for 2d22h
Previous State: Idle
Last Received Message: None
BGP Monitoring(BMP) activated for servers:
  1
Multi-protocol capability received

```

```

Emulated peer capabilities:
  Route refresh: advertised (old + new)
  4-byte AS: advertised and received
  Address family IPv4 Unicast: advertised and received
  Address family IPv6 Unicast: advertised and received
Received 0 messages, 0 notifications, 0 in queue
Sent 6 messages, 0 notifications, 0 in queue
Minimum time between advertisement runs is 15 secs

For Address Family: IPv4 Unicast

BMP emulated peer version 25
Update group: 0.1 Filter-group: 0.3 No Refresh request being processed
Route-Reflector Client

```

The following example displays the details of all emulated peers belong to a specified VRF.

```
Router#show bgp bmp mode route-monitoring local-rib vrf foo emulated-peers
```

```

BGP emulated peer is 10.0.0.1, vrf foo
Remote AS 2, local AS 2, internal link
Remote router ID 100.1.1.2
BGP state = Established, up for 2d22h
Previous State: Idle
Last Received Message: None
BGP Monitoring(BMP) activated for servers:
  1
Multi-protocol capability received
Emulated peer capabilities:
  Route refresh: advertised (old + new)
  4-byte AS: advertised and received
  Address family IPv4 Unicast: advertised and received
  Address family IPv6 Unicast: advertised and received
Received 0 messages, 0 notifications, 0 in queue
Sent 6 messages, 0 notifications, 0 in queue
Minimum time between advertisement runs is 15 secs

For Address Family: IPv4 Unicast

BMP emulated peer version 25
Update group: 0.1 Filter-group: 0.3 No Refresh request being processed
Route-Reflector Client

```

Related Commands

Command	Description
bmp server	Configures BMP server.
bmp-activate server <ID>	Enables BMP logging for a neighbor.

show bgp update out

To display address-family level update generation information, use the **show bgp update out** command in EXEC mode and XR EXEC mode.

show bgp [**vrf** *vrf-name*] [**afi** *safi*] **update out** [**brief** | **detail**]

Syntax Description

vrf <i>vrf-name</i>	(Optional) Displays non-default VRF.
afi	(Optional) Displays address-family identifier.
safi	(Optional) Displays subsequent address family identifier.
brief	(Optional) Displays brief information on process level update generation.
detail	(Optional) Displays detailed information on process level update generation.

Command Default

None

Command Modes

EXEC mode and XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.
Release 7.9.1	The command displays the summary of the neighbor address-family update-group, sub-group, or refresh sub-group information.

This example displays sample output from the **show bgp update out** command:

```
Router#show bgp update out
Address-family "IPv4 Unicast"
  Update generation status: Normal
  Update OutQ:                0 bytes (0 messages)
  AF update limit: 268435456 bytes (configured 268435456 bytes)
  EBGp Sub-group update limit: 33554432 bytes (configured 33554432 bytes)
  IBGP Sub-group update limit: 33554432 bytes (configured 33554432 bytes)

Main routing table version: 2
RIB version: 2
Minimum neighbor version: 2
AF Flags: 0x00000000
Update-groups: 1
Sub-groups: 1 (0 throttled)
Refresh sub-groups: 0 (0 throttled)
Filter-groups: 1
Neighbors: 3

History:
  Update OutQ Hi:                300 bytes (1 messages)
  Update OutQ Cumulative:        600 bytes (2 messages)
  Update OutQ Discarded:         0 bytes (0 messages)
  Update OutQ Cleared:           0 bytes (0 messages)
```



```

Last discarded from OutQ: --- (never)
Last cleared from OutQ: --- (never)
Update generation throttled 0 times, last event --- (never)
Update generation recovered 0 times, last event --- (never)
Update generation mem alloc failed 0 times, last event --- (never)

VRF "default", Address-family "IPv4 Unicast"
RD flags: 0x00000001
RD Version: 2
Table flags: 0x00000021
RIB version: 2
Update-groups: 1
Sub-groups: 1 (0 throttled)
Refresh sub-groups: 0 (0 throttled)
Filter-groups: 1
Neighbors: 3

RP/0/RSP0/CPU0:PE51_ASR-9010#
RP/0/RSP0/CPU0:PE51_ASR-9010#
RP/0/RSP0/CPU0:PE51_ASR-9010#show bgp update out filter-group
Thu Sep 13 01:43:48.183 DST

```

The command shows summary of the neighbor address-family update-group, sub-group, or refresh sub-group information. It is modified to show if the peer is configured as *Static* slow peer or *Dynamic* slow peer. The command is also modified to show summary for the slow peers only.

The **show bgp ipv6 unicast update out neighbor brief** command displays output for all peers.

The **show bgp ipv6 unicast update out neighbor slow-peers brief** command displays the output for the slow peers only.

```
Router#show bgp ipv6 unicast update out neighbor slow-peers brief
```

```
Fri Nov 18 04:53:32.903 UTC
```

```

VRF "default", Address-family "IPv6 Unicast"
Main routing table version: 1572958
RIB version: 1572958

```

Legend: (S) - Slow peer static configured
(D) - Slow peer dynamic detected

Neighbor Ack/Ack-R	FG	SG	SG-R	UG	Status OutQ	OutQ-R	Version
2020:102::1 1572958 (S)	0.52	0.24	---	0.18	Normal 0	0	1572958
2020:103::1 1572958 (S)	0.53	0.25	---	0.19	Normal 0	0	1572958
2020:104::1 1572958 (S)	0.8	0.8	---	0.20	Normal 0	0	1572958
.....							
2020:11c::1 1572958/0 (D)	0.43	0.14	0.14:1853	0.4	Normal 0	0	1572958
2020:129::1 1572958/0 (D)	0.3	0.3	0.3:1833	0.6	Normal 0	0	1572958
2020:149::1 1572678/0 (D)	0.3	0.3	0.3:1849	0.6	Normal 0	0	1572958
2020:156::1 1572958/0 (D)	0.43	0.14	0.14:1854	0.4	Normal 0	0	1572958

---More---

The command displays all neighbors update information. The output is enhanced to include slow peer details. The command has also been modified to show neighbors update information of only slow peer.

```
Router#show bgp update out neighbor slow-peers detail
Wed Jun 1 13:34:23.605 IST

VRF "default", Address-family "IPv4 Unicast"
Main routing table version: 47521
RIB version: 47521

Neighbor 192.168.0.4
Filter-group 0.1, Refresh filter-group 0.1
Sub-group 0.1, Refresh sub-group 0.1:1
Update-group 0.2

Update OutQ: 30000 bytes (50 messages)
Refresh update OutQ: 10800 bytes (18 messages)
Filter-group pending: 68 messages

Neighbor flags: 0x40310060+0x00002026
Reset 0x00003fef, Sync 0x00000000, Ver catchup 0x00000000
GSHUT 0x00000000
Neighbor AF flags: 0x00000204+0x00020030+0x00280000+0x00000018
Capability 0x00000801, GR 0x00000000

Version: 47521
Ack version: 25021 (Synced 0)
Outstanding version count: 8
Pending target version: 0 (next resume: 0)
EOR outstanding ? [No]
Refresh version: 31521
Refresh Ack version: 0
Refresh target version: 31521 (requested 31521)
Refresh pending target version: 0 (next resume: 0)
Refresh State: SLOW-RTC
Update Message Pointer: 0x7f17d4ae6988
Last Message Enqueued: 4 secs
Slow Detection State: Dynamic Detected Slow Peer
----More----
```

The **show bgp update out neighbor slow-peers detail** command displays the output of a specific neighbor address-family for the slow peers only.

```
Router#show bgp vpnv4 unicast update out neighbor 10.1.114.1 detail

Tue Nov 15 18:48:24.863 UTC

VRF "default", Address-family "VPNv6 Unicast"
Main routing table version: 51001
RIB version: 51001

Neighbor 10.1.114.1
Filter-group 0.50, Refresh filter-group 0.50
Sub-group 0.5, Refresh sub-group 0.5:538
Update-group 0.2

Update OutQ: 147400 bytes (67 messages)
Refresh update OutQ: 341000 bytes (155 messages)
Filter-group pending: 222 messages

Neighbor flags: 0x40218060+0x00000026
Reset 0x00003fef, Sync 0x00000000, Ver catchup 0x00000000
```

```

    GSHUT 0x00000000,    NbrInfo 0x00000044
Neighbor AF flags: 0x00110224+0x10060020+0x00000000+0x00000048
    Capability 0x00000001,    GR 0x00000000
    DR 0x00000000,    DR In use 0x00000000
    LLGR 0x00000000

Version: 51001
Ack version: 25750 (Synced 0)
Outstanding version count: 0
Pending target version: 0 (next resume: 0)
EOR outstanding ? [No]
Refresh version: 25750
Refresh Ack version: 0
Refresh target version: 25750 (requested 50251)
Refresh pending target version: 0 (next resume: 0)
Refresh State: SLOW
Update Message Pointer: 0x7f17d4bc6918
Last Message Enqueued: 20 secs
Slow Detection State: Dynamic Detected Slow Peer
----More----

```

Where:

- *Refresh State* indicates the state of the refresh sub-group. The states can be any of the following:
 - *Not-In-Refresh*: Refresh sub-group is not present
 - *RR*: Refresh sub-group is processing refresh request update
 - *SLOW*: Refresh sub-group is processing slow peer update
 - *RTC*: Refresh sub-group is processing RTC incremental update
 - *SLOW-RTC*: Refresh sub-group is processing both slow peer and RTC incremental update
- *Last Message Enqueued* indicates the time since the last update message was enqueued to the neighbor address-family. If this time exceeds the neighbor address-family slow peer detection threshold time, then it meets one of the conditions for detection of slow peer.
- *Slow Detection State* indicates the operational type of slow peer. The type can be any of the following:
 - *Static Slow Peer*: Neighbor address-family is static slow peer
 - *Dynamic Detected Slow Peer*: Neighbor address-family is dynamic detected slow peer
 - *Not slow peer*: Neighbor address-family is not a slow peer

show bgp update in error process

To display process level update inbound error-handling information, use the **show bgp update in error process** command in EXEC mode and XR EXEC mode.

show bgp update in error process [**brief** | **detail**]

Syntax Description	brief (Optional) Displays brief information on process level update generation.
	detail (Optional) Displays detailed information on process level update generation.

Command Modes	EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

This example displays sample output from the **show bgp update in error process** command:

```
Router#show bgp update in error process
```

```
Basic Update error-handling:
```

```
EBGP: [Enabled]
```

```
IBGP: [Enabled]
```

```
Extended Update error-handling:
```

```
EBGP: [Disabled]
```

```
IBGP: [Disabled]
```

```
Malformed Update messages: 0
```

```
Neighbors that received malformed Update messages: 0
```

```
Last malformed Update received: --- (never)
```

show bgp update out filter-group

To display update generation information at filter-group level, **show bgp update out filter-group** command in EXEC mode and XR EXEC mode.

```
show bgp [vrf vrf-name] [afi safi] update out filter-group [fg-process-id] [brief | detail]
```

Syntax Description	vrf vrf-name	Specifies the non-default VRF.
	afi safi	Specifies the address family and subsequent address family identifiers.
	fg-process-id	Specifies the filter-group process ID in <x.y> format. Range is <0-15>.<0-4294967295>.
	brief	(Optional) Displays brief information on filter-group level update generation
	detail	(Optional) Displays detailed information on filter-group level update generation.

Command Modes	EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

This example displays sample output from **show bgp update out filter-group** command:

show bgp update out process

To display process level update generation information, use the **show bgp update out process** command in EXEC mode and XR EXEC mode.

show bgp update out process [**brief** | **detail**]

Syntax Description	brief (Optional) Displays brief information on process level update generation.
	detail (Optional) Displays detailed information on process level update generation.
Command Modes	EXEC mode and XR EXEC mode
Command History	Release Modification
	Release 7.0.12 This command was introduced.

This example displays sample output from the show bgp update out process brief command:

```
Router#show bgp update out process
Wed Sep 12 08:26:04.308 DST

Update generation status: Normal
Update OutQ:              0 bytes (0 messages)
Update limit:  536870912 bytes (configured 536870912 bytes)

Update generation logging:  [Disabled]

  Address-family Status   Limit      OutQ      UG    SG(Thr)    SG-R(Thr) Nbrs
-----
IPv4 Unicast   Normal  268435456  0          1     1(0)       0(0)       3
L2VPN VPLS    Normal  268435456  0          1     1(0)       0(0)       3

History:
Update OutQ Hi:              300 bytes (1 messages)
Update OutQ Cumulative:      1200 bytes (4 messages)
Update OutQ Discarded:        0 bytes (0 messages)
Update OutQ Cleared:          0 bytes (0 messages)
Last discarded from OutQ: --- (never)
Last cleared from OutQ: --- (never)
Update generation throttled 0 times, last event --- (never)
Update generation recovered 0 times, last event --- (never)
Update generation mem alloc failed 0 times, last event --- (never)
```

show bgp update out sub-group

To display sub-group update generation information, use the **show bgp update out sub-group** command in EXEC mode and XR EXEC mode .

show bgp [**vrf** *vrf-name*] [**afi** *safi*] **update out** [**update-group** *ug-index*] **sub-group** [*sg-index*] [**brief** | **detail**]

Syntax Description	
vrf <i>vrf-name</i>	(Optional) Displays non-default VRF.
afi	(Optional) Displays address-family identifier.
safi	(Optional) Displays subsequent address family identifier.
brief	(Optional) Displays brief information on process level update generation.
detail	(Optional) Displays detailed information on process level update generation.
ug-index	(Optional) Displays the update-group process ID in <x.y> format.
sg-index	(Optional) displays the sub-group process ID in <x.y> format.

Command Modes	EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

This example displays sample output from the **show bgp update out sub-group** command:

```
Router#show bgp update out sub-group

VRF "default", Address-family "IPv4 Unicast"
  Main routing table version: 2
  RIB version: 2

  SG          UG      Status   Limit      OutQ      SG-R Nbrs Version   ()
  0.2          0.2     Normal   33554432   0          0    3    2             ()
RP/0/RSP0/CPU0:PE51_ASR-9010#
```

This table describes the significant fields shown in the display:

show bgp update out update-group

To display update-group update generation information, use the **show bgp update out update-group** command in EXEC mode and XR EXEC mode.

show bgp [**vrf** *vrf-name*] [**afi** *safi*] **update out update-group** [*ug-index*] [**brief** | **detail**]

Syntax Description

vrf <i>vrf-name</i>	(Optional) Displays non-default VRF.
<i>afi</i>	(Optional) Displays address-family identifier.
<i>safi</i>	(Optional) Displays subsequent address family identifier.
brief	(Optional) Displays brief information on process level update generation.
detail	(Optional) Displays detailed information on process level update generation.
<i>ug-index</i>	(Optional) Displays the update-group process ID in <x.y> format.

Command Modes

EXEC mode and XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

This example shows the significant fields on display form the **show bgp update out update-group** command:

```
Router#show bgp update out sub-group

VRF "default", Address-family "IPv4 Unicast"
  Main routing table version: 2
  RIB version: 2

  SG          UG      Status   Limit      OutQ      SG-R Nbrs Version   ()
  0.2          0.2    Normal   33554432   0          0   3   2             ()
RP/0/RSP0/CPU0:PE51_ASR-9010#show bgp update ou update-group
Wed Sep 12 08:37:24.756 DST

VRF "default", Address-family "IPv4 Unicast"

  UG      OutQ      SG(Thr)   SG-R(Thr)  FG   Nbrs
  0.2     0         1(0)     0(0)       1    3
```


show bgp vrf update in error

To display VRF level update inbound error-handling information, use the **show bgp vrf update in error** command in EXEC mode and XR EXEC mode.

show bgp [*vrf vrf-name*] **update in error** [*brief* | *detail*]

vrf <i>vrf-name</i>	(Optional) Displays non-default VRF.
brief	(Optional) Displays brief information.
detail	(Optional) Displays detailed information.

Command Modes EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

This example displays sample output from **show bgp vrf vrf1 update in error** command:

```
Router#show bgp update in error

VRF "default"
  Malformed Update messages: 0
  Neighbors that received malformed Update messages: 0
  Last malformed update received: --- (never)
```

show bgp advertised

To display advertisements for neighbors or a single neighbor, use the **show bgp advertised** command in EXEC mode and XR EXEC mode.

```
show bgp [ ipv4 { all | labeled-unicast | mdt | multicast | tunnel | unicast } ] advertised
[ neighbor ip-address ] [ standby ] [ summary ]
```

```
show bgp [ ipv6 { all | labeled-unicast | multicast | unicast } ] advertised [ neighbor
ip-address ] [ standby ] [ summary ]
```

```
show bgp [ all { all | labeled-unicast | multicast | tunnel | unicast } ] advertised [
neighbor ip-address ] [ standby ] [ summary ]
```

```
show bgp [ vpnv4 unicast [ rd rd-address ] ] advertised [ neighbor ip-address ] [ standby
] [ summary ]
```

```
show bgp [ vpnv6 unicast [ rd rd-address ] ] advertised [ neighbor ip-address ] [ standby
] [ summary ]
```

```
show bgp [ vrf { vrf-name | all } [ ipv4 | { labeled-unicast | unicast } | ipv6 unicast ] ]
advertised [ neighbor ip-address ] [ standby ] [ summary ]
```

Syntax Description	
ipv4	(Optional) Specifies IP Version 4 address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
all	(Optional) For address family, specifies prefixes for all address families.
tunnel	(Optional) Specifies tunnel address prefixes.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
vpnv4 unicast	(Optional) Specifies VPNv4 unicast address families.
rd rd-address	(Optional) Displays routes with a specific route distinguisher.
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
<i>vrf-name</i>	(Optional) Name of a VRF.
all	(Optional) For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.

neighbor	(Optional) Previews advertisements for a single neighbor. If the neighbor keyword is omitted, then the advertisements for all neighbors are displayed.
<i>ip-address</i>	(Optional) IP address of the neighbor.
summary	(Optional) Displays a summary of advertisements.

Command Default If no address family or subaddress family is specified, the default address family and subaddress family specified using the **set default-afi** and **set default-safi** commands are used.

Command Modes EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines



Note The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

BGP contains a separate routing table for each address family and subaddress family combination that is configured. The address family and subaddress family options specify the routing table to be examined. If the **all** keyword is specified for the address family or subaddress family, each matching routing table is examined in turn.

Use the **show bgp advertised** command to display the routes that have been advertised to peers or a specific peer. To preview advertisements that would be sent to a peer under a particular policy, even if the corresponding update messages have not been generated yet, use the **show bgp policy** command.



Note When you issue the **show bgp advertised** command, a route is not displayed in the output unless an advertisement for that route has already been sent (and not withdrawn). If an advertisement for the route has not yet been sent, the route is not displayed.

Use the **summary** keyword to display a summary of the advertised routes. If you do not specify the **summary** keyword, the software displays detailed information about the advertised routes.



Note The **show bgp advertised** command does not display the application of any outbound policy in the route details it displays. Consequently, this command provides only an indication of whether a particular route has been advertised, rather than details of which attributes were advertised. Use the **show bgp policy sent-advertisements** command to display the attributes that are advertised.



Warning Include the **neighbor ip-address** option in the **show bgp advertised** command for any AFI/SAFI to prevent a high CPU utilization that results in the performance degradation of BGP functions due to:

- a higher prefix scale,
- a higher neighbor scale, or
- a higher combination scale of prefixes and neighbors.

Examples

The following is sample output from the **show bgp advertised** command in EXEC mode and XR EXEC mode:

```
Router# show bgp advertised neighbor 10.0.101.4 summary
```

Network	Next Hop	From	AS Path
1.1.1.0/24	10.0.101.1	10.0.101.1	2 3 222 333 444 555 i
1.1.2.0/24	10.0.101.1	10.0.101.1	3 4 5 6 7 i
1.1.3.0/24	10.0.101.1	10.0.101.1	77 88 33 44 55 99 99 99 i
1.1.4.0/24	10.0.101.1	10.0.101.1	2 5 6 7 8 i
1.1.7.0/24	10.0.101.1	10.0.101.1	3 5 i
1.1.8.0/24	10.0.101.1	10.0.101.1	77 88 99 99 99 i

This table describes the significant fields shown in the display.

Table 6: show bgp advertised neighbor summary Field Descriptions

Field	Description
Network	IP prefix and prefix length for a network.
Next Hop	IP address of the next system that is used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network.
From	IP address of the peer that advertised this route.
AS Path	AS path of the peer that advertised this route.
Local	Indicates the route originated on the local system.
Local Aggregate	Indicates the route is an aggregate created on the local system.
Advertised to	Indicates the peer to which this entry was advertised. This field is used in the output when displaying a summary of the advertisements to all neighbors.

The following is sample output from the **show bgp advertised** command for detailed advertisement information:

```
RP/0/RP0/CPU0:router# show bgp advertised neighbor 172.72.77.1

172.16.0.0/24 is advertised to 172.72.77.1
  Path info:
    neighbor: Local          neighbor router id: 172.74.84.1
    valid redistributed best
  Attributes after inbound policy was applied:
next hop: 0.0.0.0
  MET ORG AS
  origin: incomplete metric: 0
  aspath:
10.52.0.0/16 is advertised to 172.72.77.1
  Path info:
    neighbor: Local Aggregate neighbor router id: 172.74.84.1
    valid aggregated best
  Attributes after inbound policy was applied:
next hop: 0.0.0.0
  ORG AGG ATOM
  origin: IGP aggregator: 172.74.84.1 (1)
  aspath:
```

This table describes the significant fields shown in the display.

Table 7: show bgp advertised neighbor Field Descriptions

Field	Description
is advertised to	IP address of the peer to which this route has been advertised. If the route has been advertised to multiple peers, the information is shown separately for each peer.
neighbor	IP address of the peer that advertised this route, or one of the following: Local—Route originated on the local system. Local Aggregate—Route is an aggregate created on the local system.
neighbor router id	BGP identifier for the peer, or the local system if the route originated on the local system.
Not advertised to any peer	Indicates the no-advertise well-known community is associated with this route. Routes with this community are not advertised to any BGP peers.
Not advertised to any EBGp peer	Indicates the no-export well-known community is associated with this route. Routes with this community are not advertised to external BGP peers, even if those external peers are part of the same confederation as the local router.
Not advertised outside the local AS	Indicates the local-AS well-known community is associated with this route. Routes with this community value are not advertised outside the local autonomous system or confederation boundary.
(Received from a RR-client)	Path was received from a route reflector client.

Field	Description
(received-only)	This path is not used for routing purposes. It is used to support soft reconfiguration, and records the path attributes before inbound policy was applied to a path received from a peer. A path marked “received-only” indicates that either the path was dropped by inbound policy, or the path information was modified by inbound policy and a separate copy of the modified path is used for routing.
(received & used)	Indicates that the path is used both for soft reconfiguration and routing purposes. A path marked “received and used,” implies the path information was not modified by inbound policy.
valid	Path is valid.
redistributed	Path is locally sourced through redistribution.
aggregated	Path is locally sourced through aggregation.
local	Path is locally sourced through the network command.
confed	Path was received from a confederation peer.
best	Path is selected as best.
multipath	Path is one of multiple paths selected for load-sharing purposes.
dampinfo	Indicates dampening information: Penalty—Current penalty for this path. Flapped—Number of times the route has flapped. In—Time (hours:minutes:seconds) since the router noticed the first flap. Reuse in—Time (hours:minutes:seconds) after which the path is made available. This field is displayed only if the path is currently suppressed.
Attributes after inbound policy was applied	Displays attributes associated with the received route, after any inbound policy has been applied. AGG—Aggregator attribute is present. AS—AS path attribute is present. ATOM—Atomic aggregate attribute is present. COMM—Communities attribute is present. EXTCOMM—Extended communities attribute is present. LOCAL—Local preference attribute is present. MET—Multi Exit Discriminator (MED) attribute is present. next hop—IP address of the next system used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network. ORG—Origin attribute is present.

Field	Description
origin	Origin of the path: IGP—Path originated from an Interior Gateway Protocol (IGP) and was sourced by BGP using a network or aggregate-address command. EGP—Path originated from an Exterior Gateway Protocol. incomplete—Origin of the path is not clear. For example, a route that is redistributed into BGP from an IGP.
neighbor as	First autonomous system (AS) number in the AS path.
aggregator	Indicates that the path was received with the aggregator attribute. The autonomous system number and router-id of the system that performed the aggregation are shown.
metric	Value of the interautonomous system metric, otherwise known as the MED metric.
localpref	Local preference value. This is used to determine the preferred exit point from the local autonomous system. It is propagated throughout the local autonomous system.
aspath	AS path associated with the route.
community	Community attributes associated with the path. Community values are displayed in AA:NN format, except for the following well-known communities: Local-AS—Community with value 4294967043 or hex 0xFFFFFFF03. Routes with this community value are not advertised outside the local autonomous system or confederation boundary. no-advertise—Community with value 4294967042 or hex 0xFFFFFFF02. Routes with this community value are not advertised to any BGP peers. no-export—Community with value 4294967041 or hex 0xFFFFFFF01. Routes with this community are not advertised to external BGP peers, even if those peers are in the same confederation with the local router.
Extended community	Extended community attributes associated with the path. For known extended community types, the following codes may be displayed: RT—Route target community SoO—Site of Origin community LB—Link Bandwidth community
Originator	Router ID of the originating router when route reflection is used.
Cluster lists	Router ID or cluster ID of all route reflectors through which the route has passed.

show bgp af-group

To display information about Border Gateway Protocol (BGP) configuration for address family groups, use the **show bgp af-group** command in EXEC mode and XR EXEC mode.

```
show bgp af-group group-name { configuration [ defaults ] [ nvgen ] | inheritance | users }
```

Syntax Description

<i>group-name</i>	Name of the address family group to display.
configuration	(Optional) Displays the effective configuration for the af-group, including any settings that have been inherited from af-groups used by this af-group.
defaults	(Optional) Displays all configuration settings, including any default settings.
nvgen	(Optional) Displays output in the format of show running-config output. If the defaults keyword is also specified, the output is not suitable for cutting and pasting into a configuration session.
inheritance	Displays the af-groups from which this af-group inherits configuration settings.
users	Displays the neighbors, neighbor groups, and af-groups that inherit configuration from this af-group.

Command Default

No default behavior or value

Command Modes

EXEC mode and XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **show bgp af-group** command with the *group-name* **configuration** argument and keyword to display the effective configuration of an af-group, taking into account any configuration that may be inherited from other af-groups through the **use af-group** command. The source of each command is shown.

If the **defaults** keyword is specified, all configuration for the af-group, including default values, is shown. Default configuration is identified in the show output. Use the **nvgen** keyword to display configuration formatted in the style of the **show running-config** command. This output is suitable for cutting and pasting into configuration sessions.

Use the **show bgp af-group** command with the *group-name* **inheritance** argument and keyword to display the address family groups from which the specified af-group inherits configuration.

Use the **show bgp af-group** command with the *group-name* **users** argument and keyword to display the neighbors, neighbor groups, and af-groups that inherit configuration from the specified af-group.

Examples

The following af-group configuration is used in the examples:


```

af-group group3 address-family ipv4 unicast
remove-private-AS
soft-reconfiguration inbound
!
af-group group1 address-family ipv4 unicast
use af-group group2
maximum-prefix 2500 75 warning-only
default-originate
soft-reconfiguration inbound disable
!
af-group group2 address-family ipv4 unicast
use af-group group3
send-community-ebgp
send-extended-community-ebgp
capability orf prefix both

```

The following is sample output from the **show bgp af-group** command with the **configuration** keyword in EXEC mode and XR EXEC mode. The source of each command is shown in the right column. For example, **default-originate** is configured directly on **af-group group1**, and the **remove-private-AS** command is inherited from af-group group2, which in turn inherits it from af-group group3.

```

Router# show bgp af-group group1 configuration

af-group group1 address-family ipv4 unicast
  capability orf prefix both           [a:group2]
  default-originate                    []
  maximum-prefix 2500 75 warning-only  []
  remove-private-AS                   [a:group2 a:group3]
  send-community                      [a:group2]
  send-extended-community              [a:group2]

```

The following is sample output from the **show bgp af-group** command with the **users** keyword:

```

Router# show bgp af-group group2 users

IPv4 Unicast: a:group1

```

The following is sample output from the **show bgp af-group** command with the **inheritance** keyword. This example shows that the specified af-group group1 directly uses the group2 af-group, which in turn uses the group3 af-group:

```

RP/0/RSP0RP0/CPU0:router# show bgp af-group group1 inheritance

IPv4 Unicast: a:group2 a:group3

```

[Table 1](#) describes the significant fields shown in the display.

This table describes the significant fields shown in the display.

Table 8: show bgp af-group Field Descriptions

Field	Description
[]	Configures the command directly on the specified address family group.
a:	Indicates the name that follows is an address family group.
n:	Indicates the name that follows is a neighbor group.
[dflt]	Indicates the setting is not explicitly configured or inherited, and the default value for the setting is used. This field may be shown when the defaults keyword is specified.
<not set>	Indicates that the configuration is disabled by default. This field may be shown when the defaults keyword is specified.

show bgp as-neighbors

To display BGP neighbor or peer relationships that are grouped by AS, use the **show bgp as-neighbors** command.

show bgp as-neighbors [*as-number* [*standby*]]

Syntax Description	as-neighbors	Displays neighbors grouped by an ASN.
	<i>as-number</i>	(Optional) Filters and displays the neighbors for the specified AS numbers. The range is 1-4294967295.
	standby	Displays the BGP neighbor information that is maintained on the standby route processor.

Command Default No default behavior.

Command Modes EXEC mode and XR EXEC mode.

Command History	Release	Modification
	Release 25.1.1	This command was introduced.

Usage Guidelines None.

Task ID	Task ID	Operations
	bgp	read

Examples

The following is the sample output of the **show bgp as-neighbors** command:

```
Router#show bgp as-neighbors
Wed Nov 20 21:10:58.133 UTC
AS: 4294967291, Neighbors: 64, Established: 0
Last updated: Nov 20 00:25:35.285
Neighbor                                State                Last state change
31.0.2.2                                Idle                 Nov 20 19:33:34.119
...
31.0.65.2                                Idle                 Nov 20 19:33:34.025

AS: 4294967292, Neighbors: 64, Established: 0
Last updated: Nov 20 00:25:35.285
Neighbor                                State                Last state change
32.0.2.3                                Active              Nov 20 19:33:39.613
...
32.0.65.3                                Active              Nov 20 19:33:39.540
```

show bgp attribute-key

To display all existing attribute keys, use the **show bgp attribute-key** command in EXEC mode and XR EXEC mode.

```
show bgp {ipv4 | ipv6 | all | vpnv4 unicast | }
{vrf | vpnv6 unicast} attribute-key [standby]
```

Syntax Description	ipv4	(Optional) Specifies IP Version 4 address prefixes.
	unicast	(Optional) Specifies unicast address prefixes.
	multicast	(Optional) Specifies multicast address prefixes.
	labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
	all	(Optional) For address family, specifies prefixes for all address families.
	tunnel	(Optional) Specifies tunnel address prefixes.
	all	(Optional) For subaddress family, specifies prefixes for all subaddress families.
	ipv6	(Optional) Specifies IP Version 6 address prefixes.
	vpnv4-unicast	(Optional) Specifies VPNv4 unicast address families.
	vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
	vrf-name	(Optional) Name of a VRF.
	all	(Optional) For VRF, specifies all VRFs.
	ipv4 { unicast labeled-unicast } }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
Command Default	If no address family or subaddress family is specified, the default address family and subaddress family specified using the set default-afi and set default-safi commands are used.	
Command Modes	EXEC mode and XR EXEC mode	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines



Note The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

Examples

The following is sample output from the **show bgp attribute-key** command in EXEC mode and XR EXEC mode:

```
Router# show bgp all all attribute-key

Address Family: IPv4 Unicast
=====

BGP router identifier 10.0.0.1, local AS number 1
BGP generic scan interval 60 secs
BGP main routing table version 109
BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network        Next Hop        AttrKey
*> 1.1.0.0/16      0.0.0.0          0x00000002
*> 10.0.0.0/16     0.0.0.0          0x00000002
*> 12.21.0.0/16    0.0.0.0          0x00000002
*> 194.3.192.1/32  10.0.101.1       0x00000009
*> 194.3.192.2/32  10.0.101.1       0x00000009
*> 194.3.192.3/32  10.0.101.1       0x00000009
*> 194.3.192.4/32  10.0.101.1       0x00000009
*> 194.3.192.5/32  10.0.101.1       0x00000009

Processed 8 prefixes, 8 paths

Address Family: IPv4 Multicast
=====

BGP router identifier 10.0.0.1, local AS number 1
BGP generic scan interval 60 secs
BGP main routing table version 15
BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network        Next Hop        AttrKey
*> 194.3.193.2/32  10.0.101.1       0x00000009
*> 194.3.193.3/32  10.0.101.1       0x00000009

Processed 2 prefixes, 2 paths

Address Family: IPv6 Unicast
=====

BGP router identifier 10.0.0.1, local AS number 1
BGP generic scan interval 60 secs
BGP main routing table version 19
```

```

BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
               i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
      Network      Next Hop      AttrKey
*> 2222::1111/128    2222::2      0x00000009
*> 2222::1112/128    2222::2      0x00000009

Processed 2 prefixes, 2 paths

```

This table describes the significant fields shown in the display.

Table 9: show bgp attribute-key Field Descriptions

Field	Description
BGP router identifier	BGP identifier for the local system.
local AS number	Autonomous system number for the local system.
BGP generic scan interval	Interval (in seconds) between scans of the BGP table by a generic scanner.
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.
BGP scan interval	Interval (in seconds) between scans.
Status codes	Status of the table entry. The status is displayed as a three-character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): >—Path is the best path to use for that network. d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.

Field	Description
Origin codes	Origin of the path. The origin code is displayed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was sourced by BGP using a network or aggregate-address command. e—Entry originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP prefix and prefix length for a network.
Next Hop	IP address of the next system that is used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network.
AttrKey	Key associated with the route attribute.
Processed <i>n</i> prefixes, <i>n</i> paths	Number of prefixes and number of paths processed for the table.

show bgp cidr-only

To display routes with nonnatural network masks, also known as classless interdomain routing (CIDR) routes, use the **show bgp cidr-only** command in EXEC mode and XR EXEC mode.

show bgp [**ipv4** | **vrf**] **cidr-only** [**standby**]

Syntax Description		
ipv4	(Optional)	Specifies the IP Version 4 address family.
unicast	(Optional)	Specifies the unicast address family.
multicast	(Optional)	Specifies the multicast address family.
labeled-unicast	(Optional)	Specifies labeled unicast address prefixes.
all	(Optional)	For subaddress family, specifies all subaddress families.
tunnel	(Optional)	Specifies the tunnel address family.
vrf	(Optional)	Specifies VPN routing and forwarding (VRF) instance.
<i>vrf-name</i>	(Optional)	Name of a VRF.
all	(Optional)	For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional)	For VRF, specifies IPv4 unicast or labeled-unicast address families.

Command Default If no address family or subaddress family is specified, the default address family and subaddress family specified using the **set default-afi** and **set default-safi** commands are used. This command is applicable only for IPv4 prefixes. If the default address family is not IPv4, then the **ipv4** keyword must be used.

Command Modes EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines



Note The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

Border Gateway Protocol (BGP) contains a separate routing table for each address family and subaddress family combination that has been configured. The address family and subaddress family options specify the routing table to be examined. If the **all** keyword is specified for subaddress family, all subaddress family routing tables are examined.

The **show bgp cidr-only** command applies only for IPv4 prefixes. If the **ipv4** keyword is not specified and the default address family is not IPv4, the command is not available.

Use the **show bgp cidr-only** command to display CIDR routes. Routes that have their correct class (class A, B, or C) prefix length are not displayed.

Examples

The following is sample output from the **show bgp cidr-only** command in EXEC mode and XR EXEC mode:

```
Router# show bgp cidr-only

BGP router identifier 172.20.1.1, local AS number 1820
BGP main routing table version 2589
Dampening enabled
BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
Network          Next Hop          Metric    LocPrf    Weight    Path
*> 192.0.0.0/8    192.168.72.24      0         1878      ?
*> 192.168.0.0/16 192.168.72.30      0         108       ?
```

This table describes the significant fields shown in the display.

Table 10: show bgp cidr-only Field Descriptions

Field	Description
BGP router identifier	BGP identifier for the local system.
local AS number	Autonomous system number for the local system.
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.
Dampening enabled	Displayed if dampening is enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.

Field	Description
Status codes	Status of the table entry. The status is displayed as a three-character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): >—Path is the best path to use for that network. d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.
Origin codes	Origin of the path. The origin code is displayed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was sourced by BGP using a network or aggregate-address command. e—Entry originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP prefix and prefix length for a network.
Next Hop	IP address of the next system that is used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network.
Metric	Value of the interautonomous system metric, otherwise known as the Multi Exit Discriminator (MED) metric.
LocPrf	Local preference value. This is used to determine the preferred exit point from the local autonomous system. It is propagated throughout the local autonomous system.
Weight	Path weight. Weight is used in choosing the preferred path to a route. It is not advertised to any neighbor.
Path	Autonomous system path to the destination network. At the end of the path is the origin code for the path.

show bgp community

To display routes that have the specified Border Gateway Protocol (BGP) communities, use the **show bgp community** command in EXEC mode and XR EXEC mode.

```
show bgp [ ipv4 { unicast | multicast | labeled-unicast | all | tunnel | mdt } ] community
community-list [ exact-match ]
show bgp [ ipv6 { unicast | multicast | labeled-unicast | all } ] community community-list
[ exact-match ]
show bgp [ all { unicast | multicast | labeled-unicast | all | tunnel } ] community
community-list [ exact-match ]
show bgp [ vpnv4 unicast [ rd rd-address ] ] community community-list [ exact-match ]
show bgp [ vrf { vrf-name | all } [ ipv4 { { unicast | labeled-unicast } | ipv6 unicast } ]
community community-list [ exact-match ]
show bgp [ vpnv6 unicast [ rd rd-address ] ] community community-list [ exact-match ]
```

Syntax Description

ipv4	(Optional) Specifies IP Version 4 address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.
tunnel	(Optional) Specifies tunnel address prefixes.
mdt	(Optional) Specifies multicast distribution tree (MDT) address prefixes.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
all	(Optional) For address family, specifies prefixes for all address families.
vpnv4 unicast	(Optional) Specifies VPNv4 unicast address families.
rd rd-address	(Optional) Displays routes with a specific route distinguisher.
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
vrf-name	(Optional) Name of a VRF.
all	(Optional) For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.
vpnv6 unicast	(Optional) Specifies VPNv6 unicast address families.
community	Specifies that only routes with communities specified by <i>community-list</i> is displayed.

<i>community-list</i>	Between one and seven communities. Each community can be a number in the range from 1 to 4294967295, a community specified in AA:NN format, or one of the following well-known communities: graceful-shutdown — Reduced preference for shutdown (well-known community) local-AS — Well-known community with value 4294967043 or hex 0xFFFFFFFF03. Routes with this community value are not advertised outside the local autonomous system or confederation boundary. no-advertise — Well-known community with value 4294967042 or hex 0xFFFFFFFF02. Routes with this community value are not advertised to any BGP peers. no-export — Well-known community with value 4294967041 or hex 0xFFFFFFFF01. Routes with this community are not advertised to external BGP peers, even if those peers are in the same confederation as the local router. internet — Well-known community whose value is not defined in BGP RFC. IOS XR BGP uses a value of 0 for the internet community. Routes with this community are advertised to all peers without any restrictions. For the AA:NN format: AA—Range is 0 to 65535. NN—Range is 1 to 4294967295. Up to seven community numbers can be specified.

exact-match	(Optional) Displays those routes that have communities exactly matching the specified communities.

Command Default	If no address family or subaddress family is specified, the default address family and subaddress family specified using the set default-afi and set default-safi commands are used.

Command Modes	EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines



Note	The set default-afi command is used to specify the default address family for the session, and the set default-safi command is used to specify the default subaddress family for the session. See the <i>System Management Command Reference for Cisco 8000 Series Routers</i> for detailed information and syntax for the set default-afi and set default-safi commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

BGP contains a separate routing table for each configured address family and subaddress family combination. The address family and subaddress family options specify the routing table to be examined. If the **all** keyword is specified for the address family or the subaddress family, each matching routing table is examined in turn.

If more than seven communities are required, it is necessary to configure a route policy and use the [show bgp route-policy, on page 407](#) command.

Use the **exact-match** keyword to display only those routes with a set of communities exactly matching the list of specified communities. If you omit the **exact-match** keyword, those routes containing at least the specified communities are displayed.

The following is sample output from the **show bgp community graceful-shutdown** command displaying the graceful maintenance feature information:

```
RP/0/0/CPU0:R4#show bgp community graceful-shutdown
Tue Jan 27 13:36:25.006 PST
BGP router identifier 192.168.0.4, local AS number 4
BGP generic scan interval 60 secs
BGP table state: Active
Table ID: 0xe0000000 RD version: 18
BGP main routing table version 18
BGP scan interval 60 secs

Status codes: s suppressed, d damped, h history, * valid, > best
               i - internal, r RIB-failure, S stale, N Nexthop-discard
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network          Next Hop          Metric LocPrf Weight Path
*   5.5.5.5/32      10.10.10.1              88      0 1 ?

Processed 1 prefixes, 1 paths
```

Examples

The following is sample output from the **show bgp community** command in EXEC mode and XR EXEC mode:

```
Router# show bgp community 1820:1 exact-match

BGP router identifier 172.20.1.1, local AS number 1820
BGP main routing table version 55
Dampening enabled
BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
               i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network          Next Hop          Metric LocPrf Weight Path
*   10.13.0.0/16    192.168.40.24              0 1878 704 701 200 ?
*   10.16.0.0/16    192.168.40.24              0 1878 704 701 i
```

This table describes the significant fields shown in the display.

Table 11: show bgp community Field Descriptions

Field	Description
BGP router identifier	BGP identifier for the local system.
local AS number	Autonomous system number for the local system.

Field	Description
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.
Dampening enabled	Displayed if dampening is enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.
Status codes	Status of the table entry. The status is displayed as a three character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): >—Path is the best path to use for that network. d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.
Origin codes	Origin of the path. The origin code is displayed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was advertised with a network or aggregate-address command. e—Path originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP prefix and prefix length for a network.
Next Hop	IP address of the next system that is used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network.
Metric	Value of the interautonomous system metric, otherwise known as the Multi Exit Discriminator (MED) metric.
LocPrf	Local preference value. This is used to determine the preferred exit point from the local autonomous system. It is propagated throughout the local autonomous system.

Field	Description
Weight	Path weight. Weight is used in choosing the preferred path to a route. It is not advertised to any neighbor.
Path	Autonomous system path to the destination network. At the end of the path is the origin code for the path.

show bgp convergence

To display whether a specific address family has reached convergence, use the **show bgp convergence** command in EXEC mode and XR EXEC mode.

```
show bgp [ipv4 {unicast | multicast | labeled-unicast | all | tunnel | mdt}] convergence
show bgp [ipv6 {unicast | multicast | labeled-unicast | all}] convergence
show bgp [all {unicast | multicast | labeled-unicast | all | mdt | tunnel}] convergence
show bgp [vpnv4 unicast ] convergence
show bgp [vpnv6 unicast ] convergence
```

Syntax Description

ipv4	(Optional) Specifies the IP Version 4 address family.
unicast	(Optional) Specifies the unicast address family.
multicast	(Optional) Specifies the multicast address family.
labeled-unicast	(Optional) Specifies unicast address prefixes.
all	(Optional) For subaddress family, specifies all subaddress families.
tunnel	(Optional) Specifies tunnel address prefixes.
mdt	(Optional) Specifies multicast distribution tree (MDT) address prefixes.
ipv6	(Optional) Specifies the IP Version 6 address family.
all	(Optional) For address family, specifies all address families.
vpnv4 unicast	(Optional) Specifies VPNv4 unicast address families.
vpnv6 unicast	(Optional) Specifies VPNv6 unicast address families.

Command Default

If no address family or subaddress family is specified, the default address family and subaddress family specified using the **set default-afi** and **set default-safi** commands are used.

Command Modes

EXEC mode and XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines



Note The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

Border Gateway Protocol (BGP) contains a separate routing table for each configured address family and subaddress family combination. The address family and subaddress family options specify the routing table to be examined. If the **all** keyword is specified for the address family or subaddress family, each matching routing table is examined in turn.

Use the **show bgp convergence** command to see if there is any pending work for BGP to perform. The software checks the following conditions to determine whether the specified address family has converged. If all the conditions are true, the address family is considered converged.

- All received updates have been processed and best routes selected.
- All selected routes have been installed in the global Routing Information Base (RIB).
- BGP is in READ-WRITE state for a given address family (This condition is only considered if bgp is not configured explicitly to be in READ-ONLY mode).
- Checks the size of the write queue and read queue of each neighbor, both queues should be empty.

The **show bgp convergence** command considers established neighbors only, because write queue is shared by all address families, there is a small possibility that the command indicates the address family has not converged when, in fact, it has converged. This could happen if the neighbor write queue contained messages from some other address family.

If the specified address family has not converged, the **show bgp convergence** command output does not indicate the amount of work that is pending. To display this information, use the **show bgp summary** command.

Examples

The following shows the result of using the **show bgp convergence** command for an address family that has converged:

```
Router# show bgp convergence

Converged.
All received routes in RIB, all neighbors updated.
Established Nbrs: 2 Not-Established Nbrs: 0
```

The following shows the result of using the **show bgp convergence** command for an address family that has not converged:

1. The following shows the output if bgp is in READ-ONLY state:

```
Router# show bgp convergence

Not converged.
Received routes may not be entered in RIB.
```

One or more neighbors may need updating.

```
First neighbor not converged: 10.10.10.4
Message pending: N
Write queue empty: Y
Update ver:0 Table ver:2 Peer Ack:1
Read queue empty: Y
Write queue size: 0 Read queue Size: 0
bgp not in read-write mode, current router_state: Read Only
Established Nbrs: 1 Not-Established Nbrs: 0
```

2. The following shows the output if router is not in READ-ONLY state:

Router# **show bgp convergence**

```
Not converged.
Received routes may not be entered in RIB.
One or more neighbors may need updating.

First neighbor not converged: 11.11.11.5
Message pending: N
Write queue empty: Y
Update ver:0 Table ver:2 Peer Ack:1
Read queue empty: Y
Write queue size: 0 Read queue Size: 0
Established Nbrs: 1 Not-Established Nbrs: 1
```

This table describes the significant fields shown in the display.

Table 12: show bgp convergence Field Descriptions

Field	Description
Converged/Not converged	Specifies whether or not all routes have been installed in the RIB and updates have been generated and sent to all neighbors.
[All] Received routes...	For convergence, all routes must have been installed into the RIB and all updates must have been generated. For non-convergence, some routes may not be installed in the RIB, or some routes that have been withdrawn have not yet been removed from the RIB, or some routes that are up to date in the RIB have not been advertised to all neighbors.
[All One or more] neighbors...	Specifies the status of neighbor updating.

show bgp dampened-paths

To display Border Gateway Protocol (BGP) dampened routes, use the **show bgp dampened-paths** command in EXEC mode and XR EXEC mode.

```
show bgp [ ipv4 { unicast | multicast | labeled-unicast | all } ] dampened-paths [ standby ]
show bgp [ ipv6 { unicast | multicast | labeled-unicast | all } ] dampened-paths [ standby ]
show bgp [ all { unicast | multicast | labeled-unicast | all | tunnel } ] dampened-paths [ standby ]
show bgp [ vpnv4 unicast [ rd rd-address ] ] dampened-paths [ standby ]
show bgp [ vrf { vrf-name | all } [ ipv4 { { unicast | labeled-unicast } | ipv6 unicast } ] dampened-paths [ standby ]
show bgp [ vpnv6 unicast [ rd rd-address ] ] dampened-paths [ standby ]
```

Syntax Description

ipv4	(Optional) Specifies IP Version 4 address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
all	(Optional) For address family, specifies prefixes for all address families.
vpnv4 unicast	(Optional) Specifies VPNv4 unicast address families.
rd rd-address	(Optional) Displays routes with a specific route distinguisher.
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
vrf-name	(Optional) Name of a VRF.
all	(Optional) For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.

Command Default

If no address family or subaddress family is specified, the default address family and subaddress family specified using the **set default-afi** and **set default-safi** commands are used.

Command Modes

EXEC mode and XR EXEC mode

Command History**Release****Modification**

Release 7.0.12 This command was introduced.

Usage Guidelines

The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

BGP contains a separate routing table for each configured address family and subaddress family combination. The address family and subaddress family options specify the routing table to be examined. If the **all** keyword is specified for the address family or for the subaddress family, each matching routing table is examined in turn.

Examples

The following is sample output from the **show bgp dampened-paths** command in EXEC mode and XR EXEC mode:

```
RP/0/RP0/CPU0:router# show bgp dampened-paths

BGP router identifier 10.2.0.1, local AS number 3
BGP generic scan interval 60 secs
BGP main routing table version 7
Dampening enabled
BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
               i - internal, S stale

Origin codes: i - IGP, e - EGP, ? - incomplete
      Network          From        Reuse      Path
*d 10.0.0.0           10.0.101.35    00:01:20  35 i
```

This table describes the significant fields shown in the display.

Table 13: show bgp dampened-paths Field Descriptions

Field	Description
BGP router identifier	BGP identifier for the local system.
local AS number	Autonomous system number for the local system.
BGP generic scan interval	Interval (in seconds) between scans of the BGP table by a generic scanner.
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.
Dampening enabled	Displayed if dampening is enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.

Field	Description
Status codes	Status of the table entry. The status is displayed as a three-character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): >—Path is the best path to use for that network. d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.
Origin codes	Origin of the path. The origin code is displayed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was advertised with a network or aggregate-address command. e—Path originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP prefix and prefix length for a network.
From	Neighbor from which the route was received.
Reuse	Time (in hours:minutes:seconds) after which the path is made available.
Path	Autonomous system path to the destination network. At the end of the path is the origin code for the path.

show bgp flap-statistics

To display information about Border Gateway Protocol (BGP) paths that have flapped, use the **show bgp flap-statistics** command in EXEC mode and XR EXEC mode.

```
show bgp [ ipv4 { unicast | multicast | labeled-unicast | all } ] flap-statistics [ regexp
regular-expression | route-policy route-policy-name | cidr-only | { ip-address | { mask /prefix-length
} } ] [ longer-prefixes ] [ detail ]
show bgp [ ipv6 { unicast | multicast | labeled-unicast | all } ] flap-statistics [ regexp
regular-expression | route-policy route-policy-name | cidr-only | { ip-address | { mask /prefix-length
} } ] [ longer-prefixes ] [ detail ]
show bgp [ all { unicast | multicast | labeled-unicast | all } ] flap-statistics [ regexp
regular-expression | route-policy route-policy-name | cidr-only | { ip-address | { mask /prefix-length
} } ] [ longer-prefixes ] [ detail ]
show bgp [ vpnv4 unicast [ rd rd-address ] ] flap-statistics [ regexp regular-expression |
route-policy route-policy-name | cidr-only | { ip-address | { mask /prefix-length } } ] [
longer-prefixes ] [ detail ]
show bgp [ vrf { vrf-name | all } [ ipv4 { unicast | labeled-unicast } | ipv6 unicast ] ]
flap-statistics [ regexp regular-expression | route-policy route-policy-name | cidr-only | {
ip-address | { mask /prefix-length } } ] [ longer-prefixes ] [ detail ]
show bgp [ vpnv6 unicast [ rd rd-address ] ] flap-statistics [ regexp regular-expression |
route-policy route-policy-name | cidr-only | { ip-address | { mask /prefix-length } } ] [
longer-prefixes ] [ detail ]
```

Syntax Description

ipv4	(Optional) Specifies IP Version 4 address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
all	(Optional) For address family, specifies prefixes for all address families.
vpnv4 unicast	(Optional) Specifies VPNv4 unicast address families.
rd rd-address	(Optional) Displays routes with a specific route distinguisher.
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
<i>vrf-name</i>	(Optional) Name of a VRF.
all	(Optional) For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.

ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.
regexp <i>regular-expression</i>	(Optional) Displays flap statistics for all paths that match the regular expression.
route-policy <i>route-policy-name</i>	(Optional) Displays flap statistics for a route policy.
cidr-only	(Optional) Displays only routes whose prefix length does not match the classful prefix length for that network. The cidr-only keyword can be specified only if the address family is IPv4.
<i>ip-address</i>	(Optional) Flap statistics for a network address only.
<i>mask</i>	(Optional) Network mask applied to the <i>ip-address</i> argument.
<i>/ prefix-length</i>	(Optional) Length of the IP address prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash (/) must precede the decimal value.
longer-prefixes	(Optional) Displays flap statistics for the specified prefix and more-specific prefixes. The longer-prefixes keyword is available when the <i>ip-address</i> and <i>mask</i> or <i>/prefix-length</i> arguments are specified.
detail	(Optional) Displays dampening parameters for the path. The detail keyword cannot be specified if the longer-prefixes keyword is specified. The detail keyword is available when the <i>ip-address</i> argument or <i>ip-address</i> and <i>mask</i> or <i>/prefix-length</i> arguments are specified.

Command Default

If no address family or subaddress family is specified, the default address family and subaddress family specified using the **set default-afi** and **set default-safi** commands are used.

Command Modes

EXEC mode and XR EXEC mode.

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines**Note**

The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

BGP contains a separate routing table for each configured address family and subaddress family combination. The address family and subaddress family options specify the routing table to be examined. If the **all** keyword is specified for the address family or subaddress family, each matching routing table is examined in turn.

Flap statistics are maintained only for paths if dampening is enabled using the **bgp dampening** command. If dampening is not enabled, the **show bgp flap-statistics** command does not display any paths.

If no arguments or keywords are specified, the software displays flap statistics for all paths for the specified address family. You can use the **regex**, **filter-list**, **cidr-only**, and **longer-prefixes** options to limit the set of paths displayed.

If you specify a network address without a mask or prefix length, the longest matching prefix for the network address is displayed. When displaying flap statistics for a single route, use the **detail** keyword to display dampening parameters for the route.

Examples

The following is sample output from the **show bgp flap-statistics** command:

```
Router# show bgp flap-statistics

BGP router identifier 172.20.1.1, local AS number 1820
BGP main routing table version 26180
Dampening enabled
BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
Network          From          Flaps Duration Reuse      Path
*d 10.0.0.0       172.20.16.177  4      00:13:31 00:18:10 100
*d 10.10.0.0      172.20.16.177  4      00:02:45 00:28:20 100
```

The following is sample output from the **show bgp flap-statistics** command with the **detail** keyword in EXEC mode and XR EXEC mode:

```
Router# show bgp flap-statistics 172.31.12.166 detail

BGP router identifier 10.0.0.5, local AS number 1
BGP main routing table version 738
Dampening enabled
BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
Network          From          Flaps Duration Reuse      Path
h 172.31.12.166  10.0.101.1    6      00:03:28          2 2000 3000

Half life      Suppress      Reuse penalty  Max. supp. time
00:15:00       2000          750            01:00:00
```

This table describes the significant fields shown in the display.

Table 14: show bgp flap-statistics Field Descriptions

Field	Description
BGP route identifier	BGP identifier for the local system.
local AS number	Autonomous system number for the local system.

Field	Description
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.
Dampening enabled	Displayed if dampening has been enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.
Status codes	Status of the table entry. The status is displayed as a three-character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): >—Path is the best path to use for that network. d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.
Origin codes	Origin of the path. The origin code is displayed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was advertised with a network or aggregate-address command. e—Path originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP prefix and prefix length for a network that is dampened.
From	IP address of the peer that advertised this route.
Flaps	Number of times the route has flapped.
Duration	Time (in hours:minutes:seconds) since the first flap.
Reuse	Time (in hours:minutes:seconds) after which the path is made available.
Path	Autonomous system path of the route that is being dampened.

Field	Description
Half life	Half-life value used when dampening this route. The half-life is the amount of time that must elapse to reduce the reuse penalty by half. The half-life value is specified using the bgp dampening command.
Suppress	Suppress value used to dampen this route. The suppress value is the value that the penalty must exceed for the route to be suppressed. The suppress value can be configured using the bgp dampening command.
Reuse penalty	Reuse penalty used to dampen this route. The penalty must fall below the reuse penalty for the route to be unsuppressed. The reuse penalty can be configured using the bgp dampening command.
Max supp. time	Maximum length of time that the route may be suppressed due to dampening. The maximum suppress time can be configured using the bgp dampening command.

show bgp inconsistent-as

To display Border Gateway Protocol (BGP) routes originated from more than one autonomous system, use the **show bgp inconsistent-as** command in EXEC mode and XR EXEC mode.

```
show bgp [ ipv4 { unicast | multicast | labeled-unicast | all | tunnel | mdt } ] inconsistent-as
[ standby ]
show bgp [ ipv6 { unicast | multicast | labeled-unicast | all } ] inconsistent-as [ standby ]
show bgp [ all { unicast | multicast | labeled-unicast | all | tunnel | mdt } ] inconsistent-as
[ standby ]
show bgp vpnv4 unicast [ rd rd-address ] inconsistent-as [ standby ]
show bgp [ vrf { vrf-name | all } [ ipv4 { { unicast | labeled-unicast } | ipv6 unicast } ]
inconsistent-as [ standby ]
show bgp [ vpnv6 unicast [ rd rd-address ] ] inconsistent-as [ standby ]
```

Syntax Description

ipv4	(Optional) Specifies IP Version 4 address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.
tunnel	(Optional) Specifies tunnel address prefixes.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
all	(Optional) For address family, specifies prefixes for all address families.
vpnv4 unicast	(Optional) Specifies VPNv4 unicast address families.
rd rd-address	(Optional) Displays routes with a specific route distinguisher.
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
<i>vrf-name</i>	(Optional) Name of a VRF.
all	(Optional) For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.

Command Default

If no address family or subaddress family is specified, the default address family and subaddress family specified using the **set default-afi** and **set default-safi** commands are used.

Command Modes

EXEC mode and XR EXEC mode.

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines



Note The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

BGP contains a separate routing table for each configured address family and subaddress family combination. The address family and subaddress family options specify the routing table to be examined. If the **all** keyword is specified for the address family or for the subaddress family, each matching routing table is examined in turn.

Use the **show bgp inconsistent-as** command to search through all prefixes in the specified BGP routing table and display the paths for any prefix that has inconsistent originating autonomous system numbers. The originating autonomous system is the last autonomous system number displayed in the path field and should be the same for all paths.

If a prefix has one or more paths originating from different autonomous systems, all paths for that prefix are displayed.

Examples

The following is sample output from the **show bgp inconsistent-as** command in EXEC mode and XR EXEC mode:

```
Router# show bgp inconsistent-as

BGP router identifier 172.20.1.1, local AS number 1820
BGP main routing table version 1129
BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
Network          Next Hop        Metric      LocPrf Weight Path
* 10.0.0.0        172.16.232.55      0           0 300 88 90 99 ?
*>               172.16.232.52      2222        0 400 ?
* 172.16.0.0      172.16.232.55      0           0 300 90 99 88 200 ?
*>               172.16.232.52      2222        0 400 ?
* 192.168.199.0   172.16.232.55      0           0 300 88 90 99 ?
*>               172.16.232.52      2222        0 400 ?
```

This table describes the significant fields shown in the display.

Table 15: show bgp inconsistent-as Field Descriptions

Field	Description
BGP router identifier	BGP identifier for the local system.
local AS number	Autonomous system number for the local system.
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.
Dampening enabled	Displayed if dampening is enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.
Status codes	Status of the table entry. The status is displayed as a three-character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): >—Path is the best path to use for that network. d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.
Origin codes	Origin of the path. The origin code is displayed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was advertised with a network or aggregate-address command. e—Path originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP prefix and prefix length for a network.

Field	Description
Next Hop	IP address of the next system that is used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network.
Metric	Value of the interautonomous system metric, otherwise known as the Multi Exit Discriminator (MED) metric.
LocPrf	Local preference value. This is used to determine the preferred exit point from the local autonomous system. It is propagated throughout the local autonomous system.
Weight	Path weight. Weight is used in choosing the preferred path to a route. It is not advertised to any neighbor.
Path	Autonomous system path to the destination network. At the end of the path is the origin code for the path.

show bgp labels

To display Border Gateway Protocol (BGP) routes and their incoming and outgoing labels, use the **show bgp labels** command in EXEC mode and XR EXEC mode.

show bgp labels

Syntax Description							
ipv4	(Optional) Specifies IP Version 4 address prefixes.						
unicast	(Optional) Specifies unicast address prefixes.						
multicast	(Optional) Specifies multicast address prefixes.						
labeled-unicast	(Optional) Specifies labeled-unicast address prefixes.						
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.						
ipv6	(Optional) Specifies IP Version 6 address prefixes.						
vpn4 unicast	(Optional) Specifies VPNv4 unicast address families.						
rd <i>rd-address</i>	(Optional) Displays routes with a specific route distinguisher.						
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.						
<i>vrf-name</i>	(Optional) Name of a VRF.						
all	(Optional) For VRF, specifies all VRFs.						
ipv4 {unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.						
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.						
Command Default	If no address family or subaddress family is specified, the default address family and subaddress family specified using the set default-afi and set default-safi commands are used.						
Command Modes	EXEC mode and XR EXEC mode						
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.0.12</td><td>This command was introduced.</td></tr> <tr> <td>Release 24.1.1</td><td>The show outputs of the following commands are modified to capture changes related to the per-vrf-46 label mode: show bgp vrf INET ipv4 unicast labels show bgp vrf INET ipv6 unicast labels </td></tr> </table>	Release	Modification	Release 7.0.12	This command was introduced.	Release 24.1.1	The show outputs of the following commands are modified to capture changes related to the per-vrf-46 label mode: show bgp vrf INET ipv4 unicast labels show bgp vrf INET ipv6 unicast labels
Release	Modification						
Release 7.0.12	This command was introduced.						
Release 24.1.1	The show outputs of the following commands are modified to capture changes related to the per-vrf-46 label mode: show bgp vrf INET ipv4 unicast labels show bgp vrf INET ipv6 unicast labels						

Examples

The following are sample outputs from the **show bgp labels** command in EXEC mode and XR EXEC mode:

Router# **show bgp vrf BAR ipv4 unicast labels**

BGP VRF BAR, state: Active BGP Route Distinguisher: 100:1 BGP router identifier 10.1.1.1,
local AS number 65550
BGP table state: Active BGP main routing table version 12

Status codes: s suppressed, d damped, h history, * valid, > best
i - internal, S stale

Origin codes: i - IGP, e - EGP, ? - incomplete

Network	Next Hop	Rcvd Label	Local Label
Route Distinguisher: 100:1 (default for vrf BAR)			
*> 198.51.100.1/24	192.0.2.0	16	nolabel
*> 198.51.100.2/24	192.0.2.0	16	nolabel
*> 198.51.100.3/24	192.0.2.0	16	nolabel
*> 198.51.100.4/24	192.0.2.0	16	nolabel
*> 198.51.100.5/24	192.0.2.0	16	nolabel

Processed 5 prefixes, 5 paths

Router# **show bgp vrf INET ipv4 unicast labels**

Wed Dec 20 03:52:23.194 UTC
BGP VRF INET, state: Active
BGP Route Distinguisher: 600:600
VRF ID: 0x60000001
BGP router identifier 198.51.100.1, local AS number 65550
Non-stop routing is enabled
BGP table state: Active
Table ID: 0xe0000001 RD version: 40540
BGP table nexthop route policy:
BGP main routing table version 40540
BGP NSR Initial initsync version 12 (Reached)
BGP NSR/ISSU Sync-Group versions 0/0

Status codes: s suppressed, d damped, h history, * valid, > best
i - internal, r RIB-failure, S stale, N Nexthop-discard

Origin codes: i - IGP, e - EGP, ? - incomplete

Network	Next Hop	Rcvd Label	Local Label
Route Distinguisher: 600:600 (default for vrf INET)			
Route Distinguisher Version: 40540			
*>198.51.100.0/24	192.0.2.1	nolabel	24100
*>198.51.100.1/24	192.0.2.1	24200	nolabel
*>198.51.100.2/24	192.0.2.1	nolabel	24100
*>198.51.100.3/24	192.0.2.1	24200	nolabel
*>198.51.100.4/24	192.0.2.1	nolabel	24100

Processed 5 prefixes, 5 paths

Router# **show bgp vrf INET ipv6 unicast labels**

Wed Dec 20 03:52:29.709 UTC
BGP VRF INET, state: Active
BGP Route Distinguisher: 600:600
VRF ID: 0x60000001
BGP router identifier 2.2.2.2, local AS number 65550
Non-stop routing is enabled
BGP table state: Active
Table ID: 0xe0800001 RD version: 34
BGP table nexthop route policy:
BGP main routing table version 34
BGP NSR Initial initsync version 12 (Reached)


```

BGP NSR/ISSU Sync-Group versions 0/0

Status codes: s suppressed, d damped, h history, * valid, > best
               i - internal, r RIB-failure, S stale, N Nexthop-discard
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network           Next Hop           Rcvd Label       Local Label
Route Distinguisher: 600:600 (default for vrf INET)
Route Distinguisher Version: 34
*>2001:DB8::1/32      ::                nolabel          24100
*>2001:DB8::2/32      2001:db8::6       24200            nolabel
*>2001:DB8::3/32      2001:db8::7       24200            nolabel
*>2001:DB8::4/32      ::                nolabel          24100

Processed 4 prefixes, 4 paths

```

This table describes the significant fields shown in the display.

Table 16: show bgp labels Field Descriptions

Field	Description
BGP Route Distinguisher	BGP route distinguisher.
BGP router identifier	BGP identifier for the local system.
local AS number	Autonomous system number for the local system.
BGP table state	State of the BGP routing table.
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.
Status codes	Status of the table entry. The status is displayed as a three-character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): >—Path is the best path to use for that network. d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.

Field	Description
Origin codes	Origin of the path. The origin code is displayed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was sourced by BGP using a network or aggregate-address command. e—Path originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path isn't clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP prefix and prefix length for a network.
Next Hop	IP address of the next system that is used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network.
Rcvd Label	Received label.
Local Label	Local label.

show bgp l2vpn

To display BGP routes associated with VPLS or VPWS or EVPN under L2VPN address family, use the **show bgp l2vpn** command in EXEC mode and XR EXEC mode.

show bgp l2vpn { vpls | vpws | evpn } rd rd_value bgp_prefix [detail]

Syntax Description	vpls	Specifies Virtual Private LAN Services (VPLS).
	vpws	Specifies Virtual Private Wire Service (VPWS).
	evpn	Specifies Ethernet Virtual Private Network (EVPN).
	rd_value	Value of the route distinguisher.
	bgp_prefix	Specifies BGP prefix.
	detail	Provides detailed output for the specified route distinguisher and BGP prefix.

Command Default No default behavior or values

Command Modes EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

The following example is sample output from the **show bgp l2vpn vpls** for route distinguisher 1:1:

```
Router#show bgp l2vpn vpls rd 1:1 2:1
BGP routing table entry for 2:1/32, Route Distinguisher: 1:1
Versions:
  Process          bRIB/RIB   SendTblVer
  Speaker          2          2
  Local Label: 16000
Paths: (1 available, best #1)
  Advertised to update-groups (with more than one peer):
    0.1
  Advertised to peers (in unique update groups):
    100.100.100.1
  Path #1: Received by speaker 0
  Local
    0.0.0.0 from 0.0.0.0 (200.200.200.1)
    Origin IGP, localpref 100, valid, redistributed, best, import-candidate
    Extended community: RT:4:4 L2VPN:19:0:1500
    Block Size:10
```

The following example is sample output from the **show bgp l2vpn vpws** for route distinguisher 200:200:

```
Router#show bgp l2vpn vpws rd 200:200 3:1
BGP routing table entry for 3:1/32, Route Distinguisher: 200:200
Versions:
```

```

Process          bRIB/RIB  SendTblVer
Speaker          6          6
  Local Label: 16015
Paths: (1 available, best #1)
  Advertised to update-groups (with more than one peer):
    0.1
  Advertised to peers (in unique update groups):
    100.100.100.1
Path #1: Received by speaker 0
Local
  0.0.0.0 from 0.0.0.0 (200.200.200.1)
  Origin IGP, localpref 100, valid, redistributed, best, import-candidate
  Extended community: RT:2:2 L2VPN:4:0:1500
  Circuit Vector:0xfd 0xff
  Block Size:10

```

The following example is sample output from the **show bgp l2vpn vpls** for local NLRI:

RD is 3.3.3.3:3276, NH Address is 100.0.0.1, and VPLS ID is 150:200. The RT is 200:100.



Note The RT and VPLS-ID are always same for the same VPLS instance.

```

Router#show bgp l2vpn vpls
Sat Jun  6 17:01:18.610 PST
BGP router identifier 3.3.3.3, local AS number 101
BGP generic scan interval 60 secs
BGP table state: Active
Table ID: 0x0
BGP main routing table version 5
BGP scan interval 60 secs

Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network        Next Hop
Route Distinguisher: 3.3.3.3:3276 (default for vrf gl:b1)
*>i200.0.0.1      30.0.0.2
*>i100.0.0.1      0.0.0.0
Route Distinguisher: 2.2.2.2:3435
*>i200.0.0.1      30.0.0.2

Processed 3 prefixes, 3 paths

Router#show bgp l2vpn vpls rd 3.3.3.3:3276 100.0.0.1
Sat Jun  6 16:40:03.191 PST
BGP routing table entry for 100.0.0.1, Route Distinguisher: 3.3.3.3:3276
Versions:
  Process          bRIB/RIB  SendTblVer
  Speaker          3          3
    Last Modified: Jun  6 11:20:57.944 for 05:19:05
Paths: (1 available, best #1)
  Advertised to peers (in unique update groups):
    30.0.0.2
Path #1: Received by speaker 0
Local
  0.0.0.0 from 0.0.0.0 (3.3.3.3)
  Origin IGP, localpref 100, valid, redistributed, best, import-candidate
  Extended community: RT:200:100 VPLS-ID:150:200

```

The following example is sample output from the `show bgp l2vpn vpls` for remote NLRI:
RD is 2.2.2.2:3435, NH Address is 200.0.0.1, and VPLS ID is 150:200. The RT is 200:100.

```
Router#show bgp l2vpn vpls rd 2.2.2.2:3435 200.0.0.1
Sat Jun  6 16:53:55.726 PST
BGP routing table entry for 200.0.0.1, Route Distinguisher: 2.2.2.2:3435
Versions:
  Process          bRIB/RIB  SendTblVer
  Speaker          5         5
Last Modified: Jun  6 11:20:57.944 for 05:32:58
Paths: (1 available, best #1)
  Not advertised to any peer
  Path #1: Received by speaker 0
Local
  30.0.0.2 from 30.0.0.2 (133.133.133.133)
    Origin IGP, localpref 100, valid, internal, best, import-candidate, imported
    Extended community: RT:200:50 VPLS-ID:150:200
```

The following example is sample output of the `show bgp l2vpn evpn` command for a Data Center Interconnect Layer 3 Gateway.

```
Router#show bgp l2vpn evpn
Fri Aug 21 00:24:10.773 PDT
BGP router identifier 30.30.30.30, local AS number 100
BGP generic scan interval 60 secs
Non-stop routing is enabled
BGP table state: Active
Table ID: 0x0 RD version: 0
BGP main routing table version 16
BGP NSR Initial initsync version 1 (Reached)
BGP NSR/ISSU Sync-Group versions 16/0
BGP scan interval 60 secs

Status codes: s suppressed, d damped, h history, * valid, > best
               i - internal, r RIB-failure, S stale, N Nexthop-discard
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network          Next Hop          Metric LocPrf Weight Path
Route Distinguisher: 100:1
*>i[2][10000][48][0226.51bd.c81c][32][200::1001]/232
      11.0.0.1                      100          0 i
*>i[2][10000][48][0226.51bd.c81c][32][200:1::1001]/232
      11.0.0.1                      100          0 i
*>i[2][10000][48][0226.51bd.c81c][32][200.1.1.1]/136
      11.0.0.1                      100          0 i
*>i[2][10000][48][0226.51bd.c81c][32][200.1.1.2]/136
      11.0.0.1                      100          0 i
*>i[5][4231][32][100.1.1.1]/80
      11.0.0.1                      100          0 i
*>i[5][4231][32][100.1.1.2]/80
      11.0.0.1                      100          0 i
*>i[5][4231][112][fec0::1001]/176
      11.0.0.1                      100          0 i
*>i[5][4232][112][fec0::1:1001]/176
      11.0.0.1                      100          0 i

Processed 8 prefixes, 8 paths
```

The following example is sample output of the `show bgp l2vpn evpn rd` command for a Data Center Interconnect Layer 3 Gateway. This sample output provides details for the specified route distinguisher and prefix.

```
Router# show bgp l2vpn evpn rd 100:1 [5][4231][112][fec0::1001]/176 detail
Fri Aug 21 00:34:43.747 PDT
```

```

BGP routing table entry for [5][4231][112][fec0::1001]/176, Route Distinguisher: 100:1
Versions:
  Process          bRIB/RIB  SendTblVer
  Speaker          5         5
  Flags: 0x04040001+0x00000000;
Last Modified: Aug 21 00:16:58.000 for 00:17:46
Paths: (1 available, best #1)
  Not advertised to any peer
  Path #1: Received by speaker 0
  Flags: 0x4000600025060005, import: 0x3f
  Not advertised to any peer
Local
  11.0.0.1 (metric 2) from 20.0.0.1 (11.0.0.1)
    Received Label 16001
    Origin IGP, localpref 100, valid, internal, best, group-best, import-candidate,
reoriginate, not-in-vrf
    Received Path ID 0, Local Path ID 1, version 5
    Extended community: Flags 0x2: Encapsulation Type:8 Router MAC:aabb.ccdd.eeff RT:65540:1
RT:40.40.40.40:1 RT:100:1
  Originator: 11.0.0.1, Cluster list: 20.20.20.20
  EVPN ESI: ffff.ffff.ffff.ffff.ff01, Gateway Address : fec0::254

```

show bgp l2vpn vpls

To display L2VPN information on BGP summary, routes for a specified bridge group domain, advertised routes, routes with a specific route distinguisher, BGP neighbor connections, nexthops, and BGP process, use the **show bgp l2vpn vpls** command in EXEC mode and XR EXEC mode.

show bgp l2vpn vpls {summary | rd | neighbors | nexthops | bdomain | advertised | process}

Syntax Description	summary	Displays the summary of BGP neighbor status.
	rd	Displays routes with a specific route distinguisher.
	neighbors	Displays detailed information on TCP and BGP neighbor connections.
	nexthops	Shows nexthop related information.
	bdomain	Displays routes for a specified Bridge Group:domain
	advertised	Shows advertised routes.
	process	Displays BGP process information.
Command Default	No default behavior or values	
Command Modes	EXEC mode and XR EXEC mode	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Example

The following example is sample output from the **show bgp l2vpn vpls** command:

```
Router#show bgp l2vpn vpls
Wed Mar 17 15:26:29.433 EDT
BGP router identifier 60.60.60.60, local AS number 1
BGP generic scan interval 60 secs
Non-stop routing is enabled
BGP table state: Active
Table ID: 0x0
BGP main routing table version 24001
BGP NSR Initial initsync version 1 (Reached)
BGP scan interval 60 secs

Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network             Next Hop           Rcvd Label       Local Label
Route Distinguisher: 101:1 (default for vrf bg1:bg1_bd1)
*>i10.10.10.10/32      10.10.10.10      nolabel          nolabel
*> 60.60.60.60/32     0.0.0.0          nolabel          nolabel
```

```

Route Distinguisher: 102:1 (default for vrf bg1:bg1_bd2)
*>i10.10.10.10/32      10.10.10.10      nolabel      nolabel
*> 60.60.60.60/32      0.0.0.0          nolabel      nolabel

```

The following example is sample output from the **show bgp l2vpn vpls** command with the summary keyword:

```

Router#show bgp l2vpn vpls summary
Wed Mar 17 15:27:09.502 EDT
BGP router identifier 60.60.60.60, local AS number 1
BGP generic scan interval 60 secs
Non-stop routing is enabled
BGP table state: Active
Table ID: 0x0
BGP main routing table version 24001
BGP NSR Initial initsync version 1 (Reached)
BGP scan interval 60 secs

```

BGP is operating in STANDALONE mode.

Process	RcvTblVer	bRIB/RIB	LabelVer	ImportVer	SendTblVer	StandbyVer
Speaker	24001	24001	24001	24001	24001	0

Neighbor	Spk	AS	MsgRcvd	MsgSent	TblVer	InQ	OutQ	Up/Down	St/PfxRcd
10.10.10.10	0	1	45532	8392	24001	0	0	03:06:25	8000

The following example is sample output from the **show bgp l2vpn vpls** command for Route Distinguisher: 101:1:

```

Router#show bgp l2vpn vpls rd 101:1
Wed Mar 17 15:27:31.347 EDT
BGP router identifier 60.60.60.60, local AS number 1
BGP generic scan interval 60 secs
Non-stop routing is enabled
BGP table state: Active
Table ID: 0x0
BGP main routing table version 24001
BGP NSR Initial initsync version 1 (Reached)
BGP scan interval 60 secs

Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network             Next Hop           Rcvd Label       Local Label
Route Distinguisher: 101:1 (default for vrf bg1:bg1_bdl)
*>i10.10.10.10/32      10.10.10.10      nolabel          nolabel
*> 60.60.60.60/32      0.0.0.0          nolabel          nolabel

```

Processed 2 prefixes, 2 paths

The following example is sample output from the **show bgp l2vpn vpls** command for BGP neighbor 10.10.10.10:

```

Router#show bgp l2vpn vpls neighbors 10.10.10.10
Wed Mar 17 15:28:28.766 EDT

BGP neighbor is 10.10.10.10
  Remote AS 1, local AS 1, internal link
  Remote router ID 10.10.10.10

```



```
BGP state = Established, up for 03:07:44
NSR State: None
Last read 00:00:31, Last read before reset 00:00:00
Hold time is 180, keepalive interval is 60 seconds
Configured hold time: 180, keepalive: 60, min acceptable hold time: 3
Last write 00:00:45, attempted 19, written 19
Second last write 00:01:45, attempted 19, written 19
Last write before reset 00:00:00, attempted 0, written 0
Second last write before reset 00:00:00, attempted 0, written 0
Last write pulse rcvd Mar 17 15:27:57.362 last full not set pulse count 847
Last write pulse rcvd before reset 00:00:00
Socket not armed for io, armed for read, armed for write
Last write thread event before reset 00:00:00, second last 00:00:00
Last KA expiry before reset 00:00:00, second last 00:00:00
Last KA error before reset 00:00:00, KA not sent 00:00:00
Last KA start before reset 00:00:00, second last 00:00:00
Precedence: internet
Non-stop routing is enabled
Graceful restart is enabled
Restart time is 300 seconds
Stale path timeout time is 1200 seconds
Neighbor capabilities:
  Route refresh: advertised and received
  Graceful Restart (GR Awareness): received
  4-byte AS: advertised and received
  Address family IPv4 Unicast: advertised and received
  Address family VPNv4 Unicast: advertised and received
  Address family L2VPN VPLS: advertised and received
Received 45533 messages, 0 notifications, 0 in queue
Sent 8393 messages, 0 notifications, 0 in queue
Minimum time between advertisement runs is 0 secs
```

```
For Address Family: IPv4 Unicast
BGP neighbor version 1
Update group: 0.2
AF-dependant capabilities:
  Graceful Restart Capability advertised and received
    Local restart time is 300, RIB purge time is 900 seconds
    Maximum stalepath time is 1200 seconds
    Remote Restart time is 300 seconds
Route refresh request: received 0, sent 0
0 accepted prefixes, 0 are bestpaths
Cumulative no. of prefixes denied: 0.
Prefix advertised 0, suppressed 0, withdrawn 0
Maximum prefixes allowed 524288
Threshold for warning message 75%, restart interval 0 min
An EoR was received during read-only mode
Last ack version 1, Last synced ack version 0
Outstanding version objects: current 0, max 0
```

```
For Address Family: VPNv4 Unicast
BGP neighbor version 1
Update group: 0.2
AF-dependant capabilities:
  Graceful Restart Capability advertised and received
    Local restart time is 300, RIB purge time is 900 seconds
    Maximum stalepath time is 1200 seconds
    Remote Restart time is 300 seconds
Route refresh request: received 0, sent 0
0 accepted prefixes, 0 are bestpaths
Cumulative no. of prefixes denied: 0.
Prefix advertised 0, suppressed 0, withdrawn 0
Maximum prefixes allowed 524288
Threshold for warning message 75%, restart interval 0 min
```

```

An EoR was received during read-only mode
Last ack version 1, Last synced ack version 0
Outstanding version objects: current 0, max 0

For Address Family: L2VPN VPLS
BGP neighbor version 24001
Update group: 0.2
AF-dependant capabilities:
  Graceful Restart Capability advertised and received
    Local restart time is 300, RIB purge time is 900 seconds
    Maximum stalepath time is 1200 seconds
    Remote Restart time is 300 seconds
Route refresh request: received 0, sent 203
8000 accepted prefixes, 8000 are bestpaths
Cumulative no. of prefixes denied: 18172.
  No policy: 0, Failed RT match: 18172
  By ORF policy: 0, By policy: 0
Prefix advertised 8000, suppressed 0, withdrawn 0
Maximum prefixes allowed 524288
Threshold for warning message 75%, restart interval 0 min
An EoR was received during read-only mode
Last ack version 24001, Last synced ack version 0
Outstanding version objects: current 0, max 2

Connections established 1; dropped 0
Local host: 60.60.60.60, Local port: 179
Foreign host: 10.10.10.10, Foreign port: 50472
Last reset 00:00:00

```

The following example is sample output from the **show bgp l2vpn vpls** command with the advertised keyword:

```

Router#show bgp l2vpn vpls advertised
Wed Mar 17 15:29:13.787 EDT
Route Distinguisher: 101:1
60.60.60.60/32 is advertised to 10.10.10.10
  Path info:
    neighbor: Local          neighbor router id: 60.60.60.60
    valid redistributed best import-candidate
  Attributes after inbound policy was applied:
    next hop: 0.0.0.0
    EXTCOMM
    origin: IGP
    aspath:
    extended community: RT:101:1 L2VPN AGI:1:101

```

The following example is sample output from the **show bgp l2vpn vpls** command with the nexthops keyword:

```

Router#show bgp l2vpn vpls nexthops
Wed Mar 17 15:29:36.357 EDT
Total Nexthop Processing
  Time Spent: 0.000 secs

Maximum Nexthop Processing
  Received: 82y46w
  Bestpaths Deleted: 0
  Bestpaths Changed: 0
  Time Spent: 0.000 secs

Last Notification Processing

```

```

Received: 03:10:50
Time Spent: 0.000 secs

Gateway Address Family: IPv4 Unicast
Table ID: 0xe0000000
Nexthop Count: 2
Critical Trigger Delay: 3000msec
Non-critical Trigger Delay: 10000msec

Nexthop Version: 1, RIB version: 1

Status codes: R/UR Reachable/Unreachable
               C/NC Connected/Not-connected
               L/NL Local/Non-local
               I   Invalid (Policy Match Failed)
Next Hop      Status      Metric      Notf      LastRIBEvent RefCount
10.10.10.10   [R] [NC] [NL]         2         1/0      03:10:50 (Cri)   8000/8003

```

The following example is sample output from the show bgp l2vpn vpls command with the process keyword:

```

Router#show bgp l2vpn vpls process
Wed Mar 17 15:29:56.086 EDT

BGP Process Information:
BGP is operating in STANDALONE mode
Autonomous System number format: ASPLAIN
Autonomous System: 1
Router ID: 60.60.60.60 (manually configured)
Default Cluster ID: 60.60.60.60
Active Cluster IDs: 60.60.60.60
Fast external fallover enabled
Neighbor logging is enabled
Enforce first AS enabled
Default local preference: 100
Default keepalive: 60
Graceful restart enabled
Restart time: 180
Stale path timeout time: 1200
RIB purge timeout time: 900
Non-stop routing is enabled
Update delay: 600
Generic scan interval: 60

Address family: L2VPN VPLS
Dampening is not enabled
Client reflection is enabled in global config
Scan interval: 60
Main Table Version: 24001
Table version synced to RIB: 1
RIB has not converged: version 0

Node          Process      Nbrs Estb Rst Upd-Rcvd Upd-Sent Nfn-Rcv Nfn-Snt
node0_RSP0_CPU0 Speaker         1    1    2    45347     237      0      0

```

show bgp neighbor-group

To display information about the Border Gateway Protocol (BGP) configuration for neighbor groups, use the **show bgp neighbor-group** command in EXEC mode and XR EXEC mode.

```
show bgp neighbor-group group-name { configuration [defaults] [nvgen] | inheritance |
users }
```

Syntax Description

<i>group-name</i>	Name of the address family group to display.
configuration	(Optional) Displays the effective configuration for the neighbor group, including any configuration inherited by this neighbor group.
defaults	(Optional) Displays all configuration, including default configuration.
nvgen	(Optional) Displays output in show running-config command output. If the defaults keyword is also specified, the output is not suitable for cutting and pasting into a configuration session.
inheritance	Displays the af-groups, session groups, and neighbor groups from which this neighbor group inherits configuration.
users	Displays the neighbors and neighbor groups that inherit configuration from this neighbor group.

Command Default

No default behavior or value

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **show bgp neighbor-group** command with the *group-name* **configuration** argument and keyword to display the effective configuration of a neighbor group, including any configuration inherited from session groups, address family groups, and neighbor groups through application of the **use** command. The source of each configured command is also displayed.

Use the **defaults** keyword to display all configuration for the neighbor group, including default configuration. The command output identifies default onfiguration. Use the **nvgen** keyword to display configuration in the output form of **show running-config** command. Output in this form is suitable for cutting and pasting into a configuration session.

The **show bgp neighbor-group** command with the *group-name* **inheritance** argument and keyword displays the session groups, address family groups, and neighbor groups from which the specified neighbor group inherits configuration.

The **show bgp neighbor-group** *group-name* command displays the neighbors and neighbor groups that inherit configuration from the specified neighbor group.

Examples

The examples use the following configuration:

```

af-group group3 address-family ipv4 unicast
  remove-private-AS
  soft-reconfiguration inbound
!
af-group group2 address-family ipv4 unicast
  use af-group group3
  send-community-ebgp
  send-extended-community-ebgp
  capability orf prefix both
!
session-group group3
  dmzlink-bw
!
neighbor-group group3
  use session-group group3
  timers 30 90
!
neighbor-group group1
  remote-as 1982
  use neighbor-group group2
  address-family ipv4 unicast
!
!
neighbor-group group2
  use neighbor-group group3
  address-family ipv4 unicast
  use af-group group2
  weight 100
!

```

The following is sample output from the **show bgp neighbor-group** command with the **configuration** keyword:

```
Router# show bgp neighbor-group group1 configuration
```

```

neighbor-group group1
  remote-as 1982                []
  timers 30 90                 [n:group2 n:group3]
  dmzlink-bw                   [n:group2 n:group3 s:group3]
  address-family ipv4 unicast  []
  capability orf prefix both   [n:group2 a:group2]
  remove-private-AS           [n:group2 a:group2 a:group3]
  send-community-ebgp         [n:group2 a:group2]
  send-extended-community-ebgp [n:group2 a:group2]
  soft-reconfiguration inbound [n:group2 a:group2 a:group3]
  weight 100                   [n:group2]

```

The configuration source is shown to the right of each command. In the output, the **remote-as** command is configured directly on neighbor group group1, and the **send-community-ebgp** command is inherited from neighbor group group2, which in turn inherits the setting from af-group group2.

The following is sample output from the **show bgp neighbor-group** command with the **users** keyword. This output shows that the group1 neighbor group inherits session (address family-independent configuration parameters) from the group2 neighbor group. The group1 neighbor group also inherits IPv4 unicast configuration parameters from the group2 neighbor group:

```
Router# show bgp neighbor-group group2 users
```

```
Session:      n:group1
```

```
IPv4 Unicast: n:group1
```

The following is sample output from the **show bgp neighbor-group** command with the **inheritance** keyword. This output shows that the specified neighbor group group1 inherits session (address family-independent configuration) from neighbor group group2, which inherits its own session from neighbor group group3. Neighbor group group3 inherited its session from session group group3. It also shows that the group1 neighbor-group inherits IPv4 unicast configuration parameters from the group2 neighbor group, which in turn inherits them from the group2 af-group, which itself inherits them from the group3 af-group:

```
Router# show bgp neighbor-group group1 inheritance
```

```
Session:      n:group2 n:group3 s:group3
IPv4 Unicast: n:group2 a:group2 a:group3
```

This table describes the significant fields shown in the display.

Table 17: show bgp neighbor-group Field Descriptions

Field	Description
[]	Configures the command directly on the specified address family group.
s:	Indicates the name that follows is a session group.
a:	Indicates the name that follows is an address family group.
n:	Indicates the name that follows is a neighbor group.
[dflt]	Indicates the setting is not explicitly configured or inherited, and the default value for the setting is used. This field may be shown when the defaults keyword is specified.
<not set>	Indicates that the default is for the setting to be disabled. This field may be shown when the defaults keyword is specified.

show bgp neighbors

To display information about Border Gateway Protocol (BGP) connections to neighbors, use the **show bgp neighbors** command in EXEC mode and XR EXEC mode.

```
show bgp neighbors [performance-statistics | missing-eor] [standby]
show bgp neighbors ip-address[advertised-routes | dampened-routes | flap-statistics |
performance-statistics | received | {prefix-filter | routes} | routes] [standby]
show bgp neighbors ip-address [configuration | [defaults] | nvgen | inheritance][standby]
show bgp neighbors ip-address [decoded-message-log | [in] | out | standby]
show bgp [ ipv4 { unicast | multicast | all } | ipv6 { unicast | multicast | all } ] neighbors
ip-address [dryrun-policy] policy-name
show bgp neighbors detail
show bgp neighbor ip-address [ advertised-count | advertised-routes | configuration | detail
]
```

Syntax Description

ipv4	(Optional) Specifies IP Version 4 address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.
tunnel	(Optional) Specifies tunnel address prefixes.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
all	(Optional) For address family, specifies prefixes for all address families.
vpn4 unicast	(Optional) Specifies VPNv4 unicast address families.
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
<i>vrf-name</i>	(Optional) Name of a VRF.
all	(Optional) For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.
performance-statistics	(Optional) Displays performance statistics relative to work done by the BGP process for this neighbor.
missing-eor	(Optional) Displays neighbors that did not send end-of-rib (EoR) notification in read-only mode.

<i>ip-address</i>	(Optional) IP address of the BGP-speaking neighbor. If you omit this argument, all neighbors are displayed.
advertised-routes	(Optional) Displays all routes the router advertised to the neighbor.
advertised-count	(Optional) Displays the total number of advertised routes.
dampened-routes	(Optional) Displays the dampened routes that are learned from the neighbor.
flap-statistics	(Optional) Displays flap statistics of the routes learned from the neighbor.
received { prefix-filter routes }	(Optional) Displays information received from the BGP neighbor. The options are: prefix-filter — Displays the prefix list filter. routes —Displays routes from the neighbor before inbound policy
routes	(Optional) Displays routes learned from the neighbor.
configuration	(Optional) Displays the effective configuration for the neighbor, including any settings that have been inherited from session groups, neighbor groups, or af-groups used by this neighbor.
defaults	(Optional) Displays all configuration settings, including any default settings.
nvgen	(Optional) Displays output in the show running-config command output.
inheritance	(Optional) Displays the session groups, neighbor groups, and af-groups from which this neighbor inherits configuration settings.
in	(Optional) Displays BGP inbound messages.
out	(Optional) Displays BGP outbound messages.
standby	Displays standby BGP information.
dryrun-policy <i>policy-name</i>	Executes the dry-run inbound policy and displays the resulting statistics.
detail	Displays detailed BGP information.

Command Default

If no address family or subaddress family is specified, the default address family and subaddress family specified using the **set default-afi** and **set default-safi** commands are used.

Command Modes

EXEC mode and XR EXEC mode.

Command History

Release	Modification
Release 7.0.12	This command was introduced.
Release 7.9.1	This command displays the slow peer configuration state and slow peer detection or processing information.
Release 24.2.11	This command was modified. The dryrun-policy keyword and <i>policy-name</i> argument were added.

Usage Guidelines



Note The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

BGP contains a separate routing table for each configured address family and subaddress family combination. The address family and subaddress family options specify which routing table should be examined. If the **all** keyword is specified for address family or subaddress family, each matching routing table is examined in turn.

Use the **show bgp neighbors** command to display detailed information about all neighbors or a specific neighbor. Use the **performance-statistics** keyword to display information about the work related to specific neighbors done by the BGP process.

Use the **show bgp neighbors** command with the **ip-address received prefix-filter** argument and keyword to display the Outbound Route Filter (ORF) received from a neighbor.

Use the **advertised-routes** keyword to display a summary of the routes advertised to the specified neighbor.

Use the **dampened-routes** keyword to display routes received from the specified neighbor that have been suppressed due to dampening. For more details, see the **show bgp dampened-paths** command.

To display information about flapping routes received from a neighbor, use the **flap-statistics** keyword. For more details, see the **show bgp flap-statistics** command.

To display the routes received from a neighbor, use the **routes** keyword. For more details, see the **show bgp** command.

Use the **show bgp neighbor** command with the **ip-address configuration** argument and keyword to display the effective configuration of a neighbor, including configuration inherited from session groups, neighbor groups, or af-groups through application of the **use** command. Use the **defaults** keyword to display the value of all configurations for the neighbor, including default configuration. Use the **nvgen** keyword to display configuration output format of the **show running-config** command. Output in this format is suitable for cutting and pasting into a configuration session. Use the **show bgp neighbors** command with the **ip-address inheritance** argument and keyword to display the session groups, neighbor groups, and af-groups from which the specified neighbor inherits configuration.

The following is the sample output from the **show bgp neighbors** command with the **ip-address** and **configuration** argument and keyword to display graceful maintenance feature attributes:

```
*****
RP/0/0/CPU0:R1#show bgp neighbor 10.12.12.5
...
  Graceful Maintenance locally active, Local Pref=45, AS prepends=3
...
  For Address Family: IPv4 Unicast
...
  GSHUT Community attribute sent to this neighbor
...
*****
```

```

RP/0/0/CPU0:R1#show bgp neighbor 10.12.12.5 configuration
Mon Feb  2 14:30:41.042 PST
neighbor 12.12.12.5
  remote-as 1 []
  graceful-maintenance 1 []
  gr-maint local-preference 45 []
  gr-maint as-prepends 3 []
  gr-maint activate []
*****

```

Examples

The following is sample output from the **show bgp neighbors** command with BGP Persistence or long lived graceful restart (LLGR) status:

```

Router# show bgp neighbors 10.3.3.3
BGP neighbor is 10.3.3.3
Remote AS 30813, local AS 30813, internal link
Remote router ID 10.3.3.3
  BGP state = Established, up for 2d19h
  NSR State: NSR Ready
  BFD enabled (initializing)
  Last read 00:00:01, Last read before reset 2d19h
  Hold time is 180, keepalive interval is 60 seconds
  Configured hold time: 180, keepalive: 60, min acceptable hold time: 3
  Last write 00:00:03, attempted 19, written 19
  Second last write 00:01:03, attempted 19, written 19
  Last write before reset 2d19h, attempted 19, written 19
  Second last write before reset 2d19h, attempted 19, written 19
  Last write pulse rcvd Nov 19 09:24:38.035 last full not set pulse count 66013
  Last write pulse rcvd before reset 2d19h
  Socket not armed for io, armed for read, armed for write
  Last write thread event before reset 2d19h, second last 2d19h
  Last KA expiry before reset 2d19h, second last 2d19h
  Last KA error before reset 00:00:00, KA not sent 00:00:00
  Last KA start before reset 2d19h, second last 2d19h
  Precedence: internet
  Non-stop routing is enabled
  Graceful restart is enabled
  Restart time is 120 seconds
  Stale path timeout time is 150 seconds
  Multi-protocol capability received
  Neighbor capabilities:
    Route refresh: advertised (old + new) and received (old + new)
    Graceful Restart (GR Awareness): advertised and received
    4-byte AS: advertised and received
    Address family IPv4 Unicast: advertised and received
    Address family VPNv4 Unicast: advertised and received
    Address family VPNv6 Unicast: advertised and received
    Address family RT Constraint: advertised and received
  Received 51634 messages, 0 notifications, 0 in queue
  Sent 33017 messages, 2 notifications, 0 in queue
  Minimum time between advertisement runs is 0 secs

For Address Family: IPv4 Unicast
BGP neighbor version 204
Update group: 0.2 Filter-group: 0.2 No Refresh request being processed
AF-dependent capabilities:
  Graceful Restart capability advertised
    Local restart time is 120, RIB purge time is 600 seconds
    Maximum stalepath time is 150 seconds

```

```
Graceful Restart capability received
Remote Restart time is 120 seconds
Neighbor preserved the forwarding state during latest restart
Route refresh request: received 0, sent 0
Policy for incoming advertisements is pass
Policy for outgoing advertisements is pass
0 accepted prefixes, 0 are bestpaths
Cumulative no. of prefixes denied: 0.
Prefix advertised 0, suppressed 0, withdrawn 0
Maximum prefixes allowed 1048576
Threshold for warning message 75%, restart interval 0 min
AIGP is enabled
An EoR was not received during read-only mode
Last ack version 204, Last synced ack version 204
Outstanding version objects: current 0, max 0
Additional-paths operation: None
Send Multicast Attributes
```

For Address Family: VPNv4 Unicast

```
BGP neighbor version 8309
Update group: 0.2 Filter-group: 0.2 No Refresh request being processed
Inbound soft reconfiguration allowed
AF-dependent capabilities:
Graceful Restart capability advertised
Local restart time is 120, RIB purge time is 600 seconds
Maximum stalepath time is 150 seconds
Graceful Restart capability received
Remote Restart time is 120 seconds
Neighbor preserved the forwarding state during latest restart
Long-lived Graceful Restart Capability advertised
Advertised Long-lived Stale time 3000 seconds
Maximum acceptable long-lived stale time from this neighbor is 3000
Long-lived Graceful Restart Capability received
Received long-lived stale time is 3000 seconds
Neighbor preserved the forwarding state during latest restart
Route refresh request: received 0, sent 0
Policy for incoming advertisements is pass
Policy for outgoing advertisements is pass
250 accepted prefixes, 250 are bestpaths
Cumulative no. of prefixes denied: 0.
Prefix advertised 100, suppressed 0, withdrawn 0
Maximum prefixes allowed 2097152
Threshold for warning message 75%, restart interval 0 min
Peer will hold long-lived stale routes for 3000 seconds
AIGP is enabled
An EoR was not received during read-only mode
Last ack version 8309, Last synced ack version 8309
Outstanding version objects: current 0, max 1
Additional-paths operation: None
Send Multicast Attributes
```

For Address Family: VPNv6 Unicast

```
BGP neighbor version 5
Update group: 0.2 Filter-group: 0.2 No Refresh request being processed
Inbound soft reconfiguration allowed
AF-dependent capabilities:
Graceful Restart capability advertised
Local restart time is 120, RIB purge time is 600 seconds
Maximum stalepath time is 150 seconds
Graceful Restart capability received
Remote Restart time is 120 seconds
Neighbor preserved the forwarding state during latest restart
Long-lived Graceful Restart Capability advertised
Advertised Long-lived Stale time 3000 seconds
```

```

Maximum acceptable long-lived stale time from this neighbor is 3000
Long-lived Graceful Restart Capability received
Received long-lived stale time is 3000 seconds
Neighbor preserved the forwarding state during latest restart
Route refresh request: received 0, sent 0
Policy for incoming advertisements is pass
Policy for outgoing advertisements is pass
0 accepted prefixes, 0 are bestpaths
Cumulative no. of prefixes denied: 0.
Prefix advertised 0, suppressed 0, withdrawn 0
Maximum prefixes allowed 1048576
Threshold for warning message 75%, restart interval 0 min
Peer will hold long-lived stale routes for 3000 seconds
AIGP is enabled
An EoR was not received during read-only mode
Last ack version 5, Last synced ack version 5
Outstanding version objects: current 0, max 0
Additional-paths operation: None
Send Multicast Attributes

For Address Family: RT Constraint
BGP neighbor version 8
Update group: 0.1 Filter-group: 0.1 No Refresh request being processed RT constraint
nbr enabled for VPN updates:
AF-dependent capabilities:
Graceful Restart capability advertised
Local restart time is 120, RIB purge time is 600 seconds
Maximum stalepath time is 150 seconds
Graceful Restart capability received
Remote Restart time is 120 seconds
Neighbor preserved the forwarding state during latest restart
Long-lived Graceful Restart Capability advertised
Advertised Long-lived Stale time 3000 seconds
Maximum acceptable long-lived stale time from this neighbor is 3000
Route refresh request: received 0, sent 0
Policy for incoming advertisements is pass
Policy for outgoing advertisements is pass
1 accepted prefixes, 1 are bestpaths
Cumulative no. of prefixes denied: 0.
Prefix advertised 2, suppressed 0, withdrawn 0
Maximum prefixes allowed 1048576
Threshold for warning message 75%, restart interval 0 min
Peer will hold long-lived stale routes for 3000 seconds
AIGP is enabled
An EoR was not received during read-only mode
Last ack version 8, Last synced ack version 8
Outstanding version objects: current 0, max 1
Additional-paths operation: None
Send Multicast Attributes

Connections established 3; dropped 2
Local host: 10.1.1.1, Local port: 179, IF Handle: 0x00000000
Foreign host: 10.3.3.3, Foreign port: 62747
Last reset 2d19h, due to BGP Notification sent: hold time expired
Time since last notification sent to neighbor: 2d19h
Error Code: hold time expired
Notification data sent:
None

```

The following is sample output from the **show bgp neighbors** command:

```

Router# show bgp neighbors 10.0.101.1

BGP neighbor is 10.0.101.1, remote AS 2, local AS 1, external link

```

```
Description: routem neighbor
Remote router ID 10.0.101.1
  BGP state = Established, up for 00:00:56
  TCP open mode: passive only
BGP neighbor is 1.1.1.2
Remote AS 300, local AS 100, external link
Remote router ID 0.0.0.0
  BGP state = Idle (LC/FIB for the neighbor in reloading)
  Last read 00:00:00, Last read before reset 00:05:12
  Hold time is 180, keepalive interval is 60 seconds
  Configured hold time: 180, keepalive: 60, min acceptable hold time: 3

BFD enabled (session initializing)
Last read 00:00:55, hold time is 180, keepalive interval is 60 seconds
DMZ-link bandwidth is 1000 Mb/s
Neighbor capabilities:
  Route refresh: advertised
  4-byte AS: advertised and received
  Address family IPv4 Unicast: advertised and received
  Address family IPv4 Multicast: advertised and received
Received 119 messages, 0 notifications, 0 in queue
Sent 119 messages, 22 notifications, 0 in queue
Minimum time between advertisement runs is 60 seconds

For Address Family: IPv4 Unicast
BGP neighbor version 137
Update group: 1.3
Community attribute sent to this neighbor
AF-dependant capabilities:
  Outbound Route Filter (ORF) type (128) Prefix-list:
    Send-mode: advertised
    Receive-mode: advertised
Route refresh request: received 0, sent 0
Policy for incoming advertisements is pass-all
Policy for outgoing advertisements is pass-all
5 accepted prefixes, 5 are bestpaths
Prefix advertised 3, suppressed 0, withdrawn 0, maximum limit 1000000
Threshold for warning message 75%

For Address Family: IPv4 Multicast
BGP neighbor version 23
Update group: 1.2
Route refresh request: received 0, sent 0
Policy for incoming advertisements is pass-all
Policy for outgoing advertisements is pass-all
2 accepted prefixes, 2 are bestpaths
Prefix advertised 0, suppressed 0, withdrawn 0, maximum limit 131072
Threshold for warning message 75%

Connections established 9; dropped 8
Last reset 00:02:10, due to User clear requested (CEASE notification sent - administrative
reset)
Time since last notification sent to neighbor: 00:02:10
Error Code: administrative reset
Notification data sent:
  None
```

This table describes the significant fields shown in the display.

Table 18: show bgp neighbors Field Descriptions

Field	Description
BGP neighbor	IP address of the BGP neighbor and its autonomous system number. If the neighbor is in the same autonomous system as the router, then the link between them is internal; otherwise, it is considered external.
Description	Neighbor specific description.
remote AS	• Number of the autonomous system to which the neighbor belongs. • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) is asdot format is 1.0 to 65535.65535.
local AS	Autonomous system number of the local system. • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) is asdot format is 1.0 to 65535.65535.
internal link	Neighbor is an internal BGP peer.
external link	Neighbor is an external BGP peer.
Administratively shut down	Neighbor connection is disabled using the shutdown command.
remote router ID	Router ID (an IP address) of the neighbor.
Neighbor under common administration	Neighbor is internal or a confederation peer.
BGP state	Internal state of this BGP connection.
BFD enabled	Status of bidirectional forwarding detection.
TCP open mode	TCP mode used in establishing the BGP session. The following valid TCP mode are supported: • default—Accept active/passive connections • passive-only—Accept only passive connections • active-only—Accept only active connections initiated by the router

Field	Description
Last read	Time since BGP last read a message from this neighbor.
hold time	Hold time (in seconds) used on the connection with this neighbor.
keepalive interval	Interval for sending keepalives to this neighbor.
DMZ-link bandwidth	DMZ link bandwidth for this neighbor.
Neighbor capabilities	BGP capabilities advertised and received from this neighbor. The following valid BGP capabilities are supported: • Multi-protocol • Route refresh • Graceful restart • Outbound Route Filter (ORF) type (128) Prefix
Route refresh	Indicates that the neighbor supports dynamic soft reset using the route refresh capability.
4-byte AS	Indicates that the neighbor supports the 4-byte AS capability.
Address family	Indicates that the local system supports the displayed address family capability. If “received” is displayed, the neighbor also supports the displayed address family.
Received	Number of messages received from this neighbor, the number of notification messages received and processed from this neighbor, and the number of messages that have been received, but not yet processed.
Sent	Number of messages sent to this neighbor, the number of notification messages generated to be sent to this neighbor, and the number of messages queued to be sent to this neighbor.
Minimum time between advertisement runs	Advertisement interval (in seconds) for this neighbor.
For Address Family	Information that follows is specific to the displayed address family.
BGP neighbor version	Last version of the BGP database that was sent to the neighbor for the specified address family.
Update group	Update group to which the neighbor belongs.
Route reflector client	Indicates that the local system is acting as a route reflector for this neighbor.

Field	Description
Inbound soft reconfiguration allowed	Indicates that soft reconfiguration is enabled for routes received from this neighbor. Note If the neighbor has route refresh capability, then soft configuration received-only routes are not stored by the local system unless “override route refresh” is displayed.
eBGP neighbor with no inbound or outbound policy: defaults to drop	Indicates that the neighbor does not have an inbound or outbound policy configured using the route-policy (BGP) command. Hence, no routes are accepted from or advertised to this neighbor.
Private AS number removed from updates to this neighbor	Indicates that remove-private-AS is configured on the specified address family for this neighbor.
NEXT_HOP is always this router	Indicates that next-hop-self is configured on the specified address family for this neighbor.
Community attribute sent to this neighbor	Indicates that send-community-ebgp is configured on the specified address family for this neighbor.
Extended community attribute sent to this neighbor	Indicates that send-extended-community-ebgp is configured on the specified address family for this neighbor.
Default information originate	Indicates that default-originate is configured on the specified address family for this neighbor, together with the policy used, if one was specified in the default-originate configuration. An indication of whether the default route has been advertised to the neighbor is also shown.
AF-dependant capabilities	BGP capabilities that are specific to a particular address family. The following valid AF-dependent BGP capabilities are supported: • route refresh capability • route refresh capability OLD value
Outbound Route Filter	Neighbor has the Outbound Route Filter (ORF) capability for the specified address family. Details of the capabilities supported are also shown: Send-mode—“advertised” is shown if the local system can send an outbound route filter to the neighbor. “received” is shown if the neighbor can send an outbound route filter to the local system. Receive-mode—“advertised” is shown if the local system can receive an outbound route filter from the neighbor. “received” is shown if the neighbor can receive an outbound route filter from the local system.
Graceful Restart Capability	Indicates whether graceful restart capability has been advertised to and received from the neighbor for the specified address family.
Neighbor preserved the forwarding state during latest restart	Indicates that when the neighbor connection was last established, the neighbor indicated that it preserved its forwarding state for the specified address family.

Field	Description
Local restart time	Restart time (in seconds) advertised to this neighbor.
RIB purge time	RIB purge time (in seconds) used for graceful restarts.
Maximum stalepath time	Maximum time (in seconds) a path received from this neighbor may be marked as stale if the neighbor restarts.
Remote Restart time	Restart time received from this neighbor.
Route refresh request	Number of route refresh requests sent and received from this neighbor.
Outbound Route Filter (ORF)	“sent” indicates that an outbound route filter has been sent to this neighbor. “received” indicates that an outbound route filter has been received from this neighbor. Note A received outbound route filter may be displayed using the show bgp neighbors command with the received prefix-filter keywords.
First update is deferred until ORF or ROUTE-REFRESH is received	If the local system advertised the receive capability and the neighbor has advertised send capability, no updates are generated until specifically asked by the neighbor (using a ROUTE-REFRESH or ORF with immediate request).
Scheduled to send the Prefix-list filter	Indicates the local system is due to send an outbound route filter request in order to receive updates from the neighbor.
Inbound path policy	Indicates if an inbound path policy is configured.
Outbound path policy	Indicates if an outbound path policy is configured.
Incoming update prefix filter list	Indicates a prefix list is configured to filter inbound updates from the neighbor.
Default weight	Default weight for routes received from the neighbor.
Policy for incoming advertisements	Indicates a route policy is configured to be applied to inbound updates from the neighbor.
Policy for outgoing advertisements	Indicates a route policy is configured to be applied to outbound updates to the neighbor.
Type	Indicates whether the condition map selects routes that should be advertised, or routes that should not be advertised: Exist—Routes advertised if permitted by the condition route map. Non-exist—Routes advertised if denied by the condition route map.
accepted prefixes	Number of prefixes accepted.
Prefix advertised	Number of prefixes advertised to the neighbor during the lifetime of the current connection with the neighbor.

Field	Description
suppressed	Number of prefix updates that were suppressed because no transitive attributes changed from one best path to the next. Note Update suppression occurs only for external BGP neighbors.
withdrawn	Number of prefixes withdrawn from the neighbor during the lifetime of the current connection with the neighbor.
maximum limit	Maximum number of prefixes that may be received from the neighbor. If “(warning-only)” is displayed, a warning message is generated when the limit is exceeded, otherwise the neighbor connection is shut down when the limit is exceeded.
Threshold for warning message	Percentage of maximum prefix limit for the neighbor at which a warning message is generated.
Connections established	Number of times the router has established a BGP peering session with the neighbor.
dropped	Number of times that a good connection has failed or been taken down.
Last reset due to	Reason that the connection with the neighbor was last reset.
Time since last notification sent to neighbor	Amount of time since a notification message was last sent to the neighbor.
Error Code	Type of notification that was sent. The notification data, if any, is also displayed.
Time since last notification received from neighbor	Amount of time since a notification message was last received from the neighbor.
Error Code	Type of notification that was received. The notification data received, if any, is also displayed
External BGP neighbor may be up to <n> hops away	Indicates ebgp-multihop is configured for the neighbor.
External BGP neighbor not directly connected	Indicates that the neighbor is not directly attached to the local system.
Notification data sent:	Data providing more details on the error along with the error notification sent to the neighbor.

The following is sample output from the **show bgp neighbors** command with the **advertised-routes** keyword:

```
Router# show bgp neighbors 172.20.16.178 routes

BGP router identifier 172.20.16.181, local AS number 1
BGP main routing table version 27
BGP scan interval 60 secs
```

```

Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
Network      Next Hop      Metric LocPrf Weight Path
*> 10.0.0.0    172.20.16.178      40                0 10 ?
*> 10.22.0.0   172.20.16.178      40                0 10 ?

```

The following is sample output from the **show bgp neighbors** command with the **routes** keyword:

```

Router# show bgp neighbors 10.0.101.1 dampened-routes

BGP router identifier 10.0.0.5, local AS number 1
BGP main routing table version 48
Dampening enabled
BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
Network      From      Reuse      Path
*d 10.0.0.0   10.0.101.1 00:59:30 2 100 1000 i
*d 11.0.0.0   10.0.101.1 00:59:30 2 100 1000 i
*d 12.0.0.0   10.0.101.1 00:59:30 2 100 1000 i
*d 13.0.0.0   10.0.101.1 00:59:30 2 100 1000 i
*d 14.0.0.0   10.0.101.1 00:59:30 2 100 1000 i

```

This table describes the significant fields shown in the display.

Table 19: show bgp neighbors routes Field Descriptions

Field	Description
BGP router identifier	BGP identifier for the local system.
local AS number	Autonomous system number for the local system.
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.
Dampening enabled	Displayed if dampening is enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.

Field	Description
Status codes	Status of the table entry. The status is displayed as a three-character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): >—Path is the best path to use for that network. d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.
Origin codes	Origin of the path. The origin code is displayed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was advertised with a network or aggregate-address command. e—Path originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP prefix and prefix length for a network.
Next Hop	IP address of the next system that is used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network.
Metric	Value of the interautonomous system metric, otherwise known as the Multi Exit Discriminator (MED) metric.
LocPrf	Local preference value. This is used to determine the preferred exit point from the local autonomous system. It is propagated throughout the local autonomous system.
Weight	Path weight. Weight is used in choosing the preferred path to a route. It is not advertised to any neighbor.
Path	Autonomous system path to the destination network. At the end of the path is the origin code for the path.

The following is sample output from the **show bgp neighbors** command with the **dampened-routes** keyword:

Router# **show bgp neighbors 10.0.101.1 flap-statistics**

```

BGP router identifier 10.0.0.5, local AS number 1
BGP main routing table version 48
Dampening enabled
BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network          From          Flaps Duration Reuse      Path
h 10.1.0.0          10.0.101.1      5008  2d02h           2 5000 1000
h 10.2.0.0          10.0.101.1      5008  2d02h           2 2000 3000
h 10.2.0.0          10.0.101.1      5008  2d02h           2 9000 6000
*d 10.0.0.0         10.0.101.1      5008  2d02h      00:59:30 2 100 1000
h 10.0.0.0/16       10.0.101.1      5008  2d02h           2 100 102
*d 10.11.0.0        10.0.101.1      5008  2d02h      00:59:30 2 100 1000
*d 10.12.0.0        10.0.101.1      5008  2d02h      00:59:30 2 100 1000
*d 10.13.0.0        10.0.101.1      5008  2d02h      00:59:30 2 100 1000
*d 10.14.0.0        10.0.101.1      5008  2d02h      00:59:30 2 100 1000
h 192.168.0.0/16    10.0.101.1      5008  2d02h           2 100 101

```

This table describes the significant fields shown in the display.

Table 20: show bgp neighbors dampened-routes Field Descriptions

Field	Description
BGP router identifier	BGP identifier for the local system.
local AS number	Autonomous system number for the local system.
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.
Dampening enabled	Displayed if dampening is enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.

Field	Description
Status codes	Status of the table entry. The status is displayed as a three-character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): >—Path is the best path to use for that network. d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.
Origin codes	Origin of the path. The origin code is displayed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was advertised with a network or aggregate-address command. e—Path originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP prefix and prefix length for a network.
From	Neighbor from which the route was received.
Reuse	Time (in hours:minutes:seconds) after which the path is made available.
Path	Autonomous system path to the destination network. At the end of the path is the origin code for the path.

The following is sample output from the **show bgp neighbors** command with the **flap-statistics** keyword:

```
Router# show bgp neighbors 10.0.101.2 performance-statistics
```

```
BGP neighbor is 10.0.101.2, remote AS 1
  Read 3023 messages (58639 bytes) in 3019 calls (time spent: 1.312 secs)
  Read throttled 0 times
  Processed 3023 inbound messages (time spent: 0.198 secs)
  Wrote 58410 bytes in 6062 calls (time spent: 3.041 secs)
  Processing write list: wrote 0 messages in 0 calls (time spent: 0.000 secs)
  Processing write queue: wrote 3040 messages in 3040 calls (time spent: 0.055 secs)
```

```
Received 3023 messages, 0 notifications, 0 in queue
Sent 3040 messages, 0 notifications, 0 in queue
```

This table describes the significant fields shown in the display.

Table 21: show bgp neighbors flap-statistics Field Descriptions

Field	Description
BGP route identifier	BGP identifier for the local system.
local AS number	Autonomous system number for the local system.
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.
Dampening enabled	Displayed if dampening has been enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between when the BGP process scans for the specified address family and subaddress family.
Status codes	Status of the table entry. The status is displayed as a three-character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.
Origin codes	Origin of the path. The origin code is displayed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was advertised with a network command. e—Path originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP prefix and prefix length for a network.

Field	Description
From	IP address of the peer that advertised this route.
Flaps	Number of times the route has flapped.
Duration	Time (in hours:minutes:seconds) since the router noticed the first flap.
Reuse	Time (in hours:minutes:seconds) after which the path is made available.
Path	Autonomous system path to reach the destination network.

The following is sample output from the **show bgp neighbors** command with the **performance-statistics** keyword:

```
Router# show bgp neighbors 10.0.101.2 performance-statistics
BGP neighbor is 10.0.101.2, remote AS 1
  Read 3023 messages (58639 bytes) in 3019 calls (time spent: 1.312 secs)
  Read throttled 0 times
  Processed 3023 inbound messages (time spent: 0.198 secs)
  Wrote 58410 bytes in 6062 calls (time spent: 3.041 secs)
  Processing write list: wrote 0 messages in 0 calls (time spent: 0.000 secs)
  Processing write queue: wrote 3040 messages in 3040 calls (time spent: 0.055 secs)
  Received 3023 messages, 0 notifications, 0 in queue
  Sent 3040 messages, 0 notifications, 0 in queue
```

This table describes the significant fields shown in the display.

Table 22: show bgp neighbors performance-statistics Field Descriptions

Field	Description
Read	Indicates the number of messages received from the neighbor, the total size of received messages, the number of read operations performed, and the real time spent (in seconds) by the process performing read operations for this neighbor.
Read throttled	Number of times that reading from the TCP connection to this neighbor has been throttled. Throttling is due to a backlog of messages that have been read but not processed.
inbound messages	Number of read messages that have been processed, and the real time spent processing inbound messages for this neighbor.
Wrote	Amount of data that has been sent to this neighbor, number of write operations performed, and the real time spent by the process performing write operations for this neighbor.
Processing write list	Number of messages written from the write list to this neighbor, number of times the write list has been processed, and real time spent processing the write list. Note Write lists typically contain only update messages.
Processing write queue	Number of messages written from the write queue to this neighbor, number of times the write queue has been processed, and real time spent processing the write queue.

Field	Description
Received	Number of messages received from this neighbor, number of notification messages received and processed from this neighbor, and number of messages that have been received, but not yet processed.
Sent	Number of messages sent to this neighbor, number of notification messages generated to be sent to this neighbor, and number of messages queued to be sent to this neighbor.

The following is sample output from the **show bgp neighbors** command with the **configuration** keyword:

```
Router# show bgp neighbors 10.0.101.1 configuration

neighbor 10.0.101.1
  remote-as 2 []
  bfd fast-detect []
  address-family ipv4 unicast []
    policy pass-all in []
    policy pass-all out []
  address-family ipv4 multicast []
    policy pass-all in []
    policy pass-all out []
```

This table describes the significant fields shown in the display.

Table 23: show bgp neighbors configuration Field Descriptions

Field	Description
neighbor	IP address configuration of the neighbor.
remote-as	Remote autonomous system configured on the neighbor.
bfd fast-detect	BFD parameter configured on the neighbor.
address-family	Address family and subsequent address family configured on the router.
route-policy pass-all in	Route policy configured for inbound updates.
route-policy pass-all out	Route policy configured for outbound updates.

The following sample output shows sample output from **show bgp neighbors** command with additional paths send and receive capabilities advertised to neighbors:

```
BGP neighbor is 10.0.0.30
  Remote AS 100, local AS 100, internal link
  Remote router ID 33.33.33.33
  BGP state = Established, up for 19:54:12
  NSR State: None
  Last read 00:00:25, Last read before reset 19:54:54
  Hold time is 180, keepalive interval is 60 seconds
  Configured hold time: 180, keepalive: 60, min acceptable hold time: 3
  Last write 00:00:02, attempted 19, written 19
  Second last write 00:01:02, attempted 19, written 19
  Last write before reset 19:54:54, attempted 29, written 29
```

show bgp neighbors

```

Second last write before reset 19:54:59, attempted 19, written 19
Last write pulse rcvd Nov 11 12:58:03.838 last full not set pulse count 2407
Last write pulse rcvd before reset 19:54:54
Socket not armed for io, armed for read, armed for write
Last write thread event before reset 19:54:54, second last 19:54:54
Last KA expiry before reset 00:00:00, second last 00:00:00
Last KA error before reset 00:00:00, KA not sent 00:00:00
Last KA start before reset 19:54:54, second last 19:54:59
Precedence: internet
Non-stop routing is enabled
Graceful restart is enabled
Restart time is 120 seconds
Stale path timeout time is 360 seconds
Neighbor capabilities:
  Adv      Rcvd
Route refresh:      Yes      Yes
4-byte AS:          Yes      Yes
Address family IPv4 Unicast:      Yes      Yes
Address family IPv4 Labeled-unicast:  Yes      Yes
Address family VPNv4 Unicast:      Yes      Yes
Address family IPv6 Unicast:      Yes      Yes
Address family VPNv6 Unicast:      Yes      Yes
Address family IPv4 MDT:           Yes      Yes
Message stats:
  InQ depth: 0, OutQ depth: 0
  Last Sent      Sent      Last Rcvd      Rcvd
Open:            Nov 10 17:03:52.731      2      Nov 10 17:03:52.730      2
Notification:    ---      0      ---      0
Update:          Nov 10 17:05:02.435      20     Nov 10 17:04:58.812      12
Keepalive:       Nov 11 12:58:03.632      1197   Nov 11 12:57:40.458      1196
Route Refresh:    ---      0      ---      0
Total:           1219      1210
Minimum time between advertisement runs is 0 secs

```

For Address Family: IPv4 Unicast

```

BGP neighbor version 13
Update group: 0.9
NEXT_HOP is always this router
AF-dependant capabilities:
  Graceful Restart capability advertised and received
  Neighbor preserved the forwarding state during latest restart
  Local restart time is 120, RIB purge time is 600 seconds
  Maximum stalepath time is 360 seconds
  Remote Restart time is 120 seconds
  Additional-paths Send: advertised and received
  Additional-paths Receive: advertised and received
Route refresh request: received 0, sent 0
0 accepted prefixes, 0 are bestpaths
Prefix advertised 10, suppressed 0, withdrawn 0, maximum limit 524288
Threshold for warning message 75%
AIGP is enabled
An EoR was received during read-only mode
Last ack version 13, Last synced ack version 0
Outstanding version objects: current 0, max 1
Additional-paths operation: Send and Receive

```

For Address Family: IPv4 Labeled-unicast

```

BGP neighbor version 13
Update group: 0.4 (Update Generation Throttled)

```

AF-dependant capabilities:

```

Graceful Restart capability advertised and received
Neighbor preserved the forwarding state during latest restart
Local restart time is 120, RIB purge time is 600 seconds
Maximum stalepath time is 360 seconds

```

```

    Remote Restart time is 120 seconds
    Additional-paths Send: received
    Additional-paths Receive: received
    Route refresh request: received 0, sent 0
    0 accepted prefixes, 0 are bestpaths
    Prefix advertised 2, suppressed 0, withdrawn 0, maximum limit 131072
    Threshold for warning message 75%
    AIGP is enabled
    An EoR was received during read-only mode
    Last ack version 13, Last synced ack version 0
    Outstanding version objects: current 0, max 1
    Additional-paths operation: None

```

This is sample output of the **show bgp neighbors** command when update wait-install is enabled. If the session open is postponed due to the reloading of the LC/FIB, the text "LC/FIB for the neighbor in reloading" is displayed next to the BGP state.

```

Router#show bgp neighbors 10.1.1.2

BGP neighbor is 10.1.1.2
  Remote AS 300, local AS 100, external link
  Remote router ID 0.0.0.0
  BGP state = Idle (LC/FIB for the neighbor in reloading)
  Last read 00:00:00, Last read before reset 00:05:12
  Hold time is 180, keepalive interval is 60 seconds
  Configured hold time: 180, keepalive: 60, min acceptable hold time: 3

```

This is sample output from **show bgp neighbors** command that displays status of Accept Own configuration:

```

Router#show bgp neighbor 192.0.2.1

BGP neighbor is 192.0.2.1
  Remote AS 100, local AS 100, internal link
  Remote router ID 45.1.1.1
  BGP state = Established, up for 00:19:54
  NSR State: None
  Last read 00:00:55, Last read before reset 00:00:00
  Hold time is 180, keepalive interval is 60 seconds
  Configured hold time: 180, keepalive: 60, min acceptable hold time: 3
  Last write 00:00:54, attempted 19, written 19
  Second last write 00:01:54, attempted 19, written 19
  Last write before reset 00:00:00, attempted 0, written 0
  Second last write before reset 00:00:00, attempted 0, written 0
  Last write pulse rcvd Jul 19 11:45:38.776 last full not set pulse count 43
  Last write pulse rcvd before reset 00:00:00
  Socket not armed for io, armed for read, armed for write
  Last write thread event before reset 00:00:00, second last 00:00:00
  Last KA expiry before reset 00:00:00, second last 00:00:00
  Last KA error before reset 00:00:00, KA not sent 00:00:00
  Last KA start before reset 00:00:00, second last 00:00:00
  Precedence: internet
  Non-stop routing is enabled
  Neighbor capabilities:
    Route refresh: advertised and received
    4-byte AS: advertised and received
    Address family VPNv4 Unicast: advertised and received
    Address family VPNv6 Unicast: advertised and received
  Received 22 messages, 0 notifications, 0 in queue
  Sent 22 messages, 0 notifications, 0 in queue
  Minimum time between advertisement runs is 0 secs

```

For Address Family: VPNv4 Unicast

```
BGP neighbor version 549
Update group: 0.3 Filter-group: 0.1 No Refresh request being processed
Route refresh request: received 0, sent 0
Policy for incoming advertisements is pass-all
Policy for outgoing advertisements is drop_111.x.x.x
0 accepted prefixes, 0 are bestpaths
Cumulative no. of prefixes denied: 0.
Prefix advertised 0, suppressed 0, withdrawn 0
Maximum prefixes allowed 524288
Threshold for warning message 75%, restart interval 0 min
AIGP is enabled
Accept-own is enabled
An EoR was received during read-only mode
Last ack version 549, Last synced ack version 0
Outstanding version objects: current 0, max 0
Additional-paths operation: None
```

For Address Family: VPNv6 Unicast

```
BGP neighbor version 549
Update group: 0.3 Filter-group: 0.1 No Refresh request being processed
Route refresh request: received 0, sent 0
Policy for incoming advertisements is pass-all
Policy for outgoing advertisements is drop_111.x.x.x
0 accepted prefixes, 0 are bestpaths
Cumulative no. of prefixes denied: 0.
Prefix advertised 0, suppressed 0, withdrawn 0
Maximum prefixes allowed 524288
Threshold for warning message 75%, restart interval 0 min
AIGP is enabled
Accept-own is enabled
An EoR was received during read-only mode
Last ack version 549, Last synced ack version 0
Outstanding version objects: current 0, max 0
Additional-paths operation: None
```

```
Connections established 1; dropped 0
Local host: 15.1.1.1, Local port: 179
Foreign host: 45.1.1.1, Foreign port: 56391
Last reset 00:00:00
```

RP/0/0/CPU0:BGPl-6#

This sample output from the **show bgp neighbor** command displays the status of permanent paths:

```
Router#show bgp neighbors 10.3.3.3
BGP neighbor is 10.3.3.3
Remote AS 30813, local AS 30813, internal link
Remote router ID 10.3.3.3
  BGP state = Established, up for 01:39:14
  Last read 00:00:58, Last read before reset 00:00:00
  Hold time is 180, keepalive interval is 60 seconds
  Configured hold time: 180, keepalive: 60, min acceptable hold time: 3
  Last write 00:00:53, attempted 2054, written 2054
  Second last write 00:00:53, attempted 45, written 45
  Last write before reset 00:00:00, attempted 0, written 0
  Second last write before reset 00:00:00, attempted 0, written 0
  Last write pulse rcvd Aug 14 07:53:56.846 last full not set pulse count 226
  Last write pulse rcvd before reset 00:00:00
  Socket not armed for io, armed for read, armed for write
  Last write thread event before reset 00:00:00, second last 00:00:00
```

```

Last KA expiry before reset 00:00:00, second last 00:00:00
Last KA error before reset 00:00:00, KA not sent 00:00:00
Last KA start before reset 00:00:00, second last 00:00:00
Precedence: internet
Multi-protocol capability received
Neighbor capabilities:          Adv          Rcvd
Route refresh:                  Yes          Yes
4-byte AS:                      Yes          Yes
Address family IPv4 Unicast:    Yes          Yes

For Address Family: IPv4 Unicast
BGP neighbor version 1111
Update group: 0.3 Filter-group: 0.5 No Refresh request being processed
NEXT_HOP is always this router
Default information originate: default sent
AF-dependent capabilities:
  Additional-paths Send: received
  Additional-paths Receive: received
Route refresh request: received 0, sent 0
Policy for incoming advertisements is PASS
Policy for outgoing advertisements is PASS
100 accepted prefixes, 100 are bestpaths
Cumulative no. of prefixes denied: 0.
Prefix advertised 5500, suppressed 0, withdrawn 0
Maximum prefixes allowed 1048576
Threshold for warning message 75%, restart interval 0 min
AIGP is enabled
An EoR was received during read-only mode
Last ack version 0, Last synced ack version 0
Outstanding version objects: current 1, max 1
Additional-paths operation: None
Advertise Permanent-Network enabled

Connections established 1; dropped 0
Local host: 10.1.1.1, Local port: 179
Foreign host: 10.3.3.3, Foreign port: 64742
Last reset 00:00:00

```

The following is sample output from the **show bgp neighbors** command displaying BGP Monitoring Protocol (BMP) information:

```

Router# show bgp neighbors 10.1.1.2

Fri Sep 15 11:38:34.470 PST

BGP neighbor is 10.1.1.2
[...]
  Precedence: internet
  BGP Monitoring(BMP) activated for servers:
    2, 3
  Multi-protocol capability not received
[...]

```

The following is sample output from the **show bgp neighbors** command displaying BGP Persistence or long lived graceful restart (LLGR) status:

```

Router# show bgp neighbors 10.3.3.3

For Address Family: VPNv4 Unicast
BGP neighbor version 0

```

```

Update group: 0.4 Filter-group: 0.0 No Refresh request being processed
Inbound soft reconfiguration allowed
Community attribute sent to this neighbor
AF-dependent capabilities:
  Graceful Restart capability advertised
    Local restart time is 120, RIB purge time is 600 seconds
    Maximum stalepath time is 120 seconds
  Long-lived Graceful Restart Capability advertised
    Advertised Long-lived Stale time 16777215 seconds
    Maximum acceptable long-lived stale time from this neighbor is 16777215
    Treat neighbor as LLGR capable
    Remaining LLGR stalepath time 16776942
Route refresh request: received 0, sent 0

```

This sample output from the **show bgp neighbor** command displays TCP MSS information for the specified neighbor:

```
Router#show bgp neighbor 10.0.0.2
```

```

BGP neighbor is 10.0.0.2
Remote AS 1, local AS 1, internal link
Remote router ID 10.0.0.2
BGP state = Established, up for 00:09:17
Last read 00:00:16, Last read before reset 00:00:00
Hold time is 180, keepalive interval is 60 seconds
Configured hold time: 180, keepalive: 60, min acceptable hold time: 3
Last write 00:00:16, attempted 19, written 19
Second last write 00:01:16, attempted 19, written 19
Last write before reset 00:00:00, attempted 0, written 0
Second last write before reset 00:00:00, attempted 0, written 0
Last write pulse rcvd Dec 7 11:58:42.411 last full not set pulse count 23
Last write pulse rcvd before reset 00:00:00
Socket not armed for io, armed for read, armed for write
Last write thread event before reset 00:00:00, second last 00:00:00
Last KA expiry before reset 00:00:00, second last 00:00:00
Last KA error before reset 00:00:00, KA not sent 00:00:00
Last KA start before reset 00:00:00, second last 00:00:00
Precedence: internet
Multi-protocol capability received
Neighbor capabilities:
Route refresh: advertised (old + new) and received (old + new)
Graceful Restart (GR Awareness): advertised and received
4-byte AS: advertised and received
Address family IPv4 Unicast: advertised and received
Received 12 messages, 0 notifications, 0 in queue
Sent 12 messages, 0 notifications, 0 in queue
Minimum time between advertisement runs is 0 secs
TCP Maximum Segment Size 500

```

```

For Address Family: IPv4 Unicast
BGP neighbor version 4
Update group: 0.2 Filter-group: 0.1 No Refresh request being processed
Route refresh request: received 0, sent 0
0 accepted prefixes, 0 are bestpaths
Cumulative no. of prefixes denied: 0.
Prefix advertised 0, suppressed 0, withdrawn 0
Maximum prefixes allowed 1048576
Threshold for warning message 75%, restart interval 0 min
AIGP is enabled
An EoR was received during read-only mode
Last ack version 4, Last synced ack version 0

```

```

Outstanding version objects: current 0, max 0
Additional-paths operation: None
Send Multicast Attributes

```

This sample output from the **show bgp neighbor** command with the **configuration** keyword displays TCP MSS configuration:

```
Router#show bgp neighbor 10.0.0.2 configuration
```

```

neighbor 10.0.0.2
remote-as 1 []
tcp-mss 400 [n:n1]
address-family IPv4 Unicast []

```

This sample output from the **show bgp neighbor** command with the **advertised-count** keyword displays the number of prefixes advertised to a specific BGP neighbor:

```
Router# show bgp neighbor 10.10.0.1 advertised-count
```

```

Mon Aug 18 11:11:00.891 UTC
No of prefixes Advertised: 5

```

This sample output from the **show bgp ipv4 unicast neighbors 10.10.10.1 dryrun-policy pass** displays path traversal statistics for the specified policy for an inbound route policy that is to be applied at the neighbor level.

```
Router# show bgp ipv4 unicast neighbors 10.10.10.1 dryrun-policy pass
```

```
Sat Oct 14 01:22:02.946 EDT
```

```
Policy Statistics
```

AFI:	IPv4 Unicast		
Direction:	Inbound		
In-use Policy:	pass		
Dry-run Policy:	pass		
Remote-as:	300		
Total Networks walked:	257		
Total Paths walked:	72257		
Dry Run elapsed time(ms):	8		

	Dry-run-Policy	In-use-Policy	Delta

Neighbor: 10.10.10.1			
Accepted Unmodified:	257	257	0
Accepted Modified:	0	0	0
Pre-inbound policy copy:	0	0	0
Denied:	0	0	0
Estimated Total Paths Memory:	26.10KB	26.10KB	0.00

This table describes the significant fields shown in the display.

Table 24: show bgp neighbors dryrun-policy Field Descriptions

Field	Description
AFI	Address family identifier.
Direction	Direction of traffic.
In-use Policy	Policy currently being used.
Dry-run Policy	Policy being tested without actual implementation.
Remote-as	Remote Autonomous System Number
Total Networks walked	Total number of networks traversed
Total Paths walked	Total number of paths traversed.
Dry Run elapsed time(ms)	Time taken for the dry run in milliseconds.
Neighbor	Neighbor for which the routing path and policy statistics are sought.
Accepted Unmodified	Number of paths accepted without modification
Accepted Modified	Number of paths accepted after modification
Pre-inbound policy copy	Number of accepted modified paths copied before applying an inbound policy.
Denied	Number of paths rejected or denied.
Estimated Total Paths Memory	Estimated memory usage for storing paths associated with the said neighbor.

```
Router# show bgp neighbor detail
```

```
Mon Aug 28 21:43:35.363 IST
```

```
BGP neighbor is 10.10.10.1
Remote AS 200, local AS 100, external link
Remote router ID 10.10.10.1
BGP state = Established, up for 00:30:44
NSR State: NSR Ready
Last read 00:00:02, Last read before reset 00:00:00
Hold time is 15, keepalive interval is 5 seconds
Configured hold time: 180, keepalive: 60, min acceptable hold time: 3
Last write 00:00:03, attempted 19, written 19
Second last write 00:00:08, attempted 19, written 19
Last write before reset 00:00:00, attempted 0, written 0
Second last write before reset 00:00:00, attempted 0, written 0
Last write pulse rcvd Aug 28 21:43:33.440 last full not set pulse count 929
Last write pulse rcvd before reset 00:00:00
Socket not armed for io, armed for read, armed for write
Last write thread event before reset 00:00:00, second last 00:00:00
Last KA expiry before reset 00:00:00, second last 00:00:00
Last KA error before reset 00:00:00, KA not sent 00:00:00
Last KA start before reset 00:00:00, second last 00:00:00
```



```

Precedence: internet
Non-stop routing is enabled
Entered Neighbor NSR TCP mode:
  TCP Initial Sync :           Aug 28 21:13:59.314
  TCP Initial Sync Phase Two :  Aug 28 21:14:00.321
  TCP Initial Sync Done :       Aug 28 21:14:01.326
Graceful restart is enabled
Restart time is 200 seconds
Stale path timeout time is 300 seconds
Enforcing first AS is enabled
Multi-protocol capability received
Neighbor capabilities:          Adv          Rcvd
  Route refresh:                Yes          Yes
  4-byte AS:                    Yes          Yes
  Address family IPv4 Unicast:  Yes          Yes
Message stats:
  InQ depth: 0, OutQ depth: 0
                                Last_Sent      Sent      Last_Rcvd      Rcvd
  Open:                         Aug 28 21:12:49.241      1      Aug 28 21:12:51.244      1
  Notification:                 ---          0      ---          0
  Update:                       Aug 28 21:12:57.318      5      Aug 28 21:12:57.326      2
  Keepalive:                    Aug 28 21:43:32.386     369      Aug 28 21:43:33.440     615
  Route_Refresh:                 ---          0      ---          0
  Total:                         375          618
Minimum time between advertisement runs is 30 secs
Inbound message logging enabled, 3 messages buffered
Outbound message logging enabled, 3 messages buffered
Event specific version bump counts:
  Interval definitions:
    Interval  Duration (min)  Start time      End time
  Live        5      Aug 28 21:42:44.370  Aug 28 21:43:35.670
  1           5      Aug 28 21:37:44.370  Aug 28 21:42:44.370
  2          15      Aug 28 21:27:44.370  Aug 28 21:42:44.370
  3          30      Aug 28 21:12:44.370  Aug 28 21:42:44.370
  Category          Total      Live  Interval 1  Interval 2  Interval
3
  Reachable          5          0          0          0
5
  Unreachable        0          0          0          0
0

For Address Family: IPv4 Unicast
BGP neighbor version 98670000062
Update group: 0.2 Filter-group: 0.2 No Refresh request being processed
AF-dependent capabilities:
  Graceful Restart capability advertised
    Local restart time is 200, RIB purge time is 600 seconds
    Maximum stalepath time is 300 seconds
  Extended Nexthop Encoding: advertised and received
Route refresh request: received 0, sent 0
Policy for incoming advertisements is pass
Policy for outgoing advertisements is pass
17 accepted prefixes, 5 are bestpaths
Accepted prefixes (modified and unmodified) high water mark : 17 (Aug 28 21:12:57.326)
Accepted prefixes modified : 0.
Accepted prefixes modified high water mark : 0 (not set)
Exact no. of prefixes denied : 0.
Denied prefixes high water mark : 0 (not set)
Cumulative no. of prefixes denied: 0.
Prefix advertised 56, suppressed 0, withdrawn 0
An EoR was received during read-only mode
Last ack version 98670000062, Last synced ack version 98670000062
Outstanding version objects: current 0, max 1, refresh 0
Additional-paths operation: None

```

show bgp neighbors

```

Advertise routes with local-label via Unicast SAFI
Slow peer flags: 18
Event specific version bump counts:
  Category                Total      Live  Interval 1  Interval 2  Interval
3  Reachable                5          0          0          0
5  Unreachable              0          0          0          0
0

Connections established 1; dropped 0
Local host: 10.10.10.2, Local port: 38803, IF Handle: 0x01004020
Foreign host: 10.10.10.1, Foreign port: 179
Last reset 00:00:00
Address-Family Ref Count:
  IPv4 Unicast: 17

BGP neighbor is 192.168.0.5
Remote AS 100, local AS 100, internal link
Remote router ID 192.168.0.5
BGP state = Established, up for 00:30:45
NSR State: NSR Ready
Last read 00:00:03, Last read before reset 00:00:00
Hold time is 15, keepalive interval is 5 seconds
Configured hold time: 180, keepalive: 60, min acceptable hold time: 3
Last write 00:00:03, attempted 19, written 19
Second last write 00:00:08, attempted 19, written 19
Last write before reset 00:00:00, attempted 0, written 0
Second last write before reset 00:00:00, attempted 0, written 0
Last write pulse rcvd Aug 28 21:43:32.665 last full not set pulse count 752
Last write pulse rcvd before reset 00:00:00
Socket not armed for io, armed for read, armed for write
Last write thread event before reset 00:00:00, second last 00:00:00
Last KA expiry before reset 00:00:00, second last 00:00:00
Last KA error before reset 00:00:00, KA not sent 00:00:00
Last KA start before reset 00:00:00, second last 00:00:00
Precedence: internet
Non-stop routing is enabled
Entered Neighbor NSR TCP mode:
  TCP Initial Sync :      Aug 28 21:13:59.314
  TCP Initial Sync Phase Two :  Aug 28 21:14:00.321
  TCP Initial Sync Done :      Aug 28 21:14:01.326
Graceful restart is enabled
Restart time is 200 seconds
Stale path timeout time is 300 seconds
Multi-protocol capability received
Neighbor capabilities:
  Adv      Rcvd
Route refresh:      Yes      Yes
4-byte AS:          Yes      Yes
Address family IPv4 Unicast:  Yes      Yes
Address family VPNv4 Unicast:  Yes      Yes
Address family IPv6 Labeled-unicast:  Yes      Yes
Address family VPNv6 Unicast:  Yes      Yes
Address family RT Constraint:  Yes      Yes
Message stats:
  InQ depth: 0, OutQ depth: 0
  Last_Sent      Sent  Last_Rcvd      Rcvd
Open:            Aug 28 21:12:48.188      1  Aug 28 21:12:50.192      1
Notification:    ---      0  ---      0
Update:          Aug 28 21:12:57.364      30  Aug 28 21:12:57.343      76
Keepalive:       Aug 28 21:43:32.463      370  Aug 28 21:43:32.417      369
Route_Refresh:   ---      0  ---      0
Total:           401      446
Minimum time between advertisement runs is 0 secs

```

Inbound message logging enabled, 3 messages buffered
 Outbound message logging enabled, 3 messages buffered
 Event specific version bump counts:

Interval definitions:					
Interval	Duration (min)	Start time	End time		
Live	5	Aug 28 21:42:44.370	Aug 28 21:43:35.670		
1	5	Aug 28 21:37:44.370	Aug 28 21:42:44.370		
2	15	Aug 28 21:27:44.370	Aug 28 21:42:44.370		
3	30	Aug 28 21:12:44.370	Aug 28 21:42:44.370		
Category	Total		Live	Interval 1	Interval 2 Interval
3 Reachable	282		0	0	0
282 Unreachable	0		0	0	0
0					

For Address Family: IPv4 Unicast
 BGP neighbor version 98670000062
 Update group: 0.3 Filter-group: 0.1 No Refresh request being processed
 AF-dependent capabilities:
 Graceful Restart capability advertised
 Local restart time is 200, RIB purge time is 600 seconds
 Maximum stalepath time is 300 seconds
 Extended Nexthop Encoding: advertised and received
 Route refresh request: received 0, sent 0
 33 accepted prefixes, 31 are bestpaths
 Accepted prefixes (modified and unmodified) high water mark : 33 (Aug 28 21:12:55.231)
 Accepted prefixes modified : 0.
 Accepted prefixes modified high water mark : 0 (not set)
 Exact no. of prefixes denied : 0.
 Denied prefixes high water mark : 0 (not set)
 Cumulative no. of prefixes denied: 0.
 Prefix advertised 30, suppressed 0, withdrawn 0
 AIGP is enabled
 An EoR was received during read-only mode
 Last ack version 98670000062, Last synced ack version 98670000062
 Outstanding version objects: current 0, max 2, refresh 0
 Additional-paths operation: None
 Send Multicast Attributes
 Advertise routes with local-label via Unicast SAFI
 Slow peer flags: 18
 Event specific version bump counts:

Category	Total	Live	Interval 1	Interval 2	Interval
3 Reachable	31	0	0	0	
31 Unreachable	0	0	0	0	
0					

For Address Family: VPNv4 Unicast
 BGP neighbor version 98670000310
 Update group: 0.2 Filter-group: 0.1 No Refresh request being processed
 AF-dependent capabilities:
 Graceful Restart capability advertised
 Local restart time is 200, RIB purge time is 600 seconds
 Maximum stalepath time is 300 seconds
 Extended Nexthop Encoding: advertised and received
 Route refresh request: received 0, sent 0
 110 accepted prefixes, 110 are bestpaths
 Accepted prefixes (modified and unmodified) high water mark : 110 (Aug 28 21:12:57.335)
 Accepted prefixes modified : 0.
 Accepted prefixes modified high water mark : 0 (not set)
 Exact no. of prefixes denied : 0.
 Denied prefixes high water mark : 0 (not set)

show bgp neighbors

```

Cumulative no. of prefixes denied: 0.
Prefix advertised 55, suppressed 0, withdrawn 0
AIGP is enabled
An EoR was received during read-only mode
Last ack version 98670000310, Last synced ack version 98670000310
Outstanding version objects: current 0, max 1, refresh 0
Additional-paths operation: None
Send Multicast Attributes
Slow peer flags: 18
Event specific version bump counts:
  Category          Total          Live  Interval 1  Interval 2  Interval
3
  Reachable          110           0           0           0
110
  Unreachable         0            0           0           0
0

```

```

For Address Family: IPv6 Labeled-unicast
BGP neighbor version 98670000062
Update group: 0.2 Filter-group: 0.2 No Refresh request being processed
AF-dependent capabilities:
  Graceful Restart capability advertised
    Local restart time is 200, RIB purge time is 600 seconds
    Maximum stalepath time is 300 seconds
Route refresh request: received 0, sent 0
33 accepted prefixes, 31 are bestpaths
Accepted prefixes (modified and unmodified) high water mark : 33 (Aug 28 21:12:55.230)
Accepted prefixes modified : 0.
Accepted prefixes modified high water mark : 0 (not set)
Exact no. of prefixes denied : 0.
Denied prefixes high water mark : 0 (not set)
Cumulative no. of prefixes denied: 0.
Prefix advertised 30, suppressed 0, withdrawn 0
AIGP is enabled
An EoR was received during read-only mode
Last ack version 98670000062, Last synced ack version 98670000062
Outstanding version objects: current 0, max 1, refresh 0
Additional-paths operation: None
Send Multicast Attributes
Slow peer flags: 18
Event specific version bump counts:
  Category          Total          Live  Interval 1  Interval 2  Interval
3
  Reachable          31           0           0           0
31
  Unreachable         0            0           0           0
0

```

```

For Address Family: VPNv6 Unicast
BGP neighbor version 98670000310
Update group: 0.2 Filter-group: 0.1 No Refresh request being processed
AF-dependent capabilities:
  Graceful Restart capability advertised
    Local restart time is 200, RIB purge time is 600 seconds
    Maximum stalepath time is 300 seconds
Route refresh request: received 0, sent 0
110 accepted prefixes, 110 are bestpaths
Accepted prefixes (modified and unmodified) high water mark : 110 (Aug 28 21:12:57.343)
Accepted prefixes modified : 0.
Accepted prefixes modified high water mark : 0 (not set)
Exact no. of prefixes denied : 0.
Denied prefixes high water mark : 0 (not set)
Cumulative no. of prefixes denied: 0.
Prefix advertised 55, suppressed 0, withdrawn 0

```

```

AIGP is enabled
An EoR was received during read-only mode
Last ack version 98670000310, Last synced ack version 98670000310
Outstanding version objects: current 0, max 1, refresh 0
Additional-paths operation: None
Send Multicast Attributes
Slow peer flags: 18
Event specific version bump counts:
  Category          Total          Live  Interval 1  Interval 2  Interval
3
  Reachable          110           0           0           0
110
  Unreachable         0           0           0           0
0

For Address Family: RT Constraint
BGP neighbor version 98670000010
Update group: 0.2 Filter-group: 0.1 No Refresh request being processed RT constraint
nbr enabled for VPN updates:
  AF-dependent capabilities:
    Graceful Restart capability advertised
    Local restart time is 200, RIB purge time is 600 seconds
    Maximum stalepath time is 300 seconds
  Route refresh request: received 0, sent 0
  10 accepted prefixes, 0 are bestpaths
  Accepted prefixes (modified and unmodified) high water mark : 10 (Aug 28 21:12:55.219)
  Accepted prefixes modified : 0.
  Accepted prefixes modified high water mark : 0 (not set)
  Exact no. of prefixes denied : 0.
  Denied prefixes high water mark : 0 (not set)
  Cumulative no. of prefixes denied: 0.
  Prefix advertised 10, suppressed 0, withdrawn 0
AIGP is enabled
An EoR was received during read-only mode
Last ack version 98670000010, Last synced ack version 98670000010
Outstanding version objects: current 0, max 1, refresh 0
Additional-paths operation: None
Send Multicast Attributes
Slow peer flags: 18
Event specific version bump counts:
  Category          Total          Live  Interval 1  Interval 2  Interval
3
  Reachable           0           0           0           0
0
  Unreachable         0           0           0           0
0

Connections established 1; dropped 0
Local host: 192.168.0.2, Local port: 24212, IF Handle: 0x00000000
Foreign host: 192.168.0.5, Foreign port: 179
Last reset 00:00:00
Address-Family Ref Count:
  IPv4 Unicast: 33
  VPNv4 Unicast: 220
  IPv6 Unicast: 33
  VPNv6 Unicast: 220
  RT Constraint: 10

BGP neighbor is 10:10:10::1
Remote AS 200, local AS 100, external link
Remote router ID 10.10.10.1
BGP state = Established, up for 00:30:45
NSR State: NSR Ready
Last read 00:00:02, Last read before reset 00:00:00

```

show bgp neighbors

```

Hold time is 15, keepalive interval is 5 seconds
Configured hold time: 180, keepalive: 60, min acceptable hold time: 3
Last write 00:00:03, attempted 19, written 19
Second last write 00:00:08, attempted 19, written 19
Last write before reset 00:00:00, attempted 0, written 0
Second last write before reset 00:00:00, attempted 0, written 0
Last write pulse rcvd Aug 28 21:43:33.434 last full not set pulse count 949
Last write pulse rcvd before reset 00:00:00
Socket not armed for io, armed for read, armed for write
Last write thread event before reset 00:00:00, second last 00:00:00
Last KA expiry before reset 00:00:00, second last 00:00:00
Last KA error before reset 00:00:00, KA not sent 00:00:00
Last KA start before reset 00:00:00, second last 00:00:00
Precedence: internet
Non-stop routing is enabled
Entered Neighbor NSR TCP mode:
  TCP Initial Sync :           Aug 28 21:13:59.314
  TCP Initial Sync Phase Two :  Aug 28 21:14:00.322
  TCP Initial Sync Done :       Aug 28 21:14:01.326
Graceful restart is enabled
Restart time is 200 seconds
Stale path timeout time is 300 seconds
Enforcing first AS is enabled
Multi-protocol capability received
Neighbor capabilities:           Adv           Rcvd
  Route refresh:                 Yes          Yes
  4-byte AS:                     Yes          Yes
  Address family IPv6 Unicast:   Yes          Yes
Message stats:
  InQ depth: 0, OutQ depth: 0
      Last_Sent           Sent   Last_Rcvd           Rcvd
Open:      Aug 28 21:12:47.832      1   Aug 28 21:12:49.848      1
Notification:  ---              0   ---                  0
Update:      Aug 28 21:12:57.326      4   Aug 28 21:12:57.329      2
Keepalive:   Aug 28 21:43:32.406     369   Aug 28 21:43:33.434     615
Route_Refresh:  ---              0   ---                  0
Total:              374              618
Minimum time between advertisement runs is 30 secs
Inbound message logging enabled, 3 messages buffered
Outbound message logging enabled, 3 messages buffered
Event specific version bump counts:
  Interval definitions:
  Interval  Duration (min)  Start time           End time
Live
1           5             Aug 28 21:42:44.370   Aug 28 21:43:35.670
2           5             Aug 28 21:37:44.370   Aug 28 21:42:44.370
3           15            Aug 28 21:27:44.370   Aug 28 21:42:44.370
4           30            Aug 28 21:12:44.370   Aug 28 21:42:44.370
Category           Total      Live   Interval 1  Interval 2  Interval
3
  Reachable              5         0         0         0
5
  Unreachable            0         0         0         0
0

For Address Family: IPv6 Unicast
BGP neighbor version 98670000062
Update group: 0.3 Filter-group: 0.1 No Refresh request being processed
Community attribute sent to this neighbor
AF-dependent capabilities:
  Graceful Restart capability advertised
    Local restart time is 200, RIB purge time is 600 seconds
    Maximum stalepath time is 300 seconds
Route refresh request: received 0, sent 0
Policy for incoming advertisements is pass

```

```

Policy for outgoing advertisements is pass
17 accepted prefixes, 5 are bestpaths
Accepted prefixes (modified and unmodified) high water mark : 17 (Aug 28 21:12:57.326)
Accepted prefixes modified : 0.
Accepted prefixes modified high water mark : 0 (not set)
Exact no. of prefixes denied : 0.
Denied prefixes high water mark : 0 (not set)
Cumulative no. of prefixes denied: 0.
Prefix advertised 56, suppressed 0, withdrawn 0
An EoR was received during read-only mode
Last ack version 98670000062, Last synced ack version 98670000062
Outstanding version objects: current 0, max 1, refresh 0
Additional-paths operation: None
Advertise routes with local-label via Unicast SAFI
Slow peer flags: 18
Event specific version bump counts:
  Category                Total      Live  Interval 1  Interval 2  Interval
3
  Reachable                5         0         0         0
5
  Unreachable              0         0         0         0
0

Connections established 1; dropped 0
Local host: 10:10:10::2, Local port: 28412, IF Handle: 0x01004020
Foreign host: 10:10:10::1, Foreign port: 179
Last reset 00:00:00
Address-Family Ref Count:
  IPv6 Unicast: 17

```

The sample output from the **show bgp neighbor** with the **detail** keyword displays the neighbor address-family slow peer configuration state and slow peer detection or processing information.

```

Router# show bgp neighbors 198.51.100.254 detail
Thu Dec 1 02:40:40.301 UTC

BGP neighbor is 198.51.100.254
Remote AS 1, local AS 1, internal link
Remote router ID 198.51.100.254
Cluster ID 209.165.201.1
  BGP state = Established, up for 04:31:32
  Previous State: Active
  Last Received Message: Update
  NSR State: None
...
For Address Family: IPv6 Labeled-unicast
  BGP neighbor version 0
  Update group: 0.2 Filter-group: 0.60 No Refresh request being processed
  Route-Reflector Client
  Inbound soft reconfiguration allowed (override route-refresh)
  AF-dependent capabilities:
    Additional-paths Send: advertised
    Additional-paths Receive: advertised
  Route refresh request: received 0, sent 0
Slow Peer State: Dynamic
  Detected state: TRUE, Detection threshold: 120
  Detection Count: 3, Recovery Count: 2
  Processing slow peer: FALSE
  Dynamic Trigger Count: 163, Dynamic Process Count: 1

```

Where:

- **Slow Peer State** indicates the effective configuration state (considering both global and neighbor address-family configuration) of neighbor address-family. Slow Peer State can be Static or Dynamic or Detection-only or None.
- **Detected State** indicates if the slow peer event is triggered for this neighbor address-family. TRUE if the neighbor address-family slow peer event is triggered, else FALSE.
- **Detection threshold** is the effective threshold configured (considering both global and neighbor address-family configuration) for the neighbor address-family. Threshold is used in determining if the peer (neighbor address-family) is slow.
- **Processing slow peer** indicates slow peer processing state of the neighbor address-family. TRUE if neighbor address-family is processed as slow peer else FALSE.

This table describes the significant fields shown in the display.

Table 25: show bgp neighbors detail Field Descriptions

Field	Description
Max Hold Time elapsed	Maximum amount of time that has passed since the last BGP keepalive message was received from a neighbor before a BGP session is considered to be down.
Max Hold Time elapsed was 6001 msec at Sep 12 17:02:36.954, crossed 40%: 2, 70%: 0	Maximum amount of time that has passed since the last BGP keepalive message was received from a neighbor before a BGP session is considered to be down. In this specific output, the fields indicate the following: <i>Max Hold Time elapsed was 6001 msec:</i> indicates that the maximum time interval between receiving keepalive messages from the neighbor was 6001 milliseconds or approximately 6 seconds. <i>at Sep 12 17:02:36.954:</i> Timestamp when this maximum hold time was observed. <i>crossed 40%: 2, 70%: 0:</i> Number of times the hold time crossed certain thresholds. The hold time crossed the 40% threshold twice and the 70% threshold zero times, suggesting that the hold time reached a significant portion of its configured value but did not exceed it by a large margin.

Field	Description
Max Hold Time elapsed before reset was 9001 msec at Sep 12 17:01:53.397, crossed 40%: 7, 70%: 2	Maximum duration between receiving BGP (Border Gateway Protocol) keepalive messages from a neighbor before the BGP session was reset. In this specific output, the fields indicate the following: <i>Max Hold Time elapsed before reset was 9001 msec:</i> Maximum time interval between receiving keepalive messages from the neighbor before the BGP session reset was 9001 milliseconds or approximately 9 seconds. <i>at Sep 12 17:01:53.397:</i> Timestamp when this maximum hold time before reset was observed. <i>crossed 40%: 7, 70%: 2:</i> Number of times the hold time crossed certain thresholds. The hold time crossed the 40% threshold seven times and the 70% threshold two times, suggesting that the hold time frequently approached significant portions of its configured maximum value before the BGP session reset
First message received at Sep 12 16:45:00.973, sent at Sep 12 16:45:00.975	Timestamp when the first message from a BGP neighbor was received by the local router. In this specific output, the fields indicate the following: <i>First message received at Sep 12 16:45:00.973:</i> First message from the BGP neighbor was received at 16:45:00 on September 12th <i>sent at Sep 12 16:45:00.975:</i> Timestamp when the corresponding message was sent by the BGP neighbor, which was nearly simultaneously, just 0.002 seconds later.
First message before reset received at Sep 12 16:42:16.573, sent at Sep 12 16:42:16.574	Timestamp when the first message from a BGP neighbor was received by the local router before a reset occurred. In this specific output, the fields indicate the following: <i>First message before reset received at Sep 12 16:42:16.573:</i> first message from the BGP neighbor was received at 16:42:16 on September 12th, before a reset occurred. <i>sent at Sep 12 16:42:16.574:</i> Timestamp when the corresponding message was sent by the BGP neighbor, which was nearly simultaneous, just 0.001 seconds later.
Max read throttled duration was 6769 msec starting at Sep 12 16:45:01.487, max InQ 1000 processed 930	Maximum duration during which the read process was throttled, indicating a restriction or limitation on the rate of reading data. In this specific output, the fields indicate the following: <i>Max read throttled duration was 6769 msec:</i> Maximum duration of throttling for reading data was 6769 milliseconds (approximately 6.769 seconds). <i>starting at Sep 12 16:45:01.487:</i> Timestamp when this maximum throttling duration started, which was at 16:45:01 on September 12th. <i>max InQ 1000 processed 930:</i> Maximum input queue (InQ) size was 1000, and during the throttled duration, 930 items were processed.

Field	Description
Start Time	Timestamp when the read throttle period started.
Dry Run elapsed time(ms)	Time taken for the dry run in milliseconds.
Duration	Duration of the throttle period in milliseconds, indicating how long the read process was restricted or limited.
Max InQ	Maximum size of the input queue during the throttle period. The input queue typically holds incoming data packets waiting to be processed.
Messages	Number of messages or data packets processed during the throttle period.
Max read throttled duration before reset was 5013 msec starting at Sep 12 16:42:17.079, max InQ 76 processed 0	Maximum duration of a read throttle period on the network device. In this specific output, the fields indicate the following: <i>Max read throttled duration before reset:</i> Maximum duration of the read throttle period, which was 5013 milliseconds or approximately 5.013 seconds. <i>Starting at Sep 12 16:42:17.079:</i> Timestamp when the read throttle period started, which was at 16:42:17 on September 12th <i>Max InQ 76 processed 0:</i> The segment <i>Max InQ 76</i> indicates that the maximum size of the input queue during the throttle period was 76. The segment <i>processed 0</i> indicates that no messages or data packets were processed during this throttle period.
Max write throttled duration was 685 msec starting at Sep 12 16:45:08.486, max OutQ 1501 queued 57	Maximum duration of the write throttle period, which was 685 milliseconds. In this specific output, the fields indicate the following: <i>Max write throttled duration:</i> Maximum duration of the write throttle period, which was 685 milliseconds. <i>Starting at Sep 12 16:45:08.486:</i> Timestamp when the write throttle period started, which was September 12th at 16:45:08.486. <i>Max OutQ:</i> Maximum size of the output queue during the throttle period. In this case, it was 1501, which typically holds data packets waiting to be transmitted. <i>Queued:</i> Number of items queued in the output queue during the throttle period. In this case, it was 57.

Field	Description
Max write throttled duration before reset was 205 msec starting at Sep 12 16:42:21.849, max OutQ 1003 queued 1	Maximum duration of a write throttle period on a network device before a reset occurred. In this specific output, the fields indicate the following: <i>Max write throttled duration before reset:</i> Maximum duration of the write throttle period before a reset occurred, which was 205 milliseconds. <i>Starting at Sep 12 16:42:21.849:</i> Timestamp when the write throttle period started, which was on September 12th at 16:42:21.849. <i>Max OutQ:</i> Maximum size of the output queue during the throttle period. In this case, it was 1003, indicating the maximum number of items that were waiting to be transmitted. <i>Queued:</i> Number of items queued in the output queue during the throttle period. In this case, it was 1.
Start Time:	Timestamp when the write throttle period started.
Duration	Duration of the write throttle period in milliseconds.
Max OutQ	Maximum size of the output queue during the throttle period. The output queue typically holds data packets waiting to be transmitted.
Messages	Number of messages or data packets transmitted during the throttle period.

The show output given below provides a history of memory changes recorded for a threshold greater than 1.0% of the memory limit (rlimit). It provides a detailed record of memory usage, network information, and related metrics over time. The last line in the show output indicates the current memory utilization. It enables you in monitoring memory usage trends, identifying potential issues or abnormalities.

Router# **show bgp memory history**

History of memory changes recorded for a threshold greater than 1.0% of rlimit.

Last shown record displays current values.

Network information for default VRF.

Time Attributes	Memory (MB)	Rlimit (%)	Memory diff (MB)	Networks	Paths	PathElems
Oct 2 16:30:37 9	152	1	152	400	400	400
Oct 2 16:31:37 725	343	4	191	396952	396869	396952
Oct 2 16:32:37 8408	425	5	81	524567	513979	524567
Oct 2 16:42:38 10753	741	9	316	1178605	1241533	1178604

```

Oct  2 16:43:38    985        12        243          1778234    1859254    1778234
11214

Oct  2 19:42:39    901        11        -84          1800688    678607    1800688
10911

Oct  2 19:45:39    766         9       -136          1332259    688784    1332259
10943

```

This table describes the significant fields shown in the display.

Table 26: show bgp neighbors dryrun-policy Field Descriptions

Field	Description
Time	Timestamp when the memory changes were recorded.
Memory(MB)	Amount of memory used in megabytes (MB) at the specified time
Rlimit(%):	Percentage of the memory limit (rlimit) utilized at the specified time.
Memory diff(MB)	Difference in memory usage compared to the previous record, in megabytes (MB)
Networks	Number of networks at the specified time.
Paths	Number of paths at the specified time.
PathElems	Number of path elements at the specified time.
Attributes	Number of attributes at the specified time

This sample output from the **show bgp neighbor** command shows that the router is configured to send a default LLGR stale time to its BGP neighbors, that the default stale time being advertised is 172800 seconds, and that the router accepts any LLGR stale time value provided by the peer without imposing its own threshold.

```

Router(config)# show bgp neighbor 192.0.2.254
...
AF-dependent capabilities:
  Long-lived Graceful Restart Capability advertised
    Advertised Long-lived Stale time 172800 seconds
  Long-lived Graceful Restart Stale Time Send Default is ON
  Default advertised long-lived stale time is 172800 seconds
  Long-lived Graceful Restart Stale Time Accept Any is ON
  Maximum acceptable long-lived stale time from this neighbor is 16777215
  Long-lived Graceful Restart Capability received
    Received long-lived stale time is 172800 seconds
    Neighbor preserved the forwarding state during latest restart
...

```

This table describes the significant fields shown in the display.

Table 27: show bgp neighbors Field Descriptions

Field	Description
Long-lived Graceful Restart Stale Time Send Default is ON	Indicates that the router is configured to send a default value for the LLGR stale time to its BGP neighbors. The default stale time is used when the router advertises its LLGR capability.
Default advertised long-lived stale time is 172800 seconds	Specifies the default LLGR stale time value that the router advertises to its BGP neighbors. In this case, the default stale time is set to 172800 seconds, which is equivalent to 2 days.
Long-lived Graceful Restart Stale Time Accept Any is ON	Indicates that the router is configured to accept any LLGR stale time value provided by its BGP neighbors. The router does not impose its own threshold for the stale time and accepts the value sent by the peer.

show bgp neighbors nsr

To display Border Gateway Protocol (BGP) nonstop routing (NSR) information across neighbors, use the **show bgp neighbors nsr** command in EXEC mode and XR EXEC mode.

show bgp [**ipv4** {**unicast** | **multicast** | **all**} | **ipv6** {**unicast** | **multicast** | **all**} | **vpn4** **unicast** | **vpn6** **unicast** | **vrf** {**allvrf_name**}] **neighbors nsr** [**standby**]

Syntax Description		
ipv4	(Optional)	Specifies IP Version 4 address prefixes.
ipv6	(Optional)	Specifies IP Version 6 address prefixes.
unicast	(Optional)	Specifies unicast address prefixes.
multicast	(Optional)	Specifies multicast address prefixes.
all	(Optional)	For address family, specifies prefixes for all address families.
vpn4 unicast	(Optional)	Specifies VPNv4 unicast address families.
vpn6 unicast	(Optional)	Specifies VPNv6 unicast address families.
vrf	(Optional)	Specifies VPN routing and forwarding (VRF) instance.
<i>vrf_name</i>	(Optional)	Name of a VRF.
all	(Optional)	For VRF, specifies all VRFs.
standby	(Optional)	Displays information about the standby card.

Command Default No default behavior or values.

Command Modes EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Examples

The following is sample output from the **show bgp neighbors nsr** command with the **standby** keyword:

```
Router# show bgp neighbors nsr standby
```

```
BGP neighbor is 2.2.2.2
  BGP state = Established, up for 5d04h
  NSR state = NSR Ready
  Outstanding Postits: 0
```

```
BGP neighbor is 10.0.101.5
  BGP state = Established, up for 05:19:00
  NSR state = NSR Ready
```

```
Outstanding Postits: 0
```

```
BGP neighbor is 10.1.0.5  
  BGP state = Established, up for 5d04h  
  NSR state = NSR Ready  
  Outstanding Postits: 0
```

This table describes the significant fields shown in the display.

Table 28: show bgp neighbors nsr Field Descriptions

Field	Description
BGP state	Displays BGP neighbor peering state.
NSR state	Displays BGP neighbor NSR state.
Outstanding Postits	Displays the postit counters of pending events.

show bgp nexthops

To display statistical information about the Border Gateway Protocol (BGP) next hops, use the **show bgp nexthops** command in EXEC mode and XR EXEC mode.

show bgp nexthops **A.B.C.D.aigp-value**[**statistics**] [**speaker** *speaker-id*] [**standby**]

Syntax Description	
ipv4	(Optional) Specifies IP Version 4 address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
labeled-unicast	(Optional) Specifies labeled-unicast address prefixes.
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.
tunnel	(Optional) Specifies tunnel address prefixes.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
all	(Optional) For address family, specifies prefixes for all address families.
vpn4 unicast	(Optional) Specifies VPNv4 unicast address families.
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
<i>vrf-name</i>	(Optional) Name of a VRF.
all	(Optional) For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.
statistics	(Optional) Specifies nexthop statistics.
speaker <i>speaker-id</i>	(Optional) Specifies a speaker process ID.
A.B.C.D	Next hop to display information about
aigp-value	Displays next hop statistics
Command Default	No default behavior or value
Command Modes	EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.
	Release 24.1.1	This command was modified. The following modifications were made: • The interval definitions fields: Interval, Duration (min), Start time, End time were added to the output of show bgp nexthops statistics command. • The counters fields: Next Hop, Reachable, Unreachable, MetricIncrease, and MetricDecrease were added to the output of show bgp nexthops command.

Usage Guidelines

The **show bgp nexthops** command displays statistical information about next-hop notifications, the time spent processing the notifications, and details about each next-hop that has been registered with the Routing Information Base (RIB).

Use the **vrf vrf-name** keyword and argument to display only the next-hops present in the specified VPN routing and forwarding (VRF) instance.

The next-hop information is displayed for all active speaker processes in distributed mode. Each speaker displays a set of next-hops that belongs to the prefixes received by the speaker and next hops that belong to best paths that were received by other speaker processes. Use the **speaker speaker-id** keyword and argument to display information for only the specified speaker process. The distributed mode must be defined using the **distributed speaker** command for the **speaker** keyword to be available.

Examples

The following is sample output from the **show bgp nexthops** command with the VRF specified:

```
Router# show bgp vrf all nexthops

Fri Mar 13 17:05:40.656 UTC

VRF: 900
=====

Total Nexthop Processing
  Time Spent: 0.000 secs

Maximum Nexthop Processing
  Received: 82y48w
  Bestpaths Deleted: 0
  Bestpaths Changed: 0
  Time Spent: 0.000 secs

Last Notification Processing
  Received: 1d22h
  Time Spent: 0.000 secs

IPv4 Unicast is active

Gateway Address Family: IPv4 Unicast
Table ID: 0xe0000001
Nexthop Count: 2
Critical Trigger Delay: 0msec
Non-critical Trigger Delay: 10000msec
```

show bgp nexthops

Nexthop Version: 1, RIB version: 1

Status codes: R/UR Reachable/Unreachable
 C/NC Connected/Not-connected
 L/NL Local/Non-local
 I Invalid (Policy Match Failed)

Next Hop	Status	Metric	Notf	LastRIBEvent	RefCount
10.0.101.201	[UR]	4294967295	0/0	1d22h (Reg)	0/3
90.0.0.2	[R][C][NL]	0	1/0	1d22h (Cri)	20/23

VRF: 901
 =====

Total Nexthop Processing
 Time Spent: 0.000 secs

Maximum Nexthop Processing
 Received: 82y48w
 Bestpaths Deleted: 0
 Bestpaths Changed: 0
 Time Spent: 0.000 secs

Last Notification Processing
 Received: 1d22h
 Time Spent: 0.000 secs

IPv4 Unicast is active

Gateway Address Family: IPv4 Unicast
 Table ID: 0xe0000002
 Nexthop Count: 2
 Critical Trigger Delay: 0msec
 Non-critical Trigger Delay: 10000msec

Nexthop Version: 1, RIB version: 1

Status codes: R/UR Reachable/Unreachable
 C/NC Connected/Not-connected
 L/NL Local/Non-local
 I Invalid (Policy Match Failed)

Next Hop	Status	Metric	Notf	LastRIBEvent	RefCount
10.0.101.201	[UR]	4294967295	0/0	1d22h (Reg)	0/3
91.0.0.2	[R][C][NL]	0	1/0	1d22h (Cri)	10/13

VRF: 902
 =====

Total Nexthop Processing
 Time Spent: 0.000 secs

Maximum Nexthop Processing
 Received: 82y48w
 Bestpaths Deleted: 0
 Bestpaths Changed: 0
 Time Spent: 0.000 secs

Last Notification Processing
 Received: 1d22h
 Time Spent: 0.000 secs

IPv4 Unicast is active

Gateway Address Family: IPv4 Unicast
 Table ID: 0xe0000003
 Nexthop Count: 2
 Critical Trigger Delay: 0msec
 Non-critical Trigger Delay: 10000msec

Nexthop Version: 1, RIB version: 1

Status codes: R/UR Reachable/Unreachable
 C/NC Connected/Not-connected
 L/NL Local/Non-local

Next Hop	Status	Metric	Notf	LastRIBEvent	RefCount
10.0.101.201	[UR]	4294967295	0/0	1d22h (Reg)	0/3
92.0.0.2	[R][C][NL]	0	1/0	1d22h (Cri)	10/13

VRF: 903
 =====

Total Nexthop Processing
 Time Spent: 0.000 secs

Maximum Nexthop Processing
 Received: 82y48w
 Bestpaths Deleted: 0
 Bestpaths Changed: 0
 Time Spent: 0.000 secs

Last Notification Processing
 Received: 1d22h
 Time Spent: 0.000 secs

IPv4 Unicast is active

Gateway Address Family: IPv4 Unicast
 Table ID: 0xe0000004
 Nexthop Count: 2
 Critical Trigger Delay: 0msec
 Non-critical Trigger Delay: 10000msec

Nexthop Version: 1, RIB version: 1

Status codes: R/UR Reachable/Unreachable
 C/NC Connected/Not-connected
 L/NL Local/Non-local

Next Hop	Status	Metric	Notf	LastRIBEvent	RefCount
10.0.101.201	[UR]	4294967295	0/0	1d22h (Reg)	0/3
93.0.0.2	[R][C][NL]	0	1/0	1d22h (Cri)	10/13

VRF: 904
 =====

Total Nexthop Processing
 Time Spent: 0.000 secs

Maximum Nexthop Processing
 Received: 82y48w
 Bestpaths Deleted: 0
 Bestpaths Changed: 0
 Time Spent: 0.000 secs

Last Notification Processing

Received: 1d22h

Time Spent: 0.000 secs

IPv4 Unicast is active

Gateway Address Family: IPv4 Unicast

Table ID: 0xe0000005

Nexthop Count: 2

Critical Trigger Delay: 0msec

Non-critical Trigger Delay: 10000msec

Nexthop Version: 1, RIB version: 1

Status codes: R/UR Reachable/Unreachable

C/NC Connected/Not-connected

L/NL Local/Non-local

I Invalid (Policy Match Failed)

Next Hop	Status	Metric	Notf	LastRIBEvent	RefCount
10.0.101.201	[UR]	4294967295	0/0	1d22h (Reg)	0/3
94.0.0.2	[R][C][NL]	0	1/0	1d22h (Cri)	10/13

VRF: 905

=====

Total Nexthop Processing

Time Spent: 0.000 secs

Maximum Nexthop Processing

Received: 82y48w

Bestpaths Deleted: 0

Bestpaths Changed: 0

Time Spent: 0.000 secs

Last Notification Processing

Received: 1d22h

Time Spent: 0.000 secs

IPv4 Unicast is active

Gateway Address Family: IPv4 Unicast

Table ID: 0xe0000006

Nexthop Count: 2

Critical Trigger Delay: 0msec

Non-critical Trigger Delay: 10000msec

Nexthop Version: 1, RIB version: 1

Status codes: R/UR Reachable/Unreachable

C/NC Connected/Not-connected

L/NL Local/Non-local

I Invalid (Policy Match Failed)

Next Hop	Status	Metric	Notf	LastRIBEvent	RefCount
10.0.101.201	[UR]	4294967295	0/0	1d22h (Reg)	0/3
95.0.0.2	[R][C][NL]	0	1/0	1d22h (Cri)	10/13

VRF: 906

=====

Total Nexthop Processing

Time Spent: 0.000 secs

Maximum Nexthop Processing

Received: 82y48w
 Bestpaths Deleted: 0
 Bestpaths Changed: 0
 Time Spent: 0.000 secs

Last Notification Processing

Received: 1d22h
 Time Spent: 0.000 secs

IPv4 Unicast is active

Gateway Address Family: IPv4 Unicast
 Table ID: 0xe0000007
 Nexthop Count: 2
 Critical Trigger Delay: 0msec
 Non-critical Trigger Delay: 10000msec

Nexthop Version: 1, RIB version: 1

Status codes: R/UR Reachable/Unreachable
 C/NC Connected/Not-connected
 L/NL Local/Non-local

I Invalid (Policy Match Failed)

Next Hop	Status	Metric	Notf	LastRIBEvent	RefCount
10.0.101.201	[UR]	4294967295	0/0	1d22h (Reg)	0/3
96.0.0.2	[R][C][NL]	0	1/0	1d22h (Cri)	10/13

VRF: 907

=====

Total Nexthop Processing

Time Spent: 0.000 secs

Maximum Nexthop Processing

Received: 82y48w
 Bestpaths Deleted: 0
 Bestpaths Changed: 0
 Time Spent: 0.000 secs

Last Notification Processing

Received: 1d22h
 Time Spent: 0.000 secs

IPv4 Unicast is active

Gateway Address Family: IPv4 Unicast
 Table ID: 0xe0000008
 Nexthop Count: 2
 Critical Trigger Delay: 0msec
 Non-critical Trigger Delay: 10000msec

Nexthop Version: 1, RIB version: 1

Status codes: R/UR Reachable/Unreachable
 C/NC Connected/Not-connected
 L/NL Local/Non-local

I Invalid (Policy Match Failed)

Next Hop	Status	Metric	Notf	LastRIBEvent	RefCount
10.0.101.201	[UR]	4294967295	0/0	1d22h (Reg)	0/3
97.0.0.2	[R][C][NL]	0	1/0	1d22h (Cri)	10/13

show bgp nexthops

VRF: 908

=====

Total Nexthop Processing
Time Spent: 0.000 secs

Maximum Nexthop Processing
Received: 82y48w
Bestpaths Deleted: 0
Bestpaths Changed: 0
Time Spent: 0.000 secs

Last Notification Processing
Received: 1d22h
Time Spent: 0.000 secs

IPv4 Unicast is active

Gateway Address Family: IPv4 Unicast
Table ID: 0xe0000009
Nexthop Count: 2
Critical Trigger Delay: 0msec
Non-critical Trigger Delay: 10000msec

Nexthop Version: 1, RIB version: 1

Status codes: R/UR Reachable/Unreachable
C/NC Connected/Not-connected
L/NL Local/Non-local
I Invalid (Policy Match Failed)

Next Hop	Status	Metric	Notf	LastRIBEvent	RefCount
10.0.101.201	[UR]	4294967295	0/0	1d22h (Reg)	0/3
98.0.0.2	[R][C][NL]	0	1/0	1d22h (Cri)	10/13

VRF: 909

=====

Total Nexthop Processing
Time Spent: 0.000 secs

Maximum Nexthop Processing
Received: 82y48w
Bestpaths Deleted: 0
Bestpaths Changed: 0
Time Spent: 0.000 secs

Last Notification Processing
Received: 1d22h
Time Spent: 0.000 secs

IPv4 Unicast is active

Gateway Address Family: IPv4 Unicast
Table ID: 0xe000000a
Nexthop Count: 1
Critical Trigger Delay: 0msec
Non-critical Trigger Delay: 10000msec

Nexthop Version: 1, RIB version: 1

Status codes: R/UR Reachable/Unreachable
C/NC Connected/Not-connected

```

          L/NL Local/Non-local
          I      Invalid (Policy Match Failed)
Next Hop      Status      Metric      Notf      LastRIBEvent RefCount
99.0.0.2      [UR]        4294967295      0/0      1d22h (Reg)      0/3

```

```

VRF: yellow
=====

```

```

Total Nexthop Processing
  Time Spent: 0.000 secs

```

```

Maximum Nexthop Processing
  Received: 82y48w
  Bestpaths Deleted: 0
  Bestpaths Changed: 0
  Time Spent: 0.000 secs

```

```

Last Notification Processing
  Received: 82y48w
  Time Spent: 0.000 secs

```

```

IPv4 Unicast is active

```

```

Gateway Address Family: IPv4 Unicast
Table ID: 0xe000000e
Nexthop Count: 0
Critical Trigger Delay: 0msec
Non-critical Trigger Delay: 10000msec

```

```

Nexthop Version: 1, RIB version: 1

```

This table describes the significant fields shown in the display.

Table 29: show bgp vrf all nexthops Field Descriptions

Field	Description
VRF	Name of the VRF.
Total Nexthop Processing Time Spent	Time spent processing trigger delays for critical and noncritical events for the VRF or address family. The time is specified in seconds.
Maximum Nexthop Processing	Time that has passed since the nexthop notification was received that resulted in spending the maximum amount of processing time for all notifications.
Last Notification Processing	Time that has passed since the last nexthop notification was received.
IPv4 Unicast is active.	VRF specified output that indicates the IPv4 unicast address family is active within the VRF.
Nexthop Count	Number of next hops for the VRF or address family.
Critical Trigger Delay	Configured critical trigger delay.
Non-critical Trigger Delay	Configured noncritical trigger delay.

Field	Description
Total Critical Notifications Received	Number of critical notifications received.
Total Non-critical Notifications Received	Number of noncritical notifications received.
Bestpaths Deleted After Last Walk	Number of best paths deleted due to the last notification.
Bestpaths Changed After Last Walk	Number of best paths modified due to the last notification.
Next Hop	IP address of the next hop.
Status	Status of the next hop.
Metric	IGP metric of the next hop.
Notf	Number of critical and noncritical notifications received.
LastRIBEvent	When the last notification was received from the RIB.
RefCount	The number of neighbors or prefixes that refer to the next hop in address family/all format.
Address Family	Name of the address family.

The following is sample output from the **show bgp ipv4 unicast nexthops** command:

```
Router# show bgp ipv4 unicast nexthops
Fri Aug 4 18:28:02.428 IST
Total Nexthop Processing
  Time Spent: 0.009 secs

Maximum Nexthop Processing
  Received: 03:11:51
  Bestpaths Deleted: 0
  Bestpaths Changed: 110
  Time Spent: 0.001 secs

Last Notification Processing
  Received: 03:10:27
  Time Spent: 0.000 secs

Gateway Address Family: IPv4 Unicast
Table ID: 0xe0000000
Gateway Reference Count: 30
Gateway AF Bits : 0x991
Nexthop Count: 5
Critical Trigger Delay: 3000msec
Non-critical Trigger Delay: 10000msec

Nexthop Version: 3, RIB version: 3
EPE Table Version: 1, EPE Label version: 1
EPE Downloaded Version: 1, EPE Standby Version: 1

Status codes: R/UR Reachable/Unreachable
               C/NC Connected/Not-connected
               L/NL Local/Non-local
               PR Pending Registration
```



```

I      Invalid (Policy drop)
Next Hop      Status      Metric      Tbl-ID      Notf      LastRIBEvent      RefCount
0.0.0.0
10.10.10.1    [R] [C] [NL]          0    e0000000    1/0    06:54:58 (Cri)      17/20
192.0.2.1     [R] [NC] [NL]         2    e0000000    0/0    06:54:14 (Reg)       5/7
198.51.100.254 [R] [NC] [NL]         3    e0000000    0/3    04:10:07 (Non)     12/246
192.168.0.5   [R] [NC] [NL]         2    e0000000    1/1    06:54:21 (Non)     16/270

```

Counters

```

Next Hop      Reachable      Unreachable      MetricIncrease      MetricDecrease
0.0.0.0
10.10.10.1    1              0                0                  0
192.0.2.1     2              1                0                  0
198.51.100.254 1              0                1                  2
192.168.0.5   1              0                0                  0

```

This table describes the significant fields shown in the display.

Table 30: show bgp ipv4 unicast nexthops Field Descriptions

Field	Description
VRF	Name of the VRF.
Total Nexthop Processing Time Spent	Time spent processing trigger delays for critical and noncritical events for the VRF or address family. The time is specified in seconds.
Maximum Nexthop Processing	Time that has passed since the nexthop notification was received that resulted in spending the maximum amount of processing time for all notifications.
Last Notification Processing	Time that has passed since the last nexthop notification was received.
IPv4 Unicast is active.	VRF specified output that indicates the IPv4 unicast address family is active within the VRF.
Nexthop Count	Number of next hops for the VRF or address family.
Critical Trigger Delay	Configured critical trigger delay.
Non-critical Trigger Delay	Configured noncritical trigger delay.
Total Critical Notifications Received	Number of critical notifications received.
Total Non-critical Notifications Received	Number of noncritical notifications received.
Bestpaths Deleted After Last Walk	Number of best paths deleted due to the last notification.
Bestpaths Changed After Last Walk	Number of best paths modified due to the last notification.
Next Hop	IP address of the next hop.
Status	Status of the next hop.
Metric	IGP metric of the next hop.

Field	Description
Notf	Number of critical and noncritical notifications received.
LastRIBEvent	When the last notification was received from the RIB.
RefCount	The number of neighbors or prefixes that refer to the next hop in address family/all format.
Address Family	Name of the address family.
Counters	Number of times each next hop has been encountered.
Next Hop	IP addresses of the next hops.
Reachable	Number of times the next hop was reachable
Unreachable	Number of times the next hop was unreachable
MetricIncrease	Number of times the metric for reaching the next hop increased.
MetricDecrease	Number of times the metric decreased.

The following is sample output from the **show bgp ipv4 unicast nexthops statistics** command:

```
Router# show bgp ipv4 unicast nexthops statistics
```

```
Fri Aug 11 19:15:07.720 IST
```

```
Total Nexthop Processing
```

```
Time Spent: 0.000 secs
```

```
Maximum Nexthop Processing
```

```
Received: 00:00:00
```

```
Bestpaths Deleted: 0
```

```
Bestpaths Changed: 0
```

```
Time Spent: 0.000 secs
```

```
Last Notification Processing
```

```
Received: 00:05:09
```

```
Time Spent: 0.000 secs
```

```
Gateway Address Family: IPv4 Unicast
```

```
Table ID: 0xe0000000
```

```
Gateway Reference Count: 30
```

```
Gateway AF Bits : 0x991
```

```
Nexthop Count: 5
```

```
Critical Trigger Delay: 3000msec
```

```
Non-critical Trigger Delay: 10000msec
```

```
Nexthop Version: 5, RIB version: 5
```

```
EPE Table Version: 1, EPE Label version: 1
```

```
EPE Downloaded Version: 1, EPE Standby Version: 1
```

```
Total Critical Notifications Received: 2
```

```
Total Non-critical Notifications Received: 0
```

```
Bestpaths Deleted After Last Walk: 0
```

```
Bestpaths Changed After Last Walk: 0
```

```
Nexthop register:
```

```
Sync calls: 3, last sync call: 00:05:00
```

```
Async calls: 2, last async call: 00:05:10
```

```
Nexthop unregister:
```

```
Async calls: 1, last async call: 00:04:12
```

```

Nexthop batch finish:
  Calls: 7, last finish call: 00:04:11

Nexthop flush timer:
  Times started: 29, last time flush timer started: 00:04:12

Nexthop pending registration list count: 0 (peak at 0)

RIB update: 13 rib update runs, last update: 00:05:00
            2 prefixes installed, 0 modified, 0 removed

Interval definitions:

```

Interval	Duration (min)	Start time	End time
Live		Sep 11 16:34:07.690	Sep 11 16:35:06.492
Interval1	5	Sep 11 16:29:07.690	Sep 11 16:34:07.690
Interval2	15	Sep 11 16:19:07.690	Sep 11 16:34:07.690
Interval3	30	Sep 11 15:49:07.664	Sep 11 16:19:07.664

Event Type	Total	Live	Interval1
Interval2	Interval3		
Reachable	12	0	0
0	12		
Unreachable	1	0	0
0	1		
Metric Increase	6	3	3
3	0		
Metric Decrease	3	0	3
3	0		

This table describes the significant fields shown in the display.

Table 31: show bgp ipv4 unicast nexthops statistics Field Descriptions

Field	Description
Interval	Name or identifier of the time interval.
Duration (min)	Duration of each interval in minutes. It specifies the length of time for which data is collected and analyzed within each interval.
Start time	Timestamp indicating the beginning of each interval.
End time	Timestamp indicating the end of each interval.
Live	Current time interval that is actively ongoing. This interval is occurring in real time, representing the present moment.
Interval1, Interval2, Interval3	Predefined time intervals for monitoring or observation. Each interval has a specified duration, start time, and end time. These intervals allow for structured monitoring of data or events over specific time periods.
Event Type	Type of event being recorded.
Total	Total number of occurrences for each event type.
Live	Current count of events of each type.

Field	Description
Reachable	Number of events where the nexthop device was reachable during the specified intervals.
Unreachable	Number of events where the nexthop device was unreachable during the specified intervals.
Metric Increase	Number of events where a metric, such as response time, latency, or errors, increased compared to the previous interval.
Metric Decrease	Number of events where a metric decreased compared to the previous interval.

show bgp nsr

To display Border Gateway Protocol (BGP) nonstop routing (NSR) information, use the **show bgp nsr** command in EXEC mode and XR EXEC mode.

```
show bgp [ ipv4 { unicast | multicast | labeled-unicast | all | tunnel | mdt } | ipv6 { unicast
| multicast | all | labeled-unicast } | all { unicast | multicast | all | labeled-unicast | tunnel } | vpnv4
unicast | vrf { vrf-name | all } [ ipv4 { unicast | labeled-unicast } | ipv6 unicast ] | vpnv6
unicast ] nsr [standby]
```

Syntax Description		
ipv4	(Optional) Specifies IP Version 4 address prefixes.	
unicast	(Optional) Specifies unicast address prefixes.	
multicast	(Optional) Specifies multicast address prefixes.	
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.	
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.	
tunnel	(Optional) Specifies tunnel address prefixes.	
mdt	(Optional) Specifies multicast distribution tree (MDT) address prefixes.	
multicast	(Optional) Specifies multicast address prefixes.	
ipv6	(Optional) Specifies IP Version 6 address prefixes.	
all	(Optional) For address family, specifies prefixes for all address families.	
vpnv4 unicast	(Optional) Specifies VPNv4 unicast address families.	
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.	
<i>vrf-name</i>	(Optional) Name of a VRF.	
all	(Optional) For VRF, specifies all VRFs.	
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.	
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.	
vpnv6 unicast	(Optional) Specifies VPNv6 unicast address families.	
standby	Displays information about the standby card.	

Command Default If no address family or subaddress family is specified, the default address family and subaddress family specified using the **set default-afi** and **set default-safi** commands are used.

Command Modes EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.
	Release 7.3.6	The output of this command was modified. The NPL Packet Processing Statistics fields were added.

Examples

The following is sample output from the **show bgp nsr** command:

```
Router# show bgp nsr

Fri Jan 30 10:18:48.171 PST PDT

BGP Process Information:
BGP is operating in STANDALONE mode
Autonomous System: 100
Router ID: 10.1.0.1 (manually configured)
Default Cluster ID: 10.1.0.1
Active Cluster IDs: 10.1.0.1
Fast external fallover enabled
Neighbor logging is not enabled
Enforce first AS enabled
AS Path ignore is enabled
AS Path multipath-relax is enabled
Default local preference: 100
Default keepalive: 60
Graceful restart enabled
Restart time: 180
Stale path timeout time: 360
RIB purge timeout time: 600
Non-stop routing is enabled
Update delay: 120
Generic scan interval: 60

Address family: IPv4 Unicast
Dampening is not enabled
Client reflection is enabled in global config
Scan interval: 60
Main Table Version: 7034
IGP notification: IGP notified
RIB has converged: version 1

===== Post Failover Summary for Active instance =====

Node                Process                Read      Write      Inbound

node0_0_CPU0        Speaker                146.75    18.90      3.46

Entered mode Standby Ready                : Jan 30 10:00:39
Entered mode TCP NSR Setup                : Jan 30 10:00:39
Entered mode TCP NSR Setup Done           : Jan 30 10:00:39
Entered mode TCP Initial Sync             : Jan 30 10:00:39
Entered mode TCP Initial Sync Done        : Jan 30 10:00:44
Entered mode FPBSN processing done        : Jan 30 10:00:44
Entered mode Update processing done       : Jan 30 10:00:44
Entered mode BGP Initial Sync             : Jan 30 10:00:44
Entered mode BGP Initial Sync done        : Jan 30 10:00:44
Entered mode NSR Ready                    : Jan 30 10:00:44
```

Current BGP NSR state - NSR Ready achieved at: Jan 30 10:00:44
 NSR State READY notified to Redcon at: Jan 30 10:16:58

NSR Post Failover Summary:

QAD Statistics:

Messages Sent	: 512	ACKs Received	: 512
Messages Received	: 8	ACKs Sent	: 8
Send Failures	: 1	Send ACK Failures	: 0
Suspends	: 1	Resumes	: 1
Messages Processed	: 8	Out of sequence drops	: 0

Postit Summary:

Total pending postit messages: 0
 Neighbors with pending postits: 0

Conv	Bestpath	TunnelUpd	Import	RIBUpd	Label	ReadWrite	LastUpd
Process: Speaker							
Yes	120	---	---	120	120	120	87531

Rib Trigger: enabled
 Last RIB down event Jan 29 09:50:03.069 received
 Last RIB convergence Jan 29 09:50:03.069 last ack received.

Address Family IPv4 Unicast converged in 87531 seconds

The following example shows sample output from the **show bgp nsr** command with the **standby** keyword:

Router# **show bgp nsr standby**

Fri Jan 30 10:18:55.654 PST PDT

BGP Process Information:
 BGP is operating in STANDALONE mode
 Autonomous System: 100
 Router ID: 10.1.0.1 (manually configured)
 Default Cluster ID: 10.1.0.1
 Active Cluster IDs: 10.1.0.1
 Fast external fallover enabled
 Neighbor logging is not enabled
 Enforce first AS enabled
 AS Path ignore is enabled
 AS Path multipath-relax is enabled
 Default local preference: 100
 Default keepalive: 60
 Graceful restart enabled
 Restart time: 180
 Stale path timeout time: 360
 RIB purge timeout time: 600
 Non-stop routing is enabled
 Update delay: 120
 Generic scan interval: 60

Address family: IPv4 Unicast
 Dampening is not enabled

```

Client reflection is enabled in global config
Scan interval: 60
Main Table Version: 7034
IGP notification: IGP notified
RIB has converged: version 1

```

```

===== Post Failover Summary for Standby instance =====

```

Node	Process	Read	Write	Inbound
node0_1_CPU0	Speaker	1.68	0.00	1.42

```

Entered mode Standby Ready      : Jan 30 10:00:39
Entered mode TCP Replication    : Jan 30 10:00:39
Entered mode TCP Init Sync Done : Jan 30 10:00:44
Entered mode NSR Ready          : Jan 30 10:00:44

```

QAD Statistics:

Messages Sent	: 9	ACKs Received	: 9	
Messages Received	: 512	ACKs Sent	: 512	
Send Failures	: 0	Send ACK Failures	: 0	
Suspends	: 0	Resumes	: 0	
Messages Processed	: 512	Standby init drops	: 0	Out of sequence
drops: 0				

Postit Summary:

```

Total pending postit messages: 0
Neighbors with pending postits: 0

```

Conv	Bestpath	TunnelUpd	Import	RIBUpd	Label	ReadWrite	LastUpd
Process: Speaker							

```

Yes 1233338444 --- --- 1233338444 1233338444 1233338444 ---

```

```

Rib Trigger: enabled
Last RIB down event Jan 29 09:50:17.308 received
Last RIB convergence Jan 29 09:50:17.308 last ack received.

```

NPL Packet Processing Statistics:

Interval (sec)	End-Time	Avg Proc time(us)	Num of pkts [start - end]	seq num
30	Aug 22 23:08:11.142	140	2 [74 - 75]	
60	Aug 22 23:08:11.142	233	4 [72 - 75]	
180	Aug 22 23:08:11.142	426	22 [54 - 75]	

This table describes the significant fields shown in the display.

Table 32: show bgp summary nsr standby Field Descriptions

Field	Description
NPL Packet Processing Statistics	Metrics and data related to the processing of network packets.

Field	Description
Interval (sec)	Timestamp indicating when the statistics were last collected.
End-Time	Timestamp indicating when the statistics were last collected.
Avg Proc time (us)	Average processing time in microseconds for each NSR packet during the specified interval.
Num of pkts:	Number of packets processed during the specified interval.
seq num [start - end]	Sequence number range of the packets processed during the specified interval.

Related Commands

Command	Description
nsr (BGP)	Activates Border Gateway Protocol (BGP) nonstop routing (NSR).

show bgp paths

To display all the Border Gateway Protocol (BGP) paths in the database, use the **show bgp paths** command in EXEC mode and XR EXEC mode.

show bgp paths [**detail**] [**debug**] [**regex** *regular-expression*]

Syntax Description	detail	(Optional) Displays detailed attribute information.
	debug	(Optional) Displays attribute process ID, hash bucket, and hash chain ID attribute information.
	regex <i>regular-expression</i>	(Optional) Specifies an autonomous system path that matches the regular expression.

Command Default No default behavior or values

Command Modes EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines Use the **show bgp paths** command to display information about AS paths and the associated attributes with which the paths were received.

If no options are specified, all stored AS paths are displayed with the number of routes using each path.



Note The AS path information is stored independently of the address family, making it possible that routes from different address families could be using the same path.

Use the *regular-expression* argument to limit the output to only those paths that match the specified regular expression. See the for information on regular expressions.

Use the **detail** keyword to display detailed information on the attributes stored with the AS path.

Examples

The following is sample output from the **show bgp paths** command:

```
Router# show bgp paths detail
```

Proc	Attributes	Refcount	Metric	Path
Spk 0	ORG AS LOCAL	7	0	i
Spk 0	ORG AS LOCAL COMM EXTCOMM	3	0	21 i
Spk 0	MET ORG AS	3	55	2 i
Spk 0	ORG AS	3	0	2 10 11 i
Spk 0	ORG AS COMM	3	0	2 10 11 i
Spk 0	MET ORG AS ATOM	3	2	2 3 4 ?
Spk 0	MET ORG AS	3	1	2 3 4 e

Spk 0 MET ORG AS

3

0 2 3 4 i

This table describes the significant fields shown in the display.

Table 33: show bgp paths Field Descriptions

Field	Description
Proc	ID of the process in which the path is stored. This is always “Spk 0.”
Attributes	Attributes that are present. The following may appear: MET—Multi Exit Discriminator (MED) attribute is present. ORG—Origin attribute is present. AS—AS path attribute is present. LOCAL—Local preference attribute is present. AGG—Aggregator attribute is present. COMM—Communities attribute is present. ATOM—Atomic aggregate attribute is present. EXTCOMM—Extended communities attribute is present.
NeighborAS	Autonomous system number of the neighbor, or 0, if the path information originated locally. • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535.
Refcount	Number of routes using a path.
Metric	Value of the interautonomous system metric, otherwise known as the MED metric.
Path	Autonomous system path to the destination network. At the end of the path is the origin code for the path: i—Path originated from an Interior Gateway Protocol (IGP) and was advertised with a network or aggregate-address command. e—Path originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.

show bgp policy

To display information about Border Gateway Protocol (BGP) advertisements under a proposed policy, use the **show bgp policy** command in EXEC mode and XR EXEC mode.

show bgp policy

Syntax	Description
ipv4	(Optional) Specifies IP Version 4 address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.
tunnel	(Optional) Specifies tunnel address prefixes.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
all	(Optional) For address family, specifies prefixes for all address families.
vpn4 unicast	(Optional) Specifies VPNv4 unicast address families.
rd <i>rd-address</i>	(Optional) Displays routes with a specific route distinguisher.
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
<i>vrf-name</i>	(Optional) Name of a VRF.
all	(Optional) For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.
neighbor	(Optional) Previews advertisements for a single neighbor.
<i>ip-address</i>	(Optional) IP address of a single neighbor.
sent-advertisements	(Optional) Displays the routes that have been advertised to neighbors. If a route has not yet been advertised to the neighbor, it is not shown.
route-policy	(Optional) Displays advertisements for an output route policy.
<i>route-policy-name</i>	(Optional) Name of the route policy.
summary	(Optional) Displays a summary of the BGP advertisements.

Command Default

Advertisements for all neighbors are displayed if the **neighbor** *ip-address* keyword and argument are not specified. If no address family or subaddress family is specified, the default address family and subaddress family specified using the **set default-afi** and **set default-safi** commands are used.

Command Modes

EXEC mode and XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines**Note**

The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

BGP contains a separate routing table for each configured address family and subaddress family combination. The address family and subaddress family options specify the routing table to be examined. If the **all** keyword is specified for the address family or subaddress family, each matching routing table is examined in turn.

Use the **show bgp policy** command to display routes that would be advertised to neighbors under a proposed policy. Unlike in the **show bgp advertised** command, the information displayed reflects any modifications made to the routes when executing the specified policy.

Use the **neighbor** keyword to limit the output to routes advertised to a particular neighbor. Use the **sent-advertisements** keyword to change the output in two ways:

- If a policy is not specified explicitly, any policy configured on the neighbor (using the **route-policy (BGP)** command) is executed before displaying the routes.
- Only routes that have already been advertised to the neighbor (and not withdrawn) are displayed. Routes that have not yet been advertised are not displayed.

Use the **summary** keyword to display abbreviated output.

**Warning**

Include the **neighbor ip-address** option in the **show bgp policy** command for any AFI/SAFI to prevent a high CPU utilization that results in the performance degradation of BGP functions due to:

- a higher prefix scale,
- a higher neighbor scale, or
- a higher combination scale of prefixes and neighbors.

Examples

The following is sample output from the **show bgp policy** command with the **summary** keyword in EXEC mode and XR EXEC mode:

```
Router# show bgp policy summary
```

Network	Next Hop	From	Advertised to
172.16.1.0/24	10.0.101.1	10.0.101.1	10.0.101.2 10.0.101.3
172.17.0.0/16	0.0.0.0	Local	10.0.101.1 10.0.101.2 10.0.101.3

This table describes the significant fields shown in the display.

Table 34: show bgp policy summary Field Descriptions

Field	Description
Network	IP prefix and prefix length for a network.
Next Hop	IP address of the next system that is used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network.
From	IP address of the peer that advertised this route.
Local	Indicates the route originated on the local system.
Local Aggregate	Indicates the route is an aggregate created on the local system.
Advertised to	Indicates the neighbors to which this route was advertised.

The following is sample output from the **show bgp policy** command in EXEC mode and XR EXEC mode:

```
Router# show bgp policy
```

```
11.0.0.0/24 is advertised to 10.4.101.1
  Path info:
    neighbor: Local          neighbor router id: 10.4.0.1
    valid local best
  Attributes after inbound policy was applied:
    next hop: 0.0.0.0
    MET ORG AS
    origin: IGP metric: 0
    aspath:
  Attributes after outbound policy was applied:
    next hop: 10.4.0.1
    MET ORG AS
    origin: IGP metric: 0
    aspath: 1

11.0.0.0/24 is advertised to 10.4.101.2
  Path info:
    neighbor: Local          neighbor router id: 10.4.0.1
    valid local best
```

```
Attributes after inbound policy was applied:
  next hop: 0.0.0.0
  MET ORG AS
  origin: IGP metric: 0
  aspath:
Attributes after outbound policy was applied:
  next hop: 10.4.0.1
  MET ORG AS
  origin: IGP metric: 0
  aspath:

11.0.0.0/24 is advertised to 10.4.101.3
Path info:
  neighbor: Local          neighbor router id: 10.4.0.1
  valid local best
Attributes after inbound policy was applied:
  next hop: 0.0.0.0
  MET ORG AS
  origin: IGP metric: 0
  aspath:
Attributes after outbound policy was applied:
  next hop: 10.4.0.1
  MET ORG AS
  origin: IGP metric: 0
  aspath:

12.0.0.0/24 is advertised to 10.4.101.2
Path info:
  neighbor: 10.4.101.1     neighbor router id: 10.4.101.1
  valid external best
Attributes after inbound policy was applied:
  next hop: 10.4.101.1
  ORG AS
  origin: IGP neighbor as: 2
  aspath: 2 3 4
Attributes after outbound policy was applied:
  next hop: 10.4.101.1
  ORG AS
  origin: IGP neighbor as: 2
  aspath:2 3 4

12.0.0.0/24 is advertised to 10.4.101.3
Path info:
  neighbor: 10.4.101.1     neighbor router id: 10.4.101.1
  valid external best
Attributes after inbound policy was applied:
  next hop: 10.4.101.1
  ORG AS
  origin: IGP neighbor as: 2
  aspath: 2 3 4
Attributes after outbound policy was applied:
  next hop: 10.4.101.1
  ORG AS
  origin: IGP neighbor as: 2
  aspath:2 3 4
```

This table describes the significant fields shown in the display.

Table 35: show bgp policy Field Descriptions

Field	Description
Is advertised to	IP address of the peer to which this route is advertised. If the route is advertised to multiple peers, information is shown separately for each peer.
neighbor	IP address of the peer that advertised this route, or one of the following: Local—Route originated on the local system. Local Aggregate—Route is an aggregate created on the local system.
neighbor router id	BGP identifier for the peer, or the local system if the route originated on the local system.
Not advertised to any peer	Indicates the no-advertise well-known community is associated with this route. Routes with this community are not advertised to any BGP peers.
Not advertised to any EBGp peer	Indicates the no-export well-known community is associated with this route. Routes with this community are not advertised to external BGP peers, even if those peers are in the same confederation as the local router.
Not advertised outside the local AS	Indicates the local-AS well-known community is associated with this route. Routes with this community value are not advertised outside the local autonomous system or confederation boundary.
(Received from a RR-client)	Path was received from a route reflector client.
(received-only)	Path is not used for routing purposes. It is used to support soft reconfiguration, and records the path attributes before inbound policy was applied to a path received from a peer. A path marked “received-only” indicates that either the path was dropped by inbound policy, or that a copy of path information was created and then modified for routing use.
(received & used)	Indicates that the path is used both for soft reconfiguration and routing purposes. A path marked “(received & used)”, implies the path information was not modified by inbound policy.
valid	Path is valid.
redistributed	Path is locally sourced through redistribution.
aggregated	Path is locally sourced through aggregation.
local	Path is locally sourced through the network command.
confed	Path was received from a confederation peer.
best	Path is selected as best.
multipath	Path is one of multiple paths selected for load-sharing purposes.

Field	Description
dampinfo	Indicates dampening information: Penalty—Current penalty for this path. Flapped—Number of times the route has flapped. In—Time (hours:minutes:seconds) since the network first flapped. Reuse in—Time (hours:minutes:seconds) after which the path is available. This field is displayed only if the path is currently suppressed.
Attributes after inbound policy was applied	Displays attributes associated with the received route, after any inbound policy has been applied. AGG—Aggregator attribute is present. AS—AS path attribute is present. ATOM—Atomic aggregate attribute is present. COMM—Communities attribute is present. EXTCOMM—Extended communities attribute is present. LOCAL—Local preference attribute is present. MET—Multi Exit Discriminator (MED) attribute is present. next hop—IP address of the next system used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network. ORG—Origin attribute is present.
origin	Origin of the path: IGP—Path originated from an Interior Gateway Protocol (IGP) and was sourced by BGP using a network or aggregate-address command. EGP—Path originated from an Exterior Gateway Protocol. incomplete—Origin of the path is not clear; in example, a route that is redistributed into BGP from an IGP.
neighbor as	First autonomous system (AS) number in the AS path.
aggregator	Indicates that the path was received with the aggregator attribute. The AS number and router-id of the system that performed the aggregation are shown.
metric	Value of the interautonomous system metric, otherwise known as the MED metric.
localpref	Local preference value. This is used to determine the preferred exit point from the local autonomous system. It is propagated throughout the local autonomous system.
aspath	AS path associated with the route.

Field	Description
community	Community attributes associated with the path. Community values are displayed in AA:NN format, except for the following well-known communities: Local-AS—Community with value 4294967043 or hex 0xFFFFFFFF03. Routes with this community value are not advertised outside the local autonomous system or confederation boundary. no-advertise—Community with value 4294967042 or hex 0xFFFFFFFF02. Routes with this community value are not advertised to any BGP peers. no-export—Community with value 4294967041 or hex 0xFFFFFFFF01. Routes with this community are not advertised to external BGP peers, even if those peers are in the same confederation as the local router.
Extended community	Extended community attributes associated with the path. For known extended community types, the following codes may be displayed: RT—Route target community SoO—Site of Origin community LB—Link Bandwidth community
Originator	Router ID of the originating router when route reflection is used.
Cluster lists	Router ID or cluster ID of all route reflectors through which the route has passed.
Attributes after outbound policy was applied	Displays attributes associated with the received route, after any outbound policy has been applied. AGG—Aggregator attribute is present. AS—AS path attribute is present. ATOM—Atomic aggregate attribute is present. COMM—Communities attribute is present. EXTCOMM—Extended communities attribute is present. LOCAL—Local preference attribute is present. MET—Multi Exit Discriminator (MED) attribute is present. next hop—IP address of the next system used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network. ORG—Origin attribute is present.

show bgp process

To display Border Gateway Protocol (BGP) process information, use the **show bgp process** command in EXEC mode and XR EXEC mode.

```
show bgp [ ipv4 | { unicast | multicast | labeled-unicast | all | tunnel | mdt } | ipv6 | { unicast |
multicast | all | labeled-unicast } | all | { unicast | multicast | all | labeled-unicast | mdt | tunnel } |
vpnv4 unicast | vpnv6 unicast ] process [ performance-statistics ] [ detail ] [ standby ]
```

Syntax Description	ipv4 (Optional) Specifies IP Version 4. unicast (Optional) Specifies the unicast subaddress family. multicast (Optional) Specifies the multicast subaddress family. labeled-unicast (Optional) Specifies labeled unicast address prefixes. all (Optional) For subaddress families, specifies prefixes for all subaddress families. tunnel (Optional) Specifies tunnel address prefixes. ipv6 (Optional) Specifies IP Version 6. all (Optional) For address family, specifies prefixes for all address families. vpnv4 unicast (Optional) Specifies VPNv4 unicast address families. performance- statistics (Optional) Displays performance statistics relative to the work done by the specified process. detail (Optional) Specifies detailed process information.						
Command Default	If no address family or subaddress family is specified, the default address family and subaddress family specified using the set default-afi and set default-safi commands are used.						
Command Modes	EXEC mode and XR EXEC mode						
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 24.1.1</td><td> The show outputs of the following commands are modified to capture changes related to the per-vrf-46 label mode: • show bgp ipv4 unicast process • show bgp ipv6 unicast process • show bgp vpnv4 unicast process • show bgp vpnv6 unicast process </td></tr> <tr> <td>Release 7.5.3</td><td>Updated output to display the delay of the BGP start-up process since the last router update.</td></tr> </table>	Release	Modification	Release 24.1.1	The show outputs of the following commands are modified to capture changes related to the per-vrf-46 label mode: • show bgp ipv4 unicast process • show bgp ipv6 unicast process • show bgp vpnv4 unicast process • show bgp vpnv6 unicast process	Release 7.5.3	Updated output to display the delay of the BGP start-up process since the last router update.
Release	Modification						
Release 24.1.1	The show outputs of the following commands are modified to capture changes related to the per-vrf-46 label mode: • show bgp ipv4 unicast process • show bgp ipv6 unicast process • show bgp vpnv4 unicast process • show bgp vpnv6 unicast process						
Release 7.5.3	Updated output to display the delay of the BGP start-up process since the last router update.						

Release	Modification

Release 7.0.12	This command was introduced.

Usage Guidelines



Note The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

Use the **show bgp process** command to display status and summary information for the Border Gateway Protocol (BGP) process. The output shows various global and address family-specific BGP configurations. A summary of the number of neighbors, update messages, and notification messages sent and received by the process is also displayed.

Use the **detail** keyword to display detailed process information. The detailed process information shows the memory used by each of various internal structure types.

Use the **performance-statistics** keyword to display a summary or detail of work done by the BGP processes. The summary display shows the real time spent performing certain operations and the time stamps for state transitions during initial convergence.

Examples

The following is sample output from the **show bgp process** command:

```
Router# show bgp process

BGP Process Information
BGP is operating in STANDALONE mode
Autonomous System: 1
Router ID: 10.0.0.5 (manually configured)
Cluster ID: 10.0.0.5
Fast external fallover enabled
Neighbor logging is enabled
Enforce first AS enabled
Default local preference: 100
Default keepalive: 60
Update delay: 120
Generic scan interval: 60

Address family: IPv4 Unicast
Dampening is enabled
Client reflection is enabled
Scan interval: 60
Main Table Version: 150
IGP notification: IGP notified

Node          Process      Nbrs Estab Rst Upd-Rcvd Upd-Sent Nfn-Rcvd Nfn-Sent
node0_0_CPU0 Speaker        3      2   1      20      10         0         0
```

This table describes the significant fields shown in the display.

Table 36: show bgp process Field Descriptions

Field	Description
BGP is operating in	Indicates BGP is operating in standalone mode. This is the only supported mode.
Autonomous System	Autonomous system number for the local system. • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535.
Router ID	BGP identifier assigned to the local system. If this is explicitly configured using the bgp router-id command, “manually configured” is displayed. If the router ID is not manually configured, it is determined from a global router ID. If no global ID is available, the router ID is shown as 0.0.0.0.
Confederation ID	Confederation identifier for the local system.
Cluster ID	Cluster identifier for the local system. If this is manually configured using the bgp cluster-id command, “manually configured” is displayed.
Default metric	Default metric. This is controlled by the default-metric command.
Fast external fallover enabled	Indicates whether fast external fallover is enabled. This is controlled by the bgp fast-external-fallover disable command.
Neighbor logging enabled	Indicates whether logging of peer connection up and down transitions is enabled. This is controlled by the bgp log neighbor changes disable command.
Enforce first AS enabled	Indicates that strict checking of the first AS number in paths received from external BGP peers is enabled. This is controlled by the bgp enforce-first-as disable command.
iBGP to IGP redistribution	Indicates internal redistribution is enabled using the bgp redistribution-internal command.
Treating missing MED as worst	Indicates missing Multi Exit Discriminator (MED) metric values are treated as worst in the route selection algorithm. This is controlled by the bgp bestpath med missing-as-worst command.
Always compare MED is enabled	Indicates that the MED is always used during the route selection algorithm, even when paths are received from external BGP neighbors in different autonomous systems. This is controlled by the bgp bestpath med always command.

Field	Description
AS Path ignore is enabled	Indicates that the AS path length is ignored by the route selection algorithm. This is controlled by the bgp bestpath as-path ignore command.
Comparing MED from confederation peers	Indicates that the MED values are used in the route selection algorithm when comparing routes received from confederation peers. This is controlled by the bgp bestpath med confed command.
Comparing router ID for eBGP paths	Indicates that the router ID is used as a tiebreaker by the route selection algorithm when comparing identical routes received from different external BGP neighbors. This is controlled by the bgp bestpath compare-routerid command.
Default local preference	Default local preference value used for BGP routes. This is controlled by the bgp default local-preference command.
Default keepalive	Default keepalive interval. This is controlled by the timers bgp command.
Graceful restart enabled	Indicates that the graceful restart capability is enabled. The configuration commands affecting graceful restart behavior are: • bgp graceful-restart • bgp graceful-restart purge-time • bgp graceful-restart stalepath-time • bgp graceful-restart restart-time • bgp graceful-restart graceful-reset
Update delay	Maximum time that a BGP process stays in read-only mode.
Generic scan interval	Interval (in seconds) between BGP scans for address family-independent tasks. This is controlled by the bgp scan-time command.
Dampening	Indicates whether dampening is enabled for the specified address family. This is controlled by the dampening command.
Client reflection	Indicates whether client-to-client route reflection is enabled for the specified address family. This is controlled by the bgp client-to-client reflection disable command.
Scan interval	Interval (in seconds) between BGP scans for the given address family. This is controlled by the bgp scan-time command in address family configuration mode.
Main Table Version	Last version of the BGP database that was installed into the main routing table.
IGP notification	Indicates whether Interior Gateway Protocols (IGP) have been notified of BGP convergence for the specified address family.
Node	Node on which the process is executing.

Field	Description
Process	Type of BGP process.
Speaker	Speaker process. A speaker process is responsible for receiving, processing, and sending BGP messages to configured neighbors.
Nbrs	Number of neighbors for which the process is responsible.
Estab	Number of neighbors that have connections in the established state for this process.
Rst	Number of times this process was restarted.
Upd-Rcvd	Number of update messages received by the process.
Upd-Sent	Number of update messages sent by the process.
Nfn-Rcvd	Number of notification messages received by the process.
Nfn-Sent	Number of notification messages sent by the process.

The following is sample output from the **show bgp process** command with the Graceful Maintenance feature enabled:

```
RP/0/0/CPU0:R1#show bgp process
```

```
...
```

```
Graceful Maintenance active. Retaining routes in RIB during BGP shutdown
```

```
...
```

Or

```
Graceful Maintenance active for all neighbors. Retaining routes in RIB during BGP shutdown
```

```
*****
```

```
RP/0/0/CPU0:Jan 28 22:01:36.356 : bgp[1056]: %ROUTING-BGP-5-ADJCHANGE : neighbor 10.10.10.4
Up (VRF: default) (AS: 4) WARNING: Graceful Maintenance is Active
```

The following is sample output from the **show bgp process** command with the **detail** keyword:

```
Router# show bgp all all process detail
```

```
BGP Process Information
BGP is operating in STANDALONE mode
Autonomous System: 1
Router ID: 10.0.0.5 (manually configured)
Cluster ID: 10.0.0.5
Fast external fallover enabled
Neighbor logging is enabled
Enforce first AS enabled
Default local preference: 100
Default keepalive: 60
Update delay: 120
Generic scan interval: 60
```

```
BGP Speaker process: 0, location node0_0_0
Neighbors: 3, established: 2
```

Sent

Received

show bgp process

```

Updates:                3                15
Notifications:          0                0

                               Number      Memory Used
Attributes:             12             1104
AS Paths:                10             400
Communities:             2             1080
Extended communities:    1             40
Route Reflector Entries: 0              0
Route-map Cache Entries: 0              0
Filter-list Cache Entries: 0            0
Next Hop Cache Entries:  2             80
Update messages queued:  0

Address family: IPv4 Unicast
Dampening is enabled
Client reflection is enabled
Main Table Version: 12
IGP notification: IGP notified

State: normal mode.
BGP Table Version: 12
Network Entries: 15, Soft Reconfig Entries: 0
Dampened Paths: 0, History Paths: 9

                               Allocated    Freed
Prefixes:                     15            0
Paths:                         19            0

                               Number      Memory Used
Prefixes:                     15             1230
Paths:                        19             760

```

This table describes the significant fields shown in the display.

Table 37: show bgp process detail Field Descriptions

Field	Description
BGP is operating in	Indicates whether BGP is operating in standalone mode.
Autonomous System	Autonomous system number for the local system.
Router ID	BGP identifier assigned to the local system. If this is explicitly configured using the bgp router-id command, “manually configured” is displayed. If the router ID is not manually configured, it is determined from a global router ID. If the global ID is not available, the router ID is shown as 0.0.0.0.
Confederation ID	Confederation identifier for the local system.
Cluster ID	Cluster identifier for the local system. If this is manually configured using the bgp cluster-id command, “manually configured” is displayed.
Default metric	Default metric.
Fast external fallover enabled	Indicates whether fast external fallover is enabled.
Neighbor logging enabled	Indicates whether logging of peer connection up and down transitions is enabled.

Field	Description
Enforce first AS enabled	Indicates that strict checking of the first autonomous system (AS) number in paths received from external BGP peers is enabled.
iBGP to IGP redistribution	Indicates internal redistribution is enabled using the bgp redistribution-internal command.
Treating missing MED as worst	Indicates missing MED metric values are treated as worst in the route selection algorithm. This is controlled by the bgp bestpath med missing-as-worst command.
Always compare MED is enabled	Indicates that the MED is always used during the route selection algorithm, even when paths are received from external BGP neighbors in different autonomous systems. This is controlled by the bgp bestpath med always command.
AS Path ignore is enabled	Indicates that the AS path length is ignored by the route selection algorithm. This is controlled by the bgp bestpath as-path ignore command.
Comparing MED from confederation peers	Indicates that the MED values are used in the route selection algorithm when comparing routes received from confederation peers. This is controlled by the bgp bestpath med confed command.
Comparing router ID for eBGP paths	Indicates that the router ID is used as a tiebreaker by the route selection algorithm when comparing identical routes received from different external BGP neighbors. This is controlled by the bgp bestpath compare-routerid command.
Default local preference	Default local preference value used for BGP routes.
Default keepalive	Default keepalive interval. This is controlled by the timers bgp command.
Graceful restart enabled	Indicates that the graceful restart capability is enabled. The configuration commands affecting graceful restart behavior are: • bgp graceful-restart • bgp graceful-restart purge-time • bgp graceful-restart stalepath-time • bgp graceful-restart restart-time • bgp graceful-restart graceful-reset
Update delay	Maximum time that a BGP process stays in read-only mode.
Generic scan interval	Interval (in seconds) between BGP scans for address family-independent tasks. This is controlled by the bgp scan-time command.
BGP Speaker Process	Speaker process responsible for receiving, processing and sending BGP messages.
Node	Node on which the specified process is executing.

Field	Description
Neighbors	Number of neighbors for which the specified process is responsible.
established	Number of neighbors that have connections in the established state for the specified process.
Updates	Number of update messages sent and received by the specified process.
Notifications	Number of notification messages sent and received by the specified process.
Attributes	Number of unique sets of attribute information stored in the specified process and the amount of memory used by the attribute information.
AS Paths	Number of unique autonomous system paths stored in the specified process and the amount of memory used by the AS path information.
Communities	Number of unique sets of community information stored in the specified process and the amount of memory used by them.
Extended communities	Number of unique sets of extended community information stored in the specified process and the amount of memory used by them.
Route Reflector Entries	Number of unique sets of route reflector information stored in the specified process and the amount of memory used by them.
Nexthop Entries	Number of entries and memory usage for cached next- hop information.
Update messages queued	Total number of update messages queued to be sent across all neighbors for which the specified process is responsible.
Address family	Specified address family.
Dampening	Indicates whether dampening is enabled for the specified address family.
Client reflection	Indicates whether client-to-client route reflection is enabled for the specified address family. This is controlled by the bgp client-to-client reflection disable command.
Scan interval	Interval (in seconds) between BGP scans for the given address family. This is controlled by the bgp scan-time command.
Main Table Version	Last version of the local BGP database for the specified address family that was injected into the main routing table.
IGP notification	Indicates whether IGP has been notified of BGP convergence for the specified address family.
RIB has converged	Indicates whether the main routing table version has converged and the version at which it converged.

Field	Description
State	BGP system state for the specified address family and process. This may be one of the following: read-only mode—Initial set of updates is being recovered. In this mode, route selection is not performed, routes are not installed in the global RIB, and updates are not advertised to peers. best-path calculation mode—Route selection is being performed for the routes that were received while in read-only mode. import mode—Routes are imported from one VRF to another VRF once the best paths are calculated. This mode is supported in VPNv4 unicast address family mode. RIB update mode—Routes that were selected in best-path calculation mode are being installed in the global RIB. label allocation mode: Labels are allocated for the received prefixes based on the requirement. normal mode—Best paths are sent to the peers for routes that exist in the RIB. The route selection, import processing, RIB updates, and label allocation are performed as new updates are received.
BGP Table Version	Last version used in the BGP database for received routes.
Attribute download	Indicates whether the RIB attribute download is enabled.
Network Entries	Number of sets of prefix information held in the specified BGP process for the specified address family.
Soft Reconfig Entries	Number of sets of prefix information that are present only for the purpose of supporting soft reconfiguration.
Dampened Paths	Number of routes that are suppressed due to dampening for the specified address family.
History Paths	Number of routes that are currently withdrawn, but are being maintained to preserve dampening information.
Prefixes (Allocated/Freed)	Number of sets of prefix information for the specified address family that have been allocated and freed during the lifetime of the process.
Paths (Allocated/Freed)	Number of sets of route information for the specified address family that have been allocated and freed during the lifetime of the process.
Prefixes (Number/Memory Used)	Number of sets of prefix information currently allocated for the specified address family, and the amount of memory used by them.
Paths (Number/Memory Used)	Number of sets of route information currently allocated for the specified address family, and the amount of memory used by them.

The following is sample output of version-rate information from the **show bgp process** command with the **performance-statistics** keyword:

```

Router# show bgp process detail performance-statistics | begin Event specific version bump
counts
Fri Sep  8 08:15:18.337 PDT
Event specific version bump counts:
Interval definitions:
Interval  Duration (min)  Start time          End time
Live      5 Sep  8 08:14:53.664  Sep  8 08:15:18.650
1         5 Sep  8 08:09:53.664  Sep  8 08:14:53.664
2        15 Sep  8 08:09:53.663  ---
3        30 Sep  8 08:09:53.663  ---

Category                                Total      Live  Interval 1  Interval 2  Interval
3
Reachable                                0         0         0         0
0
Unreachable                              0         0         0         0
0
Import                                  0         0         0         0
0
Redistribute                             0         0         0         0
0
Label                                   0         0         0         0
0
Nexthop                                 0         0         0         0
0
Other                                   0         0         0         0
0
Main table ver bumps                     197        0         0         0
0

```

This table describes the significant fields shown in the display.

Table 38: show bgp process performance-statistics Field Descriptions

Field	Description
BGP is operating in	Indicates whether BGP is operating in standalone mode.
Autonomous system	Autonomous system number for the local system.
Router ID	BGP identifier assigned to the local system. If this is explicitly configured using the bgp router-id command, “manually configured” is displayed. If the router ID is not manually configured, it is determined from a global router ID. If the global ID is not available, the router ID is shown as 0.0.0.0.
Confederation ID	Confederation identifier for the local system.
Cluster ID	The cluster identifier for the local system. If this is manually configured using the bgp cluster-id command, “manually configured” is displayed.
Default metric	Default metric.
Fast external fallover enabled	Indicates whether fast external fallover is enabled.
Neighbor logging enabled	Indicates whether logging of peer connection up and down transitions is enabled. This is controlled by the bgp log neighbor changes disable command.
Enforce first AS enabled	Indicates that strict checking of the first AS number in paths received from external BGP peers is enabled.

Field	Description
iBGP to IGP redistribution	Indicates internal redistribution is enabled using the bgp redistribution-internal command.
Treating missing MED as worst	Indicates missing MED metric values are treated as worst in the route selection algorithm. This is controlled using the bgp bestpath med missing-as-worst command.
Always compare MED is enabled	Indicates that the MED is always used during the route selection algorithm, even when paths are received from external BGP neighbors in different autonomous systems. This setting is controlled by the bgp bestpath med always command.
AS Path ignore is enabled	Indicates that the AS path length is ignored by the route selection algorithm. This is controlled by the bgp bestpath as-path ignore command.
Comparing MED from confederation peers	Indicates that the MED values are used in the route selection algorithm when comparing routes received from confederation peers. This is controlled by the bgp bestpath med confed command.
Comparing router ID for eBGP paths	Indicates that the router ID is used as a tiebreaker by the route selection algorithm when comparing identical routes received from different external BGP neighbors. This is controlled by the bgp bestpath compare-routerid command.
Default local preference	Default local preference value used for BGP routes.
Default keepalive	Default keepalive interval. This setting is controlled by the timers bgp command.
Graceful restart enabled	Indicates that the graceful restart capability is enabled. The configuration commands affecting graceful restart behavior are: bgp graceful-restart , bgp graceful-restart purge-time , bgp graceful-restart stalepath-time , bgp graceful-restart restart-time , and bgp graceful-restart graceful-reset .
Update delay	Maximum time that a BGP process stays in read-only mode.
Generic scan interval	Interval (in seconds) between BGP scans for address family-independent tasks. This setting is controlled by the bgp scan-time command in router configuration mode.
Address family	Specified address family.
Dampening	Indicates whether dampening is enabled for the specified address family.
Client reflection	Indicates whether client-to-client route reflection is enabled for the specified address family. This is controlled by the bgp client-to-client reflection disable command.
Scan interval	Interval (in seconds) between BGP scans for the given address family. This is controlled by the bgp scan-time command.

Field	Description
Main Table Version	Last version of the local BGP database for the specified address family that was injected into the main routing table.
IGP notification	Indicates whether IGP has been notified of BGP convergence for the specified address family.
Node	Node on which the process is executing.
Process	BGP process.
Speaker	Speaker process. The speaker process is responsible for receiving, processing and sending BGP messages.
Read	Real time (in seconds) spent reading messages from peers by this process.
Write	Real time (in seconds) spent writing messages to peers by this process.
Inbound	The real time (in seconds) spent processing messages read from peers by this process.
Config	Real time (in seconds) spent processing configuration commands by this process.
Data	Real time (in seconds) spent providing operational data by this process.
Conv	Indicates whether the process has converged after the initial update.
Nbr Estab	Time stamp (in seconds) recording the time when the first neighbor became established.
Bestpath	Time stamp (in seconds) recording the time the best-path calculation mode was entered.
RIB Inst	Time stamp (in seconds) recording the time RIB update mode was entered.
Read/Write	Time stamp (in seconds) recording the time normal mode was entered.
Last Upd	Time stamp (in seconds) recording the time the last update was sent to a neighbor.
Address Family IPv4 Unicast converged in <i>n</i> seconds	Indicates that BGP has reached initial convergence for the IPv4 unicast address family. The time taken for convergence is shown.
Address Family IPv6 Multicast converged in <i>n</i> seconds	Indicates that BGP has reached initial convergence for the IPv6 multicast address family. The time taken for convergence is shown.
Update wait-install enabled	Indicates the update wait-install was configured.

The following is sample output from the **show bgp process** command with the **performance-statistics** and **detail** keywords:

```
Router# show bgp process performance-statistics detail
```

```

BGP Speaker process: 0, Node: node0_0_CPU0
Restart count: 2
Neighbors: 3, established: 2

```

	Sent	Received
Updates:	20	20
Notifications:	0	0

	Number	Memory Used
Attributes:	2	184
AS Paths:	2	48
Communities:	0	0
Extended communities:	0	0
Route Reflector Entries:	0	0
Route-map Cache Entries:	0	0
Filter-list Cache Entries:	0	0
Next Hop Cache Entries:	2	80
Update messages queued:	0	

```

Read 14 messages (1142 bytes) in 12 calls (time spent: 0.024 secs)
Read throttled 0 times
Processed 14 inbound messages (time spent: 0.132 secs)
Wrote 2186 bytes in 24 calls (time spent: 0.024 secs)
Processing write list: wrote 18 messages in 4 calls (time spent: 0.000 secs)
Processing write queue: wrote 10 messages in 20 calls (time spent: 0.000 secs)
Socket setup (LPTS): 4 calls (time spent: 0.010 secs)
Configuration: 1 requests (time spent: 0.002 secs)
Operational data: 9 requests (time spent: 0.026 secs)

```

```

State: normal mode.
BGP Table Version: 150
Network Entries: 149, Soft Reconfig Entries: 0

```

	Allocated	Freed
Prefixes:	149	0
Paths:	200	0

	Number	Memory Used
Prefixes:	149	12516
Paths:	200	8000

```

Updates generated: 149 prefixes in 8 messages from 2 calls (time spent: 0.046 secs)
Scanner: 2 scanner runs (time spent: 0.008 secs)
RIB update: 1 rib update runs, 149 prefixes installed (time spent: 0.024 secs)
Process has converged for IPv4 Unicast.

```

```

First neighbor established: 1082604050s
Entered DO_BESTPATH mode: 1082604055s
Entered DO_RIBUPD mode: 1082604055s
Entered Normal mode: 1082604055s
Latest UPDATE sent: 1082604056s

```

This table describes the significant fields shown in the display.

Table 39: show bgp process performance-statistics detail Field Descriptions

Field	Description
Process	The specified process.

Field	Description
Location	Node in which the specified process is executing.
Neighbors	Number of neighbors for which the specified process is responsible.
established	Number of neighbors that have connections in the established state for the specified process.
Updates	Number of update messages sent and received by the specified process.
Notifications	Number of notification messages sent and received by the specified process.
Attributes	Number of unique sets of attribute information stored in the specified process and the amount of memory used by the attribute information.
AS Paths	Number of unique autonomous system paths stored in the specified process, and the amount of memory used by the AS path information.
Communities	Number of unique sets of community information stored in the specified process and the amount of memory used by them.
Extended communities	Number of unique sets of extended community information stored in the specified process and the amount of memory used by them.
Route Reflector Entries	Number of unique sets of route reflector information stored in the specified process and the amount of memory used by them.
Route-map Cache Entries	Number of entries and memory usage for cached results for applying a route map.
Filter-list Cache Entries	Number of entries and memory usage for cached results for applying an AS path filter list.
Next Hop Cache Entries	Number of entries and memory usage for cached next-hop information.
Update messages queued	Number of update messages queued to be sent across all neighbors for which the specified process is responsible.
Read	Indicates the number of messages read by the process, the total size of read messages, the number of read operations performed, and the real time spent by the process performing read operations.
Read throttled	Number of times that reading from TCP has been throttled due to a backlog of messages read but not processed.
inbound messages	Number of read messages that have been processed and the real time spent processing inbound messages.
Wrote	Amount of data that has been written by the process, the number of write operations performed, and the real time spent by the process performing write operations.

Field	Description
Processing write list	Number of messages written from write lists, the number of times the write list has been processed, and the real time spent processing the write list. Note Write lists typically contain only update messages.
Processing write queue	Number of messages written from write queues, number of times the write queue has been processed, and the real time spent processing the write queue.
Socket setup	Number of socket setup operations performed and the real time spent during socket setup operations.
Configuration	Number of configuration requests received by the process and the real time spent processing configuration requests.
Operational data	Number of requests for operational data (for show commands) received by the process and the real time spent processing operation data requests
State	BGP system state for the specified address family and process. This may be one of the following: read-only mode—Initial set of updates is being recovered. In this mode, route selection is not performed, routes are not installed in the global RIB, and updates are not advertised to peers. best-path calculation mode—Route selection is being performed for the routes that were received while in read-only mode. import mode—Routes are imported from one VRF to another VRF once the best paths are calculated. This mode is supported in VPNv4 unicast address family mode. RIB update mode—Routes that were selected in best-path calculation mode are being installed in the global RIB. label allocation mode: Labels are allocated for the received prefixes based on the requirement. normal mode—Best paths are sent to the peers for routes that exist in the RIB. The route selection, import processing, RIB updates, and label allocation are performed as new updates are received.
BGP Table Version	Last version used in the BGP database for received routes.
Network Entries	Number of sets of prefix information held in the specified BGP process for the specified address family.
Soft Reconfig Entries	Number of sets of prefix information that are present only for the purpose of supporting soft reconfiguration.
Dampened Paths	Number of routes that are suppressed due to dampening for the specified address family.

Field	Description
History Paths	Number of routes that are currently withdrawn, but are being maintained to preserve dampening information.
Prefixes (Allocated/Freed)	Number of sets of prefix information for the specified address family that have been allocated and freed during the lifetime of the process.
Paths (Allocated/Freed)	Number of sets of route information for the specified address family that have been allocated and freed during the lifetime of the process.
Prefixes (Number/Memory Used)	Number of sets of prefix information currently allocated for the specified address family and amount of memory used by them.
Paths (Number/Memory Used)	Number of sets of route information currently allocated for the specified address family and amount of memory used by them.
Updates generated	Number of prefixes for which updates have been generated, the number of messages used to advertise the updates, the number of update generation runs performed, and the real time spent generating updates for the specified address family.
Scanner	Number of times the scanner has run for the specified address family and real time spent in scanner processing.
RIB Update	Number of global routing information base update runs performed for the specified address family, number of prefixes installed, withdrawn, or modified in the global RIB during these runs, and real time spent performing these runs.
Process has converged	Indicates whether the process has reached initial convergence for the specified address family.
First neighbor established	Time stamp (in seconds) recording the time the first neighbor in the process was established.
Entered DO_BESTPATH mode	Time stamp (in seconds) recording the time best-path calculation mode was entered.
Entered DO_RIBUPD mode	Time stamp (in seconds) recording the time RIB update mode was entered.
Entered Normal mode	Time stamp (in seconds) recording the time normal mode was entered.
Last UPDATE sent	Time stamp (in seconds) recording the time the last update was sent to a neighbor.

The following is sample output from the **show bgp vpnv4 unicast process performance-statistics detail** command:

```
Router# show bgp vpnv4 unicast process performance-statistics detail
BGP Speaker process: 0, Node: node0_8_CPU0 Restart count: 1
                        Total                Nbrs Estab/Cfg
Default VRFs:          1                    4/12
Non-Default VRFs:      1009                 1082/1337
                        Sent                Received
```

```

Updates:                362259          5688505
Notifications:          14              0

```

```

                Number      Memory Used
Attributes:      14896      2979200
AS Paths:        17         1100
Communities:     3          120
Extended communities: 1849    124440
Route Reflector Entries: 417    25020
Nexthop Entries: 2941       539572
Update messages queued: 0

```

```

                Alloc      Free
Pool 210:        28955629    28955628
Pool 310:        363103     363103
Pool 600:        4931162     4931162
Pool 1100:       104693     104693
Pool 4300:       799374     799374

```

```

Read 34755745 messages (3542094326 bytes) in 30528983 calls (time spent: 6427.769 secs)
Read partly throttled 1506 times
  Read 14 times after crossing lower threshold Processed 5836892 inbound update messages
    (time spent: 6229.512 secs)
  Wrote 825719955 bytes in 29272669 calls (time spent: 2318.472 secs)
  Processing sub-group: wrote 861402 messages in 1113810 calls (time spent: 145.446 secs)
  Processing write queue: wrote 6288 messages in 20498 calls (time spent: 0.039 secs)
  Socket setup (LPTS): 0 calls (time spent: 0.000 secs)
  event_file_attach calls: Input 8769, Output 2810, Input-output 0
Configuration: 989 requests (time spent: 0.046 secs) Operational data: 92396 requests (time
spent: 98.864 secs)
Current Clock Time: not set Update Generation master timer:
  id: 0, time left: 0.0 sec, last processed: not set
  expiry time of parent node: not set
IO master timer:
  id: 0, time left: 0.0 sec, last processed: not set
  expiry time of parent node: not set

```

```

Address Family: VPNv4 Unicast
State: Normal mode.
BGP Table Version: 23211188
Attribute download: Disabled
Soft Reconfig Entries: 0

```

	Last 8 Triggers	Ver	Tbl Ver
Label Thread	Jun 18 05:31:39.120	23211188	23211188
	Jun 18 05:31:35.274	23211188	23211188
	Jun 18 05:31:34.340	23211187	23211188
	Jun 18 05:31:34.189	23211186	23211187
	Jun 18 05:31:29.120	23211186	23211186
	Jun 18 05:31:28.861	23211186	23211186
	Jun 18 05:31:19.640	23211186	23211186
	Jun 18 05:31:19.272	23211186	23211186
	Total triggers: 639526		
Import Thread	Jun 18 05:31:39.120	23211188	23211188
	Jun 18 05:31:35.274	23211188	23211188
	Jun 18 05:31:34.340	23211187	23211188
	Jun 18 05:31:34.189	23211186	23211187
	Jun 18 05:31:29.120	23211186	23211186
	Jun 18 05:31:28.861	23211186	23211186
	Jun 18 05:31:19.640	23211186	23211186
	Jun 18 05:31:19.272	23211186	23211186

show bgp process

```

Total triggers: 689177

RIB Thread      Jun 18 05:31:39.146  23211188  23211188
Jun 18 05:31:35.299  23211188  23211188
Jun 18 05:31:34.525  23211187  23211188
Jun 18 05:31:34.494  23211186  23211188
Jun 18 05:31:34.340  23211186  23211188
Jun 18 05:31:34.255  23211186  23211188
Jun 18 05:31:29.146  23211186  23211186
Jun 18 05:31:28.886  23211186  23211186
Total triggers: 668084

Update Thread   Jun 18 05:31:39.171  ---      23211188
Jun 18 05:31:35.324  ---      23211188
Jun 18 05:31:34.558  ---      23211188
Jun 18 05:31:34.521  ---      23211188
Jun 18 05:31:34.327  ---      23211188
Jun 18 05:31:29.170  ---      23211186
Jun 18 05:31:28.910  ---      23211186
Jun 18 05:31:19.690  ---      23211186
Total triggers: 660143

Remote Prefixes:  Allocated      Freed
Remote Paths:    3150972      2885064
                  7639074      7118286

Local Prefixes:  3760870      3425614
Local Paths:    7892100      7595657

Remote Prefixes:  Number      Mem Used
Remote Paths:    265908      29781696
Remote RDs:      520788      24997824
                  12424      2832672

Local Prefixes:  335256      37548672
Local Paths:    296443      14229264
Local RDs:      1009      230052

Total Prefixes:  601164      67330368
Total Paths:     817231      39227088
Imported Paths:  265675      12752400
Total RDs:       13433      3062724
Same RDs:        0          0

Update Groups: 3  Subgroups: 2
Updates generated: 1438448 prefixes in 67375 messages from 181564 calls (time spent: 6779.576
secs)
Scanner: 0 scanner runs (time spent: 0.000 secs) RIB update: 0 rib update runs, 0 prefixes
installed, 0 modified,
          0 prefixes removed (time spent: 0.000 secs) RIB table update: 0 table deletes,
0 table invalid, 3526736604 table skip,
          0 no local label, 0 rib retries Process has not converged for VPNv4 Unicast.

First neighbor established: Jun 11 08:32:10
Entered DO_BESTPATH mode:  Jun 11 08:52:10
Entered DO_IMPORT mode:    Jun 11 08:52:12
Entered DO_LABEL_ALLOC mode: Jun 11 08:52:16
Entered DO_RIBUPD mode:    Jun 11 08:52:19
Entered Normal mode:       Jun 11 08:52:23
Latest UPDATE sent:       Jun 18 05:31:34

```

The following is sample output from show bgp process detail command with information on additional paths send and receive information:

```
BGP Process Information:
BGP is operating in STANDALONE mode
Autonomous System number format: ASDOT
Autonomous System: 65550
Router ID: 22.22.22.22 (manually configured)
Default Cluster ID: 2.2.2.2 (manually configured)
Active Cluster IDs: 2.2.2.2
Fast external fallover enabled
Neighbor logging is enabled
Enforce first AS enabled
AS Path multipath-relax is enabled
Default local preference: 100
Default keepalive: 60
Graceful restart enabled
Restart time: 120
Stale path timeout time: 360
RIB purge timeout time: 600
Non-stop routing is enabled
Update delay: 120
Generic scan interval: 60

.....
.....
Prefixes:                Allocated      Freed
Paths:                   12              0
Path-elems:              60              0
Path-elems:              12              0

Number      Mem Used
Prefixes:   12      1200
Paths:      60     3120
Path-elems: 12      624
```

The **Update wait-install enabled** section in the **show bgp process** command displays the delay of the BGP process update since the last router reload.

```
Router# show bgp process
Wed Aug 24 00:40:48.649 PDT

BGP Process Information:
BGP is operating in STANDALONE mode
Autonomous System number format: ASPLAIN
Autonomous System: 65550
Router ID: 192.168.0.2 (manually configured)
Default Cluster ID: 192.168.0.2
Active Cluster IDs: 192.168.0.2
-----
-----
Update wait-install enabled:
  ack request 2, ack rcvd 2, slow ack 0
  startup delay 10 secs

--More--
```

The following is the sample output from the **show bgp ipv4 unicast process** command:

```
Router# show bgp ipv4 unicast process
Tue Dec 12 04:48:17.132 UTC
```

show bgp process

```

BGP Process Information:
BGP is operating in STANDALONE mode
Autonomous System number format: ASPLAIN
Autonomous System: 65550
Router ID: 2.2.10.2
Default Cluster ID: 2.2.10.2
Active Cluster IDs: 2.2.10.2
Fast external fallover enabled
Platform Loadbalance paths max: 1024
Platform RLIMIT max: 8589934592 bytes
Maximum limit for BMP buffer size: 1638 MB
Default value for BMP buffer size: 1228 MB
Current limit for BMP buffer size: 1228 MB
Current utilization of BMP buffer limit: 0 B
Neighbor logging is enabled
Enforce first AS enabled
AS Path multipath-relax is enabled
Use SR-Policy admin/metric of color-extcomm Nexthop during path comparison: disabled
Default local preference: 100
Default keepalive: 60
Graceful restart enabled
Restart time: 120
Stale path timeout time: 360
RIB purge timeout time: 600
Non-stop routing is enabled

ExtComm Color Nexthop validation: RIB
Update delay: 120
Generic scan interval: 60
Configured Segment-routing Local Block: [0, 0]
In use Segment-routing Local Block: [15000, 15999]
Platform support mix of sr-policy and native nexthop: No

Address family: IPv4 Unicast
Dampening is not enabled
Client reflection is enabled in global config
Dynamic MED is Disabled
Dynamic MED interval : 10 minutes
Dynamic MED Timer : Not Running
Dynamic MED Periodic Timer : Not Running
Scan interval: 60
Total prefixes scanned: 1037
Prefixes scanned per segment: 100000
Number of scan segments: 1
Nexthop resolution minimum prefix-length: 0 (not configured)
IPv6 Nexthop resolution minimum prefix-length: 0 (not configured)
Main Table Version: 7237
Table version synced to RIB: 7237
Table version acked by RIB: 7237
IGP notification: IGP notified
RIB has converged: version 4
RIB table prefix-limit reached ? [No], version 0
Permanent Network Unconfigured
Label alloc mode: per-vrf-46
BGP NSR scoped sync stats:
    Scoped Sync last msg failed: 0
    Scoped Sync last msg resumed: 0
    Scoped Sync default route stopped: 0
    Scoped Sync default route resumed: 0
    Scoped Sync default route lookup failure: 0

OC-RIB Telemetry Neighbor Outbound Attributes Pool summary:

```

	Alloc	Free
Pool 25:	0	0

```

Pool 49:                0                0
Pool 73:                0                0
Pool 97:                0                0
Pool 121:               0                0
Pool 145:               0                0
Pool 169:               0                0
Pool 193:               0                0
Pool 217:               0                0
Pool 241:               0                0

```

Number of Paths having particular number of OCRIB out attributes:

```

Paths
1 Out Attrs:           3623882144

```

Node	Process	Nbrs	Estb	Rst	Upd-Rcvd	Upd-Sent	Nfn-Rcv	Nfn-Snt
node0_RP0_CPU0	Speaker	1	1	3	14891			

The following is the sample output from the **show bgp ipv6 unicast process** command:

```

Router# show bgp ipv6 unicast process
Tue Dec 12 04:48:24.452 UTC

```

BGP Process Information:

```

BGP is operating in STANDALONE mode
Autonomous System number format: ASPLAIN
Autonomous System: 65550
Router ID: 2.2.10.2
Default Cluster ID: 2.2.10.2
Active Cluster IDs: 2.2.10.2
Fast external fallover enabled
Platform Loadbalance paths max: 1024
Platform RLIMIT max: 8589934592 bytes
Maximum limit for BMP buffer size: 1638 MB
Default value for BMP buffer size: 1228 MB
Current limit for BMP buffer size: 1228 MB
Current utilization of BMP buffer limit: 0 B
Neighbor logging is enabled
Enforce first AS enabled
AS Path multipath-relax is enabled
Use SR-Policy admin/metric of color-extcomm Nexthop during path comparison: disabled
Default local preference: 100
Default keepalive: 60
Graceful restart enabled
Restart time: 120
Stale path timeout time: 360
RIB purge timeout time: 600
Non-stop routing is enabled

```

```

ExtComm Color Nexthop validation: RIB
Update delay: 120
Generic scan interval: 60
Configured Segment-routing Local Block: [0, 0]
In use Segment-routing Local Block: [15000, 15999]
Platform support mix of sr-policy and native nexthop: No

```

```

Address family: IPv6 Unicast
Dampening is not enabled
Client reflection is enabled in global config
Dynamic MED is Disabled
Dynamic MED interval : 10 minutes
Dynamic MED Timer : Not Running
Dynamic MED Periodic Timer : Not Running
Scan interval: 60
Total prefixes scanned: 12
Prefixes scanned per segment: 100000

```

```

Number of scan segments: 1
Nexthop resolution minimum prefix-length: 0 (not configured)
IPv6 Nexthop resolution minimum prefix-length: 0 (not configured)
Main Table Version: 68
Table version synced to RIB: 68
Table version acked by RIB: 68
RIB has converged: version 1
RIB table prefix-limit reached ? [No], version 0
Permanent Network Unconfigured
Label alloc mode: per-vrf-46
BGP NSR scoped sync stats:
    Scoped Sync last msg failed: 0
    Scoped Sync last msg resumed: 0
    Scoped Sync default route stopped: 0
    Scoped Sync default route resumed: 0
    Scoped Sync default route lookup failure: 0

```

OC-RIB Telemetry Neighbor Outbound Attributes Pool summary:

	Alloc	Free
Pool 25:	0	0
Pool 49:	0	0
Pool 73:	0	0
Pool 97:	0	0
Pool 121:	0	0
Pool 145:	0	0
Pool 169:	0	0
Pool 193:	0	0
Pool 217:	0	0
Pool 241:	0	0

Number of Paths having particular number of OCRIB out attributes:
Paths

Node	Process	Nbrs	Estb	Rst	Upd-Rcvd	Upd-Sent	Nfn-Rcv	Nfn-Snt
node0_RP0_CPU0	Speaker	1	1	3	14891	472	0	2

The following is the sample output from the **show bgp vpnv4 unicast process** command:

Tue Dec 12 04:48:46.674 UTC

```

BGP Process Information:
BGP is operating in STANDALONE mode
Autonomous System number format: ASPLAIN
Autonomous System: 65550
Router ID: 2.2.10.2
Default Cluster ID: 2.2.10.2
Active Cluster IDs: 2.2.10.2
Fast external fallover enabled
Platform Loadbalance paths max: 1024
Platform RLIMIT max: 8589934592 bytes
Maximum limit for BMP buffer size: 1638 MB
Default value for BMP buffer size: 1228 MB
Current limit for BMP buffer size: 1228 MB
Current utilization of BMP buffer limit: 0 B
Neighbor logging is enabled
Enforce first AS enabled
AS Path multipath-relax is enabled
Use SR-Policy admin/metric of color-extcomm Nexthop during path comparison: disabled
Default local preference: 100
Default keepalive: 60
Graceful restart enabled
Restart time: 120
Stale path timeout time: 360

```



```

RIB purge timeout time: 600
Non-stop routing is enabled

ExtComm Color Nexthop validation: RIB
Update delay: 120
Generic scan interval: 60
Configured Segment-routing Local Block: [0, 0]
In use Segment-routing Local Block: [15000, 15999]
Platform support mix of sr-policy and native nexthop: No

Address family: VPNv4 Unicast
Dampening is not enabled
Client reflection is enabled in global config
Dynamic MED is Disabled
Dynamic MED interval : 10 minutes
Dynamic MED Timer : Not Running
Dynamic MED Periodic Timer : Not Running
Scan interval: 60
Total prefixes scanned: 11184
Prefixes scanned per segment: 100000
Number of scan segments: 1
Nexthop resolution minimum prefix-length: 0 (not configured)
IPv6 Nexthop resolution minimum prefix-length: 0 (not configured)
Main Table Version: 292595
Table version synced to RIB: 292595
Table version acked by RIB: 0
RIB has not converged: version 0
RIB table prefix-limit reached ? [No], version 0
RPKI version 1
RPKI soft-reconfig version 1
Origin-AS validation is enabled for this address-family
Permanent Network Unconfigured
BGP NSR scoped sync stats:
    Scoped Sync last msg failed: 0
    Scoped Sync last msg resumed: 0
    Scoped Sync default route stopped: 0
    Scoped Sync default route resumed: 0
    Scoped Sync default route lookup failure: 0

OC-RIB Telemetry Neighbor Outbound Attributes Pool summary:

```

	Alloc	Free
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0

```

Number of Paths having particular number of OCRIB out attributes:
    Paths
1 Out Attrs:      32

Node              Process      Nbrs Estb Rst Upd-Rcvd Upd-Sent Nfn-Rcv Nfn-Snt
node0_RP0_CPU0    Speaker      1     1   3   14891     472      0       2

VRF all label alloc mode: per-vrf-46

The following is the sample output from the show bgp vpnv6 unicast process command:

Router# show bgp vpnv6 unicast process
Tue Dec 12 04:48:52.603 UTC

```

show bgp process

```

BGP Process Information:
BGP is operating in STANDALONE mode
Autonomous System number format: ASPLAIN
Autonomous System: 65550
Router ID: 2.2.10.2
Default Cluster ID: 2.2.10.2
Active Cluster IDs: 2.2.10.2
Fast external fallover enabled
Platform Loadbalance paths max: 1024
Platform RLIMIT max: 8589934592 bytes
Maximum limit for BMP buffer size: 1638 MB
Default value for BMP buffer size: 1228 MB
Current limit for BMP buffer size: 1228 MB
Current utilization of BMP buffer limit: 0 B
Neighbor logging is enabled
Enforce first AS enabled
AS Path multipath-relax is enabled
Use SR-Policy admin/metric of color-extcomm Nexthop during path comparison: disabled
Default local preference: 100
Default keepalive: 60
Graceful restart enabled
Restart time: 120
Stale path timeout time: 360
RIB purge timeout time: 600
Non-stop routing is enabled

ExtComm Color Nexthop validation: RIB
Update delay: 120
Generic scan interval: 60
Configured Segment-routing Local Block: [0, 0]
In use Segment-routing Local Block: [15000, 15999]
Platform support mix of sr-policy and native nexthop: No

Address family: VPNv6 Unicast
Dampening is not enabled
Client reflection is enabled in global config
Dynamic MED is Disabled
Dynamic MED interval : 10 minutes
Dynamic MED Timer : Not Running
Dynamic MED Periodic Timer : Not Running
Scan interval: 60
Total prefixes scanned: 6
Prefixes scanned per segment: 100000
Number of scan segments: 1
Nexthop resolution minimum prefix-length: 0 (not configured)
IPv6 Nexthop resolution minimum prefix-length: 0 (not configured)
Main Table Version: 21
Table version synced to RIB: 21
Table version acked by RIB: 0
RIB has not converged: version 0
RIB table prefix-limit reached ? [No], version 0
RPKI version 1
RPKI soft-reconfig version 1
Origin-AS validation is enabled for this address-family
Permanent Network Unconfigured
BGP NSR scoped sync stats:
    Scoped Sync last msg failed: 0
    Scoped Sync last msg resumed: 0
    Scoped Sync default route stopped: 0
    Scoped Sync default route resumed: 0
    Scoped Sync default route lookup failure: 0

OC-RIB Telemetry Neighbor Outbound Attributes Pool summary:

```

	Alloc	Free
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0

Number of Paths having particular number of OCRIB out attributes:

	Paths
1 Out Attrs:	3452816845

Node	Process	Nbrs	Estb	Rst	Upd-Rcvd	Upd-Sent	Nfn-Rcv	Nfn-Snt
node0_RP0_CPU0	Speaker	1	1	3	14891	472	0	2

VRF all label alloc mode: per-vrf-46

show bgp regexp

To display routes matching the autonomous system path regular expression, use the **show bgp regexp** command in EXEC mode and XR EXEC mode.

show bgp regexp *regular-expression*

Syntax Description	ipv4	(Optional) Specifies IP Version 4 address prefixes.
	unicast	(Optional) Specifies unicast address prefixes.
	multicast	(Optional) Specifies multicast address prefixes.
	labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
	all	(Optional) For subaddress families, specifies prefixes for all subaddress families.
	tunnel	(Optional) Specifies tunnel address prefixes.
	mdt	(Optional) Specifies multicast distribution tree (MDT) address prefixes.
	ipv6	(Optional) Specifies IP Version 6 address prefixes.
	all	(Optional) For address family, specifies prefixes for all address families.
	vpn4 unicast	(Optional) Specifies VPNv4 unicast address families.
	vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
	<i>vrf-name</i>	(Optional) Name of a VRF.
	all	(Optional) For VRF, specifies all VRFs.
	ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
	ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.
	vpn6 unicast	(Optional) Specifies VPNv6 unicast address families.
	<i>regular-expression</i>	Regular expression to match the BGP autonomous system paths.
Command Default	If no address family or subaddress family is specified, the default address family and subaddress family specified using the set default-afi and set default-safi commands are used.	
Command Modes	EXEC mode and XR EXEC mode	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines



Note The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

BGP contains a separate routing table for each configured address family and subaddress family combination. The address family and subaddress family options specify the routing table to be examined. If the **all** keyword is specified for the address family or subaddress family, each matching routing table is examined in turn.

Use the **show bgp regexp** command to display all routes in the specified BGP table whose autonomous system path is matched by the specified regular expression.



Note If the regular expression contains spaces and parentheses, it must be specified and surrounded by quotation marks.

Examples

The following is sample output from the **show bgp regexp** command:

```
Router# show bgp regexp "^3 "

BGP router identifier 10.0.0.5, local AS number 1
BGP main routing table version 64
BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
               i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network        Next Hop           Metric LocPrf Weight Path
*>i172.20.17.121   10.0.101.2               100      0 3 2000 3000 i
*>i10.0.0.0        10.0.101.2               100      0 3 100 1000 i
*>i172.5.23.0/24   10.0.101.2               100      0 3 4 60 4378 i
```

This table describes the significant fields shown in the display.

Table 40: show bgp regexp Field Descriptions

Field	Description
BGP router identifier	BGP identifier for the local system.
local AS number	Autonomous system number for the local system.
Dampening enabled	Displayed if dampening has been enabled for the routes in this BGP routing table.
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.

Field	Description
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.
Status codes	Status of the table entry. The status is displayed as a three-character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): >—Path is the best path to use for that network. d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.
Origin codes	Origin of the path. The origin code is placed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was advertised with a network or aggregate-address command. e—Path originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP address of a network entity.
Next Hop	IP address of the next system that is used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network.
Metric	Value of the interautonomous system metric, otherwise known as the Multi Exit Discriminator (MED) metric.
LocPrf	Local preference value. This is used to determine the preferred exit point from the local autonomous system. It is propagated throughout the local autonomous system.
Weight	Path weight. Weight is used in choosing the preferred path to a route. It is not advertised to any neighbor.
Path	Autonomous system path to the destination network. At the end of the path is the origin code for the path.

show bgp route-policy

To display Border Gateway Protocol (BGP) information about networks that match an outbound route policy, use the **show bgp route-policy** command in EXEC mode and XR EXEC mode.

show bgp route-policy *route-policy-name* [**standby**]

Syntax	Description	
ipv4	(Optional) Specifies IP Version 4 address prefixes.	
unicast	(Optional) Specifies unicast address prefixes.	
multicast	(Optional) Specifies multicast address prefixes.	
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.	
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.	
tunnel	(Optional) Specifies tunnel address prefixes.	
ipv6	(Optional) Specifies IP Version 6 address prefixes.	
all	(Optional) For address family, specifies prefixes for all address families.	
vpn4 unicast	(Optional) Specifies VPNv4 unicast address families.	
rd <i>rd-address</i>	(Optional) Displays routes with a specific route distinguisher.	
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.	
<i>vrf-name</i>	(Optional) Name of a VRF.	
all	(Optional) For VRF, specifies all VRFs.	
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.	
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.	
<i>route-policy-name</i>	Name of a route policy.	
Command Default	If no address family or subaddress family is specified, the default address family and subaddress family specified using the set default-afi and set default-safi commands are used.	
Command Modes	EXEC mode and XR EXEC mode	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines



Note The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

BGP contains a separate routing table for each address family and subaddress family combination that has been configured. The address family and subaddress family options specify the routing table to be examined. If the **all** keyword is specified for the address family or subaddress family, each matching routing table is examined.

A route policy must be configured to use this command. When the **show bgp route-policy** command is entered, routes in the specified BGP table are compared with the specified route policy, and all routes passed by the route policy are displayed.

If a pass clause is encountered while the route policy is being applied to the route and the route policy processing completes without hitting a drop clause, the route is displayed. The route is not displayed if a drop clause is encountered, if the route policy processing completes without hitting a pass clause, or if the specified route policy does not exist.

The information displayed does not reflect modifications the policy might make to the route. To display such modifications, use the **show bgp policy** command.

Examples

The following is sample output from the **show bgp route-policy** command in EXEC mode and XR EXEC mode:

```
Router# show bgp route-policy p1

BGP router identifier 172.20.1.1, local AS number 1820
BGP main routing table version 729
Dampening enabled
BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
               i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network        Next Hop           Metric LocPrf Weight Path
*  10.13.0.0/16    192.168.40.24                      0 1878 704 701 200 ?
*  10.16.0.0/16    192.168.40.24                      0 1878 704 701 i
```

This table describes the significant fields shown in the display.

Table 41: show bgp route-policy Field Descriptions

Field	Description
BGP router identifier	BGP identifier for the local system.
local AS number	Autonomous system number for the local system.

Field	Description
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.
Dampening enabled	Displayed if dampening is enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.
Status codes	Status of the table entry. The status is displayed as a three-character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): >—Path is the best path to use for that network. d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.
Origin codes	Origin of the path. The origin code is displayed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was advertised with a network or aggregate-address command. e—Path originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP prefix and prefix length for a network.
Next Hop	IP address of the next system that is used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network.
Metric	Value of the interautonomous system metric, otherwise known as the Multi Exit discriminator (MED) metric.
LocPrf	Local preference value. This is used to determine the preferred exit point from the local autonomous system. It is propagated throughout the local autonomous system.

Field	Description
Weight	Path weight. Weight is used in choosing the preferred path to a route. It is not advertised to any neighbor.
Path	Autonomous system path to the destination network. At the end of the path is the origin code for the path.

show bgp session-group

To display information about the Border Gateway Protocol (BGP) configuration for session groups, use the **show bgp session-group** command in EXEC mode and XR EXEC mode.

```
show bgp session-group group-name { configuration [defaults] [nvgen] | inheritance |
users }
```

Syntax Description

<i>group-name</i>	Name of the session family group to display.
configuration	(Optional) Displays the effective configuration for the session group, including any inherited configuration.
defaults	(Optional) Displays all configuration, including default configuration.
nvgen	(Optional) Displays output in the form of the show running-config command. If the defaults keyword also is specified, the output is not suitable for cutting and pasting into a configuration session.
inheritance	(Optional) Displays the session groups from which this session group inherits configuration.
users	(Optional) Display the session groups, neighbor groups, and neighbors that inherit configuration from this session group.

Command Default

No default behavior or value

Command Modes

EXEC mode and XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **show bgp session-group** command with the *group-name* **configuration** argument and keyword to display the effective configuration of a session group, including any configuration inherited from other session groups through application of the **use** command. The source for each configured command is also displayed.

Use the **defaults** keyword to display the value of all configuration, including default configuration. Use the **nvgen** keyword to display configuration in the form of the **show running-config** command output. Output in this form is suitable for cutting and pasting into a configuration session.

Use the **show bgp session-group** command with the *group-name* **inheritance** argument and keyword to display the session groups from which the specified session group inherits configuration.

Use the **show bgp session-group** command with the *group-name* **users** argument and keyword to display the neighbors, neighbor groups, and session groups that inherit configuration from the specified session group.

Examples

For the example shown here, the following configuration is used:

```

session-group group3
  advertisement-interval 5
  dmzlink-bw
!
session-group group1
  use session-group group2
  update-source Loopback0
!
session-group group2
  use session-group group3
  ebgp-multihop 2

```

The following example shows the **show bgp session-group** command with the **configuration** keyword:

```
Router# show bgp session-group group1 configuration
```

```

session-group group1
  advertisement-interval 5[s:group2 s:group3]
  ebgp-multihop 2 [s:group2]
  update-source Loopback0 []
  dmzlink-bandwidth [s:group2 s:group3]

```

The source of each command is shown to the right of the command. For example, **update-source** is configured directly on session group group1. The **dmzlink-bandwidth** command is inherited from session group group2, which in turn inherits it from session group group3.

The following example shows the **show bgp session-group** command with the **users** keyword:

```
Router# show bgp session-group group2 users
```

```
IPv4 Unicast:a:group1
```

The following example shows the **show bgp session-group** command with the **inheritance** keyword.

```
Router# show bgp session-group group1 inheritance
```

```
Session:s:group2 s:group3
```

The command output shows that the session group group1 directly uses the group2 session group. The group2 session group uses the group3 session group.

This table describes the significant fields shown in the display.

Table 42: show bgp session-group Field Descriptions

Field	Description
[]	Configures the command directly on the specified session group.
s:	Indicates the name that follows is a session group.
a:	Indicates the name that follows is an address family group.
n:	Indicates the name that follows is a neighbor group.

Field	Description
[dflt]	Indicates the command is not explicitly configured or inherited, and the default value for the command is used. This field may be shown when the defaults keyword is specified.
<not set>	Indicates that the default is for the command to be disabled. This field may be shown when the defaults keyword is specified.

show bgp sessions

To display brief information about BGP neighbors, use the **show bgp sessions** command in EXEC mode and XR EXEC mode.

show bgp sessions [**not-established**] [**not-nsr-ready**]

Syntax Description

not-established (Optional) Displays all the neighbors that are not in established state

not-nsr-ready (Optional) Displays all the neighbors that are not nonstop routing (NSR) ready.

Command Default

No default behavior or values

Command Modes

EXEC mode and XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

The **show bgp sessions** command without a keyword provides brief information about all the BGP neighbors configured irrespective of the address family or VRF.

The **show bgp sessions** command with the **not-established** keyword shows BGP peers which are yet to establish their peering relationship.

The **show bgp session** command with the and **not-nsr-ready** keyword shows BGP peers which are yet to reach the nsr ready state.

Examples

The following is sample output from the **show bgp sessions** command in EXEC mode and XR EXEC mode:

```
Router# show bgp sessions
Thu Jan 15 17:41:45.277 UTC
```

Neighbor	VRF	Spk	AS	InQ	OutQ	NBRState	NSRState
2.2.2.2	default	0	1	0	0	Active	None
10.0.101.1	default	0	1	0	0	Established	NSR Ready
10.0.101.2	default	0	1	0	0	Established	NSR Ready
10.0.101.3	default	0	1	0	0	Established	NSR Ready
10.0.101.4	default	0	1	0	0	Established	NSR Ready
10.0.101.5	default	0	1	0	0	Established	NSR Ready
10.0.101.6	default	0	1	0	0	Established	NSR Ready
10.0.101.7	default	0	1	0	0	Established	NSR Ready
10.0.101.8	default	0	1	0	0	Established	NSR Ready
10.0.101.9	default	0	1	0	0	Established	NSR Ready
10.11.12.2	default	0	100	0	0	Established	NSR Ready
90.0.0.2	900	0	2	0	0	Established	NSR Ready
9000::1001	900	0	2	0	0	Established	NSR Ready
91.0.0.2	901	0	2	0	0	Established	NSR Ready
9100::1001	901	0	2	0	0	Established	NSR Ready
92.0.0.2	902	0	2	0	0	Established	NSR Ready
9200::1001	902	0	2	0	0	Established	NSR Ready

```

93.0.0.2          903          0      2      0      0 Established NSR Ready
9300::1001        903          0      2      0      0 Established NSR Ready
94.0.0.2          904          0      2      0      0 Established NSR Ready
9400::1001        904          0      2      0      0 Established NSR Ready
95.0.0.2          905          0      2      0      0 Established NSR Ready
9500::1001        905          0      2      0      0 Established NSR Ready
96.0.0.2          906          0      2      0      0 Established NSR Ready
9600::1001        906          0      2      0      0 Established NSR Ready
97.0.0.2          907          0      2      0      0 Established NSR Ready
9700::1001        907          0      2      0      0 Established NSR Ready
98.0.0.2          908          0      2      0      0 Established NSR Ready
9800::1001        908          0      2      0      0 Established NSR Ready
99.0.0.2          909          0      2      0      0 Idle         None
9900::1001        909          0      2      0      0 Idle         None
12.13.14.16       red           0      2      0      0 Idle         None
20.0.101.1        red           0      2      0      0 Active       None
1234:5678:9876::1111
                    red           0      3      0      0 Idle         None
2020::1002        red           0      2      0      0 Established NSR Ready
1.2.3.4           this-is-a-long-vrf-name
                    0      5      0      0 Idle         None
1111:2222:3333:4444:5555::6789
                    this-is-a-long-vrf-name
                    0      7      0      0 Idle         None

```

The following is sample output from the **show bgp sessions** command with the **not-established** keyword:

```

Router# show bgp sessions not-established
Fri Jan 30 11:30:42.720 PST PDT

```

Neighbor	VRF	Spk	AS	InQ	OutQ	NBRState	NSRState
10.0.101.5	default	0	100	0	0	Active	None
2.2.2.2	vrf1_1	0	302	0	0	Idle	None
2.101.1.2	vrf1_1	0	302	0	0	Idle	None
2.102.1.2	vrf1_1	0	302	0	0	Idle	None
2.103.1.2	vrf1_1	0	302	0	0	Idle	None
4.4.4.2	vrf1_1	0	304	0	0	Idle	None
2008:2:2:2::2	vrf1_1	0	302	0	0	Idle	None
11.16.1.2	vrf2_1	0	302	0	0	Idle	None

The following is sample output from the **show bgp sessions** command with the **not-nsr-ready** keyword:

```

Router# show bgp sessions not-nsr-ready
Fri Jan 30 11:30:52.301 PST PDT

```

Neighbor	VRF	Spk	AS	InQ	OutQ	NBRState	NSRState
10.0.101.5	default	0	100	0	0	Active	None
2.2.2.2	vrf1_1	0	302	0	0	Idle	None
2.101.1.2	vrf1_1	0	302	0	0	Idle	None
2.102.1.2	vrf1_1	0	302	0	0	Idle	None
2.103.1.2	vrf1_1	0	302	0	0	Idle	None
4.4.4.2	vrf1_1	0	304	0	0	Idle	None
2008:2:2:2::2	vrf1_1	0	302	0	0	Idle	None
11.16.1.2	vrf2_1	0	302	0	0	Idle	None

This table describes the significant fields shown in the display.

Table 43: show bgp sessions Field Descriptions

Field	Description
Neighbor	Displays neighbor IP address.
VRF	Displays information about the VRF.
Spk	Speaker process that is responsible for the neighbor. Always 0.
AS	Autonomous system.
InQ	Number of messages from a neighbor waiting to be processed.
OutQ	Number of messages waiting to be sent to a neighbor.
NBRState	State of the Border Gateway Protocol (BGP) neighbor sessions.
NSRState	State of the Border Gateway Protocol (BGP) nonstop routing (NSR).

show bgp sessions version-rate

To display version rate information about BGP neighbors, use the **show bgp sessions version-rate** command in EXEC mode and XR EXEC mode.

show bgp sessions version-rate [**brief** {**live** | **standby**} | **live** {**standby**}] [**standby**]

Syntax Description	brief	(Optional) Displays all the neighbors with brief version-rate information.
	live	(Optional) Displays all the neighbors with version-rate information for live interval.
	standby	(Optional) Displays standby BGP information.

Command Default No default behavior or values

Command Modes EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 24.1.1	This command was introduced.

Usage Guidelines The **show bgp sessions version-rate** command with the **brief** keyword shows BGP neighbors with brief version-rate information.

The **show bgp sessions version-rate** command with the and **live** keyword shows BGP neighbors with version-rate information for live interval.

Examples

The following is sample output from the **show bgp sessions version-rate** command in EXEC mode and XR EXEC mode:

```
Router# show bgp sessions version-rate
Thu Nov  2 11:40:41.107 IST
Interval definition(s):
  Interval  Duration (min)  Start time          End time
Live
1           5             Nov  2 11:37:22.029  Nov  2 11:40:41.413
2          15             Nov  2 11:32:22.029  Nov  2 11:37:22.029
3          30             Nov  2 11:22:22.029  Nov  2 11:37:22.029
Neighbor
Total
Interval 2
NSRState
VRF
Live
Interval 3
Spk
AFI
Interval 1
AS  InQ  OutQ
Total
Reach  UnReach
10.10.10.1
5      0      0
0      0      0
Established NSRReady
10.10.10.1
IPv4 Unicast
```

show bgp sessions version-rate

```

0          5          5          0          0          0          5          5
192.168.0.5          5          0          0          0          0          0
0          282          282          0          0          0          282          282
Established NSRReady          100          0          0
192.168.0.5          63          0          0          0          31          31
0          31          31          0          0          0          0          0
192.168.0.5          240          0          0          0          110          110
0          110          110          0          0          0          0          0
192.168.0.5          63          0          0          0          31          31
31          31          0          0          0          0          0
192.168.0.5          240          0          0          0          110          110
0          110          110          0          0          0          0          0
192.168.0.5          0          0          0          0          0          0          0
0          0          0          0          0          0          0          0
10:10:10::1          5          0          0          0          5          5
Established NSRReady          200          0          0
10:10:10::1          5          0          0          0          5          5
0          5          5          0          0          0          0          0
10.0.1.1          5          0          1          0          0          0          0
0          0          0          0          0          0          0          0
Established NSRReady          200          0          0
10.0.1.1          5          0          0          0          0          0          0
0          0          0          0          1          0          0          0
10:0:1::1          5          0          0          0          0          0          0
Established NSRReady          200          0          0
10:0:1::1          5          0          0          0          0          0          0
0          0          0          0          0          0          0          0

```

The following is sample output from the **show bgp sessions version-rate** command with the **live** keyword:

```
Router# show bgp sessions version-rate live
```

```
Thu Nov 2 11:40:48.314 IST
```

```
Interval definition(s):
```

```
Interval  Duration (min)  Start time  End time
Live      5              Nov 2 11:37:22.029  Nov 2 11:40:48.610
```

```

Neighbor          Total          VRF          AFI
                  Live          Spk    AS    InQ  OutQ  NBRState
NSRState
10.10.10.1          5          0          default  UnReach          All
NSRReady          0          0          0          0          200          0          0          Established
10.10.10.1          5          0          0          0          0          0          0          IPv4 Unicast
192.168.0.5          0          default          All

```

```

        606      0      0      0  0  100      0      0 Established
    NSRReady
192.168.0.5      63      0      0      0      IPv4 Unicast
192.168.0.5      240      0      0      0      VPNv4 Unicast
192.168.0.5      63      0      0      0      IPv6 Labeled-unicast
192.168.0.5      240      0      0      0      VPNv6 Unicast
192.168.0.5      0      0      0      0      RT Constraint
10:10:10::1      5      0      0      0      All
        5      0      0      0      0      200      0      0 Established
    NSRReady
10:10:10::1      5      0      0      0      IPv6 Unicast
10.0.1.1      5      0      1      0      0      All
        5      0      0      0      0      200      0      0 Established
    NSRReady
10.0.1.1      5      0      0      0      0      IPv4 Unicast
10:0:1::1      5      0      1      0      0      All
        5      0      0      0      0      200      0      0 Established
    NSRReady
10:0:1::1      5      0      0      0      0      IPv6 Unicast

```

The following is sample output from the **show bgp sessions version-rate** command with the **brief** keyword:

```
Router#show bgp sessions version-rate brief
```

```
Thu Nov  2 11:40:52.765 IST
```

```
Interval definition(s):
```

Interval	Duration (min)	Start time	End time
Live	5	Nov 2 11:37:22.029	Nov 2 11:40:53.072
1	5	Nov 2 11:32:22.029	Nov 2 11:37:22.029
2	15	Nov 2 11:22:22.029	Nov 2 11:37:22.029
3	30	Nov 2 10:52:22.027	Nov 2 11:22:22.027

Neighbor	OutQ	NBRState	NSRState	VRF	Total	Live	Interval1	Spk	AS	InQ
Interval3										
10.10.10.1				default				0	200	0
0	Established	NSRReady			5	0	5			5
0										
192.168.0.5				default	606	0	282	0	100	0
0	Established	NSRReady								282
0										
10:10:10::1				default	5	0	5	0	200	0
0	Established	NSRReady						5		5
0										
10.0.1.1				1	5	0	0	0	200	0
0	Established	NSRReady						0		0
0										
10:0:1::1				1	5	0	0	0	200	0
0	Established	NSRReady						0		0
0										

The following is sample output from the **show bgp sessions version-rate** command with the **brief live** keyword:

```
Router#show bgp sessions version-rate brief live
```

show bgp sessions version-rate

Thu Nov 2 11:40:55.743 IST

Interval definition(s):

Interval	Duration (min)	Start time	End time
Live	5	Nov 2 11:37:22.029	Nov 2 11:40:56.059

Neighbor	OutQ	NBRState	NSRState	VRF	Total	Live	Spk	AS	InQ
10.10.10.1				default			0	200	0
0	Established	NSRReady			5	0			
192.168.0.5				default			0	100	0
0	Established	NSRReady			606	0			
10:10:10::1				default			0	200	0
0	Established	NSRReady			5	0			
10.0.1.1				1			0	200	0
0	Established	NSRReady			5	0			
10:0:1::1				1			0	200	0
0	Established	NSRReady			5	0			

show bgp summary

To display the status of all Border Gateway Protocol (BGP) connections, use the **show bgp summary** command in EXEC mode and XR EXEC mode.

```
show bgp [ ipv4 { unicast | multicast | labeled-unicast | all | tunnel | mdt } | ipv6 { unicast
| multicast | all | labeled-unicast } | all { unicast | multicast | all | labeled-unicast | mdt | tunnel }
| vpnv4 unicast | vrf { vrf-name | all } ] [ ipv4 { unicast | labeled-unicast } | ipv6 unicast ]
| vpnv6 unicast ] summary [ soft-reconfig-stats ]
```

Syntax	Description
ipv4	(Optional) Specifies IP Version 4 address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.
tunnel	(Optional) Specifies tunnel address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
all	(Optional) For address family, specifies prefixes for all address families.
vpnv4 unicast	(Optional) Specifies VPNv4 unicast address families.
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
<i>vrf-name</i>	(Optional) Name of a VRF.
all	(Optional) For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.
soft-reconfig-stats	Statistics for the neighbor with both policy and soft reconfiguration configured.

Command Default If no address family or subaddress family is specified, the default address family and subaddress family specified using the **set default-afi** and **set default-safi** commands are used.

Command Modes EXEC mode and XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.
Release 24.2.11	This command was modified. The soft-reconfig-stats keyword was added.

Usage Guidelines

The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

Use the **show bgp summary** command to display a summary of the neighbors for which the specified address family and subaddress family are enabled. If the neighbor does not have the specified address family and subaddress family enabled, it is not included in the output of the **show** command. If the **all** keyword is specified for the address family or subaddress family, a summary for each combination of address family and subaddress family is displayed in turn.

The table versions shown in the output (RcvTblVer, bRIB/RIB, SendTblVer, and TblVer) are specific to the specified address family and subaddress family. All other information is global.

The table versions provide an indication of whether BGP is up to date with all work for the specified address family and subaddress family.

- bRIB/RIB < RcvTblVer—Some received routes have not yet been considered for installation in the global routing table.
- TblVer < SendTblVer—Some received routes have been installed in the global routing table but have not yet been considered for advertisement to this neighbor.

Examples

The following is sample output from the **show bgp summary** command:

```
Router#show bgp summary
```

```
BGP router identifier 10.0.0.0, local AS number 2
BGP generic scan interval 60 secs
BGP table state: Active
Table ID: 0xe0000000
BGP main routing table version 1
BGP scan interval 60 secs
```

```
BGP is operating in STANDALONE mode.
```

Process	RecvTblVer	bRIB/RIB	LabelVer	ImportVer	SendTblVer
Speaker	1	0	1	1	0

Neighbor	Spk	AS	MsgRcvd	MsgSent	TblVer	InQ	OutQ	Up/Down	St/PfxRcd
10.0.101.0	0	2	0	0	0	0	0	00:00:00	Idle
10.0.101.1	0	2	0	0	0	0	0	00:00:00	Idle

This table describes the significant fields shown in the display.

Table 44: show bgp summary Field Descriptions

Field	Description
BGP router identifier	IP address of the router.
local AS number	Autonomous system number set by the router bgp, on page 193 command. • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535.
BGP generic scan interval	Interval (in seconds) between scans of the BGP table by a generic scanner.
BGP table state	State of the BGP database.
Table ID	BGP database identifier.
BGP main routing table version	Last version of the BGP database that was injected into the main routing table.
Dampening enabled	Displayed if dampening has been enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.
BGP is operating in	Specifies BGP is operating in standalone mode.
Process	BGP process.
RecvTblVer	Last version used in the BGP database for received routes.
bRIB/RIB	Last version of the local BGP database that was injected into the main routing table.
LabelVer	Label version used in the BGP database for label allocation.
ImportVer	Last version of the local BGP database for importing routes.
SendTblVer	Latest version of the local BGP database that is ready to be advertised to neighbors.
Some configured eBGP neighbors do not have any policy	Some external neighbors exist that do not have both an inbound and outbound policy configured for every address family, using the route-policy (BGP) command. In this case, no prefixes are accepted and advertised to those neighbors.
Neighbor	IP address of a neighbor.

Field	Description
Spr	Speaker process that is responsible for the neighbor. Always 0.
AS	Autonomous system.
MsgRcvd	Number of BGP messages received from a neighbor.
MsgSent	Number of BGP messages sent to a neighbor.
TblVer	Last version of the BGP database that was sent to a neighbor.
InQ	Number of messages from a neighbor waiting to be processed.
OutQ	Number of messages waiting to be sent to a neighbor.
Up/Down	Length of time in (hh:mm:ss) that the BGP session has been in Established state, or the time since the session left Established state, if it is not established.
St/PfxRcd	If the BGP session is not established, the current state of the session. If the session is established, the number of prefixes the router has received from the neighbor. If the number of prefixes received exceeds the maximum allowed (as set by the maximum-prefix command), “(PfxRcd)” appears. If the connection has been shut down using the shutdown command, “(Admin)” appears. If the neighbor is external and it does not have an inbound and outbound policy configured for every address family, an exclamation mark (!) is inserted at the end of the state when using the route-policy (BGP) command. If the connection has been shut down due to out of memory (OOM), “(OOM)” appears.

The following is sample output from the **show bgp summary** command with optional keywords. The output displays the soft reconfiguration statistics for IPv4 unicast BGP sessions.

```
Router# show bgp ipv4 unicast summary soft-reconfig-stats
```

```
Tue Sep 19 14:02:39.106 EDT
BGP router identifier 192.168.0.3, local AS number 3
BGP generic scan interval 60 secs
Non-stop routing is enabled BGP table state: Active
Table ID: 0x0000000 RD version: 6
BGP table nexthop route policy:
BGP main routing table version 6
BGP NSR Initial initsync version 6 (Reached)
BGP NSR/ISSU Sync-Group versions 6/0
BGP scan interval 60 secs
```

```
BGP is operating in STANDALONE mode.
```

```
Process
Speaker   RcvTblVer bRIB/RIB  Labelver ImportVer SendTblVer StandbyVer
```



```

        6          6          6          6          6          6
Neighbor      Spk   AS   MsgRcvd  MsgSent   TblVer  InQ   OutQ  Up/Down   St/PfcRcd  SoftChgd
  Denied
10.10.10.4      0    3    15       12        6    0     0     00:46:06    2          0
0
Total
0

```

Legend:

Total PfxRcd: Sum of accepted unmodified and modified paths

Total SoftChgd: Sum of accepted modified paths

Total Denied: Sum of Denied paths

This table describes the significant fields shown in the display.

Table 45: show bgp summary soft-reconfig-stats Field Descriptions

Field	Description
BGP router identifier	IP address of the router.
local AS number	Autonomous system number set by the router bgp, on page 193 command. • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535.
BGP generic scan interval	Interval (in seconds) between scans of the BGP table by a generic scanner.
BGP table state	State of the BGP database.
Table ID	BGP database identifier.
BGP main routing table version	Last version of the BGP database that was injected into the main routing table.
Dampening enabled	Displayed if dampening has been enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.
BGP is operating in	Specifies BGP is operating in standalone mode.
Process	BGP process.
RecvTblVer	Last version used in the BGP database for received routes.
bRIB/RIB	Last version of the local BGP database that was injected into the main routing table.
LabelVer	Label version used in the BGP database for label allocation.

Field	Description
ImportVer	Last version of the local BGP database for importing routes.
SendTblVer	Latest version of the local BGP database that is ready to be advertised to neighbors.
Neighbor	IP address of a neighbor.
Spk	Speaker process that is responsible for the neighbor. Always 0.
AS	Autonomous system.
MsgRcvd	Number of BGP messages received from a neighbor.
MsgSent	Number of BGP messages sent to a neighbor.
TblVer	Last version of the BGP database that was sent to a neighbor.
InQ	Number of messages from a neighbor waiting to be processed.
OutQ	Number of messages waiting to be sent to a neighbor.
Up/Down	Length of time in (hh:mm:ss) that the BGP session has been in Established state, or the time since the session left Established state, if it is not established.
St/PfxRcd	If the BGP session is not established, the current state of the session. If the session is established, the number of prefixes the router has received from the neighbor. If the number of prefixes received exceeds the maximum allowed (as set by the maximum-prefix command), “(PfxRcd)” appears. If the connection has been shut down using the shutdown command, “(Admin)” appears. If the neighbor is external and it does not have an inbound and outbound policy configured for every address family, an exclamation mark (!) is inserted at the end of the state when using the route-policy (BGP) command. If the connection has been shut down due to out of memory (OOM), “(OOM)” appears.
soft-reconfig-stats	Statistics pertaining to each neighbor with configured policy and soft reconfiguration settings.

show bgp summary nsr

To display the summary of Border Gateway Protocol (BGP) neighbor state and nonstop routing (NSR) state information, use the **show bgp summary nsr** command in EXEC mode and XR EXEC mode.

```
show bgp summary [ipv4 {unicast | multicast | labeled-unicast | all | tunnel | mdt} | ipv6 {unicast
| multicast | all | labeled-unicast} | all {unicast | multicast | all | labeled-unicast | mdt | tunnel} | vpnv4
unicast | vrf {vrf-name | all} [ipv4 {unicast | labeled-unicast} | ipv6 unicast] | vpnv6 unicast] nsr
[standby]
```

Syntax Description		
ipv4	(Optional) Specifies IP Version 4 address prefixes.	
unicast	(Optional) Specifies unicast address prefixes.	
multicast	(Optional) Specifies multicast address prefixes.	
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.	
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.	
tunnel	(Optional) Specifies tunnel address prefixes.	
mdt	(Optional) Specifies multicast distribution tree (MDT) address prefixes.	
multicast	(Optional) Specifies multicast address prefixes.	
ipv6	(Optional) Specifies IP Version 6 address prefixes.	
all	(Optional) For address family, specifies prefixes for all address families.	
vpnv4 unicast	(Optional) Specifies VPNv4 unicast address families.	
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.	
<i>vrf-name</i>	(Optional) Name of a VRF.	
all	(Optional) For VRF, specifies all VRFs.	
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.	
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.	
vpnv6 unicast	(Optional) Specifies VPNv6 unicast address families.	
standby	Displays information about the standby card.	

Command Default If no address family or subaddress family is specified, the default address family and subaddress family specified using the **set default-afi** and **set default-safi** commands are used.

Command Modes

EXEC mode and XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Examples

The following is sample output from the **show bgp summary nsr** command:

```
Router# show bgp summary nsr
```

```
BGP router identifier 10.1.0.1, local AS number 100
BGP generic scan interval 60 secs
Non-stop routing is enabled
BGP table state: Active
Table ID: 0xe0000000
BGP main routing table version 13037
BGP NSR Initial initsync version 11034 (Reached)
BGP scan interval 60 secs
```

BGP is operating in STANDALONE mode.

```
node0_1_CPU0          Speaker
```

```
Entered mode Standby Ready           : Feb  3 14:22:00
Entered mode TCP NSR Setup            : Feb  3 14:22:00
Entered mode TCP NSR Setup Done       : Feb  3 14:22:01
Entered mode TCP Initial Sync         : Feb  3 14:22:01
Entered mode TCP Initial Sync Done    : Feb  3 14:22:44
Entered mode FPBSN processing done    : Feb  3 14:22:44
Entered mode Update processing done   : Feb  3 14:22:44
Entered mode BGP Initial Sync         : Feb  3 14:22:44
Entered mode BGP Initial Sync done    : Feb  3 14:22:49
Entered mode NSR Ready                : Feb  3 14:22:49
```

```
Current BGP NSR state - NSR Ready achieved at: Feb  3 14:22:49
NSR State READY notified to Redcon at: Feb  4 07:44:43
```

Process	RcvTblVer	bRIB/RIB	LabelVer	ImportVer	SendTblVer	StandbyVer
Speaker	13037	13037	13037	13037	13037	13037

Neighbor	Spk	AS	TblVer	SyncVer	AckVer	NBRState	NSRState
2.2.2.2	0	302	13037	13037	13037	Established	NSR Ready
10.0.101.5	0	100	13037	13037	13037	Established	NSR Ready

The following example shows sample output from the **show bgp summary nsr** command with the **standby** keyword:

```
Router# show bgp summary nsr standby
```

```
BGP router identifier 10.1.0.1, local AS number 100
BGP generic scan interval 60 secs
Non-stop routing is enabled
BGP table state: Active
Table ID: 0xe0000000
BGP main routing table version 13037
BGP NSR Initial initsync version 0 (Not Reached)
```

```
BGP scan interval 60 secs
```

```
BGP is operating in STANDALONE mode.
```

```
node0_0_CPU0      Speaker
```

```
Entered mode Standby Ready      : Feb  3 14:22:03
Entered mode TCP Replication    : Feb  3 14:22:03
Entered mode TCP Init Sync Done : Feb  3 14:22:47
Entered mode NSR Ready          : Feb  3 14:22:52
```

```
Process      RcvTblVer  bRIB/RIB  LabelVer  ImportVer  SendTblVer  StandbyVer
Speaker      13037      0         0         13037      0           0
```

```
Neighbor      Spk      AS      TblVer  SyncVer  AckVer  NBRState      NSRState
2.2.2.2        0      302    13037    0        1  Established  NSR Ready
10.0.101.5     0      100    13037    0        1  Established  NSR Ready
```

This table describes the significant fields shown in the display.

Table 46: show bgp summary nsr Field Descriptions

Field	Description
BGP router identifier	IP address of the router.
BGP generic scan interval	Interval (in seconds) between scans of the BGP table by a generic scanner.
Non-stop routing	State of the Nonstop routing.
BGP table state	State of the BGP database.
Table ID	BGP database identifier.
BGP main routing table version	Last version of the BGP database that was injected into the main routing table.
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.
BGP is operating in	Specifies BGP is operating in standalone mode.
Entered mode	The successive transition of various states of TCP and BGP, leading to the NSR ready state. Note This is used for monitoring and debugging purposes.
SyncVer	The version which has synced to standby for this neighbor.
AckVer	The version which the neighbor has acknowledge.
NBRState	State of the BGP neighbor.
NSRState	Neighbor NSR state.

Related Commands

Command	Description
nsr (BGP), on page 164	Activates Border Gateway Protocol (BGP) nonstop routing (NSR)
show bgp nsr, on page 365	Displays Border Gateway Protocol (BGP) nonstop routing (NSR) information.

show bgp table

To display the status of all Border Gateway Protocol (BGP) neighbors for a particular Address Family (AF) in the global address table, use the **show bgp table** command in EXEC mode and XR EXEC mode.

show bgp table [**ipv4** {**mdt** | **multicast** | **mvpn** | **rt-filter** | **tunnel** | **unicast**} | **ipv6** {**multicast** | **mvpn** | **unicast**} | **l2vpn** {**evpn** | **vpls** | **vpws**} | **standby** | **vpn****v4** **unicast** | **vpn****v6** **unicast**]

Syntax Description	
ipv4 mdt	(Optional) Specifies IPv4 multicast distribution tree (MDT) neighbors.
ipv4 multicast	(Optional) Specifies IPv4 multicast neighbors.
ipv4 mvpn	(Optional) Specifies the IPv4 mvpn address family neighbors.
ipv4 rt-filter	(Optional) Specifies the IPv4 RT Constraint address family neighbors.
ipv4 tunnel	(Optional) Specifies IPv4 tunnel neighbors.
ipv6 unicast	(Optional) Specifies IP Version 6 (IPv6) unicast neighbors.
ipv6 multicast	(Optional) Specifies IPv6 multicast neighbors.
ipv6 mvpn	(Optional) Specifies the IPv6 mvpn address family neighbors.
ipv6 unicast	(Optional) Specifies the IPv6 Tunnel address family neighbors.
l2vpn evpn	(Optional) Specifies the L2VPN EVPN address family neighbors.
l2vpn vpls	(Optional) Specifies the L2VPN VPLS address family neighbors.
l2vpn vpws	(Optional) Specifies the L2VPN VPWS address family neighbors.
standby	(Optional) Specifies the IPv4 Unicast address family neighbor on the standby processor.
vpn v4 unicast	(Optional) Specifies VPN Version 4 (VPNv4) unicast address family neighbors.
vpn v6 unicast	(Optional) Specifies VPN Version 6 (VPNv6) unicast address family neighbors.

Command Default If no address family or subaddress family is specified, the default address family and subaddress family specified using the **set default-afi** and **set default-safi** commands are used.

Command Modes EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See *BGP Configuration Guide for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set**

default-safi commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

Use the **show bgp table** command to display a brief summary of the neighbors for which the specified address family (AFI) and subaddress family (SAFI) are enabled. If the AFI and/or SAFI is not enabled, the command will only display the column headings.

Examples

The following is sample output from the **show bgp table vpnv4 unicast** command in EXEC mode and XR EXEC mode:

```
Router# show bgp table vpnv4 unicast
Thu Jan 15 17:43:31.215 UTC
Neighbor      VRF          Spk    AS    TblVer  InQ  OutQ  St/PfxRcd
10.0.101.1    default      0      1     951    0    0      11
10.0.101.2    default      0      1     951    0    0       5
10.0.101.3    default      0      1     951    0    0       0
10.0.101.4    default      0      1     951    0    0       0
10.0.101.5    default      0      1     951    0    0       0
10.0.101.6    default      0      1     951    0    0       0
10.0.101.7    default      0      1     951    0    0       0
10.0.101.8    default      0      1     951    0    0       0
10.0.101.9    default      0      1     951    0    0       0
90.0.0.2      900          0      2     951    0    0       1
91.0.0.2      901          0      2     951    0    0       1
92.0.0.2      902          0      2     951    0    0       1
93.0.0.2      903          0      2     951    0    0       3
94.0.0.2      904          0      2     951    0    0       3
95.0.0.2      905          0      2     951    0    0       3
96.0.0.2      906          0      2     951    0    0       3
97.0.0.2      907          0      2     951    0    0       3
98.0.0.2      908          0      2     951    0    0       3
99.0.0.2      909          0      2       0    0    0 Idle
12.13.14.16   red          0      2       0    0    0 Idle
20.0.101.1    red          0      2       0    0    0 Active
1.2.3.4       this-is-a-long-vrf-name
                                0      5       0    0    0 Idle
```

This table describes the significant fields shown in the display.

Table 47: show bgp table Field Descriptions

Field	Description
Neighbor	IP address of a neighbor.
VRF	The VRF which each neighbor belongs to; either the default VRF or a specified VRF.
Spk	Speaker process that is responsible for the neighbor. Always 0.
AS	Autonomous system.
TblVer	Last version of the BGP database that was sent to a neighbor.
InQ	Number of messages from a neighbor waiting to be processed.
OutQ	Number of messages waiting to be sent to a neighbor.

Field	Description
St/PfxRcd	If the BGP session is not established, the current state of the session. If the session is established, the number of prefixes the router has received from the neighbor. If the number of prefixes received exceeds the maximum allowed (as set by the maximum-prefix command), “(PfxRcd)” appears. If the connection has been shut down using the shutdown command, “(Admin)” appears. If the neighbor is external and it does not have an inbound and outbound policy configured for every address family, an exclamation mark (!) is inserted at the end of the state when using the route-policy (BGP) command. If the connection has been shut down due to out of memory (OOM), “(OOM)” appears.

Related Commands

Command	Description
show bgp neighbor-group	Displays information about the Border Gateway Protocol (BGP) configuration for neighbor groups.
show bgp neighbors	Displays information about Border Gateway Protocol (BGP) connections to neighbors.
show bgp summary	Displays the status of all Border Gateway Protocol (BGP) connections.

show bgp truncated-communities

To display routes in the Border Gateway Protocol (BGP) routing table for which inbound policy or aggregation has exceeded the maximum number of communities that may be attached, use the **show bgp truncated-communities** command in EXEC mode and XR EXEC mode.

show bgp truncated-communities **standby**

Syntax Description	
ipv4	(Optional) Specifies IP Version 4 address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
all	(Optional) For subaddress families, specifies prefixes for all subaddress families.
tunnel	(Optional) Specifies tunnel address prefixes.
mdt	(Optional) Specifies multicast distribution tree (MDT) address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
all	(Optional) For address family, specifies prefixes for all address families.
vpnv4 unicast	(Optional) Specifies VPNv4 unicast address families.
rd <i>rd-address</i>	(Optional) Displays routes with a specific route distinguisher.
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
<i>vrf-name</i>	(Optional) Name of a VRF.
all	(Optional) For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.
vpnv6 unicast	(Optional) Specifies VPNv6 unicast address families.
standby	(Optional) Displays information about the standby card.
Command Default	If no address family or subaddress family is specified, the default address family and subaddress family specified using the set default-afi and set default-safi commands are used.
Command Modes	EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines The **set default-afi** command is used to specify the default address family for the session, and the **set default-safi** command is used to specify the default subaddress family for the session. See the *System Management Command Reference for Cisco 8000 Series Routers* for detailed information and syntax for the **set default-afi** and **set default-safi** commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

BGP contains a separate routing table for each address family and subaddress family combination that has been configured. The address family and subaddress family options specify the routing table to be examined. If the **all** keyword is specified for the address family or subaddress family, each matching routing table is examined.

Use the **show bgp truncated-communities** command to display those routes in the specified BGP routing table in which the buffers used to store communities or extended communities have overflowed. An overflow occurs if an attempt is made to associate more communities or extended communities with the route than fits in a BGP update message. This can happen due to modification of communities or extended communities during aggregation or when inbound policy is applied.

Examples

The following is sample output from the **show bgp truncated-communities** command:

```
Router# show bgp truncated-communities

BGP router identifier 172.20.1.1, local AS number 1820
BGP main routing table version 3042
BGP scan interval 60 secs
Status codes: s suppressed, d damped, h history, * valid, > best
               i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network        Next Hop           Metric LocPrf Weight Path
*  10.13.0.0/16    192.168.40.24                      0 1878 704 701 200 ?
*> 10.16.0.0/16    192.168.40.24                      0 1878 704 701 i
```

This table describes the significant fields shown in the display.

Table 48: show bgp truncated-communities Field Descriptions

Field	Description
BGP router identifier	BGP Identifier for the local system.
local AS number	Autonomous system number for the local system.
BGP main routing table version	Last version of the BGP database that was installed into the main routing table.
Dampening enabled	Displayed if dampening is enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.

Field	Description
Status codes	Status of the table entry. The status is displayed as a three-character field at the beginning of each line in the table. The first character may be (in order of precedence): S—Path is stale, indicating that a graceful restart is in progress with the peer from which the route was learned. s—Path is more specific than a locally sourced aggregate route and has been suppressed. *—Path is valid. The second character may be (in order of precedence): >—Path is the best path to use for that network. d—Path is dampened. h—Path is a history entry, representing a route that is currently withdrawn, but that is being maintained to preserve dampening information. Such routes should never be marked as valid. The third character may be: i—Path was learned by an internal BGP (iBGP) session.
Origin codes	Origin of the path. The origin code is displayed at the end of each line in the table. It can be one of the following values: i—Path originated from an Interior Gateway Protocol (IGP) and was advertised with a network or aggregate-address command. e—Path originated from an Exterior Gateway Protocol (EGP). ?—Origin of the path is not clear. Usually, this is a route that is redistributed into BGP from an IGP.
Network	IP prefix and prefix length for a network.
Next Hop	IP address of the next system that is used when a packet is forwarded to the destination network. An entry of 0.0.0.0 indicates that the router has a non-BGP route to this network.
Metric	Value of the interautonomous system metric, otherwise known as the Multi Exit Discriminator (MED) metric.
LocPrf	Local preference value. This is used to determine the preferred exit point from the local autonomous system. It is propagated throughout the local autonomous system.
Weight	Path weight. Weight is used in choosing the preferred path to a route. It is not advertised to any neighbor.
Path	Autonomous system path to the destination network. At the end of the path is the origin code for the path.

show bgp update-group

To display Border Gateway Protocol (BGP) information for update groups, use the **show bgp update-group** command in EXEC mode and XR EXEC mode.

```
show bgp [ipv4 {unicast | multicast | labeled-unicast | all | tunnel | mdt} | ipv6 {unicast | multicast | all | labeled-unicast} | all {unicast | multicast | all | labeled-unicast | mdt | tunnel} | vpnv4 unicast | vrf {vrf-name | all} [ipv4 {unicast | labeled-unicast} | ipv6 unicast] | vpnv6 unicast] update-group [neighbor ip-address | process-id . index [summary | performance-statistics]]
```

Syntax	Description
ipv4	(Optional) Specifies IP Version 4 update groups.
unicast	(Optional) Specifies unicast update groups.
multicast	(Optional) Specifies multicast update groups.
labeled-unicast	(Optional) Specifies labeled unicast address prefixes.
all	(Optional) Displays both unicast and multicast update groups.
tunnel	(Optional) Specifies tunnel address prefixes.
ipv6	(Optional) Specifies IP Version 6 update groups.
all	(Optional) Displays both IP Version 4 and IP Version 6 update groups.
vpnv4 unicast	(Optional) Specifies VPNv4 unicast address families.
rd <i>rd-address</i>	(Optional) Displays routes with a specific route distinguisher.
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
<i>vrf-name</i>	(Optional) Name of a VRF.
all	(Optional) For VRF, specifies all VRFs.
ipv4 { unicast labeled-unicast }	(Optional) For VRF, specifies IPv4 unicast or labeled-unicast address families.
ipv6 unicast	(Optional) For VRF, specifies IPv6 unicast address families.
neighbor <i>ip-address</i>	(Optional) Specifies information on an update group for a specific neighbor.
<i>process-id.index</i>	(Optional) Update group index. Process ID range is 0 to 254. Index range is 0 to 4294967295. The <i>process id.index</i> argument is specified as follows: process ID (dot) index. In standalone mode, the process ID is always 0.
summary	(Optional) Specifies summary of update group members.

performance-statistics	(Optional) Specifies performance information about the updates generated for the update group.

Command Default	If no address family or subaddress family is specified, the default address family and subaddress family specified using the set default-afi and set default-safi commands are used.

Command Modes	EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	The set default-afi command is used to specify the default address family for the session, and the set default-safi command is used to specify the default subaddress family for the session. See the <i>System Management Command Reference for Cisco 8000 Series Routers</i> for detailed information and syntax for the set default-afi and set default-safi commands. If you do not specify a default address family, the default address family is IPv4. If you do not specify a default subaddress family, the default subaddress family is unicast.

Every BGP neighbor is automatically assigned to an update group for each address family that is enabled on the neighbor. Neighbors that have similar outbound policy, such that they are sent the same updates, are placed in the same update group.

Use the **show bgp update-group** command to display the update groups and a list of the neighbors that belong to the update group.

Use the **show bgp update-group neighbor** command to display details about the update group to which a neighbor belongs for the specified address family.

Use the **summary** keyword to display a summary of the neighbors belonging to the specified update group. The display format is the same as for the [show bgp summary](#) command.

Use the **performance-statistics** keyword to display information about the number of prefixes processed and the time taken to generate updates for the specified update group.



Note	Update group indexes are not necessarily persistent over a process restart. If a BGP process restarts, the index of the update group to which a particular neighbor is assigned may be different, though the set of neighbors belonging to the update group is the same.

Examples

The following is sample output from the **show bgp update-group** command:

```
Router# show bgp update-group

Update group for IPv4 Unicast, index 0.1:
Attributes:
  Internal
  Common admin
  Send communities
  Send extended communities
  Minimum advertisement interval: 300
Update group desynchronized: 0
```

```

Sub-groups merged: 0
Messages formatted: 0, replicated: 0
Neighbors not in any sub-group:
  10.0.101.1

```

This table describes the significant fields shown in the display.

Table 49: show bgp update-group Field Descriptions

Field	Description
Update group for	Address family to which updates in this update group apply.
index	Update group index.
Attributes	Attributes common to all members of the update group.
Unsuppress map	Unsuppress route map used to selectively unsuppress more specific routes of locally generated aggregates for members of this update group.
Outbound policy	Route policy applied to outbound updates generated for members of this update group.
Internal	Members of the update group are internal peers.
ORF Receive enabled	Members of this update group are capable of receiving an outbound route filter.
Route Reflector Client	Local system is acting as a route reflector for members of this update group.
Remove private AS numbers	Members of this update group have private AS numbers stripped from outbound updates.
Next-hop-self enabled	Next- Next hop for members of the update group is set to the local router.
Directly connected IPv6 EBGp	Members of this update group are directly connected external BGP IPv6-based peers.
Configured Local AS	Local autonomous system (AS) used for members of this update group.
Common admin	Peers in this update group are under common administration (internal or confederation peers).
Send communities	Communities are sent to neighbors in this update group.
Send extended communities	Extended communities is sent to neighbors in this update group.
Minimum advertisement interval	Minimum advertisement interval for members of this update group.
replicated	Number of update messages replicated for this update group.
Messages formatted	Number of update messages generated for this update group.
Neighbors in this update group	List of neighbors that use this update group for the given address family.

Field	Description
Update group desynchronized	Number of times an update group has been split to accommodate the slower peer. This option is disabled.
Sub-groups merged	Number of times an update group has been split and merged.
Neighbors not in any sub-group	BGP neighbor that does not belong to any subgroup.

The following is sample output from the **show bgp update-group** command with the **ipv4**, **unicast**, and **summary** keywords and the *process id.index* argument:

```
Router# show bgp ipv4 unicast update-group 0.1 summary

BGP router identifier 10.140.140.1, local AS number 1.1
BGP generic scan interval 60 secs
BGP table state: Active
Table ID: 0xe0000000
BGP main routing table version 1
BGP scan interval 60 secs

BGP is operating in STANDALONE mode.

Process          RecvTblVer    bRIB/RIB  LabelVer  ImportVer  SendTblVer
Speaker          1             0          1          1           0

Neighbor         Spr    AS MsgRcvd MsgSent   TblVer  InQ  OutQ  Up/Down  St/PfxRcd
172.25.11.8      0      1      0      0        0    0    0 00:00:00 Idle
```

This is sample output from the **show bgp ipv4 unicast update-group** command showing the status of advertised permanent paths:

```
Router# show bgp ipv4 unicast update-group
Update group for IPv4 Unicast, index 0.2:
Attributes:
  Neighbor sessions are IPv4
  Outbound policy: PASS
  Internal
  Common admin
  First neighbor AS: 30813
  Send communities
  Send extended communities
  Next-hop-self enabled
  4-byte AS capable
  Non-labeled address-family capable
  Advertise Permanent-Network capable
  Send AIGP
  Minimum advertisement interval: 0 secs
Update group desynchronized: 0
Sub-groups merged: 4
Number of refresh subgroups: 0
Messages formatted: 42, replicated: 68
Neighbors not in any sub-group:
  100.12.13.3    100.13.13.3
```


This table describes the significant fields shown in the display.

Table 50: show bgp ipv4 unicast update-group Field Descriptions

Field	Description
BGP router identifier	IP address of the router.
local AS number	Autonomous system number set by the router bgp, on page 193 command. • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535.
BGP generic scan interval	Interval (in seconds) between scans of the BGP table by a generic scanner.
BGP table state	State of the BGP database.
Table ID	BGP database identifier.
BGP main routing table version	Last version of the BGP database that was injected into the main routing table.
Dampening enabled	Displayed if dampening has been enabled for the routes in this BGP routing table.
BGP scan interval	Interval (in seconds) between scans of the BGP table specified by the address family and subaddress family.
BGP is operating in	BGP is operating in standalone mode.
Process	BGP process.
RecvTblVer	Last version used in the BGP database for received routes.
bRIB/RIB	Last version of the local BGP database that was injected into the main routing table.
LabelVer	Label version used in the BGP database for label allocation.
ImportVer	Last version of the local BGP database for importing routes.
SendTblVer	Latest version of the local BGP database that is ready to be advertised to neighbors.
Some configured eBGP neighbors do not have any policy	Some external neighbors that exist do not have both an inbound and outbound policy configured for every address family, using the route-policy (BGP) command. In this case, no prefixes are accepted or advertised to those neighbors.
Neighbor	IP address of a neighbor.

Field	Description
Spr	Speaker process that is responsible for the neighbor. Always 0.
AS	Autonomous system.
MsgRcvd	Number of BGP messages received from a neighbor.
MsgSent	Number of BGP messages sent to a neighbor.
TblVer	Last version of the BGP database that was sent to a neighbor.
InQ	Number of messages from a neighbor waiting to be processed.
OutQ	Number of messages waiting to be sent to a neighbor.
Up/Down	Length of time (in hh:mm:s) that the BGP session has been in Established state, or the time since the session left Established state, if it is not established.
St/PfxRcd	If the BGP session is not established, the current state of the session. If the session is established, the number of prefixes the router has received from the neighbor. If the number of prefixes received exceeds the maximum allowed (as set by the maximum-prefix command), “(PfxRcd)” appears. If the connection has been shut down using the shutdown command, “(Admin)” appears. If the neighbor is external and it does not have an inbound and outbound policy configured for every address family, an exclamation mark (!) is inserted at the end of the state when using the route-policy (BGP) command.

show bgp vrf

To display Border Gateway Protocol (BGP) prefix information for VPN routing and forwarding (VRF) instances, use the **show bgp vrf** command in EXEC mode and XR EXEC mode.

```
show bgp vrf { all vrf-name } { process | rpki refresh-list } { ipv4 { unicast [ ipv4-address/length [ detail ] ] | labeled-unicast } | ipv6 { unicast } | imported-routes { neighbor | standby | vrf vrf-name } }
```

Syntax Description		
<i>vrf-name</i>	Displays imported routes for a specific VRF.	
all	Displays imported routes for all VRFs.	
ipv4 { unicast labeled-unicast }	(Optional) Specifies IP Version 4 unicast or labeled-unicast imported routes.	
ipv6 unicast	(Optional) Specifies IP Version 6 unicast imported routes.	
vrf <i>source-vrf-name</i>	(Optional) Displays routes imported from the specified source VRF.	
neighbor <i>neighbor-address</i>	(Optional) Displays preview advertisements for a specified neighbor.	
standby	(Optional) Displays information about the standby card.	
process	Displays process information.	
rpki <i>refresh-list</i>	Displays BGP Resource Public Key Infrastructure (RPKI) information.	
Command Default	No default behavior or values	
Command Modes	EXEC mode and XR EXEC mode	
Command History	Release	Modification
	Release 24.1.1	The show outputs of the following commands are modified to capture changes related to the per-vrf-46 label mode: • show bgp vrf INET ipv4 unicast process • show bgp vrf INET ipv6 unicast process • show bgp vrf INET ipv4 unicast labels • show bgp vrf INET ipv6 unicast labels

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **show bgp vrf imported-routes** command to display all paths imported into a specified VRF from the default VRF. Use the **neighbor** *neighbor-address* keyword and argument to display all imported paths and which paths were learned from the specified neighbor. Use the **vrf** *source-vrf-name* keyword and argument to display all imported routes that belong to the specified source VRF. The **neighbor** *neighbor-address* and **vrf** *source-vrf-name* cannot coexist.

Examples

The following is sample output from the **show bgp vrf imported-routes** command:

```
Router# show bgp vrf vrf-1 ipv6 unicast imported-routes

BGP VRF one, state: Active BGP
BGP Route Distinguisher: 100:222
VRF ID: 0x60000001
BGP router identifier 10.2.0.1, local AS number 65550
BGP table state: Active
Table ID: 0xe0800001
BGP main routing table version 41534

Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, S stale
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network          Neighbor      Route Distinguisher   Source VRF
*>i1234:1052::/32    10.1.0.1        100:111                default
*>i2008:1:1:1::/112  10.1.0.1        100:111                default
*>i2008:111:1:1::/128
                    10.1.0.1        100:111                default

Processed 3 prefixes, 3 paths
```

The following is sample output from the **show bgp vrf vrf-name ipv4 unicast ipv4-address/length detail** command.

```
Router# show bgp vrf foo ipv4 unicast 100.1.1.1/32 detail

Mon Dec  8 23:24:50.243 PST
BGP routing table entry for 100.1.1.1/32, Route Distinguisher:
30.30.30.30:0
Versions:
  Process          bRIB/RIB  SendTblVer
  Speaker          43        43
    Local Label: 24001 (with rewrite);
    Flags: 0x05081001+0x00000200;
Last Modified: Dec  8 18:04:21.000 for 05:20:30
Paths: (1 available, best #1)
  Advertised to PE peers (in unique update groups):
    32.0.0.2
  Path #1: Received by speaker 0
  Flags: 0x400061000d060005, import: 0x80
  Advertised to PE peers (in unique update groups):
    32.0.0.2
  Local
    192.0.2.1 (metric 2) from 198.51.100.1 (192.0.2.1)
    Received Label 1234
    Origin IGP, localpref 100, valid, internal, best, group-best, import-candidate,
```

```

imported, reoriginated
    Received Path ID 0, Local Path ID 1, version 43
    Extended community: Encapsulation Type:8 Router MAC:aabb.ccdd.eeff RT:1:2
    Originator: 11.0.0.1, Cluster list: 20.20.20.20
    RIB RNH: table_id 0xe0000011, Encap 8, VNI 1234, MAC Address: aabb.ccdd.eeff, IP
Address: 11.0.0.1, IP table_id 0xe0000000
    Source AFI: L2VPN EVPN, Source VRF: default, Source Route
Distinguisher: 100:1

```

The following is sample output from the **show bgp vrf vrf-name ipv4 unicast ipv4-address/length process** command.

```
Router# show bgp vrf INET ipv4 unicast process
```

```
Wed Dec 20 03:51:13.504 UTC
```

```
BGP Process Information: VRF INET
BGP Route Distinguisher: 600:600
```

```

BGP is operating in STANDALONE mode
Autonomous System number format: ASPLAIN
Autonomous System: 65550
Router ID: 2.2.2.2
Default Cluster ID: 2.2.2.2
Active Cluster IDs: 2.2.2.2
Fast external fallover enabled
Platform Loadbalance paths max: 1024
Platform RLIMIT max: 8589934592 bytes
Maximum limit for BMP buffer size: 1638 MB
Default value for BMP buffer size: 1228 MB
Current limit for BMP buffer size: 1228 MB
Current utilization of BMP buffer limit: 0 B
Neighbor logging is enabled
Enforce first AS enabled
iBGP to IGP redistribution enabled
Use SR-Policy admin/metric of color-extcomm Nexthop during path comparison: disabled
Default local preference: 100
Default keepalive: 60
Graceful restart enabled
Restart time: 120
Stale path timeout time: 360
RIB purge timeout time: 600
Non-stop routing is enabled

```

```

ExtComm Color Nexthop validation: RIB
Update delay: 120
Generic scan interval: 60
Configured Segment-routing Local Block: [0, 0]
In use Segment-routing Local Block: [15000, 15999]
Platform support mix of sr-policy and native nexthop: No

```

```

VRF INET Address family: IPv4 Unicast
Dampening is not enabled
Client reflection is not enabled in global config
Dynamic MED is Disabled
Dynamic MED interval : 10 minutes
Dynamic MED Timer : Not Running
Dynamic MED Periodic Timer : Not Running
Scan interval: 60
Total prefixes scanned: 7
Prefixes scanned per segment: 100000

```

```

Number of scan segments: 1
Nexthop resolution minimum prefix-length: 0 (not configured)
IPv6 Nexthop resolution minimum prefix-length: 0 (not configured)
Main Table Version: 40540
Table version synced to RIB: 40540
Table version acked by RIB: 40540
IGP notification: IGP notified
RIB has converged: version 2
RIB table prefix-limit reached ? [No], version 0
Permanent Network Unconfigured
Label alloc mode: per-vrf-46
BGP NSR scoped sync stats:
  Scoped Sync last msg failed: 0
  Scoped Sync last msg resumed: 0
  Scoped Sync default route stopped: 0
  Scoped Sync default route resumed: 0
  Scoped Sync default route lookup failure: 0

```

OC-RIB Telemetry Neighbor Outbound Attributes Pool summary:

	Alloc	Free
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0

Number of Paths having particular number of OCRIB out attributes:

	Paths
1 Out Attrs:	340127644

Node	Process	Nbrs	Estb	Rst	Upd-Rcvd	Upd-Sent	Nfn-Rcv	Nfn-Snt
node0_RP0_CPU0	Speaker	1	1	2	1	31	0	0

The following is sample output from the **show bgp vrf vrf-name ipv6 unicast ipv6-address/length process** command.

Router# **show bgp vrf INET ipv6 unicast process**

Wed Dec 20 03:51:53.031 UTC

BGP Process Information: VRF INET
 BGP Route Distinguisher: 600:600

BGP is operating in STANDALONE mode
 Autonomous System number format: ASPLAIN
 Autonomous System: 65550
 Router ID: 2.2.2.2
 Default Cluster ID: 2.2.2.2
 Active Cluster IDs: 2.2.2.2
 Fast external fallover enabled
 Platform Loadbalance paths max: 1024
 Platform RLIMIT max: 8589934592 bytes
 Maximum limit for BMP buffer size: 1638 MB
 Default value for BMP buffer size: 1228 MB
 Current limit for BMP buffer size: 1228 MB
 Current utilization of BMP buffer limit: 0 B
 Neighbor logging is enabled

```

Enforce first AS enabled
iBGP to IGP redistribution enabled
Use SR-Policy admin/metric of color-extcomm Nexthop during path comparison: disabled
Default local preference: 100
Default keepalive: 60
Graceful restart enabled
Restart time: 120
Stale path timeout time: 360
RIB purge timeout time: 600
Non-stop routing is enabled

```

```

ExtComm Color Nexthop validation: RIB
Update delay: 120
Generic scan interval: 60
Configured Segment-routing Local Block: [0, 0]
In use Segment-routing Local Block: [15000, 15999]
Platform support mix of sr-policy and native nexthop: No

```

```

VRF INET Address family: IPv6 Unicast
Dampening is not enabled
Client reflection is not enabled in global config
Dynamic MED is Disabled
Dynamic MED interval : 10 minutes
Dynamic MED Timer : Not Running
Dynamic MED Periodic Timer : Not Running
Scan interval: 60
Total prefixes scanned: 6
Prefixes scanned per segment: 100000
Number of scan segments: 1
Nexthop resolution minimum prefix-length: 0 (not configured)
IPv6 Nexthop resolution minimum prefix-length: 0 (not configured)
Main Table Version: 34
Table version synced to RIB: 34
Table version acked by RIB: 34
RIB has converged: version 2
RIB table prefix-limit reached ? [No], version 0
Permanent Network Unconfigured
Label alloc mode: per-vrf-46
BGP NSR scoped sync stats:
    Scoped Sync last msg failed: 0
    Scoped Sync last msg resumed: 0
    Scoped Sync default route stopped: 0
    Scoped Sync default route resumed: 0
    Scoped Sync default route lookup failure: 0

```

OC-RIB Telemetry Neighbor Outbound Attributes Pool summary:

	Alloc	Free
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0
Pool 0:	0	0

Number of Paths having particular number of OCRIB out attributes:
Paths

Node	Process	Nbrs	Estb	Rst	Upd-Rcvd	Upd-Sent	Nfn-Rcv	Nfn-Snt
node0_RP0_CPU0	Speaker	1	1	2	1			

The following is sample output from the **show bgp vrf vrf-name ipv4 unicast ipv4-address/length label** command.

```
Router# show bgp vrf INET ipv4 unicast labels

Wed Dec 20 03:52:23.194 UTC
BGP VRF INET, state: Active
BGP Route Distinguisher: 600:600
VRF ID: 0x60000001
BGP router identifier 2.2.2.2, local AS number 65550
Non-stop routing is enabled
BGP table state: Active
Table ID: 0xe0000001 RD version: 40540
BGP table nexthop route policy:
BGP main routing table version 40540
BGP NSR Initial initsync version 12 (Reached)
BGP NSR/ISSU Sync-Group versions 0/0

Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, r RIB-failure, S stale, N Nexthop-discard
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network                Next Hop                Rcvd Label        Local Label
Route Distinguisher: 600:600 (default for vrf INET)
Route Distinguisher Version: 40540
*> 2.2.1.2/32              0.0.0.0                nolabel           24100
*>i5.5.6.5/32              5.5.5.5                24200             nolabel
*> 90.0.0.1/32             200.1.1.2              nolabel           24100
*>i160.1.1.0/24            5.5.5.5                24200             nolabel
*> 200.1.1.0/24            0.0.0.0                nolabel           24100

Processed 5 prefixes, 5 paths
```

The following is sample output from the **show bgp vrf vrf-name ipv6 unicast ipv6-address/length label** command.

```
Router# show bgp vrf INET ipv6 unicast labels

Wed Dec 20 03:52:29.709 UTC
BGP VRF INET, state: Active
BGP Route Distinguisher: 600:600
VRF ID: 0x60000001
BGP router identifier 2.2.2.2, local AS number 65550
Non-stop routing is enabled
BGP table state: Active
Table ID: 0xe0800001 RD version: 34
BGP table nexthop route policy:
BGP main routing table version 34
BGP NSR Initial initsync version 12 (Reached)
BGP NSR/ISSU Sync-Group versions 0/0

Status codes: s suppressed, d damped, h history, * valid, > best
                i - internal, r RIB-failure, S stale, N Nexthop-discard
Origin codes: i - IGP, e - EGP, ? - incomplete
   Network                Next Hop                Rcvd Label        Local Label
Route Distinguisher: 600:600 (default for vrf INET)
Route Distinguisher Version: 34
*> 2:2:1::2/128            ::                      nolabel           24100
*>i5:5:6::5/128            5.5.5.5                24200             nolabel
*>i1600::1:1:0/112         5.5.5.5                24200             nolabel
*> 2000::1:1:0/112         ::                      nolabel           24100

Processed 4 prefixes, 4 paths
```


This table describes the significant fields shown in the display output for **show bgp vrf** command.

Table 51: show bgp vrf Field Descriptions

Field	Description
BGP VRF	VRF name.
state	State of the VRF.
BGP Route Distinguisher:	Unique identifier for the BGP routing instance.
VRF Id	VRF identifier.
BGP router identifier	IP address of the router.
local AS number	Autonomous system number set by the router bgp, on page 193 command. • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535.
BGP table state	State of the BGP database.
Table ID	Table identifier.
BGP main routing table version	Last version of the BGP database that was injected into the main routing table.
Network	Network address.
Neighbor	IP address of a neighbor.
Route Distinguisher	Unique identifier for the routing instance.
Source VRF	Source VRF for the imported route.

show lpts punt excessive-flow-trap bgp

To display the details of bad actor identified for bgp protocol, use the **show lpts punt excessive-flow-trap bgp** command in the Global Configuration mode and XR Config mode.

show lpts punt excessive-flow-trap bgp

Command Default	None				
Command Modes	Global Configuration mode and XR Config mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.0.12</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

Examples

This example shows to the details of bad actor identified for bgp protocol:

```
Router# show lpts punt excessive-flow-trap bgp
Parent Interface: GigabitEthernet0/2/0/19          Src MAC Addr: 0000.6505.0102

          Intf Handle: 0x08000580                  Location: 0/2/CPU0
          Protocol: BGP                            Punt Reason: BGP-mc-known

          Penalty Rate: 0 pps (all packets dropped)  Penalty Timeout: 15 mins

          Time Remaining: 10 mins 3 secs
```

show protocols (BGP)

To display information about the Border Gateway Protocol (BGP) instances running on the router, use the **show protocols** command in EXEC mode and XR EXEC mode and specify either the **bgp** or **all** keyword.

show protocols [**ipv4** | **ipv6** | **afi-all**] [**allprotocol**]

Syntax Description	ipv4	(Optional) Specifies the IP Version 4 address family.
	ipv6	(Optional) Specifies the IP Version 6 address family.
	afi-all	(Optional) Specifies all address families.
	all	(Optional) Specifies all protocols for a given address family.
	<i>protocol</i>	(Optional) Specifies a routing protocol. For the IPv4 address family, the options are bgp , isis , rip , and ospf . For the IPv6 address family, the options are bgp , isis , and ospfv3 .

Command Default Default is IPv4.

Command Modes EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines Use the **show protocols** command to get information about the protocols running on the router and to quickly determine which protocols are active. The command is designed to summarize the important characteristics of the running protocol, and command output varies depending on the specific protocol selected. For BGP, the command output lists the protocol ID, peers with elapsed time since last reset, and miscellaneous information, such as external and internal local distances and sourced routes.

Examples

The following example shows the display for the **show protocols** command using the **bgp** keyword:

```
Router# show protocols bgp

Routing Protocol "BGP 40"

Address Family IPv4 Unicast:
  Distance: external 20 internal 200 local 200
  Sourced Networks:
    10.100.0.0/16 backdoor
    10.100.1.0/24
    10.100.2.0/24
  Routing Information Sources:
    Neighbor      State/Last update received
    10.5.0.2      Idle
```

10.9.0.3

Idle

This table describes the significant fields shown in the display.

Table 52: show protocols (BGP) Field Descriptions

Field	Description
Routing Protocol:	Identifies BGP as the running protocol and displays the BGP AS number. • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) in asdot format is 1.0 to 65535.65535.
Address Family	Specifies the address family. This can be IPv4 Unicast, IPv4 Multicast, or IPv6 Unicast.
Distance: external	Specifies the distance BGP sets when installing eBGP routes into the RIB. eBGP routes are routes received from eBGP peers. The RIB uses the distance as a tiebreaker when several protocols install a route for the same prefix.
Distance: internal	Specifies the distance BGP sets for routes received from iBGP peers.
Distance: local	Specifies the distance BGP sets for locally generated aggregates and backdoor routes.
Sourced Networks	List of locally sourced networks. These are networks sourced using the network command.
Routing information Sources	List of configured BGP neighbors.
Neighbor	Address of a BGP neighbor.
State/Last update received	State of each neighbor and the time since the last update was received from the neighbor if it is established.

show svd role

To display selective VRF download (SVD) role information, use the **show svd role** command in EXEC mode and XR EXEC mode.

show svd role

Syntax Description	This command has no keywords or arguments.				
Command Default	None.				
Command Modes	EXEC mode and XR EXEC mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.0.12</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
Usage Guidelines	The show svd role command output displays name of the line card and role for each address-family in a table.				
Task ID	<table> <tr> <th>Task ID</th><th>Operation</th></tr> <tr> <td>ip-services</td><td>read</td></tr> </table>	Task ID	Operation	ip-services	read
Task ID	Operation				
ip-services	read				

This example displays the different nodes in a line card and corresponding IPv4, and IPv6 SVD role information:

```
Router#show svd role
Thu Mar 10 10:45:17.886 PST
Node Name      IPv4 Role      IPv6 Role
-----
0/1/CPU0       Core Facing    Not Interested
0/2/CPU0       Core Facing    Core Facing
0/4/CPU0       Standard       Standard
0/5/CPU0       Standard       Standard
```

show svd state

To display selective VRF download (SVD) state information, use the **show svd state** command in EXEC mode and XR EXEC mode.

show svd state

Syntax Description	This command has no keywords or arguments.

Command Modes	EXEC mode and XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.

This example shows the SVD configuration state and the SVD operational state in a line card:

```
Router#show svd state
Thu Mar 10 10:45:32.184 PST
Selective VRF Download (SVD) Feature State:
SVD Configuration State      Enabled
SVD Operational State        Enabled
```

shutdown (BGP)

To disable a neighbor without removing its configuration, use the **shutdown** command in an appropriate configuration mode. To re-enable the neighbor and reestablish a Border Gateway Protocol (BGP) session, use the **no** form of this command.

shutdown [**inheritance-disable**]

Syntax Description	inheritance-disable (Optional) Overrides the value of a shutdown command inherited from a neighbor group or session group.				
Command Default	Neighbors are not shutdown.				
Command Modes	Neighbor configuration VRF neighbor configuration Neighbor group configuration Session group configuration				
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 7.0.12</td><td>This command was introduced.</td></tr></table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
Usage Guidelines	Use the shutdown command to terminate any active session for the specified neighbor and remove all associated routing information. Use of the shutdown command with a neighbor group or session group may suddenly terminate a large number of BGP neighbor sessions because all neighbors using the neighbor group or session group may be affected. Use the show bgp summary command to display a summary of BGP neighbors. Neighbors that are idle due to the shutdown command are displayed with the “Idle (Admin)” state. If this command is configured for a neighbor group or session group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.				

Examples

The following example shows that any active session for neighbor 192.168.40.24 is disabled:

```
Router(config)# router bgp 1
Router(config-bgp)# neighbor 192.168.40.24
Router(config-bgp-nbr)# shutdown
Router(config-bgp-nbr)# exit
```

In the following example, the session remains active for neighbor 192.168.40.24 because the inherited **shutdown** command has been overridden:

```
Router(config)# router bgp 1
Router(config-bgp)# session-group group1
Router(config-bgp-sngrp)# shutdown
Router(config-bgp-sngrp)# exit
```

```
Router(config-bgp) # neighbor 192.168.40.24
Router(config-bgp-nbr) # remote-as 1
Router(config-bgp-nbr) # use session-group group1
Router(config-bgp-nbr) # shutdown inheritance-disable
Router(config-bgp-nbr) # exit
```


site-of-origin (BGP)

To attach a site-of-origin extended community attribute to each route received from the specified peer, use the **site-of-origin** command in VRF neighbor address family configuration mode. To restore the system to its default condition, use the **no** form of this command.

site-of-origin [*as-number:nn ip-address:nn*]

Syntax Description	<i>as-number:nn</i> • <i>as-number</i> - Autonomous system (AS) number. • <i>nn</i> - 32-bit number • Range for 2-byte Autonomous system number is 1 to 65535. • Range for 4-byte Autonomous system number in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system number is asdot format is 1.0 to 65535.6553. <i>ip-address:nn</i> IP address. • <i>ip-address</i> - 32-bit IP address • <i>nn</i> - 16-bit number.				
Command Default	No default behavior or values				
Command Modes	VRF neighbor address family configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	When routes are advertised to the peer, routes whose extended communities list contain the site of origin (SoO) are filtered out and not advertised to the peer. Site-of-origin uniquely identifies the site from which the provide edge (PE) router learned routes, thus filtering based on the extended community helps prevent transient routing loops from occurring in complex and mixed network topologies.				

Examples

The following example shows how to configure SoO filtering:

```
Router(config)# router bgp 6
Router(config-bgp)# vrf vrf_A
Router(config-bgp-vrf)# neighbor 192.168.70.24
Router(config-bgp-vrf-nbr)# remote-as 10
Router(config-bgp-vrf-nbr)# address-family ipv4 unicast
Router(config-bgp-vrf-nbr-af)# site-of-origin 10.0.01:20
```

slow peer (BGP router global configuration)

To enable BGP global slow peer configuration, use the **slow-peer** command in BGP router configuration mode. Enabling global slow peer configuration enables slow peer configuration for all (default VRF and non-default VRF) BGP neighbor address-families.

The default global slow peer mode is *detection-only*.

Use the **no** form of the command to return to the default slow peer configuration.

slow-peer {dynamic [threshold sec] | detection-disable}

Syntax Description	dynamic	Enables dynamic slow peer configuration on all (default VRF and non-default VRF) BGP neighbor address-families.
	threshold	(Optional) Threshold value (in seconds) used in detecting slow peer. Range is 120 to 3600. Default is 300.
	detection-disable	Disables detection-only slow peer configuration on all (default VRF and non-default VRF) BGP neighbor address-families.

Command Default

detection-only

threshold: 300

Command Modes BGP Router configuration mode

Command History	Release	Modification
	Release 7.9.1	This command was introduced.

Usage Guidelines You can enable slow peer configuration either by using global router configuration mode or by using neighbor address-families.

This section describes global slow peer configuration under router configuration. See below for the effective slow peer configuration when slow peer is configured under both global and neighbor address-families.

		Global configuration		
		[None]	[Dynamic]	[Detection disable]
Neighbor address-family configuration	[None]	Detection-only	Dynamic	None
	[Static]	Static	Static	Static
	[Dynamic]	Dynamic	Dynamic	Dynamic
	[Dynamic Disable]	Detection-only	None	None

Slow peer global configuration can be configured as *dynamic* or *detection-disable*. The default is *detection-only*.

When global slow peer configuration is not enabled, the default slow peer functionality is *detection-only*. It means all (default VRF and non-default VRF) BGP neighbor address-families are operating in *detection-only* mode. In *detection-only* mode of operation, whenever a neighbor address-family is detected as slow or recovers from being slow, an IOS message is displayed, but there will not be any mitigation to handle slow peers.

When slow peer global configuration is *detection-disable*, then slow peer processing is disabled on all (default VRF and non-default VRF) BGP neighbor address-families.

When the slow peer global configuration is *dynamic*, all VRF BGP neighbor address-families, default and non-default, operate as dynamic slow peers. In the *dynamic* slow peer mode of operation, whenever a neighbor address-family is detected as being slow, in addition to displaying an IOS message, the peer is moved to its own refresh sub-group without impacting other peers in the update-group or a sub-group.

Task ID	Task ID	Operation
	bgp	read, write

This example below shows how to enable dynamic slow peer on all (default VRF and non-default VRF) BGP neighbor address-families:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#slow-peer dynamic
Router(config-bgp)#commit
```

This example below shows how to disable slow peer on all (default VRF and non-default VRF) BGP neighbor address-families:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#slow-peer detection-disable
Router(config-bgp)#commit
```

This example below shows how to enable dynamic slow peer with detection threshold of 120 seconds on all (default VRF and non-default VRF) BGP neighbor address-families:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#slow-peer dynamic threshold 120
Router(config-bgp)#commit
```

slow peer (BGP neighbor address-family configuration)

To enable slow peer for a BGP neighbor address-family, use **slow-peer** command in neighbor address-family configuration mode.

By default, BGP neighbor address-family slow peer configuration is disabled.

Use the **no** form of the command to return to the default slow peer configuration.

slow-peer {static | dynamic [threshold seconds] | dynamic disable}

Syntax Description

static	Enables static slow peer configuration of a BGP neighbor address-family.
dynamic	Enables dynamic slow peer configuration of a BGP neighbor address-family.
threshold	(Optional) Threshold value (in seconds) used in detecting slow peer. Range is 120 to 3600. Default is 300. The detection logic is evaluated every scanner run whose default interval is 60 seconds.
dynamic disable	Disables dynamic slow peer configuration of a BGP neighbor address-family.

Command Default

threshold: 300

Command Modes

BGP Neighbor address-family configuration

BGP VRF Neighbor address-family configuration

Command History

Release	Modification
Release 7.9.1	This command was introduced.

Usage Guidelines

You can enable slow peer configuration either by using global router configuration mode or by using neighbor address-families.

This section describes slow peer configuration under neighbor address-family configuration. See below for the effective slow peer configuration state when slow peer is configured under both global and neighbor address-family.

-	Global configuration		
-	[None]	[Dynamic]	[Detection disable]

-		Global configuration		
Neighbor address-family configuration	[None]	Detection-only	Dynamic	None
	[Static]	Static	Static	Static
	[Dynamic]	Dynamic	Dynamic	Dynamic
	[Dynamic Disable]	Detection-only	None	None

Slow peer configuration under neighbor address-family can be configured as:

- *static*
- *dynamic*
- *dynamic disable*

When slow peer is not configured under neighbor address-family, slow peer handling is disabled for that BGP neighbor address-family.

When slow peer *static* is configured under a neighbor address-family, then that neighbor address-family is moved into its own unique update-group, thus isolating this neighbor address-family from other neighbors. If the user's intention is to group all the slow-peers into a single update group, it can be accomplished by removing static slow peer configuration and configuring the same neighbor out route-policy for all the neighbors.

When slow peer *dynamic* is configured under the neighbor address-family, that BGP neighbor address-family is enabled for dynamic slow peer processing. When the neighbor address-family is enabled for dynamic slow peer processing, whenever the neighbor address-family is detected as slow, the neighbor address-family is processed in its own refresh sub-group without affecting other neighbors in the sub-group, in addition to displaying an IOS message indicating the neighbor address-family has become slow.

When slow-peer *dynamic disable* is configured under the neighbor address-family, it disables the dynamic slow peer processing for that neighbor address-family if dynamic slow peer processing was enabled due to global slow peer *dynamic* configuration.

Task ID

Task ID Operation

bgp read,
write

This example below shows how to configure static slow peer for a (default VRF and non-default VRF) BGP neighbor address-family:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#neighbor 50.0.0.1
Router(config-bgp-nbr)#address-family ipv4 unicast
Router(config-bgp-nbr-af)#slow-peer static
Router(config-bgp-nbr-af)#commit
```

This example below shows how to disable slow peer for a (default VRF and non-default VRF) BGP neighbor address-family:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#neighbor 50.0.0.1
Router(config-bgp-nbr)#address-family ipv4 unicast
Router(config-bgp-nbr-af)#slow-peer dynamic disable
Router(config-bgp-nbr-af)#commit
```

This example below shows how to enable dynamic slow peer for a (default VRF and non-default VRF) BGP neighbor address-family:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#neighbor 50.0.0.1
Router(config-bgp-nbr)#address-family ipv4 unicast
Router(config-bgp-nbr-af)#slow-peer dynamic
Router(config-bgp-nbr-af)#commit
```

This example below shows how to enable dynamic slow peer with detection threshold of 120 seconds for a (default VRF and non-default VRF) BGP neighbor address-family:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#neighbor 50.0.0.1
Router(config-bgp-nbr)#address-family ipv4 unicast
Router(config-bgp-nbr-af)#slow-peer dynamic threshold 120
Router(config-bgp-nbr-af)#commit
```

soft-reconfiguration inbound

To configure the software to store updates received from a neighbor, use the **soft-reconfiguration inbound** command in an appropriate configuration mode. To disable storing received updates, use the **no** form of this command.

soft-reconfiguration inbound [**always** | **inheritance-disable**]
no soft-reconfiguration inbound [**always** | **inheritance-disable**]

Syntax Description	always (Optional) Always performs a soft inbound clear using stored updates, even if the neighbor supports the route refresh capability.
	inheritance-disable (Optional) Overrides configuration for this command that may be inherited from a neighbor group or address family group.

Command Default Soft reconfiguration is not enabled.

Command Modes

- IPv4 address family group configuration
- IPv6 address family group configuration
- IPv4 neighbor address family configuration
- IPv4 neighbor group address family configuration
- IPv6 neighbor group address family configuration

Command History	Release	Modification
	Release 6.0	This command was introduced.

Usage Guidelines

To filter or modify some of the updates received from a neighbor, you configure an inbound policy using the **route-policy (BGP)** command. Configuring soft reconfiguration inbound causes the software to store the original unmodified route beside a route that is modified or filtered. This allows a “soft clear” to be performed after the inbound policy is changed. To perform a soft clear, use the **clear bgp soft** command with the **in** keyword specified. The unmodified routes are then passed through the new policy and installed in the BGP table.



Note If an address family group, neighbor group, or session group is configured, the configuration inside these configuration groups will not be effective unless it is applied directly or indirectly to one or more neighbors.



Note The bgp auto-policy-soft-reset is enabled by default. A soft clear is done automatically when the inbound policy configured with the **route-policy (BGP)** command is changed. This behavior can be changed by disabling the auto-policy-soft-reset using the **bgp auto-policy-soft-reset disable** command.

If the neighbor supports the route refresh capability, then the original routes are not stored because they can be retrieved from the neighbor through a route refresh request. However, if the **always** keyword is specified, the original routes are stored even when the neighbor supports the route refresh capability.

If the **soft-reconfiguration inbound** command is not configured and the neighbor does not support the route refresh capability, then an inbound soft clear is not possible. In that case, the only way to rerun the inbound policy is to use the **clear bgp ip-address** command to reset the neighbor BGP session.



Note If there is an existing BGP session with a neighbor that does not support the route refresh capability, the session is terminated and a new one is initiated.



Note The extra routes stored as a result of configuring this command use more memory on the router.

If you configure this command for a neighbor group or neighbor address family group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.

Examples

The following example shows inbound soft reconfiguration enabled for IP Version 4 (IPv4) unicast routes received from neighbor 10.108.1.1. The software stores all routes received in their unmodified form so that when an inbound soft clear is performed later, the stored information can then be used to generate a new set of modified routes.

```
Router(config)# router bgp 100
Router(config-bgp)# neighbor 10.108.1.1
Router(config-bgp-nbr)# remote-as 100
Router(config-bgp-nbr)# address-family ipv4 unicast
Router(config-bgp-nbr-af)# soft-reconfiguration inbound
Router(config-bgp-nbr-af)# exit
```


table-policy

To apply a routing policy to routes being installed into the routing table, use the **table-policy** command in an appropriate configuration mode. To disable applying a routing policy when installing routes into the routing table, use the **no** form of this command.

table-policy *policy-name*
no table-policy [*policy-name*]

Syntax Description	<i>policy-name</i> Name of the routing policy to apply.				
Command Default	No policy is applied when routes are installed into the routing table.				
Command Modes	IPv4 address family configuration IPv6 address family configuration VRF IPv4 address family configuration VRF IPv6 address family configuration				
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 6.0</td><td>This command was introduced.</td></tr></table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				

Usage Guidelines



Note Table policy provides users with the ability to drop routes from the RIB based on match criteria. This feature can be useful in certain applications and should be used with caution as it can easily create a routing ‘black hole’ where BGP advertises routes to neighbors that BGP does not install in its global routing table and forwarding table.

Use the **table-policy** command to modify route attributes as the routes are installed into the routing table by Border Gateway Protocol (BGP). Commonly, it is used to set the traffic index attribute.

Examples

The following example shows how to apply the set-traffic-index policy to IPv4 unicast routes being installed into the routing table:

```
Router(config)# router bgp 1  
Router(config-bgp)# address-family ipv4 unicast  
Router(config-bgp-af)# table-policy set-traffic-index
```

tcp ip-only-preferred

To steer the BGP Control Plane traffic through an IP-only path, use the **tcp ip-only-preferred** command in neighbor-group configuration mode.

tcp ip-only-preferred

Syntax Description	This command has no keywords or arguments.

Command Default	IP-only path is not enabled.

Command Modes	Neighbor-group configuration mode

Command History	Release	Modification
	Release 24.2.11	This command was introduced.

Usage Guidelines	tcp ip-only-preferred command implies a preferred option. If an IP-only path isn't available, the system automatically uses any available path without interrupting the BGP session.

Task ID	Task ID	Operations
	bgp	read, write

Examples	The following example shows how to steer the BGP Control Plane traffic through an IP-only path:

```
Router(config)# router bgp 140
Router(config-bgp)# neighbor-group ip-only
Router(config-bgp-nbrgrp)# remote-as 100
Router(config-bgp-nbrgrp)# update-source Loopback99
Router(config-bgp-nbrgrp)# tcp ip-only-preferred
```

timers bgp

To change the default timer values for Border Gateway Protocol (BGP) neighbors, use the **timers bgp** command in an appropriate configuration mode. To set the default timers to the default values, use the **no** form of this command.

```
timers bgp keepalive hold-time
no timers bgp [ keepalive hold-time ]
```

Syntax Description	<i>keepalive</i> Frequency (in seconds) with which the software sends keepalive messages to a neighbor. Range is 0 to 65535. <i>hold-time</i> Interval (in seconds) after not receiving a keepalive message from the neighbor that the software terminates the BGP session for the neighbor. Values are 0 or a number in the range from 3 to 65535.				
Command Default	<i>keepalive</i> : 60 seconds <i>hold-time</i> : 180 seconds				
Command Modes	Router configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 6.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
Usage Guidelines	Use the timers bgp command to adjust the default timer times used by all BGP neighbors. The values can be overridden on particular neighbors using the timers command in the neighbor configuration mode. The timers actually used in connection with the neighbor may not be the same as those configured with this command. The actual timers are negotiated with the neighbor when establishing the session. The negotiated hold time is the minimum of the configured time and the hold time received from the neighbor. If the negotiated hold time is 0, keepalives are disabled. The configured value for the keepalive must not exceed one-third of the negotiated hold time. If it does, a value of one-third of the negotiated hold time is used. In cases where mechanisms such as Bi-directional Forwarding Detection (BFD), BGP fast-external-failover or Next-hop Tracking cannot be employed to detect and react to changes in the network in a faster manner, BGP Keepalive and Hold-timer values can be configured to use smaller values than the default (60 and 180 seconds respectively). When using aggressive values, consider the router's profile and scale, particularly in respect to the number of BGP neighbors that will be using sessions with the non-default timers. Sessions using very aggressive values will be more susceptible to flap during events that cause the Route-Processor's CPU utilization levels to increase. Such events include component OIR, Route-Processor Failover, network instability, excessive churn in routing protocols etc. It is therefore recommended that the desired scale and profile of the router be tested with the non-default timer values, subjecting the router to CPU-intensive events in order to determine the timer threshold values that are appropriate for the router before configuring the values in an operational network.				

The BGP Non-Stop Routing (NSR) is able to sustain sessions with more aggressive timer values than BGP Graceful Restart (GR) since in the event of a Route-Processor Failover, Graceful Restart (GR) requires the re-establishment of the TCP session over which the BGP session takes place. When using Non-Stop Routing (NSR), both the underlying TCP session and BGP session are maintained during Route-Processor failover.

Examples

The following example shows how to configure a default keepalive time of 30 seconds and a default hold time of 90 seconds:

```
Router(config)# router bgp 1  
Router(config-bgp)# timers bgp 30 90
```

timers (BGP)

To set the timers for a specific Border Gateway Protocol (BGP) neighbor, use the **timers** command in an appropriate configuration mode. To set the timers to the default values, use the **no** form of this command.

timers *keepalive hold-time*
no timers [*keepalive hold-time*]

Syntax Description

keepalive Frequency (in seconds) with which the software sends keepalive messages to a neighbor. Range is 0 to 65535.

hold-time Interval (in seconds) after not receiving a keepalive message from the neighbor that the software terminates the BGP session for the neighbor. Values are 0 or a number in the range from 3 to 65535.

Command Default

keepalive : 60 seconds

hold-time : 180 seconds

Use the **timers bgp** command to override the default values.

Command Modes

Neighbor configuration

Neighbor group configuration

Session group configuration

Command History

Release	Modification
Release 6.0	This command was introduced.

Usage Guidelines

The timers actually used in connection with the neighbor may not be the same as those configured with this command. The actual timers are negotiated with the neighbor when establishing the session. The negotiated hold time is the minimum of the configured time and the hold time received from the neighbor. If the negotiated hold time is 0, keepalives are disabled.

The configured value for the keepalive must not exceed one-third of the negotiated hold time. If it does, a value of one-third of the negotiated hold time is used.

If this command is configured for a neighbor group or neighbor address family group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.

In cases where mechanisms such as Bi-directional Forwarding Detection (BFD), BGP fast-external-failover or Next-hop Tracking cannot be employed to detect and react to changes in the network in a faster manner, BGP Keepalive and Hold-timer values can be configured to use smaller values than the default (60 and 180 seconds respectively). When using aggressive values, consider the router's profile and scale, particularly in respect to the number of BGP neighbours that will be using sessions with the non-default timers.

Sessions using very aggressive values will be more susceptible to flap during events that cause the Route-Processor's CPU utilization levels to increase. Such events include component OIR, Route-Processor Failover, network instability, excessive churn in routing protocols etc. It is therefore recommended that the

desired scale and profile of the router be tested with the non-default timer values, subjecting the router to CPU-intensive events in order to determine the timer threshold values that are appropriate for the router before configuring the values in an operational network.

The BGP Non-Stop Routing (NSR) is able to sustain sessions with more aggressive timer values than BGP Graceful Restart (GR) since in the event of a Route-Processor Failover, Graceful Restart (GR) requires the re-establishment of the TCP session over which the BGP session takes place. When using Non-Stop Routing (NSR), both the underlying TCP session and BGP session are maintained during Route-Processor failover.

Task ID	Task ID	Operations
	bgp	read, write

Examples

The following example shows how to change the keepalive timer to 70 seconds and the hold-time timer to 210 seconds for the BGP peer 192.168.40.24:

```
RP/0/RP0/CPU0:router(config)# router bgp 109
RP/0/RP0/CPU0:router(config-bgp)# neighbor 192.168.40.24
RP/0/RP0/CPU0:router(config-bgp-nbr)# remote-as 1
RP/0/RP0/CPU0:router(config-bgp-nbr)# timers 70 210
```

update limit

To set upper bound on transient memory usage for update generation, use the **update limit** command in router configuration mode. To return the bounds to the default value, use the **no** form of this command.

```
update limit update-limit-MB  
no update limit
```

Syntax Description	<i>update-limit-MB</i> Sets the update limit in megabytes (MB). Range is 16 to 2048 MB.
Command Default	Default update limit is 512 MB.
Command Modes	Router configuration
Usage Guidelines	Use the update limit command to configure a global limit on the size of messages the software queues when updating peers. Increasing the limit can result in faster Border Gateway Protocol (BGP) convergence, but also may result in higher memory usage during convergence.

This example shows how to set the update limit as 1024 MB:

```
Router(config)# router bgp 65000  
Router(config-bgp)#update limit 1024
```

update limit address-family

To set upper bound on transient memory usage for update generation for an address family, use the **update limit address-family** command in an appropriate address-family configuration mode. To return the bounds to the default value, use the **no** form of this command.

update limit address-family *update-limit-MB*

Syntax Description

update-limit-MB Sets the update limit in megabytes (MB). Range is 4 MB to 2048 MB.

Command Default

Default update limit is 256 MB.

Command Modes

IPv4 address family configuration
 IPv6 address family configuration
 L2VPN address family configuration
 VPNv4 address family configuration
 VPNv6 address family configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

Use the **update limit address-family** command to configure a global limit on the size of messages the software queues when updating peers. Increasing the limit can result in faster Border Gateway Protocol (BGP) convergence, but also may result in higher memory usage during convergence.

This example shows how to set the update limit as *512 MB* for address family IPv4 unicast:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#address-family ipv4 unicast
Router(config-bgp-af)#update limit address-family 512
```


update limit sub-group

To set upper bound on transient memory usage for update generation for eBGP or iBGP sub-groups, use the **update limit sub-group** command in an appropriate address-family configuration mode. To return the bounds to the default value, use the **no** form of this command.

update limit sub-group {**ebgp** | **ibgp**} *update-limit-MB*

Syntax Description	ebgp	Specifies the update limit for eBGP sub-groups.
	ibgp	Specifies the update limit for iBGP sub-groups.
	<i>update-limit-MB</i>	Sets the update limit in megabytes (MB). Range is 1 MB to 512 MB.

Command Default	Default update limit is 32 MB.

Command Modes	IPv4 address family configuration IPv6 address family configuration L2VPN address family configuration VPNv4 address family configuration VPNv6 address family configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	Use the update limit sub-group command to configure a global limit on the size of messages the software queues when updating peers. Increasing the limit can result in faster Border Gateway Protocol (BGP) convergence, but also may result in higher memory usage during convergence.

This example shows how to set the update limit as 256 MB for eBGP sub-group under address family IPV4 unicast:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#address-family ipv4 unicast
Router(config-bgp-af)#update limit sub-group ebgp 256
```

update in error-handling basic disable

To disable inbound update message basic error handling for eBGP or iBGP neighbors, use the **update in error-handling basis disable** command in Global Configuration mode and XR Config mode. To enable inbound update message basic error handling, use the **no** form of this command.

update in error-handling basic {ebgp | ibgp} disable

Syntax Description	ebgp Specifies inbound update message basic error handling for eBGP neighbors.				
	ibgp Specifies inbound update message basic error handling for iBGP neighbors.				
Command Default	Inbound update message basic error handling is enabled.				
Command Modes	Global Configuration mode and XR Config mode				
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 7.0.12</td><td>This command was introduced.</td></tr></table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

This example shows how to disable inbound update message basic error handling for eBGP neighbors:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#update in error-handling basic ebgp disable
```

This example shows how to disable inbound update message basic error handling for iBGP neighbors:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#update in error-handling basic ibgp disable
```

update in error-handling extended

To enable inbound update message extended error handling for eBGP or iBGP neighbors, use the **update in error-handling extended** command in Global Configuration mode and XR Config mode. To disable inbound update message error handling, use the **no** form of this command.

update in error-handling extended {ebgp | ibgp}

Syntax Description	ebgp	Specifies to enable inbound update message extended error handling for eBGP neighbors.
	ibgp	specifies to enable inbound update message extended error handling for iBGP neighbors.
Command Default	Inbound update message extended error handling is disabled.	
Command Modes	Global Configuration mode and XR Config mode	
Command History	Release	Modification
	Release 7.0.12	This command was introduced.

This example shows how to enable inbound update message extended error handling for eBGP neighbors:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#update in error-handling extended ebgp
```

This example shows how to enable inbound update message extended error handling for iBGP neighbors:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#update in error-handling extended ibgp
```

update out logging

To enable logging of update generation events, use the **update out logging** command in Global Configuration mode and XR Config mode. To disable the logging of update generation events, use the **no** form of this command.

update out logging

Syntax Description	This command has no keywords or arguments.				
Command Default	Update generation event logging is disabled.				
Command Modes	Global Configuration mode and XR Config mode				
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 7.0.12</td><td>This command was introduced.</td></tr></table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

This example shows how to enable logging of update generation events:

```
Router#configure
Router(config)#router bgp 100
Router(config-bgp)#update out logging
```

update out originator-loopcheck disable

To bypass originator loop check for outgoing update, use the **update out originator-loopcheck disable** command in neighbor address-family configuration mode. This configuration is effective only for the neighbor in unique update group for which the update is being processed.

update out originator-loopcheck [disable]

To restore the system to its default condition, use the **no** form of this command or use the **update out originator-loopcheck** command.

no update out originator-loopcheck [disable] update out originator-loopcheck

Syntax Description	disable (optional) Prevents the update out originator-loopcheck disable command from being inherited from a parent group.	
Command Default	Originator loop check for outbound updates is enabled if there is only one neighbor, and disabled if there are multiple neighbors in the update group.	
Command Modes	Non-VRF neighbor address family configuration	
	Supported Address-families • address-family vpnv4 unicast • address-family vpnv6 unicast • address-family l2vpn evpn	
Command History	Release	Modification
	Release 6.6.2	This command was introduced.
Usage Guidelines	Use the update out originator-loopcheck disable command to bypass originator loop check for outgoing update. Use this command either with as-override command or with as-path-loopcheck out disable command for eBGP peering. For iBGP peering, separate configuration is not required. The word “originator” represents the either of the following: • The neighbor whose IP address matches with the current network path's neighbor IP address and the update is sent to that same neighbor. • The neighbor for the route reflector or iBGP, when the neighbor's router-id matches with the current network path's router-id, and the update is sent to that same neighbor. Although, the disable keyword is optional, you must configure it to disable the originator loop check. For example, under neighbor address family, if the update out originator-loopcheck disable command is configured, only then it disables the originator loop check for that neighbor. There can be scenarios where configuring the command without the optional disable keyword is useful.	

Example 1:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)#router bgp 100
RP/0/RSP0/CPU0:router(config-bgp)# neighbor 10.40.0.1
RP/0/RSP0/CPU0:router(config-bgp)# remote-as 200
RP/0/RSP0/CPU0:router (config-bgp-nbr)#address-family l2vpn evpn
RP/0/RSP0/CPU0:router (config-bgp-nbr-af)#update out originator-loopcheck disable
RP/0/RSP0/CPU0:router (config-bgp-nbr-af)#as-override
```

Example 2:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)#router bgp 100
RP/0/RSP0/CPU0:router(config-bgp)#address-family l2vpn evpn
RP/0/RSP0/CPU0:router(config-bgp-af)#as-path-loopcheck out disable
RP/0/RSP0/CPU0:router(config-bgp)#neighbor 10.40.0.1
RP/0/RSP0/CPU0:router(config-bgp-nbr)#remote-as 200
RP/0/RSP0/CPU0:router (config-bgp-nbr)#address-family l2vpn evpn
RP/0/RSP0/CPU0:router (config-bgp-nbr-af)#update out originator-loopcheck disable
```

Example 3:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)#router bgp 100
RP/0/RSP0/CPU0:router(config-bgp)#neighbor 10.60.0.1
RP/0/RSP0/CPU0:router(config-bgp-nbr)#remote-as 100
RP/0/RSP0/CPU0:router (config-bgp-nbr)#address-family vpnv4 unicast
RP/0/RSP0/CPU0:router (config-bgp-nbr-af)#update out originator-loopcheck disable
```

update-source

To allow internal Border Gateway Protocol (iBGP) sessions to use the primary IP address from a particular interface as the local address when forming an iBGP session with a neighbor, use the **update-source** command in an appropriate configuration mode. To set the chosen local IP address to the nearest interface to the neighbor, use the **no** form of this command.

update-source *type interface-path-id*

Syntax Description	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or virtual interface.
Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.		

Command Default	Best local address

Command Modes	Neighbor configuration VRF neighbor configuration Neighbor group configuration Session group configuration

Command History	<table border="1"> <tr> <th>Release</th> <th>Modification</th> </tr> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

Usage Guidelines	The update-source command is commonly used with the loopback interface feature for iBGP sessions. The loopback interface is defined, and the interface address is used as the endpoint for a BGP session through the update-source command. This mechanism allows a BGP session to remain up even if the outbound interface goes down, provided there is another route to the neighbor.

If this command is configured for a neighbor group or session group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.

Examples

The following example shows how to configure this router to use the IP address from the Loopback0 interface when trying to open a session with neighbor 172.20.16.6:

```
Router(config)# router bgp 110
Router(config-bgp)# neighbor 172.20.16.6
Router(config-bgp-nbr)# remote-as 110
Router(config-bgp-nbr)# update-source Loopback0
```

update wait-install

To configure BGP to wait for feedback from RIB indicating that the routes that BGP installed in RIB have been installed in FIB, before BGP send out updates to neighbors, use the **update wait-install** command in an appropriate configuration mode.

update wait-install

This command has no keywords or arguments.

Command Default	The update wait-install configuration is disabled.

Command Modes	Router IPv4 address family Router VPNv4 address family Router IPv6 address family Router VPNv6 address family

Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

Usage Guidelines	Starting from Release 6.6.2, when you configure the wait-install command, the BGP status message "LC/FIB for the neighbor in reloading" is displayed only when a connection is established with a directly connected EBGp neighbour.

This example shows how to enable the **update wait-install** configuration under VPNv4 unicast address family:

```
Router#configure
Router(config)#router bgp 65500
Router(config-bgp)#address-family vpnv4 unicast
Router(config-bgp-af)#update wait-install
```


update wait-install delay startup

To schedule the delay for BGP update generations to prevent routes from being advertised to peers until RIB is synchronized, run the **update wait-install delay startup** command in the System Admin Config mode.

Use the **no** form of this command to disable the feature.

update wait-install delay startup *seconds*

Syntax Description	<i>seconds</i> Delay for the BGP start-up phase. The range of the delay is from 1 second to 600 seconds.	
Command Default	The command is disabled by default.	
Command Modes	System Admin Config mode	
Command History	Release	Modification
	Release 7.5.3	This command was introduced.
Usage Guidelines	This command is applicable for the following Address Family Indicators (AFIs): • IPv4 unicast • IPv6 unicast • VPNv4 unicast • VPNv6 unicast	
Task ID	Task ID	Operations
	bgp	read, write

The following example shows how to schedule the delay of the BGP update generation in the start-up phase to prevent routes from being advertised to peers until RIB is synchronized.

```
Router# configure
Router(config)# router bgp 1
Router(config-bgp)# address-family ipv4 unicast
Router(config-bgp-af)# update wait-install delay startup 10
Router(config-bgp-af)# commit
```

vrf (BGP)

To configure a VPN routing and forwarding (VRF) instance and enter VRF configuration mode, use the **vrf** command in Global Configuration mode and XR Config mode. To remove the VRF instance from the configuration file and restore the system to its default condition, use the **no** form of this command.



Note This feature is not supported.

vrf *vrf-name*

Syntax Description	<i>vrf-name</i> Name of the VRF instance. The following names cannot be used: all, default, and global.

Command Default	No default behavior or values

Command Modes	Global Configuration mode and XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Usage Guidelines	Use the vrf command to configure a VRF instance. A VRF instance is a collection of VPN routing and forwarding tables maintained at the provider edge (PE) router.

Examples	The following example shows how to configure a VRF instance and enter VRF configuration mode:

```
Router(config)# router bgp 1
Router(config-bgp)# vrf vrf-1
Router(config-bgp-vrf)#
```

weight

To assign a weight to routes received from a neighbor, use the **weight** command in an appropriate configuration mode. To remove the **weight** command from the configuration file and restore the system to its default condition in which the software assigns the default weight to routes, use the **no** form of this command.

weight *weight-value*

Syntax Description

weight-value Weight to assign. Range is 0 to 65535.

Command Default

Routes learned through another Border Gateway Protocol (BGP) peer have a default weight of 0 and routes sourced by the local router have a default weight of 32768.

Command Modes

IPv4 address family group configuration
 IPv6 address family group configuration
 IPv4 neighbor address family configuration
 IPv4 neighbor group address family configuration
 IPv6 neighbor group address family configuration
 VPNv4 address family group configuration
 VPNv4 neighbor address family configuration
 VRF IPv4 neighbor address family configuration
 VPNv4 neighbor group address family configuration
 VPNv6 address family group configuration
 VPNv6 neighbor address family configuration
 VRF IPv6 neighbor address family configuration
 VPNv6 neighbor group address family configuration

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

The weight of a route is a Cisco-specific attribute. It is used in the best-path selection process (as the strongest tie-breaker). See the *Implementing BGP on* module of the *BGP Configuration Guide for Cisco 8000 Series Routers* for information on best path. If there are two BGP routes with the same network layer reachability information (NLRI), the route with the higher weight is always chosen no matter what the value of other BGP attributes. Weight only has significance on the local router. Weight is assigned locally to the router, is a value that only makes sense to the specific router, is not propagated or carried through any route updates, and never is sent between BGP peers (even within the same AS).



Note If an address family group, neighbor group, or session group is configured, the configuration inside these configuration groups will not be effective unless it is applied directly or indirectly to one or more neighbors.

The weight assigned to individual routes can be further manipulated in the inbound route policy of a neighbor using the **set weight** command. The **set weight** command sets the weight directly. If you have particular neighbors that you want to prefer for most of your outbound traffic, you can assign a higher weight to all routes learned from that neighbor.

The weight assigned to individual routes may be modified by using an inbound routing policy.

If this command configures a neighbor group or neighbor address family group, all neighbors using the group inherit the configuration. Values of commands configured specifically for a neighbor override inherited values.

Examples

The following example shows how to assign a weight of 50 to all IP Version 4 (IPv4) unicast routes learned through 172.20.16.6:

```
Router(config)# router bgp 1
Router(config-bgp)# neighbor 172.20.16.6
Router(config-bgp-nbr)# remote-as 1
Router(config-bgp-nbr)# address-family ipv4 unicast
Router(config-bgp-nbr-af)# weight 50
Router(config-bgp-nbr-af)# exit
```