



## Viewing and Adding Flows

---

This chapter contains the following sections:

- [Viewing Flows, on page 1](#)
- [Adding a Flow, on page 1](#)

### Viewing Flows



---

**Note** This functionality is applicable only for OpenFlow mode of deployment.

---

On the **Flows** tab, the following fields are displayed:

- Serial Number
- Status
- Flow Name
- Node

#### What to do next

Click + **Flow** to add a flow.

### Adding a Flow

---

**Step 1** Navigate to the **Flows** tab under **Administration**, click + **Flow** to add a flow.

**Step 2** On the **Add Flow Description** window, update the following fields:

Name	Description
Name field	<p>The name that you want to assign to the flow.</p> <p><b>Note</b> You cannot change the name of the flow entry after it is saved.</p>
Select a Node drop-down list	<p>Select a node name for the device.</p> <p><b>Note</b> The node you choose cannot be changed one you save the flow entry.</p>
Input Port drop-down list	<p>Choose the port on the node where traffic enters the flow.</p>
Priority field	<p>The priority that you want to apply to the flow. The default priority is 500. Flows with a higher priority are given precedence over flows with a lower priority.</p> <p><b>Note</b> The priority is considered only when all of the Layer 2, Layer 3, and Layer 4 match fields are equal.</p>
Hard Timeout field	<p>The amount of time in milliseconds for the flow to be installed before it is removed from the flow table.</p>
Idle Timeout field	<p>The amount of time in milliseconds that the flow can be idle before it is removed from the flow table.</p>
Layer 2	
Ethernet Type field	<p>The Ethernet type for the Layer 2 traffic. The Ethernet type for IPv4, in hexadecimal format, is displayed by default. Either accept the default value, or enter one of the following, in hexadecimal format:</p> <ul style="list-style-type: none"> <li>• IPv6</li> <li>• ARP</li> <li>• LLDP</li> </ul>
VLAN Identification Number field	<p>The VLAN ID for the Layer 2 traffic.</p>
VLAN Priority field	<p>The VLAN priority for the Layer 2 traffic.</p>
Source MAC Address field	<p>The source MAC address for the Layer 2 traffic.</p>
Destination MAC Address field	<p>The destination MAC address for the Layer 2 traffic.</p>
Layer 4	
Source Port field	<p>The source port of the Layer 4 traffic.</p>
Destination Port field	<p>The destination port of the Layer 4 traffic.</p>

Name	Description
<b>Protocol</b> field	The Internet protocol number of the Layer 4 traffic. Enter the IP protocol number in decimal, hexadecimal, or octal format.
<b>Actions</b> drop-down list	Select an action from the drop-down list.

**Step 3**

Click **Install Flow** to install the flow into the device OR click **Save Flow** to save the flow to the **Flow Entries** table, but the system does not install the flow in the flow table of the device.

---

