



Deploying Cisco Nexus Data Broker Embedded for OpenFlow

This chapter contains the following sections:

- [Obtaining the Cisco Nexus Data Broker Embedded Software for OpenFlow, page 1](#)
- [Upgrading From Cisco Nexus Data Broker Embedded Release 2.0 or Release 2.0.1 to Cisco Nexus Data Broker Release 2.2, page 2](#)
- [Installing and Activating the Cisco Nexus Data Broker Embedded Software for OpenFlow, page 3](#)
- [Configuring the Cisco Plug-in for OpenFlow, page 4](#)
- [Logging in to the Cisco Nexus Data Broker GUI, page 5](#)

Obtaining the Cisco Nexus Data Broker Embedded Software for OpenFlow

Procedure

- Step 1** In a web browser, navigate to Cisco.com.
 - Step 2** Under **Support**, click **All Downloads**.
 - Step 3** In the center pane, click **Cloud and Systems Management**.
 - Step 4** If prompted, enter your Cisco.com username and password to log in.
 - Step 5** In the right pane, click **Network Controllers and Applications**, and then click **Cisco Nexus Data Broker**.
 - Step 6** Download and extract the **Cisco Nexus Data Broker Release 2.2.0** application bundle zip file. The application bundle zip file contains the following:
 - The Cisco Nexus Data Broker Software Application package, for example, **ndb1000-sw-app-k9-2.2.0.zip**
 - The Cisco Plug-in for OpenFlow package, **ofa_mmemb-2.1.0-r1-nxos-SPA-k9.ova**
-

What to Do Next

Install the software on a Cisco Nexus 3000, 3100, 3500, or 9000 Series switch.

Upgrading From Cisco Nexus Data Broker Embedded Release 2.0 or Release 2.0.1 to Cisco Nexus Data Broker Release 2.2

This process involves using the GUI to download the configuration, perform the upgrade, and then upload the configuration.

Procedure

	Command or Action	Purpose
Step 1	From the Admin drop-down list, choose Management .	
Step 2	From the Admin drop-down list, choose System .	The System Administration window is displayed.
Step 3	Click Download Configuration .	It downloads the configuration in a zip file format. The name of the zip file is configuration_startup.zip .
Step 4	Save the configuration file on your local desktop.	
Step 5	Stop the Cisco Nexus Data Broker. Deactivate and uninstall the old instance.	
Step 6	Install Cisco Nexus Data Broker 2.2 instance.	
Step 7	Again, from the Admin drop-down list, choose System .	The System Administration window is displayed.
Step 8	Click Upload Configuration .	It uploads the configuration that you have downloaded. It restores the configuration in the new version.
Step 9	Restart the Cisco Nexus Data Broker by performing no activate within the virtual service and by activating it again.	

Installing and Activating the Cisco Nexus Data Broker Embedded Software for OpenFlow

Before You Begin



Note

You cannot install a new version of the Cisco Nexus Data Broker Embedded if you already have an existing Cisco Monitor Manager Embedded application installed and active.

Before you begin installing a new version of the Cisco Nexus Data Broker Embedded, you must:

- Deactivate your current Cisco Monitor Manager Embedded OVA file.
- Uninstall the Cisco Monitor Manager Embedded OVA file.



Important

Ensure that you have at least 1 GB of available space in the bootflash. The `ofa_mmemb-2.1.0-r1-nxos-SPA-k9.ova` and `ndb1000-sw-app-emb-k9-2.2.0.ova` file require a total of 850 MB of space in the bootflash for the decompression and installation processes.

Procedure

	Command or Action	Purpose
Step 1	<code>switch# copy [scp: ftp: http:] //download_dir ofa_mmemb-2.1.0-r1-nxos-SPA-k9.ova bootflash:vrf management</code>	Copies the Cisco Plug-in for OpenFlow package from the directory where you downloaded it to the switch.
Step 2	<code>switch# copy [scp: ftp: http:] //download_dir ndb1000-sw-app-emb-k9-2.2.0.ova bootflash:vrf management</code>	Copies the Cisco Nexus Data Broker Embedded package from the directory where you downloaded it to the switch.
Step 3	<code>switch# show virtual-service list</code>	Monitors the status of the copy processes.
Step 4	<code>switch# virtual-service install name ofa_ndbemb package bootflash:ofa_mmemb-2.1.0-r1-nxos-SPA-k9.ova</code>	Installs the Cisco Plug-in for OpenFlow package on the switch.
Step 5	<code>switch# virtual-service install name ndb_emb package bootflash:ndb1000-sw-app-emb-k9-2.2.0.ova</code>	Installs the Cisco Nexus Data Broker Embedded package on the switch.
Step 6	<code>switch# show virtual-service list</code>	Monitors the status of the installations. Note Do not continue until both OVA files have been successfully installed.

	Command or Action	Purpose
Step 7	switch# configure terminal	Enters global configuration mode on the switch.
Step 8	switch (config)# onep	Specifies that configuration is for onePK services.
Step 9	switch (config)# service set vty	Enables onePK VTY services.
Step 10	switch (config)# virtual-service ofa_ndbemb	Starts the virtual service for the Cisco Plug-in for OpenFlow package and enters virtual service configuration mode on the switch.
Step 11	switch(config-virt-serv)# activate	Activates the Cisco Plug-in for OpenFlow package.
Step 12	switch(config-virt-serv)# exit	Returns to global configuration mode.
Step 13	switch(config)# virtual-service ndb_emb	Starts the virtual service for the Cisco Nexus Data Broker Embedded package and enters virtual service configuration mode on the switch.
Step 14	switch(config-virt-serv)# activate	Activates the Cisco Nexus Data Broker Embedded package.
Step 15	switch(config-virt-serv)# exit	Exits virtual service configuration mode on the switch.
Step 16	switch(config)# show virtual-service list	Monitors the status of the package activations.

Configuring the Cisco Plug-in for OpenFlow

The Cisco Plug-in for OpenFlow needs to be connected to the Cisco Nexus Data Broker locally running on the Cisco Nexus 3000, 3100, 3500, or 9000 Series switch.



Note

The steps in this procedure continue the steps that were completed in the previous section.

Before You Begin

Install and activate the Cisco Nexus Data Broker package and the Cisco Plug-in for OpenFlow package.

Enter the following pre-requisite command **hardware profile openflow** for the Cisco Nexus 3000 and 3100 Series switches. Enter the following pre-requisite command **hardware profile forwarding-mode openflow-hybrid** for the Cisco Nexus 3500 Series switches.

Procedure

- Step 1** Enter the configuration mode on the switch.
configure terminal
- Step 2** Enter the Cisco Plug-in for OpenFlow configuration mode on the switch.
switch(config)# **openflow**
- Step 3** Choose the switch to which you want to connect.
switch(config-ofa)# **switch** *switch_num*
- Caution** Set the *switch_num* to **1**. This is the default value. Only expert users should set the *switch_num* number to any value other than 1.
- Step 4** Choose the pipeline to which you want to connect.
switch(config-ofa-switch)# **pipeline** *pipeline_num*
- Caution** Set the *pipeline_num* to **201** for Cisco Nexus 3000 and 3100 Series switches. This is the default value. Only expert users should set the *pipeline_num* number to any value other than 201.
- Set the *pipeline_num* to **203** for Cisco Nexus 3500 Series switches. This is the default value. Only expert users should set the *pipeline_num* number to any value other than 203.
- Step 5** Configure the controller address using vrf management.
switch(config-ofa-switch)# **controller ipv4** *management_interface_address* **port** *port_num* **vrf management**
security none
- Note**
- The controller ipv4 address should match the management interface (mgmt0) address.
 - By default, the Cisco Plug-in for OpenFlow listens on port 6653.
- Step 6** Assign ports to the Cisco Plug-in for OpenFlow.
switch(config-ofa-switch)# **of-port interface** *ethernet_port_num*
- Example:**
switch(config-ofa-switch)# **of-port interface** ethernet1/10
- Step 7** Exit from the current configuration command mode and return to EXEC mode.
switch(config-ofa-switch)# **end**
- Step 8** Verify that the Cisco Plug-in for OpenFlow is connected to the Cisco Nexus Data Broker.
switch# **show openflow switch** *switch_num* **controllers**
- See the [Cisco Plug-in for OpenFlow Configuration Guide 1.3](#)
-

Logging in to the Cisco Nexus Data Broker GUI

The default HTTPS web link for the Cisco Nexus Data Broker GUI is
`https://Nexus_Switch_Management_IP:8443/monitor`



Note You must manually specify the https:// protocol in your web browser. The controller must also be configured for HTTPS.

Procedure

Step 1 In your web browser, enter the Cisco Nexus Data Broker web link, for example, *https://Nexus_Switch_Management_IP:8443/monitor*.

Step 2 On the launch page, do the following:

- a) Enter your username and password.
The default username and password is admin/admin.
- b) Click **Log In**.

What to Do Next

See the *Cisco Nexus Data Broker Configuration Guide, Release 2.2* for the procedures that you need to configure Cisco Nexus Data Broker.